

# User Guide

**Wireless N Access Point**

**EAP110/EAP120/EAP220**

## **FCC STATEMENT** (EAP110)



This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference.
- 2) This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

## **FCC STATEMENT** (EAP120&EAP220)

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference.
- 2) This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

## **FCC RF Radiation Exposure Statement:**

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

"To comply with FCC RF exposure compliance requirements, this grant is applicable to only Mobile Configurations. The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter."

## **CE Mark Warning**

### **CE1588** (EAP110)

This is a class B product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

### **CE1588** (EAP120)

This is a class A product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

**CE1588** ⓘ (EAP220)

This is a class A product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

### **IC STATEMENT** (EAP110)

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

### **IC STATEMENT** (EAP120&EAP220)

This Class A digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.



Продукт сертифіковано згідно з правилами системи УкрСЕПРО на відповідність вимогам нормативних документів та вимогам, що передбачені чинними законодавчими актами України.



### **Safety Information**

- When product has power button, the power button is one of the way to shut off the product; When there is no power button, the only way to completely shut off power is to disconnect the product or the power adapter from the power source.
- Don't disassemble the product, or make repairs yourself. You run the risk of electric shock and voiding the limited warranty. If you need service, please contact us.
- Avoid water and wet locations.

### **NCC Notice & BSMI Notice**

注意！

依據 低功率電波輻射性電機管理辦法

第十二條 經型式認證合格之低功率射頻電機，非經許可，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性或功能。

第十四條 低功率射頻電機之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。前項合法通信，指依電信規定作業之無線電信。低功率射頻電機需忍受合法通信或工業、科學以及醫療用電波輻射性電機設備之干擾。減少電磁波影響，請妥適使用。

### 安全諮詢及注意事項



- 請使用原裝電源供應器或只能按照本產品注明的電源類型使用本產品。
- 清潔本產品之前請先拔掉電源線。請勿使用液體、噴霧清潔劑或濕布進行清潔。
- 注意防潮，請勿將水或其他液體潑灑到本產品上。
- 插槽與開口供通風使用，以確保本產品的操作可靠並防止過熱，請勿堵塞或覆蓋開口。
- 請勿將本產品置放於靠近熱源的地方。除非有正常的通風，否則不可放在密閉位置中。
- 請不要私自打開機殼，不要嘗試自行維修本產品，請由授權的專業人士進行此項工作。

此為甲類資訊技術設備，于居住環境中使用時，可能會造成射頻擾動，在此種情況下，使用者會被要求採取某些適當的對策。

For EU/EFTA, this product can be used in the following countries:

AT	BE	BG	CH	CY	CZ	DE	DK
EE	ES	FI	FR	GB	GR	HR	HU
IE	IS	IT	LI	LT	LU	LV	MT
NL	NO	PL	PT	RO	SE	SI	SK

## Explanation of the symbols on the product label

Symbol	Explanation
	DC voltage
	<p>RECYCLING</p> <p>This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environment.</p> <p>User has the choice to give his product to a competent recycling organization or to the retailer when he buys a new electrical or electronic equipment.</p>

## DECLARATION OF CONFORMITY

For the following equipment:

Product Description: Wireless N Access Point

Model No.: EAP110(EU)\_1.0,EAP120(EU)\_1.0,EAP220(EU)\_1.0,EAP110(US)\_1.0,EAP120(US)\_1.0,  
EAP220(US)\_1.0

Trademark: **TP-LINK**

We declare under our own responsibility that the above products satisfy all the technical regulations applicable to the product within the scope of Council Directives:

Directives 1999/5/EC, Directives 2006/95/EC, Directives 1999/519/EC, Directives 2011/65/EU

The above product is in conformity with the following standards or other normative documents

**EN 300 328 V1.8.1**


**EN 301 489-1 V1.9.2 & EN 301 489-17 V2.2.1**

**EN 60950-1: 2006 + A11: 2009 + A1: 2010 + A12: 2011 +A2: 2013**

**EN 50385: 2002**

**EN 301 893 V1.7.1**

*The product carries the CE Mark:*



Person responsible for making this declaration:



**Yang Hongliang**

**Product Manager of International Business**

Date of issue: 2016-3-2

### ***About this User Guide***

This User Guide is for EAP110, EAP120 and EAP220. Chapter 4 to Chapter 8 are only suitable for the EAP in Standalone mode. Refer to the EAP Controller User Guide when the EAP is managed by the EAP Controller software.

### ***Convention***

Unless otherwise noted, the EAP or the device mentioned in this guide stands for 300Mbps Wireless N Access Point EAP110, Wireless N Gigabit Access Point EAP120 and EAP220.

# CONTENTS

Chapter 1	Introduction .....	3
1.1	Overview of the EAP .....	3
1.2	Hardware Overview .....	3
1.2.1	LED.....	3
1.2.2	Interface Panel.....	4
1.2.3	Mounting Bracket.....	6
Chapter 2	Network Topology .....	7
Chapter 3	Management Mode.....	8
3.1	Standalone Mode.....	8
3.2	Managed Mode .....	8
3.3	Switch to Standalone Mode.....	8
Chapter 4	Network .....	9
Chapter 5	Wireless .....	10
5.1	Wireless Settings .....	11
5.1.1	Wireless Basic Settings .....	12
5.1.2	SSIDs.....	13
5.1.3	Wireless Advanced Settings .....	17
5.1.4	Load Balance .....	18
5.2	Portal.....	18
5.2.1	Portal Configuration.....	19
5.2.2	Free Authentication Policy.....	24
5.3	MAC Filtering .....	26
5.4	Scheduler .....	28
5.5	QoS.....	32
5.5.1	AP EDCA Parameters.....	33
5.5.2	Station EDCA Parameters .....	34
5.6	Rogue AP Detection.....	35
5.6.1	Settings .....	36
5.6.2	Detected Rogue AP List .....	36
5.6.3	Trusted AP List .....	37



5.6.4	Download/Backup Trusted AP List.....	37
Chapter 6	Monitoring.....	39
6.1	AP.....	39
6.1.1	AP List.....	39
6.2	SSID.....	43
6.2.1	SSID List.....	44
6.3	Client.....	44
6.3.1	User List.....	45
6.3.2	Portal Authenticated Guest.....	46
Chapter 7	Management.....	47
7.1	System Log.....	47
7.1.1	Log List.....	47
7.1.2	Log Settings.....	48
7.2	Web Server.....	49
7.3	Management Access.....	50
7.4	LED ON/OFF.....	51
7.5	SSH.....	51
7.6	SNMP.....	52
Chapter 8	System.....	55
8.1	User Account.....	55
8.2	Time Settings.....	55
8.2.1	Time Settings.....	56
8.2.2	Daylight Saving.....	57
8.3	Reboot/Reset.....	58
8.4	Backup & Restore.....	59
8.5	Firmware Upgrade.....	59
	<b>Appendix A: Specifications.....</b>	<b>61</b>

# Chapter 1 Introduction

## 1.1 Overview of the EAP

EAP series products provide wireless coverage solutions for small-medium business. They can either work independently as standalone APs or be centrally managed by the EAP Controller software, providing a flexible, richly-functional but easily-configured enterprise-grade wireless network for small and medium business.

“Ceiling lamp” appearance and easily mounting design with chassis make EAP easy to be installed on a wall or ceiling and blend in with most interior decorations.

EAP110 is provided with a passive PoE adapter for power supply. EAP120/EAP220 can be powered via a PSE\* device or the provided power adapter.

With two built-in omnidirectional antennas, both EAP110 and EAP120 work within the 2.4GHz frequency band and apply 802.11 standards and 2\*2MIMO technology, allowing packet transmission at up to 300Mbps.

EAP220 has four built-in omnidirectional antennas. Wireless network created by EAP220 can operate at both 2.4GHz and 5GHz. It applies 802.11n standard and two 2\*2MIMO technology, allowing packet transmission at up to 600Mbps (300Mbps per radio).

\*PSE: Power Sourcing Equipment, a device (switch or hub for instance) that will provide power in a PoE setup.

## 1.2 Hardware Overview

### 1.2.1 LED

EAP110, EAP120 and EAP220 have the same LED status and corresponding indications.




Figure 1-1 Top View of the EAP

LED Status	Indication
Solid green	The device is working properly.
Flashing red	System errors. RAM, flash, Ethernet, WLAN or firmware may be malfunctioning.
Flashing yellow	Firmware update is in progress. Do not disconnect or power off the device.
Double-flashing red, green, yellow	The device is being reset to its factory default settings.

## 1.2.2 Interface Panel

### EAP110:




Figure 1-2 Interface Panel of EAP110

## EAP120/EAP220:




Figure 1-3 Interface Panel of EAP120/EAP220

Please note that EAP110 does not have the CONSOLE port, POWER port and ON/OFF button. The interface panel components of the EAP, from left to right, are described in the following list.


- **Kensington Security Slot:** Secure the lock (not provided) into the security slot to prevent the device from being stolen.
- **RESET:** With the device powered on, press and hold the RESET button for about 8 seconds until the LED flashes red, then release the button. The device will restore to factory default settings.
- **CONSOLE:** This port is used to connect to the serial port of a computer or a terminal to check and monitor system information of the EAP120/EAP220.

Note: CLI commands are not available in current software version. We will release a new version supporting CLI commands soon. Please pay close attention to our official website.

- **ARROW 1:** This arrow is used to align with ARROW 2 on the mounting bracket to lock the EAP into place.
- **ETHERNET:**  
For EAP110, this port is used to connect to the POE port of the provided PoE adapter for both data transmission and power supply through Ethernet cabling.  
For EAP120/EAP220, this port is used to connect to a router to transmit data or to a PSE (Power Sourcing Equipment), such as a PoE switch, for both data transmission and Power over Ethernet (PoE) through Ethernet cabling.

- **ON/OFF:** Press this button to turn on/off the EAP120/EAP220.
- **POWER:** The power port is used to connect the EAP120/EAP220 to an electrical wall outlet via power adapter. Please only use the provided power adapter.

### Passive PoE Adapter:



- **Power LED:** The Power LED indicates the status of the electric current: green (0-0.8A), red (0.8A-1A).
- **POE Port:** This port is used to connect the ETHERNET port of the EAP110.
- **LAN Port:** This port is used to connect your LAN.

### 1.2.3 Mounting Bracket

The following figure describes the structure of the mounting bracket.




Figure 1-4 Layout of the Mounting Bracket

# Chapter 2 Network Topology

A typical network topology for the EAP is shown below.




Figure 2-1 Typical Topology

To deploy an EAP in your local network, a DHCP server is required to assign IP addresses to the EAP and clients. Typically, a router acts as the DHCP server. Ensure the EAPs are in the same subnet with the Controller Host in which the EAP Controller is installed.

The EAP can be managed by the EAP Controller software, which is a management software specially designed for the TP-LINK EAP devices on a local wireless network, allowing you to centrally configure and monitor mass EAP devices using a web browser on your PC. For more information about the EAP Controller, please find the **EAP Controller User Guide** from our official website:

<http://www.tp-link.com/en/support/download/>

# Chapter 3 Management Mode

300Mbps Wireless N Access Point EAP110 and Wireless N Gigabit Access Point EAP120/EAP220 can either work under the control of the EAP Controller software or work independently as a standalone access point.

When user establishes a large-scale wireless network, the management of every single AP in the network is complex and complicated. With the EAP Controller software, you can centrally manage the mass APs simply in a web browser.

The Standalone mode applies to a relatively small-sized wireless network. EAPs in the Standalone mode cannot be managed centrally by the EAP Controller software.

## 3.1 Standalone Mode

By default, the EAP works independently as a standalone access point. By entering the IP address of the standalone EAP, you can log in to its web interface and perform configurations.

The factory default IP address configuration of the EAP is DHCP (Dynamic Host Configuration Protocol). Before you access the web interface of the EAP, please make sure the DHCP server works properly. Typically, a router acts as the DHCP server.

Follow the steps below to log in to the web interface of a standalone EAP.

1. Launch a web browser, enter the DHCP address in the address field and press the **Enter** key.
2. Enter **admin** (all lowercase) for both username and password.

## 3.2 Managed Mode

The EAP will become a managed AP once it is adopted via the EAP Controller software. Users can manage the AP via a web browser. Refer to the EAP Controller User Guide to know more about EAP Controller software.

## 3.3 Switch to Standalone Mode

The web interface of a specific EAP is not available once this EAP is adopted by the EAP Controller. You can *Forget* the EAP via the EAP Controller to turn it back as a standalone AP. Refer to the EAP Controller User Guide to learn more.

### **TIPS:**

Proceed to the following chapters for information on using the EAP in standalone mode. EAP110 is taken as the example.

# Chapter 4 Network

On Network page you can configure the IP address of the standalone EAP.




Figure 4-1 Network Page

---

**Dynamic/Static:** By default, the EAP device obtains an IP address from a DHCP server (typically a router). Select **Static** to configure IP address manually.

---

**Fallback IP:** If the EAP fails to get a dynamic IP address from a DHCP server within ten seconds, the fallback IP will work as the IP address of the device. After that, however, the device will keep trying to obtain an IP address from the DHCP server until it succeeds.

---

**DHCP Fallback IP/IP MASK:** Enter the fallback IP/IP mask.

---

**DHCP Fallback Gateway:** Enter the fallback gateway.

---



# Chapter 5 Wireless

Wireless page, consisting of Wireless Settings, Portal, MAC Filtering, Scheduler, QoS and Rogue AP Detection, is shown below.

The screenshot shows the TP-LINK EAP110 wireless settings interface. At the top, there is a navigation bar with tabs for Network, Wireless (selected), Monitoring, Management, and System. Below this, there are sub-tabs for Wireless Settings, Portal, MAC Filtering, Scheduler, QoS, and Rogue AP Detection. The main content area is divided into four sections:

- Wireless Basic Settings:** Includes options for 2.4GHz Wireless Radio (checked), Wireless Mode (802.11b/g/n mixed), Channel Width (20/40MHz), Channel (Auto), and Tx power (20).
- SSIDs:** A table with columns for ID, SSID Name, Wireless VLAN ID, SSID Broadcast, Security Mode, Portal, SSID Isolation, and Modify. One SSID is listed: TP-LINK\_2.4GHz\_16E290.
- Wireless Advanced Settings:** Includes Beacon Interval (100 ms), DTIM Period (1), RTS Threshold (2347), and Fragmentation Threshold (2346).
- Load Balance:** Includes a Load Balance toggle (ON) and Maximum Associated Clients (0).

Figure 5-1 Wireless Page

## 5.1 Wireless Settings

Following is the page of Wireless Settings.

**TP-LINK** | EAP110
Access Point ▼ ↶ ?

Network
Wireless
Monitoring
Management
System

Wireless Settings
Portal
MAC Filtering
Scheduler
Qos
Rogue AP Detection

### Wireless Basic Settings

---

2.4GHz Wireless Radio:  Enable

Wireless Mode:  ▼

Channel Width:  ▼

Channel:  ▼

Tx power:  (1-30)

Save

### SSIDs

+ Add

ID	SSID Name	Wireless VLAN ID	SSID Broadcast	Security Mode	Portal	SSID Isolation	Modify
1	TP-LINK_2.4GHz_16E290	0	Enable	None	Disable	Disable	<span style="font-size: 0.8em;">✎</span> <span style="font-size: 0.8em;">🗑️</span>

### Wireless Advanced Settings

---

Beacon Interval:  ms (40-100)

DTIM Period:  (1-255)

RTS Threshold:  (1-2347)

Fragmentation Threshold:  (256-2346, works only in 11b/g mode)

Save

### Load Balance

---

Load Balance:  ON  OFF

Maximum Associated Clients:  (1-99)

Save

Figure 5-2 Wireless Settings Page

## 5.1.1 Wireless Basic Settings

Wireless Basic Settings

2.4GHz Wireless Radio:  Enable

Wireless Mode: 802.11b/g/n mixed ▼

Channel Width: 20/40MHz ▼

Channel: Auto ▼

Tx power: 20 (1-30)

Save

Figure 5-3 Wireless Basic Settings

---

**2.4GHz Wireless Radio:** Check the box to enable 2.4GHz Wireless Radio.

---

**Wireless Mode:** Select the protocol standard for the wireless network.

Wireless network created by the EAP is able to operate in the 2.4GHz frequency. The EAP supports 802.11b/g/n, 802.11b/g, and 802.11n standards. It is recommended to select 802.11b/g/n, in which way clients supporting 11b, 11g or 11n mode can access your wireless network.

EAP220 the wireless network can work within 2.4GHz and 5GHz frequency. Wireless network of EAP220 operating at 5GHz frequency band supports 802.11a/n, 802.11a and 802.11n standards. It is recommended to select 802.11a/n, in which way your wireless network can be connected by clients supporting 11a or 11n mode.

---

**Channel Width:** Select the channel width of this device. Options include 20MHz, 40MHz and 20/40MHz (this device automatically selects 20MHz or 40MHz, and 20MHz will be used if 40MHz is not available). According to IEEE 802.11n standard, using a channel width of 40MHz can increase wireless throughput. However, users may choose lower bandwidth due to the following reasons:

1. To increase the available number of channels within the limited total bandwidth.
2. To avoid interference from overlapping channels occupied by other devices in the environment.
3. Lower bandwidth can concentrate higher transmit power, increasing stability of wireless links over long distances.

---

**Channel:** Select the channel used by this device to improve wireless performance. 1/2412MHz means the Channel is 1 and the frequency is 2412MHz. By default, channel is automatically selected.

---

**Tx power:** Enter the transmit power value. By default, the value is 20.


If the maximum transmit power is set to be larger than local regulation allows, the maximum Tx power regulated will be applied in actual situation.

**NOTE:** In most cases, it is unnecessary to select maximum transmit power. Selecting larger transmit power than needed may cause interference to neighborhood. Also it consumes more power and will reduce longevity of the device. Select a certain transmit power is enough to achieve the best performance.



## 5.1.2 SSIDs

SSIDs can work together with switches supporting 802.1Q VLAN. The EAP can build up to eight virtual wireless networks per radio for users to access. At the same time, it adds different VLAN tags to the clients which connect to the corresponding wireless network. It supports maximum 8 VLANs per radio. The clients in different VLAN cannot directly communicate with each other.

Clients connected to the device via cable do not belong to any VLAN. Thus wired client can communicate with all the wireless clients despite the VLAN settings.

Click  in the Modify column, the following content will be shown.

**SSIDs** + Add

ID	SSID Name	Wireless VLAN ID	SSID Broadcast	Security Mode	Portal	SSID Isolation	Modify
1	TP-LINK_2.4GHz_16E290	0	Enable	None	Disable	Disable	 

**SSID Name:**

**Wireless VLAN ID:**  (0-4094, 0 is used to disable VLAN tagging)

**SSID Broadcast:**  Enable

**Security Mode:**

**Portal:**  Enable

**SSID Isolation:**  Enable

Figure 5-4 SSIDs



Click to add up to 8 wireless networks per radio.

**SSID Name:** Enter up to 32 characters as the SSID name.

**Wireless VLAN ID:** Set a VLAN ID (ranges from 0 to 4094) for the wireless network. VLAN 0 means VLAN function is disabled. Wireless networks with the same VLAN ID are grouped to a VLAN.

**SSID Broadcast:** Enable this function, AP will broadcast its SSID to hosts in the surrounding environment, as thus hosts can find the wireless network identified by this SSID. If SSID Broadcast is not enabled, hosts must enter the AP's SSID manually to connect to this AP.

---

**Security Mode:** Select the security mode of the wireless network. For the security of wireless network, you are suggested to encrypt your wireless network. This device provides three security modes: **WPA-Enterprise**, **WPA-PSK** (WPA Pre-Shared Key) and **WEP** (Wired Equivalent Privacy). WPA-PSK is recommended. Settings vary in different security modes as the details are in the following introduction. Select **None** and the hosts can access the wireless network without password.



---

**Portal:** Portal provides authentication service for the clients who want to access the wireless local area network. For more information, refer to [5.2 Portal](#). After Portal is enabled, the configurations in [5.2 Portal](#) will be applied.

---

**SSID Isolation:** After enabling SSID Isolation, the devices connected in the same SSID cannot communicate with each other.

---

**Modify:** Click  to open the page to edit the parameters of SSID.  
Click  to delete the SSID.

---


Following is the detailed introduction of security mode: **WEP**, **WPA-Enterprise** and **WPA-PSK**.

- **WEP**

WEP (Wired Equivalent Privacy), based on the IEEE 802.11 standard, is less safe than WPA-Enterprise or WPA-PSK.

**NOTE:**

WEP is not supported in 802.11n mode. If WEP is applied in 802.11n mode, the clients may not be able to access the wireless network. If WEP is applied in 11b/g/n mode (in the 2.4GHz frequency band) or 11a/n (in the 5GHz frequency band), the device may work at a low transmission rate.



The screenshot shows a configuration interface for WEP security mode. It includes the following fields and options:

- Security Mode:** A dropdown menu set to "WEP".
- Type:** Radio buttons for "Auto" (selected), "Open System", and "Shared Key".
- Key Selected:** A dropdown menu set to "Key1".
- Wep Key Format:** Radio buttons for "ASCII" (selected) and "Hexadecimal".
- Key Type:** Radio buttons for "64 Bit" (selected), "128 Bit", and "152 Bit".
- Key Value:** A text input field containing "weppw".

Figure 5-5 Security Mode\_WEP

---

**Type:** Select the authentication type for WEP.

- **Auto:** The default setting is Auto, which can select Open System or Shared Key automatically based on the wireless station's capability and request.
- **Open System:** After you select Open System, clients can pass the authentication and associate with the wireless network without password. However, correct password is necessary for data transmission.

---

---

- **Shared Key:** After you select Shared Key, clients has to input password to pass the authentication, or it cannot associate with the wireless network or transmit data.

---

**Key Selected:** You can configure four keys in advance and select one as the present valid key.

---

**Wep Key Format:** Select the wep key format ASCII or Hexadecimal.

- **ASCII:** ASCII format stands for any combination of keyboard characters in the specified length.
- **Hexadecimal:** Hexadecimal format stands for any combination of hexadecimal digits (0-9, a-f, A-F) in the specified length.

---

**Key Type:** Select the WEP key length (64-bit, or 128-bit, or 152-bit) for encryption.

- **64-bit:** You can enter 10 hexadecimal digits (any combination of 0-9, a-f, A-F without null key) or 5 ASCII characters.
- **128-bit:** You can enter 26 hexadecimal digits (any combination of 0-9, a-f, A-F without null key) or 13 ASCII characters.
- **152-bit:** You can enter 32 hexadecimal digits (any combination of 0-9, a-f, A-F without null key) or 16 ASCII characters.

---

**Key Value:** Enter the key value.

---

- **WPA-Enterprise**

Based on RADIUS server, WPA-Enterprise can generate different passwords for different users and it is much safer than WPA-PSK. However, it costs much to maintain and is more suitable for enterprise users. At present, WPA-Enterprise has two versions: WPA-PSK and WPA2-PSK.

The screenshot shows a configuration window for WPA-Enterprise. It includes the following fields and options:

- Security Mode:** A dropdown menu set to "WPA-Enterprise".
- Version:** Radio buttons for "Auto" (selected), "WPA-PSK", and "WPA2-PSK".
- Encryption:** Radio buttons for "Auto" (selected), "TKIP", and "AES".
- Radius Server IP:** A text input field containing "0.0.0.0".
- Radius Port:** A text input field containing "0", with a note "(1-65535,0 means default port 1812)".
- Radius Password:** A text input field.
- Group Key Update Period:** A text input field containing "0", with a note "seconds(30-8640000,0 means no upgrade)".

Figure 5-6 Security Mode\_WPA-Enterprise

---

**Version:** Select one of the following versions:

- **Auto:** Select WPA-PSK or WPA2-PSK automatically based on the wireless station's capability and request.
- **WPA-PSK:** Pre-shared key of WPA.
- **WPA2-PSK:** Pre-shared key of WPA2.

---

<b>Encryption:</b>	Select the encryption type, including <b>Auto</b> , <b>TKIP</b> , and <b>AES</b> . The default setting is Auto, which can select TKIP (Temporal Key Integrity Protocol) or AES (Advanced Encryption Standard) automatically based on the wireless station's capability and request. AES is more secure than TKIP and TKIP is not supported in 802.11n mode. It is recommended to select AES as the encryption type.
<b>RADIUS Server IP/Port:</b>	Enter the IP address/port of the RADIUS server.
<b>RADIUS Password:</b>	Enter the shared secret of RADIUS server to access the RADIUS server.
<b>Group Key Update period:</b>	Specify the group key update period in seconds. The value can be either 0 or at least 30. 0 means no update.

**NOTE:**

Encryption type TKIP is not supported in 802.11n mode. If TKIP is applied in 802.11n mode, the clients may not be able to access the wireless network of the EAP. If TKIP is applied in 11b/g/n mode (in the 2.4GHz frequency band) or 11a/n (in the 5GHz frequency band), the device may work at a low transmission rate.

● **WPA-PSK**

Based on pre-shared key, security mode WPA-PSK is characterized by high security and simple configuration, which suits for common households and small business. WPA-PSK has two versions: WPA-PSK and WPA2-PSK.

The screenshot shows a configuration form for WPA-PSK security mode. It includes the following fields and options:

- Security Mode:** A dropdown menu set to "WPA-PSK".
- Version:** Radio buttons for "Auto" (selected), "WPA-PSK", and "WPA2-PSK".
- Encryption:** Radio buttons for "Auto", "TKIP", and "AES" (selected).
- Wireless Password:** A text input field containing "wpapass1".
- Group Key Update Period:** A text input field containing "0", with a note "seconds(30-8640000,0 means no upgrade)".

Figure 5-7 Security Mode\_WPA-PSK

<b>Version:</b>	<ul style="list-style-type: none"> <li>● <b>Auto:</b> Select WPA or WPA2 automatically based on the wireless station's capability and request.</li> <li>● <b>WPA:</b> Pre-shared key of WPA.</li> <li>● <b>WPA2:</b> Pre-shared key of WPA2.</li> </ul>
-----------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

---

**Encryption:** Select the encryption type, including **Auto**, **TKIP**, and **AES**. The default setting is Auto, which can select TKIP (Temporal Key Integrity Protocol) or AES (Advanced Encryption Standard) automatically based on the wireless station's capability and request. AES is more secure than TKIP and TKIP is not supported in 802.11n mode. It is recommended to select AES as the encryption type.

---

**Wireless Password:** Configure the WPA-PSK/WPA2-PSK password with ASCII or Hexadecimal characters. For ASCII, the length should be between 8 and 63 characters with combination of numbers, letters (case-sensitive) and common punctuations. For Hexadecimal, the length should be 64 characters (case-insensitive, 0-9, a-f, A-F).

---

**Group Key Update Period:** Specify the group key update period in seconds. The value can be either 0 or at least 30. 0 means no update.

---

### 5.1.3 Wireless Advanced Settings

Wireless Advanced Settings		
Beacon Interval:	100	ms (40-100)
DTIM Period:	1	(1-255)
RTS Threshold:	2347	(1-2347)
Fragmentation Threshold:	2346	(256-2346 works only in 11b/g mode)

[Save](#)

Figure 5-8 Wireless Advanced Settings

---

**Beacon Interval:** Beacons are transmitted periodically by the device to announce the presence of a wireless network for the clients. Beacon Interval value determines the time interval of the beacons sent by the device. You can specify a value from 40 to 100. The default value is 100 milliseconds.

---

**DTIM Period:** This value indicates the number of beacon intervals between successive Delivery Traffic Indication Messages (DTIMs) and this number is included in each Beacon frame. A DTIM is contained in Beacon frames to indicate whether the access point has buffered broadcast and/or multicast data for the client devices. Following a Beacon frame containing a DTIM, the access point will release the buffered broadcast and/or multicast data, if any exists. You can specify the value between 1-255 Beacon Intervals. The default value is 1, indicating the DTIM Period is the same as Beacon Interval. An excessive DTIM period may reduce the performance of multicast applications. It is recommended to keep it by default.

---

**RTS Threshold:** When the RTS threshold is activated, all the stations and APs follow the Request to Send (RTS) protocol. When the station is to send packets, it will send a RTS to AP to inform the AP that it will send data. After receiving the RTS, the AP notices other stations in the same wireless network to delay their transmitting of data. At the same time, the AP inform the requesting station to send data. The value range is from 1 to 2347 bytes. The default value is 2347, which means that RTS is disabled.

---



---

**Fragmentation Threshold:** Specify the fragmentation threshold for packets. If the size of the packet is larger than the fragmentation threshold, the packet will be fragmented into several packets. Too low fragmentation threshold may result in poor wireless performance caused by the excessive packets. The recommended and default value is 2346 bytes.

---

## 5.1.4 Load Balance

By restricting the maximum number of clients accessing the EAPs, Load Balance helps to achieve rational use of network resources.



The screenshot shows a configuration panel for 'Load Balance'. At the top, the title 'Load Balance' is displayed. Below it, there are two main settings. The first is 'Load Balance:', which has a toggle switch with 'ON' and 'OFF' options; the 'OFF' option is currently selected. The second is 'Maximum Associated Clients:', which has a text input field containing the number '0' and a range indicator '(1-99)' to its right. At the bottom right of the panel, there is a green button labeled 'Save'.

Figure 5-9 Load Balance

---

**Load Balance:** Disable by default. Click **ON** to enable the function. After enabling it, you can set a number for maximum associated clients to control the wireless access.

---

**Maximum Associated Clients:** Enter the number of clients to be allowed for connection to the EAP. The number ranges from 1 to 99.

---

## 5.2 Portal

Portal authentication enhances the network security by providing authentication service to the clients who want to access the wireless local network. Portal is also called web authentication. The users have to log in a web page to establish verification.

Network resources can be classified into different types for different users. Part of them can be accessed for free by the clients; while some specific resources can only be accessed by authorized users. What's more, you can customize the authentication login page and specify a URL which the newly authenticated client will be redirected to. Please refer to [Portal Configuration](#) or [Free Authentication Policy](#) according to your need.

Following is the page of Portal.

**TP-LINK** | EAP110 Access Point ↩ ?

Network **Wireless** Monitoring Management System

Wireless Settings **Portal** MAC Filtering Scheduler Qos Rogue AP Detection

### Portal Configuration

Authentication Type: No Authentication

Authentication Timeout: 1 Hours

D  H  M

Redirect:  Enable

Redirect URL:

Portal Customization: Local Web Portal

Term of Use:

I accept the Term of Use

Login

**Save**

### Free Authentication Policy

+ Add

ID	Policy Name	Source IP Range	Destination IP Range	Source MAC	Destination Port	Status	Settings
--	--	--	--	--	--	--	--

Figure 5-10 Portal Page

**NOTE:**

To apply Portal in a wireless network, please go to **Wireless**→**Wireless Settings**→**SSIDs** to enable Portal of a selected SSID.

### 5.2.1 Portal Configuration

Three authentication types are available: No Authentication, Local Password and External RADIUS Server.

1. No Authentication: Users are required to finish only two steps: agree with the user protocol and click the **Login** button.

2. Local Password: Users are required to enter the preset user name and password, which are saved in the EAP.
3. External RADIUS Server: Users are required to enter the preset user name and password, which are saved in the database of the RADIUS server. The RADIUS server acts as the authentication server, which allows you to set different user name and password for different users.

Refer to the following content to configure Portal based on actual network situations.

- **No Authentication**

The screenshot shows the 'Portal Configuration' interface. The 'Authentication Type' is set to 'No Authentication'. The 'Authentication Timeout' is set to '1 Hours', with input fields for Days (D), Hours (H), and Minutes (M). The 'Redirect' checkbox is unchecked. The 'Redirect URL' field is empty. The 'Portal Customization' is set to 'Local Web Portal'. A preview window shows a login form with a 'Term of Use' section, a checked checkbox 'I accept the Term of Use', and a 'Login' button. A 'Save' button is located at the bottom right of the configuration area.

Figure 5-11 Portal Configuration\_No Authentication

---

**Authentication Type:** Select **No Authentication**.

---

**Authentication Timeout:** After successful verification, an authentication session is established. Authentication Timeout decides the active time of the session. Within the active time, the device keeps the authentication session open with the associated client. To reopen the session, the client needs to log in the web authentication page and enter the user name and password again once authentication timeout is reached.

By default, authentication timeout is one hour. Select **Custom** from the drop-down list to customize the parameter.

---

**Redirect:** Disable by default. Redirect specifies that the portal should redirect the newly authenticated clients to the configured URL.

---


---

**Redirect URL:** Enter the URL that a newly authenticated client will be directed to.

---

**Portal Customization:** Select Local Web Portal, the authentication login page will be provided by the built-in portal server.

The page configured below will be presented to users as the login page. Words can be filled in Input Box 1 and Input Box 2.



Enter up to 31 characters as the title of the authentication login page in Input Box 1, like "Guest Portal of TP-LINK".

Enter the terms presented to users in Input Box 2. The terms can be 1 to 1023 characters long.

---

- **Local Password**

**Portal Configuration**

Authentication Type: Local Password

Username: [Text Field]

Password: [Text Field]

Authentication Timeout: 1 Hours

[D] [H] [M]

Redirect:  Enable

Redirect URL: [Text Field]

Portal Customization: Local Web Portal

Preview:

[Text Field]

Username: [Text Field]

Password: [Text Field]

Term of Use:

[Text Field]

I accept the Term of Use

Login

Save

Figure 5-12 Portal Configuration\_Local Password

---

**Authentication Type:** Select **Local Password**.

---

**Username:** Enter the user name for local authentication.

---

**Password:** Enter the password for local authentication.

---

Please refer to [No Authentication](#) to configure **Authentication Timeout**, **Redirect**, **Redirect URL**, and **Portal Customization**.

- **External RADIUS Server**

External RADIUS Server provides two types of portal customization: Local Web Portal and External Web Portal. The authentication login page of Local Web Portal is provided by the built-in portal server of the EAP, as Figure 5-13 shown. The authentication login page of External Web Portal is provided by external portal server, as Figure 5-14 shown.

## 1. Local Web Portal

### Portal Configuration

**Authentication Type:** External Radius Serve ▼

**Radius Server Ip:**

**Port:**

**Radius Password:**

**Authentication Timeout:** 1 Hours ▼

D  H  M

**Redirect:**  Enable

**Redirect URL:**

**Portal Customization:** Local Web Portal ▼

**Username:**

**Password:**

**Term of Use:**

I accept the Term of Use

Login

Save

Figure 5-13 Portal Configuration\_External RADIUS Server\_Local Web Portal

---

**Authentication Type:** Select **External RADIUS Server**.

---

**RADIUS Server IP:** Enter the IP address of the RADIUS server.

---

**Port:** Enter the port for authentication service.

---

**RADIUS Password:** Enter the shared secret of RADIUS server to log in to the RADIUS server.

---

Please refer to [No Authentication](#) to configure **Authentication Timeout**, **Redirect**, **Redirect URL**, and **Portal Customization**.

## 2. External Web Portal

**Portal Configuration**

---

Authentication Type: External Radius Serve ▾

Radius Server Ip:

Port:

Radius Password:

Authentication Timeout: 1 Hours ▾

D  H  M

Redirect:  Enable

Redirect URL:

Portal Customization: External Web Portal ▾

External Web Portal URL:

Save

Figure 5-14 Portal Configuration\_External RADIUS Server\_External Web Portal

<b>Authentication Type:</b>	Select <b>External RADIUS Server</b> .
<b>RADIUS Server IP:</b>	Enter the IP address of the RADIUS server.
<b>Port:</b>	Enter the port for authentication service.
<b>RADIUS Password:</b>	Enter the shared secret of RADIUS server to log in to the RADIUS server.
<b>Portal Customization:</b>	Select <b>External Web Portal</b> .
<b>External Web Portal URL:</b>	Enter the authentication login page's URL, which is provided by the remote portal server.

Please refer to [No Authentication](#) to configure **Authentication Timeout**, **Redirect** and **Redirect URL**.

### 5.2.2 Free Authentication Policy


Free Authentication Policy allows clients to access network resources for free. On the lower part of the Portal page you can configure and view free authentication policies.


**Free Authentication Policy**

+ Add

ID	Policy Name	Source IP Range	Destination IP Range	Source Mac	Destination Port	Status	Settings
--	--	--	--	--	--	--	--

Figure 5-15 Free Authentication Policy

Click  **Add** to add a new authentication policy and configure its parameters.

**Free Authentication Policy**  Add

ID	Policy Name	Source IP Range	Destination IP Range	Source MAC	Destination Port	Status	Settings
--	--	--	--	--	--	--	--

**Policy Name:**

**Source IP Range:**  /  (Optional)

**Destination IP Range:**  /  (Optional)

**Source MAC:**  (Optional)

**Destination Port:**  (Optional)

**Status:**  **Enable**

Figure 5-16 Configure Free Authentication Policy

<b>Policy Name:</b>	Enter a policy name.
<b>Source IP Range:</b>	Enter the source IP address and subnet mask of the clients who can enjoy the free authentication policy. Leaving the field empty means all IP addresses can access the specific resources.
<b>Destination IP Range:</b>	Enter the destination IP address and subnet mask for free authentication policy. Leaving the field empty means all IP addresses can be visited. When <b>External Radius Server</b> is configured and <b>External Web Portal</b> is selected, please set the IP address and subnet mask of your external web server as the <b>Destination IP Range</b> .
<b>Source MAC:</b>	Enter the source MAC address of the clients who can enjoy the free authentication policy. Leaving the field empty means all MAC addresses can access the specific resources.
<b>Destination Port:</b>	Enter the destination port for free authentication policy. Leaving the field empty means all ports can be accessed.
<b>Status:</b>	Check the box to enable the policy.



Click the button **OK** in Figure 5-16 and the policy is successfully added as Figure 5-17 shows.

Free Authentication Policy							
ID	Policy Name	Source IP Range	Destination IP Range	Source MAC	Destination Port	Status	Settings
1	Policy 1	192.168.2.0/24	10.10.10.0/24	--	--	Enable	

Figure 5-17 Add Free Authentication Policy

Here is the explanation of Figure 5-17: The policy name is Policy 1. Clients with IP address range 192.168.2.0/24 are able to visit IP range 10.10.10.0/24. Policy 1 is enabled.

Click to edit the policy. Click to delete the policy.

### 5.3 MAC Filtering

MAC Filtering uses MAC addresses to determine whether one host can access the wireless network or not. Thereby it can effectively control the user access in the wireless network.

**TP-LINK** | EAP110 Access Point

Network **Wireless** Monitoring Management System

Wireless Settings Portal **MAC Filtering** Scheduler Qos Rogue AP Detection

**Settings**

Enable MAC Filtering:  Enable **Save**

**Station MAC Group**

**MAC Filtering Association**

ID	SSID Name	Band	MAC Group Name	Action
1	TP-LINK_2.4GHz_16E290	2.4GHz	None	Deny

**Note:**  
Deny: Deny the access of the stations specified in the MAC group.  
Allow: Allow the access of the stations specified in the MAC group. **Save**

Figure 5-18 MAC Filtering Page

- **Settings**

---


**Enable MAC Filtering:** Check the box to enable MAC Filtering.

---

- **Station MAC Group**

Follow the steps below to add MAC groups.

**Step 1:**

Click  **Create Groups**, two tables will be shown.





Figure 5-19 Station MAC Group

**Step 2:**

Click  **Add a Group** and fill in a name for the MAC group.





Figure 5-20 Add a Group

**Step 3:**

Click  **Add a Group Member** and input the MAC address you want to organize into this group.






Figure 5-21 Add a Group Member

Click  in Modify column to edit the MAC group name or MAC address. Click  to delete the MAC group or group member.

## • MAC Filtering Association




Figure 5-22 MAC Filtering Association

<b>SSID Name:</b>	Displays the SSID of the wireless network.
<b>Band:</b>	Displays the frequency band the wireless network operates at.
<b>MAC Group Name:</b>	Select a MAC group from the drop-down list to allow or deny its members to access the wireless network.
<b>Action:</b>	<ul style="list-style-type: none"> <li>• <b>Allow:</b> Allow the access of the stations specified in the MAC group.</li> <li>• <b>Deny:</b> Deny the access of the stations specified in the MAC group.</li> </ul>

## 5.4 Scheduler

Scheduler allows you to configure rules with specific time interval for radios to operate, which automates the enabling or disabling of the radio.




Figure 5-23 Scheduler Page

- **Settings**


**Scheduler:** Check the box to enable Scheduler.

**Association Mode:** Select **Associated with SSID/AP**, you can perform configurations on the SSIDs/AP. The display of Scheduler Association is based on your option here.

- **Scheduler Profile Configuration**

Follow the steps below to add rules.

**Step 1:**

Click  **Create Profiles**, two tables will be shown.




Figure 5-24 Scheduler Profile Configuration

**Step 2:**

Click **+ Add a Profile** and input a profile name for the rule.




Figure 5-25 Add a Profile

**Step 3:**

Click **+ Add a Item** and configure the recurring schedule for the rule.




Figure 5-26 Add a Rule

- **Scheduler Association**

This zone will display different contents based on your selection of association mode in [Settings](#).

### 1. Associated with SSID

**Scheduler Association**

ID	SSID Name	Band	Profile Name	Action
1	TP-LINK_2.4GHz_16E290	2.4GHz	None ▼	Radio Off ▼

Figure 5-27 Scheduler Association\_Associated with SSID

- 
- SSID Name:** Displays the SSID of the standalone AP.
- 
- Band:** Displays the frequency band which the wireless network operates at.
- 
- Profile Name:** Select a profile name from the drop-down list. Profile name is configured in Scheduler Profile Configuration.
- 
- Action:** Select **Radio On/Off** to turn on/off the wireless network during the time interval set for the profile.
- 

### 2. Associated with AP

**Scheduler Association**

ID	AP	AP MAC	Profile Name	Action
2	EAP110-00-0a-eb-16-e2-98	00-0A-EB-16-E2-98	None ▼	Radio off ▼

Figure 5-28 Scheduler Association\_Associated with AP

- 
- AP:** Displays the name of the device.
- 
- AP MAC:** Displays the MAC address of the device.
- 
- Profile Name:** Select a profile name from the drop-down list. Profile name is configured in Scheduler Profile Configuration.
- 
- Action:** Select **Radio On/Off** to turn on/off the wireless network during the time interval set for the profile.
-

## 5.5 QoS

The EAP supports Quality of Service (QoS) to prioritize voice and video traffic over other traffic types.

In normal use, the default values for the EAP device and station EDCA should not need to be changed. Changing these values affects the QoS provided.

**TP-LINK** | EAP110 Access Point ▼ ↶ ?

Network **Wireless** Monitoring Management System

Wireless Settings Portal MAC Filtering Scheduler **Qos** Rogue AP Detection

**Wi-Fi Multimedia (WMM):**  Enable

**AP EDCA Parameters**

Queue	Arbitration Inter-Frame Space	Minimum Contention Window	Maximum Contention Window	Maximum Burst
Data 0(Voice)	1	3 ▼	7 ▼	1504
Data 1(Video)	1	7 ▼	15 ▼	3008
Data 2(Best Effort)	3	15 ▼	63 ▼	0
Data 3(Background)	7	15 ▼	1023 ▼	0

**Station EDCA Parameters**

Queue	Arbitration Inter-Frame Space	Minimum Contention Window	Maximum Contention Window	TXOP Limit
Data 0(Voice)	2	3 ▼	7 ▼	1504
Data 1(Video)	2	7 ▼	15 ▼	3008
Data 2(Best Effort)	3	15 ▼	1023 ▼	0
Data 3(Background)	7	15 ▼	1023 ▼	0

**No Acknowledgement:**  Enable

**Unscheduled Automatic Power Save Delivery:**  Enable

**Save**

Figure 5-29 QoS Page

---

**Wi-Fi Multimedia (WMM):** By default, WMM is enabled. After WMM is enabled, the device has the QoS function to guarantee the transmission of audio and video packets with high priority.

---

## 5.5.1 AP EDCA Parameters

AP Enhanced Distributed Channel Access (EDCA) parameters affect traffic flowing from the EAP device to the client station.

AP EDCA Parameters				
Queue	Arbitration Inter-Frame Space	Minimum Contention Window	Maximum Contention Window	Maximum Burst
Data 0(Voice)	1	3	7	1504
Data 1(Video)	1	7	15	3008
Data 2(Best Effort)	3	15	63	0
Data 3(Background)	7	15	1023	0

Figure 5-30 AP EDCA Parameters

<b>Queue:</b>	Displays the transmission queues: Data 0>Data 1>Data 2>Data 3.
<b>Arbitration Inter-Frame Space:</b>	A wait time for data frames. The wait time is measured in slots. Valid values for AIFS are from 1 to 15.
<b>Minimum Contention Window:</b>	An input to the algorithm that determines the initial random backoff wait time (window) for retry of a transmission.
<b>Maximum Contention Window:</b>	The upper limit (in milliseconds) for the doubling of the random backoff value.
<b>Maximum Burst</b>	This parameter applies only to traffic flowing from EAP to the client station. This value specifies (in milliseconds) the maximum burst length allowed for packet bursts on the wireless network. A packet burst is a collection of multiple frames transmitted without header information. The decreased overhead results in higher throughput and better performance. Valid values for Maximum Burst are from 0 to 8192 and should be exactly divided by 32.



## 5.5.2 Station EDCA Parameters

Station EDCA parameters affect traffic flowing from the client station to the EAP device.

Station EDCA Parameters				
Queue	Arbitration Inter-Frame Space	Minimum Contention Window	Maximum Contention Window	TXOP Limit
Data 0(Voice)	2	3	7	1504
Data 1(Video)	2	7	15	3008
Data 2(Best Effort)	3	15	1023	0
Data 3(Background)	7	15	1023	0

No Acknowledgement:  Enable

Unscheduled Automatic Power Save Delivery:  Enable

Figure 5-31 Station EDCA Parameters

<b>Queue:</b>	Displays the transmission queues: Data 0>Data 1>Data 2>Data 3.
<b>Arbitration Inter-Frame Space:</b>	A wait time for data frames. The wait time is measured in slots. Valid values for AIFS are 1 through 15.
<b>Minimum Contention Window:</b>	An input to the algorithm that determines the initial random backoff wait time (window) for retry of a transmission.
<b>Maximum Contention Window:</b>	The upper limit (in milliseconds) for the doubling of the random backoff value.
<b>TXOP Limit:</b>	The Transmission Opportunity (TXOP) is an interval of time, in milliseconds, when a WME client station has the right to initiate transmissions onto the wireless medium towards the EAP device. Valid values for TXOP Limit are from 0 to 8192 and should be exactly divided by 32.
<b>No Acknowledgement:</b>	Select <b>Enable</b> to specify that the EAP device should not acknowledge frames with QoSNoAck as the service class value. By default, it is disabled.
<b>Unscheduled Automatic Power Save Delivery:</b>	Select <b>Enable</b> to enable APSD, which is a power management method. APSD is recommended if VoIP phones access the network through the EAP device. By default, it is enabled.

## 5.6 Rogue AP Detection

A Rogue AP is an access point that has been installed on a secure network without explicit authorization from a system administrator.

The EAP device can scan all channels to detect all APs in the vicinity of the network. If rogue APs are detected, they are shown on the Detected Rogue AP List. If an AP listed as a rogue is legitimate, you can add it to the Trusted AP List.

The screenshot shows the TP-LINK EAP110 web interface. The top navigation bar includes 'Network', 'Wireless', 'Monitoring', 'Management', and 'System'. The 'Wireless' tab is active, and the 'Rogue AP Detection' sub-tab is selected. The 'Settings' section has a 'Rogue AP Detection' checkbox that is currently disabled. A 'Save' button is located to the right. Below this is the 'Detected Rogue AP List' section, which includes a 'Scan' button and a table with columns: Action, MAC, SSID, Band, Channel, Security, Beacon Interval, and Signal. The table is currently empty. The 'Trusted AP List' section also contains an empty table with columns: Action, MAC, SSID, Band, Channel, and Security. At the bottom, the 'Download/Backup Trusted AP List' section has radio buttons for 'Download(PC to AP)' (selected) and 'Backup(AP to PC)'. There is a 'Source File Name' input field with a 'Browse' button, and 'File Management' options for 'Replace' (selected) and 'Merge'. A final 'Save' button is at the bottom right.

Figure 5-32 Rogue AP Detection Page

## 5.6.1 Settings



Settings

Rogue AP Detection:  Enable


Save

Figure 5-33 Enable Rogue AP Detection

**Rogue AP Detection:** Check the box to enable Rogue AP Detection, then click **Save**.

## 5.6.2 Detected Rogue AP List

Information about the detected rogue APs is displayed in the list. By default, the status of the detected rogue AP is unknown. You can click **Known** in Action column to move the AP to the Trusted AP List.





Action	MAC	SSID	Band	Channel	Security	Beacon Interval	Signal
Known	F8:1A:67:D3:36:80	TP-LINK_9E7YTP	2.4	1	ON	100	
Known	F4:EC:38:22:D3:10	TP-LINK_22D310	2.4	1	ON	100	

Figure 5-34 Detected Rogue AP List



Click to scan rogue APs. Make sure you have enabled Rogue AP Detection and saved the setting before you click the button.

**Action:** Click **Known** to move the AP to the Trusted AP List. After the configurations are saved, the moved AP will not be displayed in the Detected Rogue AP List.

**MAC:** The MAC address of the rogue AP.

**SSID:** The SSID for the rogue AP.

**Band:** Displays the frequency band which the wireless network of the rogue AP operates at.

**Channel:** The channel on which the rogue AP is currently broadcasting.

**Security:** Displays the enabling or disabling of the security mode of the wireless network.

<b>Beacon Interval:</b>	The beacon interval used by the rogue AP. Beacon frames are transmitted by an AP at regular intervals to announce the existence of the wireless network. The default behavior is to send a beacon frame once every 100 milliseconds (or 10 per second).
<b>Signal:</b>	The strength of the radio signal emitting from the rogue AP.

### 5.6.3 Trusted AP List

Information about the trusted APs is displayed in the list.

Trusted AP List					
Action	MAC	SSID	Band	Channel	Security
Unknown	40:16:9F:BF:56:12	TP-LINK_2.4GHZ_BF5612	2.4	11	ON
Unknown	B0:48:7A:DB:8A:A5	TP-LINK_2.4GHZ_DB8AA5	2.4	1	ON

Figure 5-35 Trusted AP List

<b>Action:</b>	Click <b>Unknown</b> to move the AP out of the Trusted AP List.
<b>MAC:</b>	The MAC address of the trusted AP.
<b>SSID:</b>	The SSID for the trusted AP.
<b>Band:</b>	Displays the frequency band which the wireless network of the trusted AP operates at.
<b>Channel:</b>	The channel on which the trusted AP is currently broadcasting.
<b>Security:</b>	Displays the enabling or disabling of the security mode of the wireless network.

### 5.6.4 Download/Backup Trusted AP List

You can import a list of trusted APs from a saved list which is acquired from another AP or created from a text file. The AP whose MAC address is in the Trusted AP List will not be detected as a rogue.

You can also backup a list and save it in your PC.

Download/Backup Trusted AP List	
Save Action:	<input checked="" type="radio"/> Download(PC to AP) <input type="radio"/> Backup(AP to PC)
Source File Name:	<input type="text"/> <input type="button" value="Browse"/>
File Management:	<input checked="" type="radio"/> Replace <input type="radio"/> Merge
<input type="button" value="Save"/>	

Figure 5-36 Download/Backup Trusted AP List

---

<b>Save Action:</b>	Select <b>Download (PC to AP)</b> to import a trusted AP list to the device. Select <b>Backup (AP to PC)</b> to copy the trusted AP list to your PC.
---------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------

---

<b>Source File Name:</b>	Click <b>Browse</b> and choose the path of a saved trusted AP list or to save a trusted AP list.
--------------------------	--------------------------------------------------------------------------------------------------

---

<b>File Management:</b>	Select <b>Replace</b> to import the list and replace the contents of the Trusted AP List. Select <b>Merge</b> to import the list and add the APs in the imported file to the APs currently shown in the Trusted AP List
-------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

---

**NOTE:**

EAP device does not have any control over the APs in the Detected Rogue AP List.

# Chapter 6 Monitoring

On Monitoring page, you can monitor the network running status and statistics based on AP, SSID and Client.

## 6.1 AP

AP List on the Monitoring page displays the device name, its MAC address and the number of clients. Below the AP List the AP's detailed information will be shown, including [Device Information](#), [Wireless Settings](#), [LAN Information](#), [Client](#), [LAN Traffic](#) and [Radio Traffic](#).




Figure 6-1 AP Monitoring

### 6.1.1 AP List




Figure 6-2 AP List

<b>Device Name:</b>	Displays the device name.
<b>MAC:</b>	Displays the MAC address of the EAP.
<b>Num of Clients:</b>	Displays the number of clients connected to the EAP.

- **Device Information**




Figure 6-3 Device Information

<b>Device Name:</b>	Displays the device name.
<b>Device Model:</b>	Displays the model of the device.
<b>Firmware Version:</b>	Displays the firmware version of the device. If you want to upgrade the firmware, please refer to <a href="#">8.5 Firmware Upgrade</a> .
<b>System Time:</b>	Displays the system time of the device. If you want to adjust the system time, please refer to <a href="#">8.2.1 Time Settings</a> .
<b>Uptime:</b>	Displays the time that has elapsed since the last reboot.
<b>CPU:</b>	Displays the CPU occupancy, which helps you to preliminarily judge whether the device functions properly.
<b>Memory:</b>	Displays the memory usage, which helps you to preliminarily judge whether the device functions properly.

- **Wireless Settings**

Device Information   <a href="#">Wireless Settings</a>   LAN Information   Client   LAN Traffic   Radio Traffic	
<b>Channel/Frequency:</b>	3 / 2422MHz
<b>Channel Width:</b>	20/40MHz
<b>IEEE802.11 Mode:</b>	b/g/n mixed
<b>Max TX Rate:</b>	300.0Mbps
<b>Transmit Power:</b>	20dBm

Figure 6-4 Wireless Settings

---

<b>Channel/Frequency:</b>	Displays the channel number and the operating frequency. If you want to change them, please refer to <a href="#">5.1.1 Wireless Basic Settings</a> .
<b>Channel Width:</b>	Displays the spectral width of the radio channel used by the device. If you want to change it, refer to <a href="#">5.1.1 Wireless Basic Settings</a> .
<b>IEEE802.11 Mode:</b>	Displays the radio standard used for operation of your device. If you want to change it, refer to <a href="#">5.1.1 Wireless Basic Settings</a> .
<b>Max TX Rate:</b>	Displays the maximum data rate at which the device should transmit wireless packets.
<b>Transmit Power:</b>	Displays the maximum average transmit power of the device. If you want to change it, refer to <a href="#">5.1.1 Wireless Basic Settings</a> .

---

- **LAN Information**

Device Information   <a href="#">Wireless Settings</a>   <a href="#">LAN Information</a>   Client   LAN Traffic   Radio Traffic	
<b>MAC Address:</b>	00-0A-EB-16-E2-90
<b>IP Address:</b>	192.168.0.4
<b>Subnet Mask:</b>	255.255.255.0
<b>LAN Port:</b>	100Mbps - FD

Figure 6-5 LAN Information

---

<b>MAC Address:</b>	Displays the MAC address of the device.
<b>IP Address:</b>	Displays the IP address of the device.
<b>Subnet Mask:</b>	Displays the subnet mask of the device.
<b>LAN Port:</b>	Displays the maximum transmission rate and duplex mode (half-duplex or full-duplex) of the port.

---



- **Client**

ID	MAC	SSID	SNR(dB)	CCQ(%)	Rate(Mbps)	Down(Byte)	Up(Byte)	Active Time
1	14-F4-2A-3B-D7-E9	TP-LINK_2.4GHZ_666666	21	100	13.9	52k	7k	0 days 00:02:12

Figure 6-6 Client

<b>MAC:</b>	Displays the MAC address of the client of the AP selected in AP List.
<b>SSID:</b>	Displays the SSID the client is connected to.
<b>SNR(dB):</b>	Signal to Noise Ratio, the power ratio between the received wireless signal strength and the environmental noise strength. The bigger the value of SNR, the better network performance the device provides.
<b>CCQ(%):</b>	Displays the wireless Client Connection Quality (CCQ). CCQ refers to the ratio of current effective transmission bandwidth and the theoretically maximum available bandwidth. CCQ reflects the actual link condition.
<b>Rate(Mbps):</b>	Displays the data rate at which the client transmits wireless packets.
<b>Down(Byte):</b>	Displays the throughput of the downstream data.
<b>Up(Byte):</b>	Displays the throughput of the upstream data.
<b>Active Time:</b>	Displays the amount of time the client has been connected to the device.

- **LAN Traffic**

Click **LAN Traffic** and you can monitor the data transmission status of the LAN port.

Device Information   Wireless Settings   LAN Information   Client   LAN Traffic   Radio Traffic			
<b>Rx Packets:</b>	715	<b>Tx Packets:</b>	854
<b>Rx Bytes:</b>	83401	<b>Tx Bytes:</b>	815917
<b>Rx Dropped Packets:</b>	65	<b>Tx Dropped Packets:</b>	0
<b>Rx Errors:</b>	0	<b>Tx Errors:</b>	0

Figure 6-7 LAN Traffic

<b>Rx/Tx Packets:</b>	Displays the total amount of packets received/sent on the LAN port.
<b>Rx/Tx Bytes:</b>	Displays the total amount of data (in bytes) received/sent on the LAN port.

<b>Rx/Tx Dropped Packets:</b>	Displays the total amount of dropped packets received/sent on the LAN port.
<b>Rx/Tx Errors:</b>	Displays the total amount of error packets received/sent-on the LAN port.

- **Radio Traffic**

Click **Radio Traffic** and you can monitor the data transmission status of the wireless network.

<a href="#">Device Information</a>   <a href="#">Wireless Settings</a>   <a href="#">LAN Information</a>   <a href="#">Client</a>   <a href="#">LAN Traffic</a>   <a href="#">Radio Traffic</a>			
<b>Rx Packets:</b>	10868	<b>Tx Packets:</b>	7299
<b>Rx Bytes:</b>	1277064	<b>Tx Bytes:</b>	181327
<b>Rx Dropped Packets:</b>	0	<b>Tx Dropped Packets:</b>	0
<b>Rx Errors:</b>	0	<b>Tx Errors:</b>	0

Figure 6-8 Radio Traffic

<b>Rx/Tx Packets:</b>	Displays the total amount of packets received/sent by the wireless network.
<b>Rx/Tx Bytes:</b>	Displays the total amount of data (in bytes) received/sent by the wireless network.
<b>Rx/Tx Dropped Packets:</b>	Displays the total amount of dropped packets received/sent by the wireless network.
<b>Rx/Tx Errors:</b>	Displays the total amount of error packets received/sent by the wireless network.

## 6.2 SSID

<b>TP-LINK</b>   EAP110		Access Point <span>↩</span> <span>?</span>									
Network		Wireless		Monitoring				Management		System	
AP				SSID				Client			
<b>SSID List</b> <span style="float: right;">Refresh</span>											
ID	SSID Name	VLAN ID	Num of Clients	SSID Broadcast	Band	Security	Portal	MAC Filtering	Isolation	Down(Byte)	Up(Byte)
1	TP-LINK_2.4GHz_FFFFFF	0	0	enable	2.4GHz	none	disable	disable	disable	0	0

Figure 6-9 SSID Monitoring

## 6.2.1 SSID List

In SSID List you can monitor the related parameters of the wireless network.

SSID List											
ID	SSID Name	VLAN ID	Num of Clients	SSID Broadcast	Band	Security	Portal	MAC Filtering	Isolation	Down(Byte)	Up(Byte)
1	TP-LINK_2.4GHz_FFFFFF	0	0	enable	2.4GHz	none	disable	disable	disable	0	0

Figure 6-10 SSID List

<b>SSID Name:</b>	Displays the SSID name. If you want to modify it, please refer to <a href="#">5.1.2 SSIDs</a> .
<b>VLAN ID:</b>	Displays the VLAN which the SSID belongs to. If you want to change the VLAN ID, please refer to <a href="#">5.1.2 SSIDs</a> .
<b>Num of Clients:</b>	Displays the number of clients connected to the SSID. If you want to get more information about these clients, please refer to <a href="#">5.1.2 SSIDs</a> .
<b>SSID Broadcast:</b>	Displays the enabling or disabling of SSID broadcast. If you want to modify it, please refer to <a href="#">5.1.2 SSIDs</a> .
<b>Band:</b>	Displays the frequency band the wireless network is operating at.
<b>Security:</b>	Displays the security mode the wireless network is applying. If you want to modify it, please refer to <a href="#">5.1.2 SSIDs</a> .
<b>Portal:</b>	Displays the enabling or disabling of Portal. If you want to modify it, please refer to <a href="#">5.1.2 SSIDs</a> .
<b>MAC Filtering:</b>	Displays the enabling or disabling of MAC Filtering. If you want to modify it, please refer to <a href="#">5.1.2 SSIDs</a> .
<b>Isolation:</b>	Displays the enabling or disabling of SSID Isolation. If you want to modify it, please refer to <a href="#">5.1.2 SSIDs</a> .
<b>Down(Byte):</b>	Displays the throughput of the downstream data.
<b>Up(Byte):</b>	Displays the throughput of the upstream data.

## 6.3 Client

From User List, you can monitor the status of all the clients connected to the EAP including those who are authenticated.

TP-LINK | EAP110 Access Point

Network Wireless **Monitoring** Management System

AP SSID **Client**

**User List**  Refresh

ID	MAC	Access Point	SSID	SNR(dB)	CCQ(%)	Rate(Mbps)	Down(Byte)	Up(Byte)	Active Time
1	14-F4-2A-3B-D7-E9	EAP110-00-0a-eb-13-7b-00	TP-LINK_2.4GHZ_FFFFFF	36	16	39.7	3k	1k	0 days 00:00:09

**Portal Authenticated Guest**  Refresh

ID	MAC	Access Point	SSID	SNR(dB)	CCQ(%)	Rate(Mbps)	Down(Byte)	Up(Byte)	Active Time	Action
--	--	--	--	--	--	--	--	--	--	--

Figure 6-11 Client Monitoring

### 6.3.1 User List

**User List**  Refresh

ID	MAC	Access Point	SSID	SNR(dB)	CCQ(%)	Rate(Mbps)	Down(Byte)	Up(Byte)	Active Time
1	14-F4-2A-3B-D7-E9	EAP110-00-0a-eb-13-7b-00	TP-LINK_2.4GHZ_FFFFFF	36	16	39.7	3k	1k	0 days 00:00:09

Figure 6-12 User List

**MAC:** Displays the MAC address of the client.

**Access Point:** Displays the name of the device to which the client is connected.

**SSID:** Displays the SSID the client is connected to.

**SNR(dB):** Signal to Noise Ratio, the power ratio between the received wireless signal strength and the environmental noise strength. The bigger the value of SNR, the better network performance the device provides.

**CCQ(%):** Displays the wireless Client Connection Quality (CCQ). CCQ refers to the ratio of current effective transmission bandwidth and the theoretically maximum available bandwidth. CCQ reflects the actual link condition.

**Rate(Mbps):** Displays the data rate at which the client transmits wireless packets.

**Down(Byte):** Displays the throughput of the downstream data.

**Up(Byte):** Displays the throughput of the upstream data.


---

**Active Time:** Displays the amount of time the client has been connected to the device.

---

### 6.3.2 Portal Authenticated Guest

The Portal Authenticated Guest displays information about clients that have set up valid authentication.



ID	MAC	Access Point	SSID	SNR(dB)	CCQ(%)	Rate(Mbps)	Down(k)	Up(k)	Active Time	Action
--	--	--	--	--	--	--	--	--	--	--

Figure 6-13 Portal Authenticated Guest

---

**MAC:** Displays the MAC address of the authenticated client.

---

**Access Point:** Displays the name of the device to which the authenticated client is connected

---

**SSID:** Displays the SSID the authenticated client is connected to.

---

**SNR(dB):** Signal to Noise Ratio, the power ratio between the received wireless signal strength and the environmental noise strength. The bigger the value of SNR, the better network performance the device provides.

---

**CCQ(%):** Displays the Client Connection Quality (CCQ) of the authenticated client. CCQ refers to the ratio of current effective transmission bandwidth and the theoretically maximum available bandwidth. CCQ reflects the actual link condition.

---

**Rate(Mbps):** Displays the data rate at which the authenticated client transmits wireless packets.

---

**Down(Byte):** Displays the throughput of the downstream data.

---

**Up(Byte):** Displays the throughput of the upstream data.

---

**Active Time:** Displays the amount of time the authenticated client has been connected to the root AP.

---

**Action:** Click **Unauthorize** to stop giving authorization to the clients connected to the wireless network.

---

# Chapter 7 Management

Management page is mainly used for device management and maintenance.

## 7.1 System Log

System log records information about hardware, software as well as system issues and monitors system events. With the help of system log, you can get informed of system running status and detect the reasons for failure.

Following is the page of System Log.

The screenshot displays the TP-LINK EAP110 management interface. The top navigation bar includes 'Network', 'Wireless', 'Monitoring', 'Management' (highlighted), and 'System'. Below this, a sub-menu shows 'System Log' (highlighted), 'Web Server', 'Management Access', 'LED ON/OFF', 'SSH', and 'SNMP'. The main content area is titled 'Log List' and features a 'Refresh' button. A table lists log entries with columns for Index, Time, Type, Level, and Log Content. Below the table is a pagination control showing '1 2'. The 'Log Settings' section contains three options: 'Enable Auto Mail' (checkbox for Auto Mail Feature), 'Enable Server' (checkbox for Enable Server), and 'Enable Nvram' (checkbox for Enable Nvram). A 'Save' button is located at the bottom right of the settings area.

Index	Time	Type	Level	Log Content
3	2014-01-01 00:00:31	DHCP	NOTICE	DHCP Recv OFFER from server 192.168.0.111 with ip 192.168.0.100
2	2014-01-01 00:00:30	DHCP	NOTICE	DHCP Send DISCOVER with request ip 0.0.0.0 and unicast flag 0
1	1970-01-01 00:00:10	OTHER	INFO	System started

Figure 7-1 System Log Page

### 7.1.1 Log List

From Log List you can view detailed information about hardware, software, system issues and so on.

Log List				
Index	Time	Type	Level	Log Content
3	2014-01-01 00:00:31	DHCP	NOTICE	DHCP Recv OFFER from server 192.168.0.111 with ip 192.168.0.100
2	2014-01-01 00:00:30	DHCP	NOTICE	DHCP Send DISCOVER with request ip 0.0.0.0 and unicast flag 0
1	1970-01-01 00:00:10	OTHER	INFO	System started

Refresh

< 1 >

Figure 7-2 Log List

## 7.1.2 Log Settings

You can choose the way to receive system logs in Log Settings zone, where these parameters can be configured: [Enable Auto Mail](#), [Enable Server](#) and [Enable Nvram](#).

Log Settings	
Enable Auto Mail:	<input type="checkbox"/> Auto Mail Feature
Enable Server:	<input type="checkbox"/> Enable Server
Enable Nvram:	<input type="checkbox"/> Enable Nvram
<a href="#">Save</a>	

Figure 7-3 Log Settings

- **Enable Auto Mail**

If Auto Mail is enabled, system logs will be sent to a mailbox. The following content will be shown.

Enable Auto Mail:	<input checked="" type="checkbox"/> Auto Mail Feature
From:	<input type="text"/>
To:	<input type="text"/>
SMTP Server:	<input type="text"/>
Enable Authentication:	<input type="checkbox"/> Enable Authentication
User Name:	<input type="text"/>
Password:	<input type="text"/>
Confirm Password:	<input type="text"/>
Time Mode:	<input checked="" type="radio"/> Fixation Time <input type="radio"/> Period Time
Fixation Time:	00 : 00 (HH:MM)

Figure 7-4 Enable Auto Mail

---

**From:** Enter the sender's email address.

---

**To:** Enter the recipient's email address, which will receive the system logs.

---

<b>SMTP Server:</b>	Enter the IP address of the SMTP server.
<b>Enable Authentication:</b>	<p>Generally users are required to log in to the SMTP server by entering user name and password.</p> <ul style="list-style-type: none"> <li>• <b>User Name:</b> Enter the sender's email address.</li> <li>• <b>Password:</b> Enter the password of the sender's email address.</li> <li>• <b>Confirm Password:</b> Enter the password again for confirmation.</li> </ul>
<b>Time Mode:</b>	<p>System logs can be sent at specific time or time interval.</p> <ul style="list-style-type: none"> <li>• <b>Fixation Time:</b> Set a fixed time, for example, 15:00. The recipient will receive the system logs sent by the device at 15:00 every day.</li> <li>• <b>Period Time:</b> Set a time interval, for example, 5 hours. The recipient will receive the system logs sent by the device every 5 hours.</li> </ul>

- **Enable Server**

System logs can also be sent to a server. After Auto Mail Feature is enabled, the following content will be shown.

Enable Server:	<input checked="" type="checkbox"/> Enable Server
System Log Server IP:	<input type="text" value="0.0.0.0"/>
System Log Server Port:	<input type="text" value="514"/>

Figure 7-5 Enable Server

<b>System Log Server IP:</b>	Enter the IP address of the remote server.
<b>System Log Server Port:</b>	Enter the port of the remote server.

- **Enable Nvram**

By default, Nvram is disabled. Check the box to enable Nvram, system logs will be saved after power supply is cut.

## 7.2 Web Server

You can log in web management interface, thereby manage and maintain the device.



Following is the page of Web Server.




Figure 7-6 Web Server Page

<b>HTTPS:</b>	HTTPS (Hypertext Transfer Protocol Secure) is enabled by default.
<b>Secure Server Port:</b>	Designate a secure server port for web server in HTTPS mode. By default the port is 443.
<b>Server Port:</b>	Designate a server port for web server in HTTP mode. By default the port is 80.
<b>Session Timeout:</b>	Set the session timeout time. If you do nothing with the web management page within the timeout time, the system will log out automatically. Please login again if you want to go back to web management page.

### 7.3 Management Access

Management Access Control allows you to configure up to four MAC addresses of the hosts that are allowed to log in to the web management page of the EAP. Click **Add PC's MAC** and the MAC address of the current host will be added to MAC address list.

Following is the page of Management Access.




Figure 7-7 Management Access Page

**MAC Authentication:** Check the box to enable MAC Authentication. After MAC Authentication is enabled, only the PCs in MAC address list can log in the device's web management page. By default this function is disabled. All PCs in LAN can log in and manage the device.

**MAC1~MAC4:** Enter the MAC addresses of the PCs which are authorized to log in the device.

## 7.4 LED ON/OFF

Following is the page of LED ON/OFF. By default the LED is on.




Figure 7-8 LED ON/OFF

## 7.5 SSH

This device supports the SSH Server function that allows users to login and manage it through SSH connection on the SSH client software.

SSH (Secure Shell) is a security protocol established on application and transport layers. SSH-encrypted-connection is similar to a telnet connection, but essentially the old telnet remote management method is not safe, because the password and data transmitted with plain-text can be easily intercepted. SSH can provide information security and powerful authentication when you login this device remotely through an insecure network environment. It can encrypt all the transmission data and prevent the information in remote management from being leaked. Following is the page of SSH.




Figure 7-9 SSH Page

---

**Server Port:** Enter the server port. By default, it is port 22.

---

**SSH Login:** Check the box to enable SSH Server. By default, it is disabled.

---

## 7.6 SNMP

The device can be configured as an SNMP agent.

SNMP (Simple Network Management Protocol), the most widely applied network management protocol, provides a management framework to monitor and maintain Internet devices. Main functions of SNMP include monitoring network performance, detecting and analyzing network error, configuring network devices, and so on. When networks function properly, SNMP can perform the functions of statistics, configuration and testing. When networks have troubles, SNMP can detect and restore these troubles.

An SNMP consists of three key components: manager, agent and MIB (Management Information Base). SNMP manager is a client program operating at workstation, assisting network administrators to accomplish most network device management tasks. An agent is a network-management software module that resides on a managed device and responsible for receiving and dealing with data sent by managing device. Generally the managed devices are network devices including hosts, bridges, switches and routers. MIB is the collection of managed devices. It defines a series of properties of the managed devices. Every SNMP agent has its own MIB.

Once the device has become an SNMP agent, it is able to receive and process request messages from SNMP manager.

Following is the page of SNMP.




Figure 7-10 SNMP Page

**SNMP Agent:** Enable SNMP Agent and the SNMP Agent will collect the information of this device and respond to information requests from one or more management systems.

**SysContact:** Enter the textual identification of the contact person for this managed node.

**SysName:** Enter an administratively-assigned name for this managed node.

**SysLocation:** Enter the physical location of this managed node.

**Get Community:** Community refers to a host group aiming at network management. Get Community only has the read-only right of the device's SNMP information. The community name can be considered a group password. The default setting is public.

**Get Source:** Defines the IP address (for example, 10.10.10.1) or subnet for management systems that can serve as Get Community to read the SNMP information of this device. The format of subnet is "IP address/bit" (such as 10.10.10.0/24). The default is 0.0.0.0, which means all hosts can read the SNMP information of this device.

**Set Community:** Set Community has the read and write right of the device's SNMP information. Enter the community name that allows read/write access to the device's SNMP information. The community name can be considered a group password. The default setting is private.

---

**Set Source:** Defines the IP address (for example, 10.10.10.1) or subnet for management systems that can serve as Set Community to read and write the SNMP information of this device. The format of subnet is "IP address/bit" (such as 10.10.10.0/24). The default is 0.0.0.0, which means all hosts can read and write the SNMP information of this device.

---

**NOTE:**

Defining community can allow management systems in the same community to communicate with the SNMP Agent. The community name can be seen as the shared password of the network hosts group. Thus, for the security, we suggest modifying the default community name before enabling the SNMP Agent service. If the field of community is blank, the SNMP Agent will not respond to any community name.

# Chapter 8 System

System page is mainly used to configure some basic information like user account and time, and realize functions including reboot, reset, backup, restore and upgrade the device.

## 8.1 User Account

You can change the username and password to protect your device from unauthorized login. We recommend that you change the default user password on the very first system setup.




Figure 8-1 User Account Page

---

**Old User Name/Password:** Enter the present user name and password of the admin account to get the permission of modification.

---

**New User Name/Password:** Enter a new user name and password for the admin account. Both values are case-sensitive, up to 64 characters and with no space.

---

**Confirm New Password:** Enter the new password again.

---

## 8.2 Time Settings

System time represents the device system's notion of the passing of time. System time is the standard time for Scheduler and other time-based functions. You can manually set the system time, configure the system to acquire its time settings from a preconfigured NTP server or synchronize the system time with the PC's clock.

The device supports DST (daylight saving time).

Figure 8-2 Time Settings

## 8.2.1 Time Settings

Figure 8-3 Time Settings

<b>Get GMT</b>	Click the button and the device will obtain GMT time from NTP server. IP address of the NTP server has to be filled in.
<b>Synchronize PC's Clock</b>	Click the button, your PC's time will be obtained as the device's system time.
<b>Time zone:</b>	Select your local time zone from the drop-down list.
<b>Date:</b>	Set the current date, in format MM/DD/YYYY. For example, for November 25, 2014, enter 11/25/2014 in the field.
<b>Time:</b>	Specify the device's time. Select the number from the drop-down list in time format HH/MM/SS.

---

**Primary/Secondary NTP Server:** If you've selected **Get GMT** from an NTP server, please input the primary NTP server address and an alternative NTP server address.

---

## 8.2.2 Daylight Saving




Figure 8-4 Daylight Saving

---

**Daylight Saving:** Enable or disable the DST. DST is disabled by default.

---

**Mode:** Options include Predefined Mode, Recurring Mode and Date Mode. Please refer to the following content for more information.

---

- **Predefined Mode**




Figure 8-5 Predefined Mode

---

**Mode:** Select **Predefined Mode**.

---

**Predefine Country:** Select a predefined DST configuration. Europe is the predefined country by default.

- **USA:** Second Sunday in March, 02:00 ~ First Sunday in November, 02:00
  - **European:** Last Sunday in March, 01:00 ~ Last Sunday in October, 01:00
  - **Australia:** First Sunday in October, 02:00 ~ First Sunday in April, 03:00
  - **New Zealand:** Last Sunday in September, 02:00 ~ First Sunday in April, 03:00
-



- **Recurring Mode**

Figure 8-6 Recurring Mode

---

**Mode:** Select **Recurring Mode**. The configuration is recurring in use.

---

**Time Offset:** Specify the time adding in minutes when Daylight Saving Time comes.

---

**Start/End:** Select starting time and ending time of Daylight Saving Time.

---

- **Date Mode**

Figure 8-7 Date Mode

---

**Mode:** Select **Date Mode**.

---

**Time Offset:** Specify the time adding in minutes when Daylight Saving Time comes.

---

**Start/End:** Select starting time and ending time of Daylight Saving Time.

---

### 8.3 Reboot/Reset

Figure 8-8 Reboot & Reset

Click **Reboot** to restart the device. Click **Reset** to restore the device to factory default settings.

## 8.4 Backup & Restore




Figure 8-9 Backup & Restore

You can save the current configuration of the EAP as a backup file and restore the configuration via a backup file. Back up the settings before you upgrade the device or upload a new configuration file can prevent it from being lost.

Restore function helps you to restore the device to previous settings by uploading a backup file.

## 8.5 Firmware Upgrade




Figure 8-10 Firmware Upgrade

Please log in <http://www.tp-link.com/en/support/download/> to download the latest system file. Click **Browse** to choose the firmware file. Click **Upgrade** to upgrade the devices.

**NOTE:**

1. Please select the proper software version that matches your hardware to upgrade.
2. To avoid damage, please do not turn off the device while upgrading.
3. After upgrading, the device will reboot automatically.

## Appendix A: Specifications

<b>HARDWARE FEATURES</b>			
Model	EAP110	EAP120	EAP220
Interface	Kensington lock slot RESET button		
	ETHERNET: 10/100Mbps Ethernet port (RJ-45)	ETHERNET: 10/100/1000Mbps Ethernet port (RJ-45) CONSOLE port (RJ-45) Power connector (DC-2)	
Power Supply	24V/1A passive PoE adapter (included)	PoE(802.3af-compliant, 36-57VDC, 0.2A Max) or external 12VDC/1A power supply	PoE (802.3af-compliant, 36-57VDC, 0.4A Max) or external 12VDC/1.5A power supply
Maximum Power Consumption	7.7W	4.4W	9.6W
Antenna	2*3dBi embedded	2*4dBi embedded	4*4dBi embedded
Mounting	Ceiling/Wall mounting (kits included)		
Certification	CE, FCC, RoHS		
Operating Temperature	0°C~40°C (32°F~104°F)		
Operating Humidity	10%~90% non-condensing		
<b>WIRELESS FEATURES</b>			
Wireless Frequency	2.4GHz		2.4GHz & 5GHz
Wi-Fi Standard	IEEE 802.11b/g/n		IEEE 802.11a/b/g/n
Maximum Data Rate	Up to 300Mbps		Up to 600Mbps
Max RF Transmission Power	23dBm		2.4GHz:23dBm 5GHz:20dBm
Multiple SSIDs	Up to eight per radio		
Captive Portal Authentication	Support		
Wireless Security	WEP WPA/WPA2-personal WPA/WPA2-enterprise		