




# CLI Guide

**JetStream 24-Port 10/100Mbps + 4-Port Gigabit  
L2 Managed Switch**

**T2500-28TC (TL-SL5428E)**

REV2.0.0  
1910011988

## COPYRIGHT & TRADEMARKS

Specifications are subject to change without notice.  **tp-link** is a registered trademark of TP-Link Technologies Co., Ltd. Other brands and product names are trademarks or registered trademarks of their respective holders.

No part of the specifications may be reproduced in any form or by any means or used to make any derivative such as translation, transformation, or adaptation without permission from TP-Link Technologies Co., Ltd. Copyright © 2016 TP-Link Technologies Co., Ltd. All rights reserved.

<http://www.tp-link.com>

# CONTENTS

<b>Preface</b> .....	<b>1</b>
<b>Chapter 1 Using the CLI</b> .....	<b>5</b>
1.1 Accessing the CLI.....	5
1.1.1 Logon by a console port.....	5
1.1.2 Logon by Telnet.....	6
1.1.3 Logon by SSH .....	10
1.2 CLI Command Modes .....	15
1.3 Security Levels .....	18
1.4 Conventions.....	18
1.4.1 Format Conventions.....	18
1.4.2 Special Characters.....	18
1.4.3 Parameter Format.....	19
<b>Chapter 2 User Interface</b> .....	<b>20</b>
enable.....	20
enable password .....	20
disable .....	21
configure.....	21
exit.....	22
end.....	22
history.....	23
history clear .....	23
<b>Chapter 3 IEEE 802.1Q VLAN Commands</b> .....	<b>24</b>
vlan.....	24
interface vlan.....	25
name .....	25
switchport mode .....	26
switchport access vlan .....	26
switchport trunk allowed vlan .....	27
switchport general allowed vlan.....	28
switchport pvid .....	28
show vlan summary .....	29
show vlan brief .....	29
show vlan .....	30

<b>Chapter 4</b>	<b>MAC-based VLAN Commands</b>	<b>31</b>
	mac-vlan mac-address	31
	mac-vlan	32
	show mac-vlan	32
	show mac-vlan interface	33
<b>Chapter 5</b>	<b>Protocol-based VLAN Commands</b>	<b>34</b>
	protocol-vlan template	34
	protocol-vlan vlan	35
	protocol-vlan	35
	show protocol-vlan template	36
	show protocol-vlan vlan	36
	show protocol-vlan interface	37
<b>Chapter 6</b>	<b>VLAN-VPN Commands</b>	<b>38</b>
	dot1q-tunnel	38
	dot1q-tunnel tpid	38
	dot1q-tunnel mapping	39
	switchport dot1q-tunnel mapping	40
	switchport dot1q-tunnel mode uplink	40
	show dot1q-tunnel	41
	show dot1q-tunnel mapping	41
	show dot1q-tunnel mapping interface	42
	show dot1q-tunnel uplink	42
<b>Chapter 7</b>	<b>Voice VLAN Commands</b>	<b>43</b>
	voice vlan	43
	voice vlan aging time	43
	voice vlan priority	44
	voice vlan mac-address	45
	switchport voice vlan mode	45
	switchport voice vlan security	46
	show voice vlan	47
	show voice vlan oui	47
	show voice vlan switchport	48
<b>Chapter 8</b>	<b>Private VLAN Commands</b>	<b>49</b>
	private-vlan primary	49
	private-vlan community	49

private-vlan association.....	50
switchport private-vlan .....	50
switchport private-vlan host-association .....	51
switchport private-vlan mapping .....	52
show vlan private-vlan.....	53
<b>Chapter 9 GVRP Commands.....</b>	<b>54</b>
gvrp.....	54
gvrp (interface) .....	54
gvrp registration .....	55
gvrp timer .....	56
show gvrp global .....	57
show gvrp interface .....	57
<b>Chapter 10 Etherchannel Commands .....</b>	<b>58</b>
channel-group .....	58
port-channel load-balance .....	59
lACP system-priority .....	59
lACP port-priority .....	60
show etherchannel.....	60
show etherchannel load-balance .....	61
show lACP .....	61
show lACP sys-id.....	62
<b>Chapter 11 User Manage Commands.....</b>	<b>63</b>
user name .....	63
user access-control ip-based.....	64
user access-control mac-based.....	64
user access-control port-based.....	65
user max-number .....	66
user idle-timeout.....	66
line .....	67
password .....	68
login .....	69
login local .....	69
show user account-list.....	70
show user configuration .....	70
<b>Chapter 12 Binding Table Commands.....</b>	<b>71</b>

ip source binding .....	71
ip source binding index .....	72
ip dhcp snooping .....	73
ip dhcp snooping global .....	73
ip dhcp snooping information option .....	74
ip dhcp snooping information strategy .....	75
ip dhcp snooping information remote-id .....	76
ip dhcp snooping information circuit-id .....	76
ip dhcp snooping trust .....	77
ip dhcp snooping mac-verify .....	78
ip dhcp snooping limit rate .....	78
ip dhcp snooping decline .....	79
show ip source binding .....	79
show ip dhcp snooping .....	80
show ip dhcp snooping information interface .....	80
show ip dhcp snooping interface .....	81
<b>Chapter 13 ARP Inspection Commands.....</b>	<b>82</b>
ip arp inspection(global) .....	82
ip arp inspection trust .....	82
ip arp inspection(interface) .....	83
ip arp inspection limit-rate .....	84
ip arp inspection recover .....	84
show ip arp inspection .....	85
show ip arp inspection interface .....	85
show ip arp inspection statistics .....	86
clear ip arp inspection statistics .....	86
<b>Chapter 14 IP Verify Source Commands.....</b>	<b>87</b>
ip verify source .....	87
show ip verify source .....	88
<b>Chapter 15 DoS Defend Command.....</b>	<b>89</b>
ip dos-prevent .....	89
ip dos-prevent ping-rate .....	89
ip dos-prevent syn-rate .....	90
ip dos-prevent type .....	91
ip dos-prevent detect .....	92
clear ip dos-prevent detect statistics .....	92

show ip dos-prevent .....	93
<b>Chapter 16 IEEE 802.1X Commands .....</b>	<b>94</b>
dot1x system-auth-control .....	94
dot1x auth-method .....	95
dot1x guest-vlan(global) .....	95
dot1x accounting .....	96
dot1x quiet-period .....	97
dot1x timeout .....	97
dot1x max-reauth-req .....	98
dot1x .....	98
dot1x guest-vlan(interface) .....	99
dot1x port-control .....	100
dot1x port-method .....	100
show dot1x global .....	101
show dot1x interface .....	102
<b>Chapter 17 PPPoE Circuit-ID Insertion Commands .....</b>	<b>103</b>
pppoe circuit-id(global) .....	103
pppoe circuit-id(interface) .....	103
pppoe circuit-id type .....	104
show pppoe circuit-id global .....	105
show pppoe circuit-id interface .....	105
<b>Chapter 18 System Log Commands .....</b>	<b>107</b>
logging buffer .....	107
logging file flash .....	108
logging file flash frequency .....	108
logging file flash level .....	109
clear logging .....	110
logging host index .....	110
show logging local-config .....	111
show logging loghost .....	111
show logging buffer .....	112
show logging flash .....	112
<b>Chapter 19 SSH Commands .....</b>	<b>114</b>
ip ssh server .....	114
ip ssh version .....	114

ip ssh timeout .....	115
ip ssh max-client .....	115
ip ssh download .....	116
show ip ssh.....	117
<b>Chapter 20 SSL Commands .....</b>	<b>118</b>
ip http secure-server .....	118
ip http secure-server download certificate .....	118
ip http secure-server download key .....	119
show ip http secure-server.....	120
<b>Chapter 21 MAC Address Commands.....</b>	<b>121</b>
mac address-table static .....	121
mac address-table aging-time.....	122
mac address-table filtering .....	122
mac address-table max-mac-count.....	123
show mac address-table .....	124
show mac address-table aging-time .....	125
show mac address-table max-mac-count interface .....	125
show mac address-table interface .....	126
show mac address-table count .....	126
show mac address-table address .....	126
show mac address-table vlan .....	127
<b>Chapter 22 System Configuration Commands.....</b>	<b>128</b>
system-time manual .....	128
system-time ntp.....	128
system-time dst predefined.....	130
system-time dst date .....	131
system-time dst recurring.....	132
hostname.....	133
location .....	133
contact-info.....	134
ip management-vlan.....	134
ip address.....	135
ip address-alloc dhcp .....	135
ip address-alloc bootp .....	136
reset .....	136
reboot .....	137



copy running-config startup-config.....	137
copy startup-config tftp.....	138
copy tftp startup-config.....	138
firmware upgrade.....	139
ping.....	140
tracert.....	141
loopback interface.....	142
show system-time.....	142
show system-time dst.....	143
show system-time ntp.....	143
show system-info.....	143
show running-config.....	144
show cable-diagnostics interface.....	144
<b>Chapter 23 IPv6 Address Configuration Commands.....</b>	<b>146</b>
ipv6 enable.....	146
ipv6 address autoconfig.....	146
ipv6 address link-local.....	147
ipv6 address dhcp.....	148
ipv6 address ra.....	148
ipv6 address eui-64.....	149
ipv6 address.....	149
show ipv6 interface vlan.....	150
<b>Chapter 24 Ethernet Configuration Commands.....</b>	<b>151</b>
interface fastEthernet.....	151
interface range fastEthernet.....	151
interface gigabitEthernet.....	152
interface range gigabitEthernet.....	152
description.....	153
shutdown.....	154
flow-control.....	154
media-type.....	155
duplex.....	155
speed.....	156
storm-control broadcast.....	156
storm-control multicast.....	157
storm-control unicast.....	158

bandwidth .....	158
clear counters.....	159
show interface status .....	159
show interface counters .....	160
show interface description .....	161
show interface flowcontrol.....	161
show interface configuration .....	162
show storm-control.....	162
show bandwidth.....	163
<b>Chapter 25 QoS Commands.....</b>	<b>164</b>
qos.....	164
qos cos .....	164
qos dscp .....	165
qos queue cos-map.....	166
qos queue dscp-map.....	166
qos queue mode .....	167
show qos interface .....	168
show qos cos-map .....	169
show qos dscp-map .....	169
show qos queue mode.....	170
show qos status.....	170
<b>Chapter 26 Port Mirror Commands .....</b>	<b>171</b>
monitor session destination interface .....	171
monitor session source interface .....	172
show monitor session.....	173
<b>Chapter 27 Port isolation Commands .....</b>	<b>174</b>
port isolation .....	174
show port isolation .....	175
<b>Chapter 28 Loopback Detection Commands.....</b>	<b>176</b>
loopback-detection(global).....	176
loopback-detection interval .....	176
loopback-detection recovery-time .....	177
loopback-detection(interface).....	177
loopback-detection config .....	178
loopback-detection recover.....	179

show loopback-detection global.....	179
show loopback-detection interface .....	180
<b>Chapter 29 DDM Commands.....</b>	<b>181</b>
ddm state enable.....	181
ddm shutdown.....	181
ddm temperature_threshold.....	182
ddm voltage_threshold.....	183
ddm bias_current_threshold .....	184
ddm tx_power_threshold.....	185
ddm rx_power_threshold .....	186
show ddm configuration .....	187
show ddm status .....	188
<b>Chapter 30 ACL Commands.....</b>	<b>189</b>
time-range .....	189
absolute.....	189
periodic.....	190
holiday .....	191
holiday(global).....	191
access-list create .....	192
mac access-list.....	192
access-list standard .....	193
access-list extended.....	194
access-list combined.....	195
rule.....	197
access-list policy name .....	198
access-list policy action.....	199
redirect interface .....	199
redirect vlan.....	200
s-condition .....	200
s-mirror .....	201
qos-remark .....	201
access-list bind(interface) .....	202
access-list bind(vlan).....	203
show time-range.....	203
show holiday.....	203
show access-list .....	204

show access-list policy .....	204
show access-list bind .....	205
<b>Chapter 31 MSTP Commands .....</b>	<b>206</b>
spanning-tree(global) .....	206
spanning-tree(interface) .....	206
spanning-tree common-config .....	207
spanning-tree mode .....	208
spanning-tree mst configuration .....	209
instance .....	209
name .....	210
revision .....	210
spanning-tree mst instance .....	211
spanning-tree mst .....	212
spanning-tree priority .....	212
spanning-tree tc-defend .....	213
spanning-tree timer .....	214
spanning-tree hold-count .....	214
spanning-tree max-hops .....	215
spanning-tree bpdufilter .....	216
spanning-tree bpduguard .....	216
spanning-tree guard loop .....	217
spanning-tree guard root .....	217
spanning-tree guard tc .....	218
spanning-tree mcheck .....	218
show spanning-tree active .....	219
show spanning-tree bridge .....	219
show spanning-tree interface .....	220
show spanning-tree interface-security .....	220
show spanning-tree mst .....	221
<b>Chapter 32 Ethernet OAM Commands .....</b>	<b>223</b>
ethernet-oam .....	223
ethernet-oam mode .....	223
ethernet-oam link-monitor symbol-period .....	224
ethernet-oam link-monitor frame .....	225
ethernet-oam link-monitor frame-period .....	226
ethernet-oam link-monitor frame-seconds .....	227

ethernet-oam remote-failure .....	228
ethernet-oam remote-loopback received-remote- loopback.....	229
ethernet-oam remote-loopback.....	230
clear ethernet-oam statistics .....	230
clear ethernet-oam event-log .....	231
show ethernet-oam configuration .....	232
show ethernet-oam event-log .....	232
show ethernet-oam statistics .....	233
show ethernet-oam status.....	233
<b>Chapter 33 DLDP Commands .....</b>	<b>235</b>
dldp(global).....	235
dldp interval .....	235
dldp shut-mode.....	236
dldp reset(global) .....	236
dldp(interface) .....	237
dldp reset(interface) .....	237
show dldp .....	238
show dldp interface .....	238
<b>Chapter 34 IGMP Snooping Commands .....</b>	<b>240</b>
ip igmp snooping(global).....	240
ip igmp snooping(interface).....	240
ip igmp snooping immediate-leave .....	241
ip igmp snooping drop-unknown.....	241
ip igmp snooping vlan-config .....	242
ip igmp snooping multi-vlan-config .....	243
ip igmp snooping filter add-id.....	244
ip igmp snooping filter(global).....	245
ip igmp snooping filter(interface).....	245
ip igmp snooping filter maxgroup.....	246
ip igmp snooping filter mode .....	246
ip igmp snooping querier vlan.....	247
ip igmp snooping querier vlan (general query) .....	248
ip igmp snooping querier vlan (specific query).....	249
ip igmp snooping authentication .....	250
show ip igmp snooping.....	250
show ip igmp snooping interface.....	251

show ip igmp snooping vlan.....	251
show ip igmp snooping multi-vlan.....	252
show ip igmp snooping groups .....	252
show ip igmp snooping filter.....	253
show ip igmp snooping querier vlan .....	254
show ip igmp snooping querier .....	254
show ip igmp snooping interface authentication.....	254
<b>Chapter 35 MLD Snooping Commands.....</b>	<b>256</b>
ipv6 mld snooping .....	256
ipv6 mld snooping router-aging-time .....	256
ipv6 mld snooping member-aging-time.....	257
ipv6 mld snooping report-suppression.....	257
ipv6 mld snooping unknown-filter.....	258
ipv6 mld snooping last-listener query-inteval.....	258
ipv6 mld snooping last-listener query-count .....	259
ipv6 mld snooping multicast-vlan.....	259
ipv6 mld snooping multicast-vlan vlan-id .....	260
ipv6 mld snooping vlan.....	260
ipv6 mld snooping vlan router-aging-time.....	261
ipv6 mld snooping vlan member-aging-time .....	261
ipv6 mld snooping vlan immediate-leave.....	262
ipv6 mld snooping vlan mrouter .....	262
ipv6 mld snooping vlan static .....	263
ipv6 mld snooping querier vlan .....	263
ipv6 mld snooping querier vlan max-response-time.....	264
ipv6 mld snooping querier vlan query-interval .....	265
ipv6 mld snooping querier vlan query-source.....	265
ipv6 mld snooping filter(global) .....	266
ipv6 mld snooping filter(interface).....	266
ipv6 mld snooping filter-mode .....	267
ipv6 mld snooping filter-id .....	267
ipv6 mld snooping max-group.....	268
clear ipv6 mld snooping statistics .....	268
show ipv6 mld snooping.....	269
show ipv6 mld snooping vlan .....	269
show ipv6 mld snooping static-mcast .....	270
show ipv6 mld snooping group .....	270

show ipv6 mld snooping filter .....	271
show ipv6 mld snooping interface.....	271
show ipv6 mld snooping interface filter.....	271
show ipv6 mld snooping querier .....	272
show ipv6 mld snooping statistics.....	272
<b>Chapter 36 SNMP Commands.....</b>	<b>274</b>
snmp-server .....	274
snmp-server view .....	274
snmp-server group .....	275
snmp-server user .....	276
snmp-server community.....	278
snmp-server host .....	279
snmp-server engineID.....	280
snmp-server traps snmp .....	281
snmp-server traps security.....	282
snmp-server traps link-status.....	283
snmp-server traps .....	283
snmp-server traps ddm .....	284
snmp-server traps mac .....	285
snmp-server traps vlan.....	286
rmon history.....	287
rmon event .....	288
rmon alarm .....	289
show snmp-server.....	291
show snmp-server view.....	291
show snmp-server group .....	291
show snmp-server user.....	292
show snmp-server community .....	292
show snmp-server host.....	293
show snmp-server engineID .....	293
show rmon history .....	293
show rmon event.....	294
show rmon alarm.....	294
<b>Chapter 37 LLDP Commands.....</b>	<b>296</b>
lldp .....	296
lldp hold-multiplier .....	296

lldp timer .....	297
lldp receive .....	298
lldp transmit .....	298
lldp snmp-trap .....	299
lldp tlv-select .....	300
lldp med-fast-count .....	300
lldp med-status .....	301
lldp med-tlv-select .....	301
lldp med-location .....	302
show lldp .....	303
show lldp interface .....	303
show lldp local-information interface .....	304
show lldp neighbor-information interface .....	304
show lldp traffic interface .....	305
<b>Chapter 38 Cluster Commands .....</b>	<b>306</b>
cluster ndp .....	306
cluster ntdp .....	307
cluster explore .....	308
cluster .....	308
cluster ip pool .....	309
cluster commander .....	309
cluster manage .....	310
cluster member .....	310
cluster candidate .....	311
cluster individual .....	311
show cluster ndp .....	312
show cluster ntdp .....	312
show cluster .....	313
show cluster member .....	313
show cluster manage role .....	314
show cluster neighbor .....	314
<b>Chapter 39 AAA Commands .....</b>	<b>315</b>
aaa enable .....	315
tacacs-server host .....	316
show tacacs-server .....	317
radius-server host .....	317



show radius-server .....	318
aaa group .....	319
server .....	320
show aaa group.....	320
aaa authentication login .....	321
aaa authentication enable.....	322
aaa authentication dot1x default.....	323
aaa accounting dot1x default.....	323
show aaa authentication .....	324
show aaa accounting .....	324
line console .....	325
login authentication(console) .....	325
enable authentication(console).....	326
line telnet.....	327
login authentication(telnet).....	327
enable authentication(telnet).....	328
line ssh .....	328
login authentication(ssh) .....	329
enable authentication(ssh).....	329
ip http login authentication .....	330
ip http enable authentication .....	331
show aaa global .....	331
<b>Chapter 40 DHCP Relay Commands .....</b>	<b>332</b>
ip dhcp relay .....	332
ip dhcp relay helper-address.....	332
ip dhcp relay information option.....	333
ip dhcp relay information strategy .....	333
ip dhcp relay information circuit-id .....	334
ip dhcp relay information remote-id .....	334
show ip dhcp relay .....	335
show ip dhcp relay helper-address .....	335

## Preface

This Guide is intended for network administrator to provide referenced information about CLI (Command Line Interface). The device mentioned in this Guide stands for T2500-28TC 24-Port 10/100Mbps + 4-Port Gigabit JetStream L2 Managed Switch.

When using this guide, please notice that features of the switch may vary slightly depending on the model and software version you have, and on your location, language, and Internet service provider. All parameters and descriptions documented in this guide are used for demonstration only.

The information in this document is subject to change without notice. Every effort has been made in the preparation of this document to ensure accuracy of the contents, but all statements, information, and recommendations in this document do not constitute the warranty of any kind, express or implied. Users must take full responsibility for their application of any products.

## Overview of this Guide

### Chapter 1: Using the CLI

Provide information about how to use the CLI, CLI Command Modes, Security Levels and some Conventions.

### Chapter 2: User Interface

Provide information about the commands used to switch between five CLI Command Modes.

### Chapter 3: IEEE 802.1Q VLAN Commands

Provide information about the commands used for configuring IEEE 802.1Q VLAN.

### Chapter 4: MAC-based VLAN Commands

Provide information about the commands used for configuring MAC-Based VLAN.

### Chapter 5: Protocol-based VLAN Commands

Provide information about the commands used for configuring Protocol-based VLAN.

### Chapter 6: VLAN-VPN Commands

Provide information about the commands used for configuring VLAN-VPN (Virtual Private Network) function.

### Chapter 7: Voice VLAN Commands

Provide information about the commands used for configuring Voice VLAN.

### Chapter 8: Private VLAN Commands

Provide information about the commands used for configuring Private VLAN.

### Chapter 9: GVRP Commands

Provide information about the commands used for configuring GVRP (GARP VLAN registration protocol).

**Chapter 10: EtherChannel Commands**

Provide information about the commands used for configuring LAG (Link Aggregation Group) and LACP (Link Aggregation Control Protocol).

**Chapter 11: User Manage Commands**

Provide information about the commands used for user management.

**Chapter 12: Binding Table Commands**

Provide information about the commands used for binding the IP address, MAC address, VLAN and the connected Port number of the Host together. Besides it also provide information about the commands used for monitoring the process of the Host obtaining the IP address from DHCP server, and record the IP address, MAC address, VLAN and the connected Port number of the Host for automatic binding.

**Chapter 13: ARP Inspection Commands**

Provide information about the commands used for protecting the switch from the ARP cheating or ARP Attack.

**Chapter 14: IP Verify Source Commands**

Provide information about the commands used for guarding the IP Source by filtering the IP packets based on the IP-MAC Binding entries.

**Chapter 15: DoS Defend Command**

Provide information about the commands used for DoS defend and detecting the DoS attack.

**Chapter 16: IEEE 802.1X Commands**

Provide information about the commands used for configuring IEEE 802.1X function.

**Chapter 17: PPPoE Circuit-ID Insertion Commands**

Provide information about the commands used for configuring PPPoE Circuit-ID function.

**Chapter 18: System Log Commands**

Provide information about the commands used for configuring system log.

**Chapter 19: SSH Commands**

Provide information about the commands used for configuring and managing SSH (Security Shell).

**Chapter 20: SSL Commands**

Provide information about the commands used for configuring and managing SSL (Secure Sockets Layer).

**Chapter 21: MAC Address Commands**

Provide information about the commands used for MAC address configuration.

### **Chapter 22: System Configuration Commands**

Provide information about the commands used for configuring the System information and System IP, reboot and reset the switch, upgrade the switch system and commands used for device diagnose, including loopback test and cable test.

### **Chapter 23: IPv6 Address Configuration Commands**

Provide information about the commands used for configuring the System IPv6 addresses.

### **Chapter 24: Ethernet Configuration Commands**

Provide information about the commands used for configuring the Bandwidth Control, Negotiation Mode, and Storm Control for ethernet ports.

### **Chapter 25: QoS Commands**

Provide information about the commands used for configuring the QoS function.

### **Chapter 26: Port Mirror Commands**

Provide information about the commands used for configuring the Port Mirror function.

### **Chapter 27: Port isolation Commands**

Provide information about the commands used for configuring the Port isolation function.

### **Chapter 28: Loopback Detection Commands**

Provide information about the commands used for loopback detection.

### **Chapter 29: DDM Commands**

Provide information about the commands used for DDM (Digital Diagnostic Monitoring) function.

### **Chapter 30: ACL Commands**

Provide information about the commands used for configuring the ACL (Access Control List).

### **Chapter 31: MSTP Commands**

Provide information about the commands used for configuring the MSTP (Multiple Spanning Tree Protocol).

### **Chapter 32: Ethernet OAM Commands**

Provide information about the commands used for configuring the Ethernet OAM (Operation, Administration, and Maintenance) function.

### **Chapter 33: DLDP Commands**

Provide information about the commands used for configuring the DLDP (Device Link Detection Protocol).

### **Chapter 34: IGMP Snooping Commands**

Provide information about the commands used for configuring the IGMP Snooping (Internet Group Management Protocol Snooping).

**Chapter 35: MLD Snooping Commands**

Provide information about the commands used for configuring the MLD Snooping (Multicast Listener Discovery Snooping).

**Chapter 36: SNMP Commands**

Provide information about the commands used for configuring the SNMP (Simple Network Management Protocol) functions.

**Chapter 37: LLDP Commands**

Provide information about the commands used for configuring the LLDP functions.

**Chapter 38: Cluster Commands**

Provide information about the commands used for configuring the Cluster Management function.

**Chapter 39: AAA Commands**

Provide information about the commands used for configuring the AAA function.

**Chapter 40: DHCP Relay Commands**

Provide information about the commands used for configuring the DHCP Relay function.

# Chapter 1 Using the CLI

## 1.1 Accessing the CLI

You can log on to the switch and access the CLI by the following three methods:

1. Log on to the switch by the console port on the switch.
2. Log on to the switch remotely by a Telnet connection through an Ethernet port.
3. Log on to the switch remotely by an SSH connection through an Ethernet port.

### 1.1.1 Logon by a console port

Take the following steps to log on to the switch by the console port.

1. Connect the PCs or Terminals to the console port on the switch by the provided cable.
2. Start the terminal emulation program (such as the HyperTerminal) on the PC.
3. Configure the terminal emulation program or the terminal to use the following settings:
  - Baud rate: 38400 bps
  - Data bits: 8
  - Parity: none
  - Stop bits: 1
  - Flow control: none
4. The DOS prompt “T2500-28TC>” will appear after pressing the Enter button as shown in Figure 1-1. It indicates that you can use the CLI now.




Figure 1-1 Log in the Switch

### 1.1.2 Logon by Telnet

For Telnet connection, you should also configure the Telnet login mode and login authentication information through console connection.

Telnet login has the following two modes. You can choose one according to your needs:

**Login local Mode:** It requires username and password, which are both **admin** by default.

**Login Mode:** It doesn't require username and password, but a connection password is required.

Before Telnet login, you are required to configure Telnet login mode and login authentication information through console connection.

#### ➤ Login Local Mode

Firstly, configure the Telnet login mode as “**login local**” in the prompted DOS screen shown in Figure 1-2.




Figure 1-2 Configure login local mode

Now, you can logon by Telnet in **login local** mode.

1. Make sure the switch and the PC are in the same LAN. Click **Start** and type in **cmd** in the Search programs and files window and press the **Enter** button.




Figure 1-3 Run Window

2. Type **telnet 192.168.0.1** in the command prompt shown as Figure 1-4, and press the **Enter** button.




Figure 1-4 Connecting to the Switch

3. Type the default user name and password (both of them are **admin**), then press the **Enter** button so as to enter User EXEC Mode.





Figure 1-5 Enter into the User EXEC Mode



4. Type **enable** command to enter Privileged EXEC Mode.



```

Telnet 192.168.0.1

***** User Access Login *****

User:admin
Password:

T2500-28TC>#2006-01-01 12:45:03,[User]/3/Login the CLI by admin on vty0 <192.168.0.200>.

T2500-28TC>enable

T2500-28TC#


```

Figure 1-6 Enter into the Priviledged EXEC Mode

Now you can manage your switch with CLI commands through Telnet connection.

#### ➤ Login Mode

Firstly configure the Telnet login mode as “**login**” and the connection password as **456** in the prompted DOS screen shown in Figure 1-7.



```

TP-LINK - HyperTerminal
File Edit View Call Transfer Help

T2500-28TC>enable
T2500-28TC#config
T2500-28TC (config)#line vty 0 5
T2500-28TC (config-line)#login ← set login mode
T2500-28TC (config-line)#password 456 ← set connection password
T2500-28TC (config-line)#exit
T2500-28TC (config)#

```

Figure 1-7 Configure login mode

Now, you can logon by Telnet in **login mode**:

1. Make sure the switch and the PC are in the same LAN. Click **Start** and type in **cmd** in the Search programs and files window and press the **Enter** button.




Figure 1-8 Run Window

2. Type **telnet 192.168.0.1** in the command prompt shown as Figure 1-9, and press the **Enter** button.




Figure 1-9 Connecting to the Switch

3. You are prompted to enter the connection password **456** you have set through Console port connection, and then you are in User EXEC Mode.





Figure 1-10 Enter into the User EXEC Mode

4. Type **enable** command to enter Privileged EXEC Mode.



```

ca: Telnet 192.168.0.1
Password:
T2500-28TC>enable
T2500-28TC#

```

Figure 1-11 Enter into the Privileged EXEC Mode

Now you can manage your switch with CLI commands through Telnet connection.

**Note:**

You can refer to [Chapter 11 User Management Commands](#) for detailed commands information of the Telnet connection configuration.

### 1.1.3 Logon by SSH


To log on by SSH, a Putty client software is recommended. There are two authentication modes to set up an SSH connection:

**Password Authentication Mode:** It requires username and password, which are both **admin** by default.

**Key Authentication Mode:** It requires a public key for the switch and a private key for the SSH client software. You can generate the public key and the private key through Putty Key Generator.

**Note:**

Before SSH login, please follow the steps shown in Figure 1-12 to enable the SSH function through Telnet connection.



```

ca: Telnet 192.168.0.1
***** User Access Login *****
User:admin
Password:
T2500-28TC>#2006-01-01 13:01:32,[[User]3/Login the CLI by admin on vty0 <192.168.0.200>.
T2500-28TC>enable
T2500-28TC#config
T2500-28TC(config)#ip ssh server
T2500-28TC(config)#

```

Figure 1-12 Enable SSH function

➤ **Password Authentication Mode**

1. Open the software to log on to the interface of PuTTY. Enter the IP address of the switch into **Host Name** field; keep the default value 22 in the **Port** field; select **SSH** as the Connection type.




Figure 1-13 SSH Connection Config

2. Click the **Open** button in the above figure to log on to the switch. Enter the login user name and password to log on the switch, and then enter enable to enter Privileged EXEC Mode, so you can continue to configure the switch.




Figure 1-14 Log on the Switch

➤ **Key Authentication Mode**

1. Select the key type and key length, and generate SSH key.




Figure 1-15 Generate SSH Key

 **Note:**

1. The key length is in the range of 512 to 3072 bits.
2. During the key generation, randomly moving the mouse quickly can accelerate the key generation.

- After the key is successfully generated, please save the public key to a TFTP server and save the private key on the local host.




Figure 1-16 Save the Generated Key

- Log on to the switch by Telnet and download the public key file from the TFTP server to the switch, as the following figure shows:




Figure 1-17 Download the Public Key

**Note:**

1. The key type should accord with the type of the key file.
2. The SSH key downloading can not be interrupted.
4. After the public key is downloaded, please log on to the interface of PuTTY and enter the IP address for login.




Figure 1-18 SSH Connection Config

- Click **Browse** to download the private key file to SSH client software and click **Open**.




Figure 1-19 Download the Private Key

- After successful authentication, please enter the login user name. If you log on to the switch without entering password, it indicates that the key has been successfully downloaded.





Figure 1-20 Log on the Switch

## 1.2 CLI Command Modes

The CLI is divided into different command modes: User EXEC Mode, Privileged EXEC Mode, Global Configuration Mode, Interface Configuration Mode and VLAN Database (VLAN



Configuration Mode). Interface Configuration Mode can also be divided into Interface fastEthernet, Interface gigabitEthernet, Interface link-aggregation and some other modes, which is shown as the following diagram.



The following table gives detailed information about the Accessing path, Prompt of each mode and how to exit the current mode and access the next mode.

Mode	Accessing Path	Prompt	Logout or Access the next mode
User EXEC Mode	Primary mode once it is connected with the switch.	T2500-28TC>	Use the <b>exit</b> command to disconnect the switch (except that the switch is connected through the Console port).  Use the <b>enable</b> command to access Privileged EXEC mode.
Privileged EXEC Mode	Use the <b>enable</b> command to enter this mode from User EXEC mode.	T2500-28TC #	Enter the <b>disable</b> or the <b>exit</b> command to return to User EXEC mode.  Enter <b>configure</b> command to access Global Configuration mode.
Global Configuration Mode	Use the <b>configure</b> command to enter this mode from Privileged EXEC mode.	T2500-28TC(config)#	Use the <b>exit</b> or the <b>end</b> command or press <b>Ctrl+Z</b> to return to Privileged EXEC mode.  Use the <b>interface fastEthernet/gigabitEthernet port</b> or <b>interface range fastEthernet/gigabitEthernet port-list</b> command to access interface Configuration mode.  Use the <b>vlan vlan-list</b> to access VLAN Configuration mode.

Mode	Accessing Path	Prompt	Logout or Access the next mode
Interface Configuration Mode	Use the <b>interface fastEthernet/gigabitEthernet</b> <i>port</i> or <b>interface range fastEthernet/gigabitEthernet</b> <i>port-list</i> command to enter this mode from Global Configuration mode.	<b>T2500-28TC(config-if)#</b>  <b>T2500-28TC(config-if-range)#</b>	Use the <b>end</b> command or press <b>Ctrl+Z</b> to return to Privileged EXEC mode.  Enter <b>exit</b> or <b>#</b> command to return to Global Configuration mode.  A port number must be specified in the <b>interface</b> command.
VLAN Configuration Mode	Use the <b>vlan</b> <i>vlan-list</i> command to enter this mode from Global Configuration mode.	<b>T2500-28TC(config-vlan)#</b>	Use the <b>end</b> command or press <b>Ctrl+Z</b> to return to Privileged EXEC mode.  Enter the <b>exit</b> or <b>#</b> command to return to Global configuration mode.

**Note:**

- The user is automatically in User EXEC Mode after the connection between the PC and the switch is established by a console port or by a telnet connection.
- Each command mode has its own set of specific commands. To configure some commands, you should access the corresponding command mode firstly.
  - Global Configuration Mode:** In this mode, global commands are provided, such as the Spanning Tree, Schedule Mode and so on.
  - Interface Configuration Mode:** In this mode, users can configure one or several ports. Different ports correspond to different commands
    - Interface fastEthernet/gigabitEthernet: Configure parameters for a Fast/Gigabit Ethernet port, such as Duplex-mode, flow control status.
    - Interface range fastEthernet/gigabitEthernet: Configure parameters for several Ethernet ports.
    - Interface link-aggregation: Configure parameters for a link-aggregation, such as broadcast storm.
    - Interface range link-aggregation: Configure parameters for multi-trunks.
    - Interface vlan: Configure parameters for the vlan-port.
  - Vlan Configuration Mode:** In this mode, users can create a VLAN and add a specified port to the VLAN.
- Some commands are global, that means they can be performed in all modes:
  - show:** Displays all information of switch, for example: statistic information, port information, VLAN information.

## 1.3 Security Levels

This switch's security is divided into two levels: User level and Admin level.

User level only allows users to do some simple operations in User EXEC Mode; Admin level allows you to monitor, configure and manage the switch in Privileged EXEC Mode, Global Configuration Mode, Interface Configuration Mode and VLAN Configuration Mode.

Users get the privilege to the User level once logging in by Telnet/SSH. However, Guest users are restricted to access the CLI.

Users can enter Privileged EXEC mode from User EXEC mode by using the **enable** command. In default case, no password is needed. In Global Configuration Mode, you can configure password for Admin level by **enable password** command. Once password is configured, you are required to enter it to access Privileged EXEC mode.

## 1.4 Conventions

### 1.4.1 Format Conventions

The following conventions are used in this Guide:

- Items in square brackets [ ] are optional
- Items in braces { } are required
- Alternative items are grouped in braces and separated by vertical bars. For example: **speed** {10 | 100 | 1000 }
- Bold indicates an unalterable keyword. For example: **show logging**
- Normal Font indicates a constant (several options are enumerated and only one can be selected). For example: **switchport type** { access | trunk | general }
- Italic Font indicates a variable (an actual value must be assigned). For example: **bridge aging-time** *aging-time*

### 1.4.2 Special Characters

You should pay attentions to the description below if the variable is a character string:

- These six characters " < > , \ & can not be input.

- If a blank is contained in a character string, single or double quotation marks should be used, for example 'hello world', "hello world", and the words in the quotation marks will be identified as a string. Otherwise, the words will be identified as several strings.

### **1.4.3 Parameter Format**

Some parameters must be entered in special formats which are shown as follows:

- MAC address must be enter in the format of xx:xx:xx:xx:xx:xx
- One or several values can be typed for a port-list or a vlan-list using comma to separate. Use a hyphen to designate a range of values, for instance, 1,3-5,7 indicates choosing 1, 3, 4, 5, and 7.
- The port number must enter in the format of 1/0/3, meaning unit/slot/port. The unit number is always 1, and slot number is always 0 and the port number is a variable (an actual value must be assigned).

## Chapter 2 User Interface

### enable

#### Description

The **enable** command is used to access Privileged EXEC Mode from User EXEC Mode.

#### Syntax

**enable**

#### Command Mode

User EXEC Mode

#### Example

If you have set the password to access Privileged EXEC Mode from User EXEC Mode:

```
T2500-28TC>enable
Enter password:
T2500-28TC#
```

### enable password

#### Description

The **enable password** command is used to set the password for users to access Privileged EXEC Mode from User EXEC Mode. To return to the default configuration, please use **no enable password** command.

#### Syntax

**enable password** *password* [**secret** {simple | cipher} ]  
**no enable password**

#### Parameter

*password* — super password, which contains 31 characters at most, composing digits, English letters and underdashes only. By default, it is empty.

simple | cipher — The way of displaying password in configuration file. By default, it is “cipher”.

#### Command Mode

Global Configuration Mode

#### Example

Set the super password as “admin” to access Privileged EXEC Mode from User EXEC Mode:

```
T2500-28TC(config)#enable password admin
```

## disable

### Description

The **disable** command is used to return to User EXEC Mode from Privileged EXEC Mode.

### Syntax

```
disable
```

### Command Mode

Privileged EXEC Mode

### Example

Return to User EXEC Mode from Privileged EXEC Mode:

```
T2500-28TC#disable  
T2500-28TC>
```

## configure

### Description

The **configure** command is used to access Global Configuration Mode from Privileged EXEC Mode.

### Syntax

```
configure
```

### Command Mode

Privileged EXEC Mode

### Example

Access Global Configuration Mode from Privileged EXEC Mode:

```
T2500-28TC#configure  
T2500-28TC(config)#
```

## exit

### Description

The **exit** command is used to return to the previous Mode from the current Mode.

### Syntax

**exit**

### Command Mode

Any Configuration Mode

### Example

Return to Global Configuration Mode from Interface Configuration Mode, and then return to Privileged EXEC Mode:

```
T2500-28TC(config-if)#exit
T2500-28TC(config)#exit
T2500-28TC#
```

## end

### Description

The **end** command is used to return to Privileged EXEC Mode.

### Syntax

**end**

### Command Mode

Any Configuration Mode

### Example

Return to Privileged EXEC Mode from Interface Configuration Mode:

```
T2500-28TC(config-if)#end
T2500-28TC#
```

## history

### Description

The **history** command is used to show the latest 20 commands you entered in the current mode since the switch is powered.

### Syntax

```
history
```

### Command Mode

Privileged EXEC Mode and any Configuration Mode

### Example

Show the commands you have entered in the current mode:

```
T2500-28TC (config)# history
1 history
```

## history clear

### Description

The **history clear** command is used to clear the commands you have entered in the current mode, therefore these commands will not be shown next time you use the **history** command.

### Syntax

```
history clear
```

### Command Mode

Privileged EXEC Mode and any Configuration Mode

### Example

Clear the commands you have entered in the current mode:

```
T2500-28TC(config)#history clear
```



## Chapter 3 IEEE 802.1Q VLAN Commands

VLAN (Virtual Local Area Network) technology is developed for the switch to divide the LAN into multiple logical LANs flexibly. Hosts in the same VLAN can communicate with each other, regardless of their physical locations. VLAN can enhance performance by conserving bandwidth, and improve security by limiting traffic to specific domains.

### vlan

#### Description

The **vlan** command is used to create IEEE 802.1Q VLAN hereafter to access to VLAN Configuration Mode. To delete the IEEE 802.1Q VLAN, please use **no vlan** command.

#### Syntax

**vlan** *vlan-list*

**no vlan** *vlan-list*

#### Parameter

*vlan-list* — VLAN ID list, ranging from 2 to 4094, in the format of 2-3, 5. It is multi-optional.

#### Command Mode

Global Configuration Mode

#### Example

Create VLAN 2-10 and VLAN 100:

```
T2500-28TC(config)#vlan 2-10,100
```

Delete VLAN 2:

```
T2500-28TC(config)#no vlan 2
```

## interface vlan

### Description

The **interface vlan** command is used to create VLAN Interface hereafter to access to Interface VLAN Mode.

### Syntax

```
interface vlan vlan-id  
no interface vlan vlan-id
```

### Parameter

*vlan-id* — Specify IEEE 802.1Q VLAN ID, ranging from 1 to 4094.

### Command Mode

Global Configuration Mode

### Example

Create VLAN Interface 2:

```
T2500-28TC(config)#interface vlan 2
```

## name

### Description

The **name** command is used to assign a description string to a VLAN. To clear the description, please use **no name** command.

### Syntax

```
name descript  
no name
```

### Parameter

*descript* — String to describe the VLAN, which contains 16 characters at most.

### Command Mode

VLAN Configuration Mode (VLAN)

## Example

Specify the description string of the VLAN 2 as “VLAN002”:

```
T2500-28TC(config)#vlan 2
T2500-28TC(config-vlan)#name VLAN002
```

## switchport mode

### Description

The **switchport mode** command is used to configure the Link Types for the ports.

### Syntax

```
switchport mode { access | trunk | general }
```

### Parameter

access | trunk | general — Link Types. There are three Link Types for the ports.

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

Specify the Link Type of Fast Ethernet port 3 as “trunk”:

```
T2500-28TC(config)#interface fastEthernet 1/0/3
T2500-28TC(config-if)#switchport mode trunk
```

## switchport access vlan

### Description

The **switchport access vlan** command is used to add the desired Access port to IEEE 802.1Q VLAN, or to remove a port from the corresponding VLAN.

### Syntax

```
switchport access vlan vlan-id
no switchport access vlan
```

## Parameter

*vlan-id* — Specify IEEE 802.1Q VLAN ID, ranging from 2 to 4094.

## Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

Configure Fast Ethernet port 3 whose link type is “access” to VLAN 2:

```
T2500-28TC(config)#interface fastEthernet 1/0/3
T2500-28TC(config-if)#switchport access vlan 2
```

# switchport trunk allowed vlan

## Description

The **switchport trunk allowed vlan** command is used to add the desired Trunk port to IEEE 802.1Q VLAN. To remove a Trunk port from the corresponding VLAN, please use **no switchport trunk allowed vlan** command.

## Syntax

```
switchport trunk allowed vlan {vlan-list }
no switchport trunk allowed vlan {vlan-list }
```

## Parameter

*vlan-list* — VLAN ID list, ranging from 2 to 4094, in the format of 2-3, 5. It is multi-optional.

## Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

Configure the link type of port 2 as trunk and add it to VLAN 2:

```
T2500-28TC(config)#interface fastEthernet 1/0/2
T2500-28TC(config-if)#switchport mode trunk
T2500-28TC(config-if)#switchport trunk allowed vlan 2
```

## switchport general allowed vlan

### Description

The **switchport general allowed vlan** command is used to add the desired General port to IEEE 802.1Q VLAN, or to remove a port from the corresponding VLAN.

### Syntax

```
switchport general allowed vlan vlan-list { tagged | untagged }
```

```
no switchport general allowed vlan vlan-list
```

### Parameter

*vlan-list* — VLAN ID list, ranging from 2 to 4094, in the format of 2-3, 5. It is multi-optional.

tagged | untagged — egress-rule.

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

Configure Fast Ethernet port 4 whose link type is “general” to VLAN 2 and its egress-rule as “tagged”:

```
T2500-28TC(config)#interface fastEthernet 1/0/4
```

```
T2500-28TC(config-if)#switchport mode general
```

```
T2500-28TC(config-if)#switchport general allowed vlan 2 tagged
```

## switchport pvid

### Description

The **switchport pvid** command is used to configure the PVID for the switch ports.

### Syntax

```
switchport pvid vlan-id
```

### Parameter

*vlan-id* — Specify IEEE 802.1Q VLAN ID, ranging from 1 to 4094.

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

Specify the PVID of Fast Ethernet port 3 as 1:

```
T2500-28TC(config)#interface fastEthernet 1/0/3
T2500-28TC(config-if)#switchport pvid 1
```

## show vlan summary

### Description

The **show vlan summary** command is used to display the summarized information of IEEE 802.1Q VLAN.

### Syntax

```
show vlan summary
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the summarized information of IEEE 802.1Q VLAN:

```
T2500-28TC(config)#show vlan summary
```

## show vlan brief

### Description

The **show vlan brief** command is used to display the brief information of IEEE 802.1Q VLAN.

### Syntax

```
show vlan brief
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display the brief information of IEEE 802.1Q VLAN:

```
T2500-28TC(config)#show vlan brief
```

# show vlan

## Description

The **show vlan** command is used to display the detailed information of IEEE 802.1Q VLAN. By default, the detailed information of all the ports will be displayed.

## Syntax

```
show vlan [id vlan-list]
```

## Parameter

*vlan-list* — Specify IEEE 802.1Q VLAN ID, ranging from 1 to 4094.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display the detailed information of VLAN 2-10:

```
T2500-28TC(config)#show vlan id 2-10
```

## Chapter 4 MAC-based VLAN Commands

MAC VLAN (Virtual Local Area Network) is the way to classify the VLANs based on MAC address. A MAC address is relative to a single VLAN ID. The untagged packets and the priority-tagged packets coming from the MAC address will be tagged with this VLAN ID.

### mac-vlan mac-address

#### Description

The **mac-vlan mac-address** command is used to create a MAC-based VLAN entry. To delete a MAC-based VLAN entry, please use the **no mac-vlan mac-address** command.

#### Syntax

```
mac-vlan mac-address mac-addr vlan vlan-id [description descript]  
no mac-vlan mac-address mac-addr
```

#### Parameter

*mac-addr* — MAC address, in the format of XX:XX:XX:XX:XX:XX.

*vlan-id* — Specify IEEE 802.1Q VLAN ID, ranging from 1 to 4094.

*descript* — Give a description to the MAC address for identification, which contains 8 characters at most.

#### Command Mode

Global Configuration Mode

#### Example

Create VLAN 2, named “TP”, and the MAC address is 00:11:11:01:01:12:

```
T2500-28TC(config)#mac-vlan mac-address 00:11:11:01:01:12 vlan 2  
description TP
```



## mac-vlan

### Description

The **mac-vlan** command is used to enable a port for the MAC-based VLAN feature. Only the port is enabled can the configured MAC-based VLAN take effect. To disable the MAC-based VLAN function, please use **no mac-vlan** command. All the ports are disabled by default.

### Syntax

```
mac-vlan
no mac-vlan
```

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

Enable the Fast Ethernet port 3 for the MAC-based VLAN feature:

```
T2500-28TC(config)#interface fastEthernet 1/0/3
T2500-28TC(config-if)#mac-vlan
```

## show mac-vlan

### Description

The **show mac-vlan** command is used to display the information of the MAC-based VLAN entry. MAC address and VLAN ID can be used to filter the displayed information.

### Syntax

```
show mac-vlan { all | mac-address mac-addr | vlan vlan-id }
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Parameter

*mac-addr* — MAC address, in the format of XX:XX:XX:XX:XX:XX.  
*vlan-id* — Specify IEEE 802.1Q VLAN ID, ranging from 1 to 4094.

## Example

Display the information of all the MAC-based VLAN entry:

```
T2500-28TC(config)#show mac-vlan all
```

# show mac-vlan interface

## Description

The **show mac-vlan interface** command is used to display the port state of MAC-based VLAN.

## Syntax

```
show mac-vlan interface
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display the enable state of all the ports:

```
T2500-28TC(config)#show mac-vlan interface
```

## Chapter 5 Protocol-based VLAN Commands

Protocol VLAN (Virtual Local Area Network) is the way to classify VLANs based on Protocols. A Protocol is relative to a single VLAN ID. The untagged packets and the priority-tagged packets matching the protocol template will be tagged with this VLAN ID.

### protocol-vlan template

#### Description

The **protocol-vlan template** command is used to create Protocol-based VLAN template. To delete Protocol-based VLAN template, please use **no protocol-vlan template** command.

#### Syntax

```
protocol-vlan template name protocol-name ether-type type  
no protocol-vlan template template-idx
```

#### Parameter

*protocol-name* — Give a name for the Protocol-based VLAN Template , which contains 8 characters at most.

*type* — Enter the Ethernet protocol type field in the protocol template, composing of 4 Hex integers.

*template-idx* — The number of the Protocol-based VLAN Template. You can get the template corresponding to the number by the [show protocol-vlan template](#) command.

#### Command Mode

Global Configuration Mode

#### Example

Create a Protocol-based VLAN template named “TP” whose Ethernet protocol type is 0x2024:

```
T2500-28TC(config)#protocol-vlan template name TP ether-type 2024
```

## protocol-vlan vlan

### Description

The **protocol-vlan vlan** command is used to create a Protocol-based VLAN entry. To delete a Protocol-based VLAN entry, please use **no protocol-vlan vlan** command.

### Syntax

```
protocol-vlan vlan vlan-id template template-idx  
no protocol-vlan vlan group-idx
```

### Parameter

*vlan-id* — Specify IEEE 802.1Q VLAN ID, ranging from 1-4094.

*template-idx* —The number of the Protocol-based VLAN Template. You can get the template corresponding to the number by the [show protocol-vlan template](#) command.

*group-idx* —The number of the Protocol-based VLAN entry. You can get the Protocol-based VLAN entry corresponding to the number by the [show protocol-vlan vlan](#) command.

### Command Mode

Global Configuration Mode

### Example

Create Protocol-based VLAN 2 and bind it with Protocol-based VLAN Template 3:

```
T2500-28TC(config)#protocol-vlan vlan 2 template 3
```

## protocol-vlan

### Description

The **protocol-vlan** command is used to enable the Protocol-based VLAN feature for a specified port. To disable the Protocol-based VLAN feature of this port, please use **no protocol-vlan** command. By default, the Protocol-based VLAN feature of all ports is disabled.

## Syntax

```
protocol-vlan
no protocol-vlan
```

## Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

Enable the Protocol-based VLAN feature for the Gigabit Ethernet port 25:

```
T2500-28TC(config)#interface gigabitEthernet 1/0/25
T2500-28TC(config-if)#protocol-vlan
```

# show protocol-vlan template

## Description

The **show protocol-vlan template** command is used to display the information of the Protocol-based VLAN templates.

## Syntax

```
show protocol-vlan template
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display the information of the Protocol-based VLAN templates:

```
T2500-28TC(config)#show protocol-vlan template
```

# show protocol-vlan vlan

## Description

The **show protocol-vlan vlan** command is used to display the information about Protocol-based VLAN entry.

## Syntax

```
show protocol-vlan vlan
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display information of the Protocol-based VLAN entry:

```
T2500-28TC(config)#show protocol-vlan vlan
```

# show protocol-vlan interface

## Description

The **show protocol-vlan interface** command is used to display port state and of Protocol-based VLAN interface.

## Syntax

```
show protocol-vlan interface
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display the port state and of Protocol-based VLAN interface:

```
T2500-28TC(config)#show protocol-vlan interface
```

## Chapter 6 VLAN-VPN Commands

VLAN-VPN (Virtual Private Network) function, the implement of a simple and flexible Layer 2 VPN technology, allows the packets with VLAN tags of private networks to be encapsulated with VLAN tags of public networks at the network access terminal of the Internet Service Provider. And these packets will be transmitted with double-tag across the public networks.

### dot1q-tunnel

#### Description

The **dot1q-tunnel** command is used to enable the VLAN-VPN function globally. To disable the VLAN-VPN function, please use the **no dot1q-tunnel** command.

#### Syntax

```
dot1q-tunnel
no dot1q-tunnel
```

#### Command Mode

Global Configuration Mode

#### Example

Enable the VLAN-VPN function globally:

```
T2500-28TC(config)#dot1q-tunnel
```

### dot1q-tunnel tpid

#### Description

The **dot1q-tunnel tpid** command is used to configure Global TPID of the VLAN-VPN. To restore to the default value, please use the **no dot1q-tunnel tpid** command.

#### Syntax

```
dot1q-tunnel tpid num
no dot1q-tunnel tpid
```

### Parameter

*num* — The value of Global TPID. It must be 4 Hex integers. By default, it is 8100.

### Command Mode

Global Configuration Mode

### Example

Configure Global TPID of the VLAN-VPN as 0x9100:

```
T2500-28TC(config)#dot1q-tunnel tpid 9100
```

## dot1q-tunnel mapping

### Description

The **dot1q-tunnel mapping** command is used to add the VLAN Mapping entry. To delete the VLAN Mapping entry, please use the **no dot1q-tunnel mapping** command.

### Syntax

```
dot1q-tunnel mapping c-vlan sp-vlan [descript]  
no dot1q-tunnel mapping c-vlan
```

### Parameter

*c-vlan* — Customer VLAN ID, ranging from 1 to 4094.

*sp-vlan* — Service Provider VLAN ID, ranging from 1 to 4094.

*descript* — Give a description to the VLAN Mapping entry, which contains 15 characters at most.

### Command Mode

Global Configuration Mode

### Example

Add a VLAN Mapping entry named “TP” with the C-VLAN being 2 and the SP-VLAN being 10:

```
T2500-28TC(config)#dot1q-tunnel mapping 2 10 TP
```



## switchport dot1q-tunnel mapping

### Description

The **switchport dot1q-tunnel mapping** command is used to enable the VLAN Mapping feature for a specified port. To disable the VLAN Mapping feature of this port, please use the **no switchport dot1q-tunnel mapping** command. By default, the VLAN Mapping feature of all ports is disabled.

### Syntax

```
switchport dot1q-tunnel mapping  
no switchport dot1q-tunnel mapping
```

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

Enable the VLAN Mapping feature for the Fast Ethernet port 3:

```
T2500-28TC(config)#interface fastEthernet 1/0/3  
T2500-28TC(config-if)#switchport dot1q-tunnel mapping
```

## switchport dot1q-tunnel mode uplink

### Description

The **switchport dot1q-tunnel mode uplink** command is used to configure a specified port as the VPN Up-link port. To cancel this VPN Up-link port, please use the **no switchport dot1q-tunnel mode uplink** command. By default, no port has been configured as the VPN Up-link port.

### Syntax

```
switchport dot1q-tunnel mode uplink  
no switchport dot1q-tunnel mode uplink
```

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

Configure the Fast Ethernet port 3 as the VPN Up-link ports:

```
T2500-28TC(config)#interface fastEthernet 1/0/3
T2500-28TC(config-if)#switchport dot1q-tunnel mode uplink
```

## show dot1q-tunnel

### Description

The **show dot1q-tunnel** command is used to display the global configuration information of the VLAN VPN.

### Syntax

```
show dot1q-tunnel
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the global configuration information of the VLAN VPN:

```
T2500-28TC(config)#show dot1q-tunnel
```

## show dot1q-tunnel mapping

### Description

The **show dot1q-tunnel mapping** command is used to display the information of VLAN Mapping entry.

### Syntax

```
show dot1q-tunnel mapping
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the information of VLAN Mapping entry:

```
T2500-28TC(config)#show dot1q-tunnel mapping
```

## show dot1q-tunnel mapping interface

### Description

The **show dot1q-tunnel mapping interface** command is used to display the VLAN Mapping port enable state of VLAN Mapping

### Syntax

```
show dot1q-tunnel mapping interface
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the enable state of all VLAN Mapping ports:

```
T2500-28TC(config)#show dot1q-tunnel mapping interface
```

## show dot1q-tunnel uplink

### Description

The **show dot1q-tunnel uplink** command is used to display the configuration information of the VLAN VPN Up-link ports.

### Syntax

```
show dot1q-tunnel uplink
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the configuration information of the VLAN VPN Up-link ports:

```
T2500-28TC(config)# show dot1q-tunnel uplink
```

## Chapter 7 Voice VLAN Commands

Voice VLANs are configured specially for voice data stream. By configuring Voice VLANs and adding the ports with voice devices attached to voice VLANs, you can perform QoS-related configuration for voice data, ensuring the transmission priority of voice data stream and voice quality.

### voice vlan

#### Description

The **voice vlan** command is used to enable Voice VLAN function. To disable Voice VLAN function, please use **no voice vlan** command.

#### Syntax

**voice vlan** *vlan-id*

**no voice vlan**

#### Parameter

*vlan-id* — Specify IEEE 802.1Q VLAN ID, ranging from 2 to 4094.

#### Command Mode

Global Configuration Mode

#### Example

Enable the Voice VLAN function for VLAN 10:

```
T2500-28TC(config)#voice vlan 10
```

### voice vlan aging time

#### Description

The **voice vlan aging time** command is used to set the aging time for a voice VLAN. To restore to the default aging time for the Voice VLAN, please use **no voice vlan aging time** command. By default, the aging time is 1440 minutes.

#### Syntax

**voice vlan aging time** *time*

**no voice vlan aging time**

### Parameter

*time* — Aging time (in minutes) to be set for the Voice VLAN. It ranges from 1 to 43200.

### Command Mode

Global Configuration Mode

### Example

Set the aging time for the Voice VLAN as 1 minute:

```
T2500-28TC(config)#voice vlan aging time 1
```

## voice vlan priority

### Description

The **voice vlan priority** command is used to configure the priority for the Voice VLAN. To restore to the default priority, please use **no voice vlan priority** command. By default, the priority value is 6.

### Syntax

**voice vlan priority** *pri*

**no voice vlan priority**

### Parameter

*pri* — Priority, ranging from 0 to 7.

### Command Mode

Global Configuration Mode

### Example

Configure the priority of the Voice VLAN as 5:

```
T2500-28TC(config)#voice vlan priority 5
```

## voice vlan mac-address

### Description

The **voice vlan mac-address** command is used to create Voice VLAN OUI. To delete the specified Voice VLAN OUI, please use **no voice vlan mac-address** command.

### Syntax

**voice vlan mac-address** *mac-addr* **mask** *mask* [**description** *descriptf*]

**no voice vlan mac-address** *mac-addr*

### Parameter

*mac-addr* — The OUI address of the voice device, in the format of XX:XX:XX:XX:XX:XX.

*mask* — The OUI address mask of the voice device, in the format of XX:XX:XX:XX:XX:XX.

*descript* — Give a description to the OUI for identification which contains 16 characters at most.

### Command Mode

Global Configuration Mode

### Example

Create a Voice VLAN OUI described as “TP-Phone” with the OUI address 00:11:11:11:11:11 and the mask address FF:FF:FF:00:00:00:

```
T2500-28TC(config)#voice vlan mac-address 00:11:11:11:11:11 mask  
FF:FF:FF:00:00:00 description TP- Phone
```

## switchport voice vlan mode

### Description

The **switchport voice vlan mode** command is used to configure the Voice VLAN mode for the Ethernet port.

### Syntax

**switchport voice vlan mode** { manual | auto }

## Parameter

manual | auto — Port mode.

## Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

Configure the Fast Ethernet port 3 to operate in the auto voice VLAN mode:

```
T2500-28TC(config)#interface fastEthernet 1/0/3
T2500-28TC(config-if)#switchport voice vlan mode auto
```

# switchport voice vlan security

## Description

The **switchport voice vlan security** command is used to enable the Voice VLAN security feature. To disable the Voice VLAN security feature, please use **no switchport voice vlan security** command.

## Syntax

```
switchport voice vlan security
no switchport voice vlan security
```

## Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

Enable the Fast Ethernet port 3 for Voice VLAN security feature:

```
T2500-28TC(config)#interface fastEthernet 1/0/3
T2500-28TC(config-if)#switchport voice vlan security
```

## show voice vlan

### Description

The **show voice vlan** command is used to display the global configuration information of Voice VLAN.

### Syntax

```
show voice vlan
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the configuration information of Voice VLAN globally:

```
T2500-28TC(config)#show voice vlan
```

## show voice vlan oui

### Description

The **show voice vlan oui** command is used to display the configuration information of Voice VLAN OUI.

### Syntax

```
show voice vlan oui
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the configuration information of Voice VLAN OUI:

```
T2500-28TC(config)#show voice vlan oui
```



## show voice vlan switchport

### Description

The **show voice vlan switchport** command is used to display the configuration information of all the ports or one specified port in the Voice VLAN.

### Syntax

```
show voice vlan switchport [fastEthernet port | gigabitEthernet port]
```

### Parameter

*port* —The Fast/Gigabit Ethernet port number selected to display the configuration information.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the configuration information of Fast Ethernet port 1 in the Voice VLAN:

```
T2500-28TC(config)#show voice vlan switchport fastEthernet 1/0/1
```

Display the configuration information of all the ports in the Voice VLAN:

```
T2500-28TC(config)#show voice vlan switchport
```

## Chapter 8 Private VLAN Commands

Private VLANs are configured specially for saving VLAN resource of uplink devices and decreasing broadcast.

### private-vlan primary

#### Description

The **private-vlan primary** command is used to configure the designated VLAN as the primary VLAN of the Private VLAN. To abolish the currently primary VLAN, please use **no private-vlan primary** command.

#### Syntax

```
private-vlan primary
no private-vlan primary
```

#### Command Mode

VLAN Configuration Mode (VLAN)

#### Example

Configure the VLAN 3 as the primary VLAN of the private VLAN:

```
T2500-28TC(config)#vlan 3
T2500-28TC(config-vlan)#private-vlan primary
```

### private-vlan community

#### Description

The **private-vlan community** command is used to configure the designated VLAN as the community VLAN of the Private VLAN. To invalid the currently community VLAN, please use **no private-vlan community** command.

#### Syntax

```
private-vlan community
no private-vlan community
```

## Command Mode

VLAN Configuration Mode (VLAN)

## Example

Configure the VLAN 4 as the community VLAN of the private VLAN:

```
T2500-28TC(config)#vlan 4
T2500-28TC(config-vlan)#private-vlan community
```

# private-vlan association

## Description

The **private-vlan association** command is used to associate primary VLAN with secondary VLAN. To exterminate the currently association, please use **no private-vlan association** command.

## Syntax

```
private-vlan association vlan_list
no private-vlan association vlan_list
```

## Parameter

*vlan\_list* — Secondary VLAN ID, ranging from 2 to 4049.

## Command Mode

VLAN Configuration Mode (VLAN)

## Example

Associate primary VLAN 3 with community VLAN 4 as a private VLAN:

```
T2500-28TC(config)#vlan 3
T2500-28TC(config-vlan)#private-vlan association 4
```

# switchport private-vlan

## Description

The **switchport private-vlan** command is used to configure the private VLAN mode for the switchport. To invalid the configuration, please use **no switchport private-vlan** command.

## Syntax

```
switchport private-vlan { promiscuous | host }
no switchport private-vlan { promiscuous | host }
```

## Parameter

promiscuous | host — Configure the private VLAN mode for the switchport.

## Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

Configure Fast Ethernet port 3 as “host”:

```
T2500-28TC(config)#interface fastEthernet 1/0/3
T2500-28TC(config-if)#switchport private-vlan host
```

# switchport private-vlan host-association

## Description

The **switchport private-vlan host-association** command is used to add host type port to private VLAN. To remove the port from Private VLAN, please use **no switchport private-vlan host-association** command.

## Syntax

```
switchport private-vlan host-association primary_vlan_id secondary_vlan_id
no switchport private-vlan host-association primary_vlan_id
secondary_vlan_id
```

## Parameter

*primary-vlan-id* — Primary VLAN ID, ranging from 2 to 4094.

*secondary-vlan-id* — Secondary VLAN ID, ranging from 2 to 4094.

## Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

Configure host type Fast Ethernet port 3 as a member of primary VLAN 3 and secondary VLAN 4:

```
T2500-28TC(config)#interface fastEthernet 1/0/3
T2500-28TC(config-if)#switchport private-vlan host-association 3 4
```

## switchport private-vlan mapping

### Description

The **switchport private-vlan mapping** command is used to add promiscuous type port to private VLAN. To remove the port from Private VLAN, please use **no switchport private-vlan mapping** command.

### Syntax

```
switchport private-vlan mapping primary_vlan_id secondary_vlan_id
no switchport private-vlan mapping primary_vlan_id secondary_vlan_id
```

### Parameter

*primary-vlan-id* — Primary VLAN ID, ranging from 2 to 4094.

*secondary-vlan-id* — Secondary VLAN ID, ranging from 2 to 4094.

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

Configure promiscuous type Fast Ethernet port 3 as a member of primary VLAN 3 and secondary VLAN 4:

```
T2500-28TC(config)#interface fastEthernet 1/0/3
T2500-28TC(config-if)#switchport private-vlan mapping 3 4
```

## show vlan private-vlan

### Description

The **show vlan private-vlan** command is used to display the Private VLAN configuration information of the switch.

### Syntax

```
show vlan private-vlan
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the configuration information of all Private VLAN:

```
T2500-28TC(config)#show vlan private-vlan
```

## Chapter 9 GVRP Commands

GVRP (GARP VLAN registration protocol) is an implementation of GARP (generic attribute registration protocol). GVRP allows the switch to automatically add or remove the VLANs via the dynamic VLAN registration information and propagate the local VLAN registration information to other switches, without having to individually configure each VLAN.

### gvrp

#### Description

The **gvrp** command is used to enable the GVRP function globally. To disable the GVRP function, please use **no gvrp** command.

#### Syntax

```
gvrp
no gvrp
```

#### Command Mode

Global Configuration Mode

#### Example

Enable the GVRP function globally:

```
T2500-28TC(config)#gvrp
```

### gvrp (interface)

#### Description

The **gvrp** command is used to enable the GVRP function for the desired port. To disable it, please use **no gvrp** command. The GVRP feature can only be enabled for the trunk-type ports.

#### Syntax

```
gvrp
no gvrp
```

## Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

Enable the GVRP function for Fast Ethernet ports 2-6:

```
T2500-28TC(config)#interface range fastEthernet 1/0/2-6
T2500-28TC(config-if-range)#gvrp
```

# gvrp registration

## Description

The **gvrp registration** command is used to configure the GVRP registration type for the desired port. To restore to the default value, please use **no gvrp registration** command.

## Syntax

```
gvrp registration { normal | fixed | forbidden }
no gvrp registration
```

## Parameter

normal | fixed | forbidden — Registration mode. By default, the registration mode is “normal”.

## Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

Configure the GVRP registration mode as “fixed” for Fast Ethernet ports 2-6:

```
T2500-28TC(config)#interface range fastEthernet 1/0/2-6
T2500-28TC(config-if-range)#gvrp registration fixed
```



## gvrp timer

### Description

The **gvrp timer** command is used to set a GVRP timer for the desired port. To restore to the default setting of a GARP timer, please use **no gvrp timer** command.

### Syntax

```
gvrp timer { leaveall | join | leave } value
```

```
no gvrp timer [leaveall | join | leave]
```

### Parameter

leaveall | join | leave — They are the three timers: leave All、join and leave. Once the LeaveAll Timer is set, the port with GVRP enabled can send a LeaveAll message after the timer times out, so that other GARP ports can re-register all the attribute information. After that, the LeaveAll timer will start to begin a new cycle. To guarantee the transmission of the Join messages, a GARP port sends each Join message two times. The Join Timer is used to define the interval between the two sending operations of each Join message. Once the Leave Timer is set, the GARP port receiving a Leave message will start its Leave timer, and deregister the attribute information if it does not receive a Join message again before the timer times out.

*value* —The value of the timer. The LeaveAll Timer ranges from 1000 to 30000 centiseconds and the default value is 1000. The Join Timer ranges from 20 to 1000 centiseconds and the default value is 20. The Leave Timer ranges from 60 to 3000 centiseconds and the default value is 60.

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

Set the GARP leaveall timer of Fast Ethernet port 6 as 2000 centiseconds and restore the join timer of it to the default value:

```
T2500-28TC(config)#interface fastEthernet 1/0/6
```

```
T2500-28TC(config-if)#gvrp timer leaveall 2000
```

```
T2500-28TC(config-if)#no gvrp timer join
```

## show gvrp global

### Description

The **show gvrp global** command is used to display the global GVRP status.

### Syntax

```
show gvrp global
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the global GVRP status:

```
T2500-28TC(config)#show gvrp global
```

## show gvrp interface

### Description

The **show gvrp interface** command is used to display the GVRP configuration information of a specified Ethernet port or of all Ethernet ports.

### Syntax

```
show gvrp interface [fastEthernet port | gigabitEthernet port]
```

### Parameter

*port* —The Fast/Gigabit Ethernet port number. By default, the GVRP configuration information of all the Ethernet ports is displayed.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the GVRP configuration information of Fast Ethernet port 1:

```
T2500-28TC(config)#show gvrp interface fastEthernet 1/0/1
```

Display the GVRP configuration information of all Ethernet ports:

```
T2500-28TC(config)#show gvrp interface
```

## Chapter 10 Etherchannel Commands

Etherchannel Commands are used to configure LAG and LACP function.

LAG (Link Aggregation Group) is to combine a number of ports together to make a single high-bandwidth data path, which can highly extend the bandwidth. The bandwidth of the LAG is the sum of bandwidth of its member port.

LACP (Link Aggregation Control Protocol) is defined in IEEE802.3ad and enables the dynamic link aggregation and disaggregation by exchanging LACP packets with its partner. The switch can dynamically group similarly configured ports into a single logical link, which will highly extend the bandwidth and flexibly balance the load.

### channel-group

#### Description

The **channel-group** command is used to add a port to the EtherChannel Group and configure its mode. To delete the port from the EtherChannel Group, please use **no channel-group** command.

#### Syntax

```
channel-group num mode { on | active | passive }
```

```
no channel-group
```

#### Parameter

*num* —— The number of the EtherChannel Group, ranging from 1 to 14.

on —— Enable the static LAG.

active —— Enable the active LACP mode.

passive —— Enable the passive LACP mode.

#### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

#### Example

Add the Fast Ethernet port 2-4 to EtherChannel Group 1 and enable the static LAG:

```
T2500-28TC(config)#interface range fastEthernet 1/0/2-4
```

```
T2500-28TC(config-if-range)#channel-group 1 mode on
```

## port-channel load-balance

### Description

The **port-channel load-balance** command is used to configure the Aggregate Arithmetic for LAG. To return to the default configurations, please use **no port-channel load-balance** command.

### Syntax

```
port-channel load-balance {src-dst-mac | src-dst-ip}  
no port-channel load-balance
```

### Parameter

**src-dst-mac** — The source and destination MAC address. When this option is selected, the Aggregate Arithmetic will be based on the source and destination MAC addresses of the packets. The Aggregate Arithmetic for LAG is “src-dst-mac” by default.

**src-dst-ip** — The source and destination IP address. When this option is selected, the Aggregate Arithmetic will be based on the source and destination IP addresses of the packets.

### Command Mode

Global Configuration Mode

### Example

Configure the Aggregate Arithmetic for LAG as “src-dst-mac”:

```
T2500-28TC(config)#port-channel load-balance src-dst-mac
```

## lACP system-priority

### Description

The **lACP system-priority** command is used to configure the LACP system priority globally. To return to the default configurations, please use **no lACP system-priority** command.

### Syntax

```
lACP system-priority pri  
no lACP system-priority
```

### Parameter

*pri* — The system priority, ranging from 0 to 65535. It is 32768 by default.

## Command Mode

Global Configuration Mode

## Example

Configure the LACP system priority as 1024 globally:

```
T2500-28TC(config)#lacp system-priority 1024
```

# lacp port-priority

## Description

The **lacp port-priority** command is used to configure the LACP system priority globally. To return to the default configurations, please use **no lacp port-priority** command.

## Syntax

```
lacp port-priority pri
```

```
no lacp port-priority
```

## Parameter

*pri* — The port priority, ranging from 0 to 65535. It is 32768 by default.

## Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

Configure the LACP port priority as 1024 for Fast Ethernet port 1:

```
T2500-28TC(config)#interface fastEthernet 1/0/1
```

```
T2500-28TC(config-if)#lacp port-priority 1024
```

# show etherchannel

## Description

The **show etherchannel** command is used to display the EtherChannel information.

## Syntax

```
show etherchannel [channel-group-num] { detail | summary }
```

### Parameter

*channel-group-num* — The EtherChannel Group number, ranging from 1 to 14. By default, it is empty, and will display the information of all EtherChannel Groups.

*detail* — The detailed information of EtherChannel.

*summary* — The EtherChannel information in summary.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the detailed information of EtherChannel Group 1:

```
T2500-28TC(config)#show etherchannel 1 detail
```

## show etherchannel load-balance

### Description

The **show etherchannel load-balance** command is used to display the Aggregate Arithmetic of LAG.

### Syntax

```
show etherchannel load-balance
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the Aggregate Arithmetic of LAG:

```
T2500-28TC(config)#show etherchannel load-balance
```

## show lacp

### Description

The **show lacp** command is used to display the LACP information for a specified EtherChannel Group.

### Syntax

```
show lacp [ channel-group-num ] { internal | neighbor }
```

### Parameter

*channel-group-num* — The EtherChannel Group number, ranging from 1 to 14. By default, it is empty, and will display the information of all LACP groups.

*internal* — The internal LACP information.

*neighbor* — The neighbor LACP information.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the internal LACP information of EtherChannel Group 1:

```
T2500-28TC(config)#show lacp 1 internal
```

## show lacp sys-id

### Description

The **show lacp sys-id** command is used to display the LACP system priority globally.

### Syntax

```
show lacp sys-id
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the LACP system priority:

```
T2500-28TC(config)#show lacp sys-id
```

## Chapter 11 User Manage Commands

User Manage Commands are used to manage the user's logging information by Web, CLI or SSH, so as to protect the settings of the switch from being randomly changed.

### user name

#### Description

The **user name** command is used to add a new user or modify the existed users' information. To delete the existed users, please use **no user name** command.

#### Syntax

**user name** *user-name* **password** *password* [**type** {guest | admin}] [**status** disable | enable] [**secret** {simple | cipher}]

**no user name** *user-name*

#### Parameter

*user-name* —— Type a name for users' login, which contains 16 characters at most, composing digits, English letters and under dashes only.

*password* —— Type a password for users' login, which contains 31 characters at most, composing digits, English letters and under dashes only.

guest | admin —— Access level. "Guest" means that you can only view the settings without the right to edit and modify. "Admin" means that you can edit, modify and view all the settings of different functions. It is "admin" by default.

disable | enable —— Enable/disable the user. The new added user is "enable" by default.

simple | cipher —— The way of displaying password in configuration file. By default, it is "cipher".

#### Command Mode

Global Configuration Mode

#### Example

Add and enable a new admin user named "tplink", of which the password is "password":



```
T2500-28TC(config)#user name tplink password password type admin
status enable
```

## user access-control ip-based

### Description

The **user access-control ip-based** command is used to limit the IP-range of the users for login. Only the users within the IP-range you set here are allowed to login. To cancel the user access limit, please use **no user access-control** command.

### Syntax

```
user access-control ip-based ip-addr ip-mask
no user access-control
```

### Parameter

*ip-addr* — The source IP address. Only the users within the IP-range you set here are allowed to login.

*ip-mask* — The subnet mask of the IP address.

### Command Mode

Global Configuration Mode

### Example

Configure that only the user with the IP address 192.168.0.148 is allowed to login:

```
T2500-28TC(config)#user access-control ip-based 192.168.0.148 255.255.255.255
```

## user access-control mac-based

### Description

The **user access-control mac-based** command is used to limit the MAC address of the users for login. Only the user with this MAC address you set here is allowed to login. To cancel the user access limit, please use **no user access-control** command.

## Syntax

```

user access-control mac-based mac-addr
no user access-control

```

## Parameter

*mac-addr* — The source MAC address. Only the user with this MAC address is allowed to login.

## Command Mode

Global Configuration Mode

## Example

Configure that only the user with the MAC address 00:00:13:0A:00:01 is allowed to login:

```
T2500-28TC(config)#user access-control mac-based 00:00:13:0A:00:01
```

# user access-control port-based

## Description

The **user access-control port-based** command is used to limit the ports for login. Only the users connected to these ports you set here are allowed for login. To cancel the user access limit, please use **no user access-control** command.

## Syntax

```

user access-control port-based interface { fastEthernet port | gigabitEthernet
port | range fastEthernet port-list | range gigabitEthernet port-list }
no user access-control

```

## Parameter

*port* — The Fast/Gigabit Ethernet port number.

*port-list* — The list group of Ethernet ports. You can appoint 5 ports at most.

## Command Mode

Global Configuration Mode

## Example

Configure that only the users connected to Fast Ethernet ports 2-6 are allowed to login:

```
T2500-28TC(config)#user access-control port-based interface range
fastEthernet 1/0/2-6
```

## user max-number

### Description

The **user max-number** command is used to configure the maximum login user number at the same time. To cancel the limit on login number, please use **no user max-number** command.

### Syntax

```
user max-number admin-num guest-num
no user max-number
```

### Parameter

*admin-num* — The maximum number of the users allowed to log on as Admin, ranging from 1 to 16. The total number of Admin and Guest should be less than 16.

*guest-num* — The maximum number of the users allowed to log on as Guest, ranging from 0 to 15. The total number of Admin and Guest should be less than 16.

### Command Mode

Global Configuration Mode

### Example

Configure the maximum number of users' login as Admin and Guest as 5 and 3:

```
T2500-28TC(config)#user max-num 5 3
```

## user idle-timeout

### Description

The **user idle-timeout** command is used to configure the timeout time of the switch. To restore to the default timeout time, please use **no user idle-timeout** command.

### Syntax

```
user idle-timeout minutes
no user idle-timeout
```

## Parameter

*minutes* — The timeout time, ranging from 5 to 30 in minutes. The value is 10 by default.

## Command Mode

Global Configuration Mode

## Example

Configure the timeout time of the switch as 15 minutes:

```
T2500-28TC(config)#user idle-timeout 15
```

# line

## Description

The **line** command is used to enter the Line Configuration Mode and make related configurations for the desired user(s), including the login mode and password configurations.

## Syntax

```
line [console linenum | vty startlinenum endlinenum ]
```

## Parameter

*linenum* — The number of users allowed to login through console port. Its value is 0 in general as there is only one console port on a switch.

*startlinenum* — The start serial number of the login user selected to configure the login mode and password, ranging from 0 to 15. 0 means the first login user number, 1 means the second, and the rest can be done on the same manner.

*endlinenum* — The end serial number of the login user selected to configure the login mode and password, ranging from 0 to 15. 0 means the first login user number, 1 means the second, and the rest can be done on the same manner.

## Command Mode

Global Configuration Mode

## Example

Enter the Console port configuration mode and configure the console port 0:

```
T2500-28TC(config)#line console 0
```

Enter the Virtual Terminal configuration mode so as to prepare further configurations such as password and login mode for virtual terminal 0 to 5:

```
T2500-28TC(config)#line vty 0 5
```

## password

### Description

The **password** command is used to configure the connection password. To clear the password, please use **no password** command.

### Syntax

```
password password [secret {simple | cipher} ]
```

```
no password
```

### Parameter

*password* — Configure the connection password, which contains 16 characters at most, composing digits, English letters and under dashes only.

simple | cipher — The way of displaying password in configuration file. By default, it is “cipher”.

### Command Mode

Line Configuration Mode

### Example

Configure the connection password of Console port connection 0 as “tplink”:

```
T2500-28TC(config)#line console 0
```

```
T2500-28TC(config-line)#password tplink
```

Configure the connection password of virtual terminal connection 0-5 as “tplink”:

```
T2500-28TC(config)#line vty 0 5
```

```
T2500-28TC(config-line)#password tplink
```

## login

### Description

The **login** command is used to configure the login of a switch not to use the user name and password. At this situation, a connection password must be set for virtual terminal connection.

### Syntax

```
login
```

### Command Mode

Line Configuration Mode

### Example

Configure the login of Console port connection 0 as login mode:

```
T2500-28TC(config)#line console 0
```

```
T2500-28TC(config-line)#login
```

Configure the login of virtual terminal connection 0-5 as login mode:

```
T2500-28TC(config)#line vty 0 5
```

```
T2500-28TC(config-line)#login
```

## login local

### Description

The **login local** command is used to configure the login of a switch with the user name and password.

### Syntax

```
login local
```

### Command Mode

Line Configuration Mode

### Example

Configure the login of virtual terminal connection 0-5 as login local mode:

```
T2500-28TC(config)#line vty 0 5
```

```
T2500-28TC(config-line)#login local
```

Configure the login of Console port connection 0 as login local mode:

```
T2500-28TC(config)#line console 0
```

```
T2500-28TC(config-line)#login local
```

## show user account-list

### Description

The **show user account-list** command is used to display the information of the current users.

### Syntax

```
show user account-list
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the information of the current users:

```
T2500-28TC(config)#show user account-list
```

## show user configuration

### Description

The **user configuration** command is used to display the security configuration information of the users, including access-control, max-number and the idle-timeout, etc.

### Syntax

```
show user configuration
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the security configuration information of the users:

```
T2500-28TC(config)#show user configuration
```

## Chapter 12 Binding Table Commands

You can bind the IP address, MAC address, VLAN and the connected Port number of the Host together, which can be the condition for the ARP Inspection and IP verify source to filter the packets.

### ip source binding

#### Description

The **ip source binding** command is used to bind the IP address, MAC address, VLAN ID and the Port number together manually. You can manually bind the IP address, MAC address, VLAN ID and the Port number together in the condition that you have got the related information of the Hosts in the LAN. To delete the IP-MAC –VID-PORT entry from the binding table, please use **no ip source binding index** command.

#### Syntax

```
ip source binding hostname ip-addr mac-addr vlan vlan-id interface
{ fastEthernet port | gigabitEthernet port } { none | arp-detection |
ip-verify-source | both } [ forced-source {arp-scanning | dhcp-snooping} ]
no ip source binding index idx
```

#### Parameter

*hostname* — The Host Name, which contains 20 characters at most.

*ip-addr* — The IP address of the Host.

*mac-addr* — The MAC address of the Host.

*vlan-id* — The VLAN ID needed to be bound, ranging from 1 to 4094.

*port* — The number of port connected to the Host.

none | arp-detection | ip-verify-source | both — The protect type for the entry. “arp-detection” indicates ARP detection; “ip-verify-source” indicates IP source filter; “none” indicates applying none; “both” indicates applying both.

forced-source — The source of the binding entry can be specified as “arp-scanning” or “dhcp-snooping”. It is multi-optional.

*idx* — The entry number needed to be deleted. You can use the [show ip source binding](#) command to get the idx. Pay attention that the entry number is the actual number in the binding table which is not display in an arranged order.



## Command Mode

Global Configuration Mode

## Example

Bind an ACL entry with the IP 192.168.0.1, MAC 00:00:00:00:00:01, VLAN ID 2 and the Port number 5 manually. And then enable the entry for the ARP detection and IP filter function:

```
T2500-28TC(config)#ip source binding host1 192.168.0.1 00:00:00:00:00:01
vlan 2 interface fastEthernet 1/0/5 both
```

Delete the IP-MAC –VID-PORT entry with the index 5:

```
T2500-28TC(config)#no ip source binding index 5
```

## ip source binding index

### Description

The **ip source binding index** command is used to modify the existing entry of ip source binding.

### Syntax

```
ip source binding index idx {hostname hostname | mac mac-addr | vlan
vlan-id| interface { fastEthernet port | gigabitEthernet port} | none |
arp-detection | ip-verify-source | both }
```

### Parameter

*idx* —The entry number needed to be modified. You can use the [show ip source binding](#) command to get the idx. Pay attention that the entry number is the actual number in the binding table which is not displayed in an arranged order.

*hostname* —The modified Host Name, which contains 20 characters at most.

*mac-addr* — The modified MAC address of the Host.

*vlan-id* —The modified VLAN ID, ranging from 1 to 4094.

*port* — The modified number of port connected to the Host.

none | arp-detection | ip-verify-source | both —The modified protect type for the entry. “arp-detection” indicates ARP detection; “ip-verify-source” indicates IP source filter; “none” indicates applying none; “both” indicates applying both.

## Command Mode

Global Configuration Mode

## Example

Modify the hostname as “tp-link” of the entry with the index 1:

```
T2500-28TC(config)#ip source binding index 1 hostname tp-link
```

# ip dhcp snooping

## Description

The **ip dhcp snooping** command is used to enable DHCP-Snooping function globally. To disable DHCP-Snooping function globally, please use **no ip dhcp snooping** command. DHCP Snooping functions to monitor the process of the Host obtaining the IP address from DHCP server, and record the IP address, MAC address, VLAN and the connected Port number of the Host for automatic binding. The switch can also propagate the control information and the network parameters via the Option 82 field to provide more information for the Host.

## Syntax

**ip dhcp snooping**

**no ip dhcp snooping**

## Command Mode

Global Configuration Mode

## Example

Enable the DHCP-Snooping function globally:

```
T2500-28TC(config)#ip dhcp snooping
```

# ip dhcp snooping global

## Description

The **ip dhcp snooping global** command is configure DHCP-Snooping globally. To restore to the default value, please use **no dhcp-snooping global** command.

## Syntax

```
ip dhcp snooping global { [global-rate global-rate] [dec-threshold
dec-threshold] [dec-rate dec-rate] }
```

```
no ip dhcp snooping global
```

## Parameter

*global-rate* — The value to specify the maximum amount of DHCP messages that can be forwarded by the switch per second. The excessive messages will be discarded. The options are 0/10/20/30/40/50 (packet/second). By default, it is 0 standing for “disable”.

*dec-threshold* — The value to specify the minimum transmission rate of the Decline packets to trigger the Decline protection for the specific port. The options are 0/5/10/15/20/25/30 (packet/second). By default, it is 0 standing for “disable”.

*dec-rate* — The value to specify the Decline Flow Control. The traffic flow of the corresponding port will be limited to be this value if the transmission rate of the Decline packets exceeds the Decline Threshold. The options are 5/10/15/20/25/30 (packet/second). By default, it is 5.

## Command Mode

Global Configuration Mode

## Example

Configure the Global Flow Control as 30pps, the Decline Threshold as 20 pps, and decline Flow Control as 20 pps for DHCP Snooping:

```
T2500-28TC(config)#ip dhcp snooping global global-rate 30 dec-threshold
20 dec-rate 20
```

# ip dhcp snooping information option

## Description

The **ip dhcp snooping information option** command is used to enable the Option 82 function of DHCP Snooping. To disable the Option 82 function, please use **no ip dhcp snooping information option** command.

## Syntax

```
ip dhcp snooping information option
```

**no ip dhcp snooping information option**

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

Enable the Option 82 function of DHCP Snooping for port 2:

```
T2500-28TC(config)#interface fastEthernet 1/0/2
```

```
T2500-28TC(config-if)#ip dhcp snooping information option
```

## ip dhcp snooping information strategy

### Description

The **ip dhcp snooping information strategy** command is used to select the operation for the Option 82 field of the DHCP request packets from the Host. To restore to the default option, please use **no ip dhcp snooping information strategy** command.

### Syntax

**ip dhcp snooping information strategy** *strategy*

**no ip dhcp snooping information strategy**

### Parameter

*strategy* — The operations for Option 82 field of the DHCP request packets from the Host, including three types:

keep: Indicates to keep the Option 82 field of the packets. It is the default option.

replace: Indicates to replace the Option 82 field of the packets with the switch defined one.

drop: Indicates to discard the packets including the Option 82 field.

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

For port 2, replace the Option 82 field of the packets with the switch defined one and then send out:

```
T2500-28TC(config)#interface fastEthernet 1/0/2
```

```
T2500-28TC(config-if)#ip dhcp snooping information strategy replace
```

## ip dhcp snooping information remote-id

### Description

The **ip dhcp snooping information remote-id** command is used to enable and configure the customized sub-option Remote ID for the Option 82. To return to default Remote ID for the Option 82, please use **no ip dhcp snooping information remote-id** command.

### Syntax

```
ip dhcp snooping information remote-id string
```

```
no ip dhcp snooping information remote-id
```

### Parameter

*string* — Enter the sub-option Remote ID, which contains 32 characters at most.

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

For port 2, enable and configure the customized sub-option Remote ID for the Option 82 as tplink:

```
T2500-28TC(config)#interface fastEthernet 1/0/2
```

```
T2500-28TC(config-if)#ip dhcp snooping information remote-id tplink
```

## ip dhcp snooping information circuit-id

### Description

The **ip dhcp snooping information circuit-id** command is used to enable and configure the customized sub-option Circuit ID for the Option 82. To return to the default Circuit ID for the Option 82, please use **no ip dhcp snooping information circuit-id** command.

## Syntax

```
ip dhcp snooping information circuit-id string
no ip dhcp snooping information circuit-id
```

## Parameter

*string* — Enter the sub-option Circuit ID, which contains 32 characters at most.

## Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

For port 2, enable and configure the customized sub-option Circuit ID for the Option 82 as “tplink”:

```
T2500-28TC(config)#interface fastEthernet 1/0/2
T2500-28TC(config-if)#ip dhcp snooping information circuit-id tplink
```

# ip dhcp snooping trust

## Description

The **ip dhcp snooping trust** command is used to configure a port to be a Trusted Port. Only the Trusted Port can receive the DHCP packets from DHCP servers. To turn the port back to a distrusted port, please use **no ip dhcp snooping trust** command.

## Syntax

```
ip dhcp snooping trust
no ip dhcp snooping trust
```

## Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

Configure the Fast Ethernet port 2 to be a Trusted Port:

```
T2500-28TC(config)#interface fastEthernet 1/0/2
T2500-28TC(config-if)#ip dhcp snooping trust
```

## ip dhcp snooping mac-verify

### Description

The **ip dhcp snooping mac-verify** command is used to enable the MAC Verify feature. To disable the MAC Verify feature, please use **no ip dhcp snooping mac-verify** command. There are two fields of the DHCP packet containing the MAC address of the Host. The MAC Verify feature is to compare the two fields and discard the packet if the two fields are different.

### Syntax

```
ip dhcp snooping mac-verify
no ip dhcp snooping mac-verify
```

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

Enable the MAC Verify feature for the Fast Ethernet port 2:

```
T2500-28TC(config)#interface fastEthernet 1/0/2
T2500-28TC(config-if)#ip dhcp snooping mac-verify
```

## ip dhcp snooping limit rate

### Description

The **ip dhcp snooping limit rate** command is used to enable the Flow Control feature for the DHCP packets. The excessive DHCP packets will be discarded. To restore to the default configuration, please use **no ip dhcp snooping limit rate** command.

### Syntax

```
ip dhcp snooping limit rate value
no ip dhcp snooping limit rate
```

### Parameter

*value* — The value of Flow Control. The options are 0/5/10/15/20/25/30 (packet/second). The default value is 0, which stands for “disable”.

## Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

Set the Flow Control of Fast Ethernet port 2 as 20 pps:

```
T2500-28TC(config)#interface fastEthernet 1/0/2
T2500-28TC(config-if)#ip dhcp snooping limit rate 20
```

# ip dhcp snooping decline

## Description

The **ip dhcp snooping decline** command is used to enable the Decline Protect feature. To disable the Decline Protect feature, please use **no ip dhcp snooping decline** command.

## Syntax

```
ip dhcp snooping decline
no ip dhcp snooping decline
```

## Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

Enable the Decline Protect feature of Fast Ethernet port 2:

```
T2500-28TC(config)#interface fastEthernet 1/0/2
T2500-28TC(config-if)#ip dhcp snooping decline
```

# show ip source binding

## Description

The **show ip source binding** command is used to display the IP-MAC-VID-PORT binding table.

## Syntax

```
show ip source binding
```



## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display the IP-MAC-VID-PORT binding table:

```
T2500-28TC(config)#show ip source binding
```

# show ip dhcp snooping

## Description

The **show ip dhcp snooping** command is used to display the running status of DHCP-Snooping.

## Syntax

```
show ip dhcp snooping
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display the running status of DHCP-Snooping:

```
T2500-28TC#show ip dhcp snooping
```

# show ip dhcp snooping information interface

## Description

The **show ip dhcp snooping information interface** command is used to display the Option 82 configuration status of a desired Fast/Gigabit Ethernet ports or of all Ethernet ports.

## Syntax

```
show ip dhcp snooping information interface [ fastEthernet port |  
gigabitEthernet port ]
```

## Parameters

*port* —The Fast/Gigabit Ethernet port number.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the Option 82 configuration status of all Ethernet ports:

```
T2500-28TC#show ip dhcp snooping information interface
```

Display the Option 82 configuration status of Fast Ethernet port 5:

```
T2500-28TC#show ip dhcp snooping information interface fastEthernet  
1/0/5
```

## show ip dhcp snooping interface

### Description

The **show ip dhcp snooping interface** command is used to display the DHCP-Snooping configuration of a desired Fast/Gigabit Ethernet ports or of all Ethernet ports.

### Syntax

```
show ip dhcp snooping interface [ fastEthernet port | gigabitEthernet port ]
```

### Parameters

*port* —The Fast/Gigabit Ethernet port number.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the DHCP-Snooping configuration of all Ethernet ports:

```
T2500-28TC#show ip dhcp snooping interface
```

Display the DHCP-Snooping configuration of Fast Ethernet port 5:

```
T2500-28TC#show ip dhcp snooping interface fastEthernet 1/0/5
```

## Chapter 13 ARP Inspection Commands

ARP (Address Resolution Protocol) Detect function is to protect the switch from the ARP cheating, such as the Network Gateway Spoofing and Man-In-The-Middle Attack, etc.

### ip arp inspection(global)

#### Description

The **ip arp inspection** command is used to enable the ARP Detection function globally. To disable the ARP Detection function, please use **no ip arp detection** command.

#### Syntax

**ip arp inspection**  
**no ip arp inspection**

#### Command Mode

Global Configuration Mode

#### Example

Enable the ARP Detection function globally:

```
T2500-28TC(config)#ip arp inspection
```

### ip arp inspection trust

#### Description

The **ip arp inspection trust** command is used to configure the port for which the ARP Detect function is unnecessary as the Trusted Port. To clear the Trusted Port list, please use **no ip arp detection trust** command. The specific ports, such as up-linked port, routing port and LAG port, should be set as Trusted Port. To ensure the normal communication of the switch, please configure the ARP Trusted Port before enabling the ARP Detect function.

#### Syntax

**ip arp inspection trust**  
**no ip arp inspection trust**

## Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

Configure the Fast Ethernet ports 2-5 as the Trusted Port:

```
T2500-28TC(config)#interface range fastEthernet 1/0/2-5
```

```
T2500-28TC(config-if-range)#ip arp inspection trust
```

# ip arp inspection(interface)

## Description

The **ip arp inspection** command is used to enable the ARP Defend function. To disable the ARP detection function, please use **no ip arp inspection** command. ARP Attack flood produces lots of ARP Packets, which will occupy the bandwidth and slow the network speed extremely. With the ARP Defend enabled, the switch can terminate receiving the ARP packets for 300 seconds when the transmission speed of the legal ARP packet on the port exceeds the defined value so as to avoid ARP Attack flood.

## Syntax

**ip arp inspection**

**no ip arp inspection**

## Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

Enable the arp defend function for the Fast Ethernet ports 2-6:

```
T2500-28TC(config)#interface range fastEthernet 1/0/2-6
```

```
T2500-28TC(config-if-range)#ip arp inspection
```

## ip arp inspection limit-rate

### Description

The **ip arp inspection limit-rate** command is used to configure the ARP speed of a specified port. To restore to the default speed, please use **no ip arp inspection limit-rate** command.

### Syntax

```
ip arp inspection limit-rate value  
no ip arp inspection limit-rate
```

### Parameter

*value* —The *value* to specify the maximum amount of the received ARP packets per second, ranging from 10 to 100 in pps(packet/second). By default, the value is 15.

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

Configure the maximum amount of the received ARP packets per second as 50 pps for Fast Ethernet port 5:

```
T2500-28TC(config)#interface fastEthernet 1/0/5  
T2500-28TC(config-if)#ip arp inspection limit-rate 50
```

## ip arp inspection recover

### Description

The **ip arp inspection recover** command is used to restore a port to the ARP transmit status from the ARP filter status.

### Syntax

```
ip arp inspection recover
```

### Command Mode

Interface Configuration Mode (Interface fastEthernet / Interface range fastEthernet / Interface gigabitEthernet / Interface range gigabitEthernet)

## Example

Restore Fast Ethernet port 5 to the ARP transmit status:

```
T2500-28TC(config)#interface fastEthernet 1/0/5
T2500-28TC(config-if)#ip arp inspection recover
```

## show ip arp inspection

### Description

The **show ip arp inspection** command is used to display the ARP detection global configuration including the enable/disable status and the Trusted Port list.

### Syntax

```
show ip arp inspection
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the ARP detection configuration globally:

```
T2500-28TC(config)#show ip arp inspection
```

## show ip arp inspection interface

### Description

The **show ip arp inspection interface** command is used to display the interface configuration of ARP detection.

### Syntax

```
show ip arp inspection interface [ fastEthernet port | gigabitEthernet port]
```

### Parameter

*port* —The Fast/Gigabit Ethernet port number.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the configuration of Fast Ethernet port 1:

```
T2500-28TC(config)#show ip arp inspection interface fastEthernet 1/0/1
```

Display the configuration of all Ethernet ports:

```
T2500-28TC(config)#show ip arp inspection interface
```

## show ip arp inspection statistics

### Description

The **show ip arp inspection statistics** command is used to display the number of the illegal ARP packets received.

### Syntax

```
show ip arp inspection statistics
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the number of the illegal ARP packets received:

```
T2500-28TC(config)#show ip arp inspection statistics
```

## clear ip arp inspection statistics

### Description

The **clear ip arp inspection statistics** command is used to clear the statistic of the illegal ARP packets received.

### Syntax

```
clear ip arp inspection statistics
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Clear the statistic of the illegal ARP packets received:

```
T2500-28TC(config)#clear ip arp inspection statistics
```

## Chapter 14 IP Verify Source Commands

IP Verify Source is to filter the IP packets based on the IP-MAC Binding entries. Only the packets matched to the IP-MAC Binding rules can be processed, which can enhance the bandwidth utility.

### ip verify source

#### Description

The **ip verify source** command is used to configure the IP Verify Source mode for a specified port. To disable the IP Verify Source function, please use **no ip verify source** command.

#### Syntax

```
ip verify source {sip | sip+mac}
no ip verify source
```

#### Parameter

sip | sip+mac—— Security type. “sip” indicates that only the packets with its source IP address and port number matched to the IP-MAC binding rules can be processed. “sip+mac” indicates that only the packets with its source IP address, source MAC address and port number matched to the IP-MAC binding rules can be processed.

#### Command Mode

Interface Configuration Mode ( interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet )

#### Example

Enable the IP Verify Source function for Fast Ethernet ports 5-10. Configure that only the packets with its source IP address, source MAC address and port number matched to the IP-MAC binding rules can be processed:

```
T2500-28TC(config)#interface range fastEthernet 1/0/5-10
T2500-28TC(config-if-range)#ip verify source sip+mac
```



## show ip verify source

### Description

The **show ip verify source** command is used to display the IP Verify Source configuration information.

### Syntax

```
show ip verify source
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the IP Verify Source configuration information:

```
T2500-28TC(config)#show ip verify source
```

## Chapter 15 DoS Defend Command

DoS (Denial of Service) Attack is to occupy the network bandwidth maliciously by the network attackers or the evil programs sending a lot of service requests to the Host. With the DoS Defend enabled, the switch can analyze the specific field of the received packets and provide the defend measures to ensure the normal working of the local network.

### ip dos-prevent

#### Description

The **ip dos-prevent** command is used to enable the DoS defend function globally. To disable the DoS defend function, please use **no ip dos-prevent** command.

#### Syntax

```
ip dos-prevent
no ip dos-prevent
```

#### Command Mode

Global Configuration Mode

#### Example

Enable the DoS defend function globally:

```
T2500-28TC(config)#ip dos-prevent
```

### ip dos-prevent ping-rate

#### Description

The **ip dos-prevent ping-rate** command is used to configure the transmission rate of the Ping packets. To restore to default, please use **no ip dos-prevent ping-rate** command.

#### Syntax

```
ip dos-prevent ping-rate ping-rate
no ip dos-prevent ping-rate
```

### Parameter

*ping-rate* — Specify the transmission rate of the Ping packets when the Defend Type Ping Flooding is enabled. The options are 128k、256k、512k、1m、2m、4m in bps. By default, the value is 128k.

### Command Mode

Global Configuration Mode

### Example

Specify the transmission rate of the Ping packets as 256k:

```
T2500-28TC(config)#ip dos-prevent ping-rate 256k
```

## ip dos-prevent syn-rate

### Description

The **ip dos-prevent syn-rate** command is used to configure the transmission rate of the SYN/SYN-ACK packets. To restore to default, please use **no ip dos-prevent syn-rate** command.

### Syntax

```
ip dos-prevent syn-rate syn-rate
```

```
no ip dos-prevent syn-rate
```

### Parameter

*syn-rate* — Specify the transmission rate of the SYN/SYN-ACK packets when the Defend Type SYN/SYN-ACK Flooding is enabled. The options are 128k、256k、512k、1m、2m、4m in bps. By default, the value is 128k.

### Command Mode

Global Configuration Mode

### Example

Specify the transmission rate of the SYN/SYN-ACK packets as 1m:

```
T2500-28TC(config)#ip dos-prevent syn-rate 1m
```

## ip dos-prevent type

### Description

The **ip dos-prevent type** command is used to select the DoS Defend Type. To disable the corresponding Defend Type, please use **no ip dos-prevent type** command.

### Syntax

**ip dos-prevent type** { land | scan-synfin | xma-scan | null-scan | port-less-1024 | smurf | blat | ping-flood | syn-flood | win-nuke | ping-of-death }

**no ip dos-prevent type** { land | scan-synfin | xma-scan | null-scan | port-less-1024 | smurf | blat | ping-flood | syn-flood | win-nuke | ping-of-death }

### Parameter

land — Land attack.

scan-synfin — Scan SYNFIN attack.

xma-scan — Xma Scan attack.

null-scan — NULL Scan attack.

port-less-1024 —The SYN packets whose Source Port less than 1024.

smurf — Smurf attack.

blat — Blat attack.

ping-flood — Ping flooding attack. With the ping flood attack enabled, the switch will limit automatically the forwarding speed of ping packets to 512K when attacked by ping flood.

syn-flood — SYN/SYN-ACK flooding attack. With the syn-flood attack enabled, the switch will limit automatically the forwarding speed of ping packets to 512K when attacked by syn-flood.

win-nuke — winNuke attack.

ping-of-death— Ping of Death attack

### Command Mode

Global Configuration Mode

### Example

Enable the DoS Defend Type named Land attack:

```
T2500-28TC(config)#ip dos-prevent type land
```

## ip dos-prevent detect

### Description

The **ip dos-prevent detect** command is used to configure the detect time for each DoS attack type except the flooding attack type.

### Syntax

```
ip dos-prevent detect detect-time
```

### Parameter

*detect-time* — Specify the detect time for each DoS attack type except the flooding attack type, ranging from 1 to 5 in second.

### Command Mode

Global Configuration Mode

### Example

Detect the DoS attack and specify the detect time for each DoS attack type except the flooding attack type as 5 seconds:

```
T2500-28TC(config)#ip dos-prevent detect 5
```

## clear ip dos-prevent detect statistics

### Description

The **clear ip dos-prevent detect statistics** command is used to clear the information statistic of the detected DoS attack.

### Syntax

```
clear ip dos-prevent detect statistics
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Clear the information statistic of the detected DoS attack:

```
T2500-28TC(config)#clear ip dos-prevent detect statistics
```

## show ip dos-prevent

### Description

The **show ip dos-prevent** command is used to display the DoS information of the detected DoS attack, including enable/disable status, the DoS Defend Type, the count of the attack, etc.

### Syntax

```
show ip dos-prevent
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the DoS information of the detected DoS attack globally:

```
T2500-28TC(config)#show ip dos-prevent
```

## Chapter 16 IEEE 802.1X Commands

IEEE 802.1X function is to provide an access control for LAN ports via the authentication. An 802.1X system include three entities: supplicant, authenticator and authentication server.

- Supplicant: the device that requests access to the LAN.
- Authentication server: performs the actual authentication of the supplicant. It validates the identity of the supplicant and notifies the authenticator whether or not the supplicant is authorized to access the LAN.
- Authenticator: controls the physical access to the network based on the authentication status of the supplicant. It is usually an 802.1X-supported network device, such as this TP-Link switch. It acts as an intermediary (proxy) between the supplicant and the authentication server, requesting identity information from the supplicant, verifying that information with the authentication server, and relaying a response to the supplicant.

This chapter handles with the authentication process between the supplicant and the switch. To realize the authentication and accounting function, you should also enable the AAA function and configure the RADIUS server. Go to [Chapter 38 AAA Commands](#) for more details.

### dot1x system-auth-control

#### Description

The **dot1x system-auth-control** command is used to enable the IEEE 802.1X function globally. To disable the IEEE 802.1X function, please use **no dot1x system-auth-control** command.

#### Syntax

```
dot1x system-auth-control  
no dot1x system-auth-control
```

#### Command Mode

Global Configuration Mode

#### Example

Enable the IEEE 802.1X function:

```
T2500-28TC(config)#dot1x system-auth-control
```

## dot1x auth-method

### Description

The **dot1x auth-method** command is used to configure the Authentication Method of IEEE 802.1X and the default 802.1X authentication method is “eap-md5”. To restore to the default 802.1X authentication method, please use **no dot1x auth-method** command.

### Syntax

```
dot1x auth-method { pap | eap-md5 }
```

```
no dot1x auth-method
```

### Parameter

pap | eap-md5 —Authentication Methods.

pap: IEEE 802.1X authentication system uses extensible authentication protocol (EAP) to exchange information between the switch and the client. The transmission of EAP packets is terminated at the switch and the EAP packets are converted to the other protocol (such as RADIUS) packets for transmission

eap-md5: IEEE 802.1X authentication system uses extensible authentication protocol (EAP) to exchange information between the switch and the client. The EAP protocol packets with authentication data can be encapsulated in the advanced protocol (such as RADIUS) packets to be transmitted to the authentication server.

### Command Mode

Global Configuration Mode

### Example

Configure the Authentication Method of IEEE 802.1X as “pap”:

```
T2500-28TC(config)#dot1x auth-method pap
```

## dot1x guest-vlan(global)

### Description

The **dot1x guest-vlan** command is used to enable the Guest VLAN function globally. To disable the Guest VLAN function, please use **no dot1x guest-vlan** command.



## Syntax

```
dot1x guest-vlan vid  
no dot1x guest-vlan
```

## Parameter

*vid* — The VLAN ID needed to enable the Guest VLAN function, ranging from 2 to 4094. The supplicants in the Guest VLAN can access the specified network source.

## Command Mode

Global Configuration Mode

## Example

Enable the Guest VLAN function for VLAN 5:

```
T2500-28TC(config)#dot1x guest-vlan 5
```

# dot1x accounting

## Description

The **dot1x accounting** command is used to enable the IEEE 802.1X accounting function globally. To disable the IEEE 802.1X accounting function, please use **no dot1x accounting** command.

## Syntax

```
dot1x accounting  
no dot1x accounting
```

## Command Mode

Global Configuration Mode

## Example

Enable the 802.1X accounting function globally:

```
T2500-28TC(config)# dot1x accounting
```

## dot1x quiet-period

### Description

The **dot1x quiet-period** command is used to enable the quiet-period function. To disable the function, please use **no dot1x quiet-period** command.

### Syntax

```
dot1x quiet-period
no dot1x quiet-period
```

### Command Mode

Global Configuration Mode

### Example

Enable the quiet-period function:

```
T2500-28TC(config)#dot1x quiet-period
```

## dot1x timeout

### Description

The **dot1x timeout** command is used to configure the quiet period and the supplicant timeout. To restore to the default, please use **no dot1x timeout** command.

### Syntax

```
dot1x timeout {quiet-period time | reauth-period time}
no dot1x timeout {quiet-period | reauth-period}
```

### Parameter

**quiet-period *time*** —The value for Quiet Period, ranging from 1 to 999 in seconds. By default, it is 10. Once the supplicant failed to the 802.1X Authentication, then the switch will not respond to the authentication request from the same supplicant during the Quiet Period.

**reauth-period *time*** —The maximum time for the switch to wait for the response from supplicant before resending a request to the supplicant., ranging from 1 to 9 in second. By default, it is 3.

## Command Mode

Global Configuration Mode

## Example

Configure the quiet period as 100 seconds:

```
T2500-28TC(config)#dot1x timeout quiet-period 100
```

# dot1x max-reauth-req

## Description

The **dot1x max-reauth-req** command is used to configure the maximum transfer times of the repeated authentication request when the server cannot be connected. To restore to the default value, please use **no dot1x max-reauth-req** command.

## Syntax

```
dot1x max-reauth-req times
```

```
no dot1x max-reauth-req
```

## Parameter

*times* — The maximum transfer times of the repeated authentication request, ranging from 1 to 9 in times. By default, the value is 3.

## Command Mode

Global Configuration Mode

## Example

Configure the maximum transfer times of the repeated authentication request as 5:

```
T2500-28TC(config)#dot1x max-reauth-req 5
```

# dot1x

## Description

The **dot1x** command is used to enable the IEEE 802.1X function for a specified port. To disable the IEEE 802.1X function for a specified port, please use **no dot1x** command.

## Syntax

```
dot1x
no dot1x
```

## Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

Enable the IEEE 802.1X function for the Fast Ethernet port 1:

```
T2500-28TC(config)#interface fastEthernet 1/0/1
T2500-28TC(config-if)#dot1x
```

# dot1x guest-vlan(interface)

## Description

The **dot1x guest-vlan** command is used to enable the guest VLAN function for a specified port. To disable the Guest VLAN function for a specified port, please use **no dot1x guest-vlan** command. Please ensure that the Control Type of the corresponding port is port-based before enabling the guest VLAN function for it.

## Syntax

```
dot1x guest-vlan
no dot1x guest-vlan
```

## Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

Enable the Guest VLAN function for Fast Ethernet port 2:

```
T2500-28TC(config)#interface fastEthernet 1/0/2
T2500-28TC(config-if)#dot1x guest-vlan
```

## dot1x port-control

### Description

The **dot1x port-control** command is used to configure the Control Mode of IEEE 802.1X for the specified port. By default, the control mode is “auto”. To restore to the default configuration, please use **no dot1x port-control** command.

### Syntax

```
dot1x port-control {auto | authorized-force | unauthorized-force}
```

```
no dot1x port-control
```

### Parameter

auto | authorized-force | unauthorized-force — The Control Mode for the port.

auto: In this mode, the port will normally work only after passing the 802.1X Authentication.

authorized-force: In this mode, the port can work normally without passing the 802.1X Authentication.

unauthorized-force: In this mode, the port is forbidden working for its fixed unauthorized status.

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

Configure the Control Mode for Gigabit Ethernet port 25 as “authorized-force”:

```
T2500-28TC(config)#interface gigabitEthernet 1/0/25
```

```
T2500-28TC(config-if)#dot1x port-control authorized-force
```

## dot1x port-method

### Description

The **dot1x port-method** command is used to configure the control type of IEEE 802.1X for the specified port. By default, the control type is “mac-based”. To restore to the default configuration, please use **no dot1x port-method** command.

## Syntax

```
dot1x port-method { mac-based | port-based }  
no dot1x port-method
```

## Parameter

mac-based | port-based —The control type for the port.

mac-based: Any client connected to the port should pass the 802.1X authentication for access.

port-based: All the clients connected to the port can access the network on the condition that any one of the clients has passed the 802.1X Authentication.

## Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

Configure the Control Type for Gigabit Ethernet port 25 as “port-based”:

```
T2500-28TC(config)#interface gigabitEthernet 1/0/25  
T2500-28TC(config-if)#dot1x port-method port-based
```

# show dot1x global

## Description

The **show dot1x global** command is used to display the global configuration of 801.X.

## Syntax

```
show dot1x global
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display the configuration of 801.X globally:

```
T2500-28TC(config)#show dot1x global
```

## show dot1x interface

### Description

The **show dot1x interface** command is used to display all ports or the specified port's configuration information of 801.X.

### Syntax

```
show dot1x interface [ fastEthernet port | gigabitEthernet port ]
```

### Parameter

*port* — The Fast/Gigabit Ethernet port number. Display the configuration of all the ports by default.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the configuration information of 801.X for Gigabit Ethernet port 25:

```
T2500-28TC(config)#show dot1x interface gigabitEthernet 1/0/25
```

Display the configuration information of 801.X for all Ethernet ports:

```
T2500-28TC(config)#show dot1x interface
```

## Chapter 17 PPPoE Circuit-ID Insertion Commands

The PPPoE Circuit-ID Insertion feature provides a way to extract a Circuit-ID as an identifier for the authentication, authorization, and accounting (AAA) access requests on an Ethernet interface. When enabled, the switch attaches a tag to the PPPoE discovery packets, which is called the PPPoE Vendor-Specific tag and it contains a unique line identifier. The BRAS receives the tagged packet, decodes the tag, and uses the Circuit-ID field of that tag as a NAS-Port-ID attribute in the RADIUS server for PPP authentication and AAA (authentication, authorization, and accounting) access requests. The switch will remove the Circuit-ID tag from the received PPPoE Active Discovery Offer and Session-confirmation packets from the BRAS.

### pppoe circuit-id(global)

#### Description

The **pppoe circuit-id** command is used to enable the PPPoE Circuit-ID Insertion function globally. To disable the PPPoE Circuit-ID Insertion function, please use **no pppoe circuit-id** command.

#### Syntax

```
pppoe circuit-id
no pppoe circuit-id
```

#### Command Mode

Global Configuration Mode

#### Example

Enable the PPPoE Circuit-ID Insertion function:

```
T2500-28TC(config)# pppoe circuit-id
```

### pppoe circuit-id(interface)

#### Description

The **pppoe circuit-id** command is used to enable the PPPoE Circuit-ID Insertion function for a specified port. To disable the PPPoE Circuit-ID Insertion function on a specified port, please use **no pppoe circuit-id** command.



## Syntax

```
pppoe circuit-id
no pppoe circuit-id
```

## Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

Enable the PPPoE Circuit-ID Insertion function for the Fast Ethernet port 1/0/1:

```
T2500-28TC (config)# interface fastEthernet 1/0/1
T2500-28TC (config-if)# pppoe circuit-id
```

# pppoe circuit-id type

## Description

The **pppoe circuit-id type** command is used to configure the type of PPPoE Circuit-ID for a specified port. By default, the PPPoE Circuit-ID type is "ip".

## Syntax

```
pppoe circuit-id type { mac | ip | udf [UDF Value] }
```

## Parameter

mac | ip | udf — The type of PPPoE Circuit-ID for the port.

mac: The MAC address of the switch will be used to encode the Circuit-ID option.

ip: The IP address of the switch will be used to encode the Circuit-ID option. This is the default value.

udf: A user specified string with the maximum length of 32 characters will be used to encode the Circuit-ID option.

*UDF Value* — The value of UDF. The maximum length is 32 characters.

## Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

Configure the type of PPPoE Circuit-ID as “mac” for the Fast Ethernet port 1/0/1:

```
T2500-28TC (config)# interface fastEthernet 1/0/1
T2500-28TC (config-if)# pppoe circuit-id type mac
```

## show pppoe circuit-id global

### Description

The **show pppoe circuit-id global** command is used to display the global configuration of PPPoE Circuit-ID Insertion function.

### Syntax

```
show pppoe circuit-id global
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the configuration of PPPoE Circuit-ID Insertion function globally:

```
T2500-28TC # show pppoe circuit-id global
```

## show pppoe circuit-id interface

### Description

The **show pppoe circuit-id interface** command is used to display all ports' or the specified port's configuration information of PPPoE Circuit-ID Insertion function.

### Syntax

```
show pppoe circuit-id interface [ fastEthernet port | gigabitEthernet port ]
```

### Parameter

*port* — The Fast/Gigabit Ethernet port number.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the configuration information of PPPoE Circuit-ID Insertion function of all Ethernet ports:

```
T2500-28TC# show pppoe circuit-id interface
```

Display the configuration of PPPoE Circuit-ID Insertion function of the Fast Ethernet port 1/0/1 :

```
T2500-28TC# show pppoe interface fastEthernet 1/0/1
```

## Chapter 18 System Log Commands

The log information will record the settings and operation of the switch respectively for you to monitor operation status and diagnose malfunction.

### logging buffer

#### Description

The **logging buffer** command is used to configure the severity level and the status of the configuration input to the log buffer. To disable the logging buffer function, please use **no logging buffer** command. Local Log is the log information saved in the switch. It has two output channels, that is, it can be saved to two different positions, log buffer and log file. The log buffer indicates the RAM for saving system log and the information in the log buffer can be got by [show logging buffer](#) command. It will be lost when the switch is restarted.

#### Syntax

**logging buffer** *level*

**no logging buffer**

#### Parameter

*level* — Severity level of the log information output to each channel. There are 8 severity levels marked with values 0-7. The smaller value has the higher priority. Only the log with the same or smaller severity level value will be output. By default, it is 7 indicating that all the log information will be saved in the log buffer.

#### Command Mode

Global Configuration Mode

#### Example

Set the severity level as 6:

```
T2500-28TC(config)#logging buffer 6
```

## logging file flash

### Description

The **logging file flash** command is used to configure the level and the status of the log file input. To disable the logging file flash function, please use **no logging file flash** command. The log file indicates the flash sector for saving system log. The information in the log file will not be lost after the switch is restarted and can be got by the [show logging flash](#) command.

### Syntax

**logging file flash**

**no logging file flash**

### Command Mode

Global Configuration Mode

### Example

Enable the log file function and set the severity as 7:

```
T2500-28TC(config)#logging file flash 7
```

## logging file flash frequency

### Description

The **logging file flash frequency** command is used to specify the frequency to synchronize the system log file in the log buffer to the flash. To resume the default synchronizing frequency, please use the **no logging file flash frequency** command.

### Syntax

**logging file flash frequency { periodic *periodic* | immediate }**

**no logging file flash frequency**

### Parameter

*periodic* —The frequency to synchronize the system log file in the log buffer to the flash, ranging from 1 to 48 hours. By default, the synchronization process takes place every 24 hours.

**Immediate**— The system log file in the buffer will be synchronized to the flash immediately. This option will reduce the life of the flash and is not recommended.

### Command Mode

Global Configuration Mode

### Example

Specify the log file synchronization frequency as 10 hours:

```
T2500-28TC(config)# logging file flash frequency periodic10
```

## logging file flash level

### Description

The **logging file flash level** command is used to specify the system log message severity level. Messages with a severity level equal to or higher than this value will be stored to the flash. To restore to the default level, please use **no logging file flash level** command.

### Syntax

**logging file flash level** *level*

**no logging file flash level**

### Parameter

*level* — Severity level of the log information. There are 8 severity levels marked with values 0-7. The smaller value has the higher priority. Only the log with the same or smaller severity level value will be output. By default, it is 2 indicating that the log information marked with 0 – 2 will be saved in the log buffer.

### Command Mode

Global Configuration Mode

### Example

Enable the log file function and set the severity as 7:

```
T2500-28TC(config)#logging file flash level 7
```

## clear logging

### Description

The **clear logging** command is used to clear the information in the log buffer and log file.

### Syntax

```
clear logging [ buffer | flash ]
```

### Parameter

buffer | flash —The output channels: buffer and flash. Clear the information of the two channels, by default.

### Command Mode

Global Configuration Mode

### Example

Clear the information in the log file:

```
T2500-28TC(config)#clear logging buffer
```

## logging host index

### Description

The **logging host index** command is used to configure the Log Host. To clear the configuration of the specified Log Host, please use **no logging host index** command. Log Host is to receive the system log from other devices. You can remotely monitor the settings and operation status of other devices through the log host.

### Syntax

```
logging host index idx host-ip level
```

```
no logging host index idx
```

### Parameter

*idx* —The index of the log host. The switch supports 4 log hosts.

*host-ip* — The IP for the log host.

*level* —The severity level of the log information sent to each log host. There are 8 severity levels marked with values 0-7. The smaller value has the higher

priority. Only the log with the same or smaller severity level value will be sent to the corresponding log host. By default, it is 6 indicating that the log information marked with 0 - 6 will be sent to the log host.

### Command Mode

Global Configuration Mode

### Example

Set the IP address as 192.168.0.148, the level 5:

```
T2500-28TC(config)#logging host index 2 192.168.0.148 5
```

## show logging local-config

### Description

The **show logging local-config** command is used to display the configuration of the Local Log including the log buffer and the log file.

### Syntax

```
show logging local-config
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the configuration of the Local Log:

```
T2500-28TC(config)#show logging local-config
```

## show logging loghost

### Description

The **show logging loghost** command is used to display the configuration of the log host.

### Syntax

```
show logging loghost [index]
```

### Parameter



*index* —The index of the log host whose configuration will be displayed.  
Display the configuration of all the log hosts by default.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the configuration of the log host 2:

```
T2500-28TC(config)#show logging loghost 2
```

## show logging buffer

### Description

The **show logging buffer** command is used to display the log information in the log buffer according to the severity level.

### Syntax

```
show logging buffer [level level]
```

### Parameter

*level* — Severity level. There are 8 severity levels marked with values 0-7.  
The information of levels with priority not lower than the select level will display.  
Display all the log information in the log buffer by default.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the log information from level 0 to level 5 in the log buffer:

```
T2500-28TC(config)#show logging buffer level 5
```

## show logging flash

### Description

The **show logging flash** command is used to display the log information in the log file according to the severity level.

## Syntax

```
show logging flash [level level]
```

## Parameter

*level* —Severity level. There are 8 severity levels marked with values 0-7. The information of levels with priority not lower than the select level will display. Display all the log information in the log file by default.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display the log information with the level marked 0 – 3 in the log file:

```
T2500-28TC(config)#show logging flash level 3
```

## Chapter 19 SSH Commands

SSH (Security Shell) can provide the unsecured remote management with security and powerful authentication to ensure the security of the management information.

### ip ssh server

#### Description

The **ip ssh server** command is used to enable SSH function. To disable the SSH function, please use **no ip ssh server** command.

#### Syntax

```
ip ssh server
no ip ssh server
```

#### Command Mode

Global Configuration Mode

#### Example

Enable the SSH function:

```
T2500-28TC(config)#ip ssh server
```

### ip ssh version

#### Description

The **ip ssh version** command is used to enable the SSH protocol version. To disable the protocol version, please use **no ip ssh version** command.

#### Syntax

```
ip ssh version {v1 | v2 }
no ip ssh version {v1 | v2}
```

#### Parameter

v1 | v2 — The SSH protocol version to be enabled. They represent SSH v1 and SSH v2 respectively.

#### Command Mode

Global Configuration Mode

## Example

Enable SSH v2:

```
T2500-28TC(config)#ip ssh version v2
```

## ip ssh timeout

### Description

The **ip ssh timeout** command is used to specify the idle-timeout time of SSH. To restore to the factory defaults, please use **ip ssh timeout** command.

### Syntax

```
ip ssh timeout value  
no ip ssh timeout
```

### Parameter

*value* — The Idle-timeout time. During this period, the system will automatically release the connection if there is no operation from the client. It ranges from 1 to 120 in seconds. By default, this value is 120.

### Command Mode

Global Configuration Mode

### Example

Specify the idle-timeout time of SSH as 100 seconds:

```
T2500-28TC(config)#ip ssh timeout 100
```

## ip ssh max-client

### Description

The **ip ssh max-client** command is used to specify the maximum number of the connections to the SSH server. To return to the default configuration, please use **no ip ssh max-client** command.

### Syntax

```
ip ssh max-client num  
no ip ssh max-client
```

### Parameter

*num* — The maximum number of the connections to the SSH server. It ranges from 1 to 5. By default, this value is 5.

## Command Mode

Global Configuration Mode

## Example

Specify the maximum number of the connections to the SSH server as 3:

```
T2500-28TC(config)#ip ssh max-client 3
```

# ip ssh download

## Description

The **ip ssh download** command is used to download the SSH key file from TFTP server.

## Syntax

```
ip ssh download {v1 | v2 } key-file ip-address ip-addr
```

## Parameter

*v1 | v2* — Select the type of SSH key to download, v1 represents SSH-1, v2 represents SSH-2.

*key-file* — The name of the key-file which is selected to download. The length of the name ranges from 1 to 25 characters. The key length of the downloaded file must be in the range of 256 to 3072 bits.

*ip-addr* — The IP address of the TFTP server. Both IPv4 and IPv6 addresses are supported, for example 192.168.0.1 or fe80::1234.

## Command Mode

Global Configuration Mode

## Example

Download an SSH-1 type key file named ssh-key from TFTP server with the IP address 192.168.0.148:

```
T2500-28TC(config)#ip ssh download v1 ssh-key ip-address 192.168.0.148
```

Download an SSH-1 type key file named ssh-key from TFTP server with the IP address fe80::1234:

```
T2500-28TC(config)# ip ssh download v1 ssh-key ip-address fe80::1234
```

## show ip ssh

### Description

The **show ip ssh** command is used to display the global configuration of SSH.

### Syntax

```
show ip ssh
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the global configuration of SSH:

```
T2500-28TC(config)#show ip ssh
```

## Chapter 20 SSL Commands

SSL (Secure Sockets Layer) , a security protocol, is to provide a secure connection for the application layer protocol(e.g. HTTP) based on TCP. Adopting asymmetrical encryption technology, SSL uses key pair to encrypt/decrypt information. A key pair refers to a public key (contained in the certificate) and its corresponding private key. By default the switch has a certificate (self-signed certificate) and a corresponding private key. The Certificate/Key Download function enables the user to replace the default key pair.

### ip http secure-server

#### Description

The **ip http secure-server** command is used to enable the SSL function globally on the switch. To disable the SSL function, please use **no ip http secure-server** command. Only the SSL function is enabled, a secure HTTPS connection can be established.

#### Syntax

```
ip http secure-server
no ip http secure-server
```

#### Command Mode

Global Configuration Mode

#### Example

Enable the SSL function:

```
T2500-28TC(config)#ip http secure-server
```

### ip http secure-server download certificate

#### Description

The **ip http secure-server download certificate** command is used to download a certificate to the switch from TFTP server.

#### Syntax

```
ip http secure-server download certificate ssl-cert ip-address ip-addr
```

## Parameter

*ssl-cert* — The name of the SSL certificate which is selected to download to the switch. The length of the name ranges from 1 to 25 characters. The Certificate must be BASE64 encoded.

*ip-addr* — The IP address of the TFTP server. Both IPv4 and IPv6 addresses are supported, for example 192.168.0.1 or fe80::1234.

## Command Mode

Global Configuration Mode

## Example

Download an SSL Certificate named *ssl-cert* from TFTP server with the IP address of 192.168.0.146:

```
T2500-28TC(config)#ip http secure-server download certificate ssl-cert
ip-address 192.168.0.146
```

Download an SSL Certificate named *ssl-cert* from TFTP server with the IP address of fe80::1234

```
T2500-28TC(config)# ip http secure-server download certificate ssl-cert
ip-address fe80::1234
```

# ip http secure-server download key

## Description

The **ip http secure-server download key** command is used to download an SSL key to the switch from TFTP server.

## Syntax

```
ip http secure-server download key ssl-key ip-address ip-addr
```

## Parameter

*ssl-key* — The name of the SSL key which is selected to download to the switch. The length of the name ranges from 1 to 25 characters. The Key must be BASE64 encoded.

*ip-addr* — The IP address of the TFTP server. Both IPv4 and IPv6 addresses are supported, for example 192.168.0.1 or fe80::1234.



## Command Mode

Global Configuration Mode

## Example

Download an SSL key named ssl-key from TFTP server with the IP address of 192.168.0.146:

```
T2500-28TC(config)# ip http secure-server download key ssl-key  
ip-address 192.168.0.146
```

Download an SSL key named ssl-key from TFTP server with the IP address of fe80::1234

```
T2500-28TC(config)# ip http secure-server download key ssl-key  
ip-address fe80::1234
```

## show ip http secure-server

### Description

The **show ip http secure-server** command is used to display the global configuration of SSL.

### Syntax

```
show ip http secure-server
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the global configuration of SSL:

```
T2500-28TC(config)#show ip http secure-server
```

## Chapter 21 MAC Address Commands

MAC address configuration can improve the network security by configuring the Port Security and maintaining the address information by managing the Address Table.

### mac address-table static

#### Description

The **mac address-table static** command is used to add the static MAC address entry. To remove the corresponding entry, please use **no mac address-table static** command. The static address can be added or removed manually, independent of the aging time. In the stable networks, the static MAC address entries can facilitate the switch to reduce broadcast packets and enhance the efficiency of packets forwarding remarkably.

#### Syntax

```
mac address-table static mac-addr vid vid interface { fastEthernet port | gigabitEthernet port }
```

```
no mac address-table static { mac-addr | vid vid | mac mac-addr vid vid | interface { fastEthernet port | gigabitEthernet port } }
```

#### Parameter

*mac-addr* — The MAC address of the entry you desire to add.

*vid* — The VLAN ID number of your desired entry. It ranges from 1 to 4094.

*port* — The Fast/Gigabit Ethernet port number.

#### Command Mode

Global Configuration Mode

#### Example

Add a static Mac address entry to bind the MAC address 00:02:58:4f:6c:23, VLAN1 and Fast Ethernet port 1 together:

```
T2500-28TC(config)#mac address-table static 00:02:58:4f:6c:23 vid 1
interface fastEthernet 1/0/1
```

Delete the static address entry whose VLAN id is 1:

```
T2500-28TC(config)#no mac address-table static vid 1
```

Delete the static address entry whose MAC address is 00:02:58:4f:6c:23:

```
T2500-28TC(config)#no mac address-table static 00:02:58:4f:6c:23
```

## mac address-table aging-time

### Description

The **mac address-table aging-time** command is used to configure aging time for the dynamic address. To return to the default configuration, please use **no mac address-table aging-time** command.

### Syntax

```
mac address-table aging-time aging-time  
no mac address-table aging-time
```

### Parameter

*aging-time* — The aging time for the dynamic address. The value of it can be 0 or ranges from 10 to 630 seconds. When 0 is entered, the Auto Aging function is disabled. It is 300 by default.

### Command Mode

Global Configuration Mode

### Example

Configure the aging time as 500 seconds:

```
T2500-28TC(config)#mac address-table aging-time 500
```

## mac address-table filtering

### Description

The **mac address-table filtering** command is used to add the filtering address entry. To delete the corresponding entry, please use **no mac address-table filtering** command. The filtering address function is to forbid the undesired package to be forwarded. The filtering address can be added or removed manually, independent of the aging time.

### Syntax

```
mac address-table filtering mac-addr vid vid  
no mac address-table filtering { [mac-addr] [vid vid] }
```

### Parameter

*mac-addr* — The MAC address to be filtered.

*vid* — The corresponding VLAN ID of the MAC address. It ranges from 1 to 4094.

### Command Mode

Global Configuration Mode

### Example

Add a filtering address entry of which VLAN ID is 1 and MAC address is 00:1e:4b:04:01:5d:

```
T2500-28TC(config)#mac address-table filtering 00:1e:4b:04:01:5d vid 1
```

## mac address-table max-mac-count

### Description

The **mac address-table max-mac-count** command is used to configure the Port Security. To return to the default configurations, please use **no mac address-table max-mac-count** command. Port Security is to protect the switch from the malicious MAC address attack by limiting the maximum number of the MAC addresses that can be learned on the port. The port with Port Security feature enabled will learn the MAC address dynamically. When the learned MAC address number reaches the maximum, the port will stop learning. Therefore, the other devices with the MAC address unlearned can not access to the network via this port.

### Syntax

```
mac address-table max-mac-count { [max-number num] [mode { dynamic | static | permanent } ] [status { disable | enable } ] }
```

```
no mac address-table max-mac-count
```

### Parameter

*num* — The maximum number of MAC addresses that can be learned on the port. It ranges from 0 to 64. By default this value is 64.

**dynamic** | **static** | **permanent** — Learn mode for MAC addresses. There are three modes, including Dynamic mode, Static mode and Permanent mode. When Dynamic mode is selected, the learned MAC address will be deleted automatically after the aging time. When Static mode is selected, the learned MAC address will be out of the influence of the aging time and can only be deleted manually. The learned entries will be cleared after the switch is rebooted. When permanent mode is selected, the learned MAC address will be out of the

influence of the aging time and can only be deleted manually too. However, the learned entries will be saved even the switch is rebooted.

**status** — Enable or disable the Port Security function for a specified port. By default, this function is disabled.

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

Enable Port Security function for Fast Ethernet port 1, select Static mode as the learn mode, and specify the maximum number of MAC addresses that can be learned on this port as 30:

```
T2500-28TC(config)#interface fastEthernet 1/0/1
T2500-28TC(config-if)#mac address-table max-mac-count max-number 30
mode static status enable
```

## show mac address-table

### Description

The **show mac address-table** command is used to display the information of all address entries.

### Syntax

```
show mac address-table {dynamic | static | drop | all }
```

### Parameter

dynamic | static | drop | all — The type of your desired entry.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the information of all address entries:

```
T2500-28TC(config)#show mac address-table all
```

## show mac address-table aging-time

### Description

The **show mac address-table aging-time** command is used to display the Aging Time of the MAC address.

### Syntax

```
show mac address-table aging-time
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the Aging Time of the MAC address:

```
T2500-28TC(config)#show mac address-table aging-time
```

## show mac address-table max-mac-count interface

### Description

The **show mac address-table max-mac-count interface** command is used to display the security configuration of an Ethernet port or of all Fast/Gigabit Ethernet ports.

### Syntax

```
show mac address-table max-mac-count interface { fastEthernet [port] |  
gigabitEthernet [port] }
```

### Parameter

*port* — The Fast/Gigabit Ethernet port number.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the security configuration of all Gigabit Ethernet ports:

```
T2500-28TC(config)#show mac address-table max-mac-count interface  
gigabitEthernet
```

Display the security configuration of Gigabit Ethernet port 25:

```
T2500-28TC(config)#show mac address-table max-mac-count interface  
gigabitEthernet 1/0/25
```

## show mac address-table interface

### Description

The **show mac address-table interface** command is used to display the address configuration of an Ethernet port.

### Syntax

```
show mac address-table interface { fastEthernet port | gigabitEthernet port }
```

### Parameter

*port* — The Fast/Gigabit Ethernet port number.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the address configuration of Fast Ethernet port 1:

```
T2500-28TC(config)#show mac address-table interface fastEthernet 1/0/1
```

## show mac address-table count

### Description

The **show mac address-table count** command is used to display the total amount of MAC address table.

### Syntax

```
show mac address-table count
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the total amount of MAC address table:

```
T2500-28TC(config)#show mac address-table count
```

## show mac address-table address

### Description

The **show mac address-table address** command is used to display the information of a specified MAC address.

## Syntax

```
show mac address-table address mac-addr
```

## Parameter

*mac-addr* — The specified MAC address.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display the information of the MAC address 00:00:00:23:00:00:

```
T2500-28TC(config)#show mac address-table address 00:00:00:23:00:00:
```

# show mac address-table vlan

## Description

The **show mac address-table vlan** command is used to display the MAC address configuration of the specified vlan.

## Syntax

```
show mac address-table vlan vid
```

## Parameter

*vid* — The specified VLAN id.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display the MAC address configuration of vlan 1:

```
T2500-28TC(config)#show mac address-table vlan 1
```



## Chapter 22 System Configuration Commands

System Configuration Commands can be used to configure the system information and system IP of the switch, and to reboot and reset the switch, upgrade the switch system and commands used for device diagnose, including loopback test and cable test.

### system-time manual

#### Description

The **system-time manual** command is used to configure the system time manually.

#### Syntax

**system-time manual** *time*

#### Parameter

*time* — Set the date and time manually, in the format of MM/DD/YYYY-HH:MM:SS.

#### Command Mode

Global Configuration Mode

#### Example

Configure the system time as 02/14/2012-12:30:00:

```
T2500-28TC(config)#system-time manual 02/14/2012-12:30:00
```

### system-time ntp

#### Description

The **system-time ntp** command is used to configure the time zone and the IP address for the NTP Server. The switch will get UTC automatically if it has connected to an NTP Server.

#### Syntax

**system-time ntp** { *timezone* } { *ntp-server* } { *backup-ntp-server* } { *fetching-rate* }

#### Parameter

*timezone* — Your local time-zone, and it ranges from UTC-12:00 to UTC+13:00.

The detailed information that each time-zone means are displayed as follow:

UTC-12:00 — TimeZone for International Date Line West.  
UTC-11:00 — TimeZone for Coordinated Universal Time-11.  
UTC-10:00 — TimeZone for Hawaii.  
UTC-09:00 — TimeZone for Alaska.  
UTC-08:00 — TimeZone for Pacific Time(US Canada).  
UTC-07:00 — TimeZone for Mountain Time(US Canada).  
UTC-06:00 — TimeZone for Central Time(US Canada).  
UTC-05:00 — TimeZone for Eastern Time(US Canada).  
UTC-04:30 — TimeZone for Caracas.  
UTC-04:00 — TimeZone for Atlantic Time(Canada).  
UTC-03:30 — TimeZone for Newfoundland.  
UTC-03:00 — TimeZone for Buenos Aires, Salvador, Brasilia.  
UTC-02:00 — TimeZone for Mid-Atlantic.  
UTC-01:00 — TimeZone for Azores, Cape Verde Is.  
UTC — TimeZone for Dublin, Edinburgh, Lisbon, London.  
UTC+01:00 — TimeZone for Amsterdam, Berlin, Bern, Rome, Stockholm, Vienna.  
UTC+02:00 — TimeZone for Cairo, Athens, Bucharest, Amman, Beirut, Jerusalem.  
UTC+03:00 — TimeZone for Kuwait, Riyadh, Baghdad.  
UTC+03:30 — TimeZone for Tehran.  
UTC+04:00 — TimeZone for Moscow, St.Petersburg, Volgograd, Tbilisi, Port Louis.  
UTC+04:30 — TimeZone for Kabul.  
UTC+05:00 — TimeZone for Islamabad, Karachi, Tashkent.  
UTC+05:30 — TimeZone for Chennai, Kolkata, Mumbai, New Delhi.  
UTC+05:45 — TimeZone for Kathmandu.  
UTC+06:00 — TimeZone for Dhaka,Astana, Ekaterinburg.  
UTC+06:30 — TimeZone for Yangon (Rangoon).  
UTC+07:00 — TimeZone for Novosibirsk, Bangkok, Hanoi, Jakarta.  
UTC+08:00 — TimeZone for Beijing, Chongqing, Hong Kong, Urumqi, Singapore.  
UTC+09:00 — TimeZone for Seoul, Irkutsk, Osaka, Sapporo, Tokyo.  
UTC+09:30 — TimeZone for Darwin, Adelaide.  
UTC+10:00 — TimeZone for Canberra, Melbourne, Sydney, Brisbane.  
UTC+11:00 — TimeZone for Solomon Is., New Caledonia, Vladivostok.  
UTC+12:00 — TimeZone for Fiji, Magadan, Auckland, Wellington.  
UTC+13:00 — TimeZone for Nuku'alofa, Samoa.  
*ntp-server* — The IP address for the Primary NTP Server.

*backup-ntp-server* — The IP address for the Secondary NTP Server.

*fetching-rate* — Specify the rate fetching time from NTP server.

## Command Mode

Global Configuration Mode

## Example

Configure the system time mode as NTP, the time zone is UTC-12:00, the primary NTP server is 133.100.9.2 and the secondary NTP server is 139.78.100.163, the fetching-rate is 11 hours:

```
T2500-28TC(config)#system-time ntp UTC-12:00 133.100.9.2 139.79.100.163
11
```

## system-time dst predefined

### Description

The **system-time dst predefined** command is used to select a predefined DST configuration and the configuration can be recycled.

### Syntax

**system-time dst predefined** [ USA | Australia | European | New-Zealand ]

### Parameter

USA | Australia | European | New-Zealand — Predefined DST mode, with four options: USA, Australia, European and New-Zealand. By default, the setting is “European”.

The DST time periods which the four predefined DST mode represents are displayed as follow:

USA: Second Sunday in March, 02:00 – First Sunday in November, 02:00.

Australia: First Sunday in October, 02:00 – First Sunday in April, 03:00.

European: Last Sunday in March, 01:00 – Last Sunday in October, 01:00.

New Zealand: Last Sunday in September, 02:00 – First Sunday in April, 03:00.

## Command Mode

Global Configuration Mode

## Example

Configure the DST period of the switch as European:

```
T2500-28TC(config)#system-time dst predefined European
```

## system-time dst date

### Description

The **system-time dst date** command is used to specify the DST configuration in Date mode. This configuration is one-off in use. By default, the current year is used as the starting time. DST time periods should be within 12 months over one/two year.

### Syntax

```
system-time dst date {smonth} {sday} {stime} {emonth} {eday} {etime} [offset]
```

### Parameter

*smonth* ——— Month to start, with the options: Jan, Feb, Mar, Apr, May, Jun, Jul, Aug, Sep, Oct, Nov, Dec

*sday* ——— Day to start, ranging from 1 to 31. Please mind that the number of days depends on the month.

*stime* ——— Time to start, in the format of hh:mm.

*emonth* ——— Month to end, with the options: Jan, Feb, Mar, Apr, May, Jun, Jul, Aug, Sep, Oct, Nov, Dec

*eday* ——— Day to end, ranging from 1 to 31. Please mind that the number of days depends on the month.

*etime* ——— Time to end, in the format of hh:mm.

*offset* ——— Specify the time adding in minutes when Daylight Saving Time comes. The value ranges from 1 to 1440 and the default value is 60 minutes. It is optional.

### Command Mode

Global Configuration Mode

### Example

Configure the DST start time as 00:00 am on April 1<sup>st</sup>, the end time as 00:00 am on October 1<sup>st</sup> and the offset as 30 minutes:

```
T2500-28TC(config)#system-time dst date Apr 1 00:00 Oct 1 00:00 30
```

## system-time dst recurring

### Description

The **system-time dst recurring** command is used to specify the DST configuration in recurring mode. This configuration is recurring in use. The time period is not restricted to be within one year.

### Syntax

```
system-time dst recurring {sweek} {sday} {smonth} {stime} {eweeek} {eday}
{emonth} {etime} [offset]
```

### Parameter

*sweek* — Week to start, with the options: first, second, third, fourth, last.

*sday* — Day to start, with the options: Sun, Mon, Tue, Wed, Thu, Fri, Sat.

*smonth* — Month to start, with options: Jan, Feb, Mar, Apr, May, Jun, Jul, Aug, Sep, Oct, Nov, Dec.

*stime* — Time to start, in the format of: hh:mm.

*eweeek* — Week to end, with options: first, second, third, fourth, last.

*eday* — Day to end, with options: Sun, Mon, Tue, Wed, Thu, Fri, Sat.

*emonth* — Month to end, with options: Jan, Feb, Mar, Apr, May, Jun, Jul, Aug, Sep, Oct, Nov, Dec.

*etime* — Time to end, in the format of: hh:mm.

*offset* — Specify the time adding in minutes when Daylight Saving Time comes. The range of value depends and the default value is 60 minutes. It is optional.

### Command Mode

Global Configuration Mode

### Example

Specify the DST start time of the switch as 2:00 am on the first Sunday in May, the end time as 2:00 am on the last Sunday in October and the offset as 45 minutes:

```
T2500-28TC(config)#system-time dst recurring first Sun May 02:00 last Sun
Oct 02:00 45
```

## hostname

### Description

The **hostname** command is used to configure the system name. To clear the system name information, please use **no hostname** command.

### Syntax

**hostname** *hostname*

**no hostname** *hostname*

### Parameter

*hostname* — System Name, ranging from 1 to 32 characters. It is the product name by default. Here it is T2500-28TC.

### Command Mode

Global Configuration Mode

### Example

Configure the system name as TPLINK:

```
T2500-28TC(config)#hostname TPLINK
```

## location

### Description

The **location** command is used to configure the system location. To clear the system location information, please use **no location** command.

### Syntax

**location** *location*

**no location** *location*

### Parameter

*location* — Device Location. It consists of 32 characters at most. It is SHENZHEN by default.

### Command Mode

Global Configuration Mode

### Example

Configure the system location as GUANGZHOU:

```
T2500-28TC(config)#location GUANGZHOU
```

## contact-info

### Description

The **contact-info** command is used to configure the system contact information.

To clear the system contact information, please use **no contact-info** command.

### Syntax

```
contact-info contact_info
```

```
no contact-info contact_info
```

### Parameter

*contact\_info* — Contact Information. It consists of 32 characters at most. It is www.tp-link.com by default.

### Command Mode

Global Configuration Mode

### Example

Configure the system contact information as www.tp-link.com:

```
T2500-28TC(config)#contact-info www.tp-link.com
```

## ip management-vlan

### Description

The **ip management-vlan** command is used to configure the management VLAN, through which you can log on to the switch. By default the management VLAN is VLAN1.

### Syntax

```
ip management-vlan {vlan-id}
```

### Parameter

*vlan-id* — VLAN ID, ranging from 1 to 4094.

### Command Mode

Global Configuration Mode

### Example

Set the VLAN6 as management VLAN:

```
T2500-28TC(config)# ip management-vlan 6
```

## ip address

### Description

The **ip address** command is used to configure the system IP address, Subnet Mask and Default Gateway. To restore to the factory defaults, please use **no ip address** command. This command should be configured in the Interface Configuration Mode of the management VLAN.

### Syntax

```
ip address {ip-addr} {ip-mask} [gateway]
```

```
no ip address
```

### Parameter

*ip-addr* — The system IP of the switch. The default system IP is 192.168.0.1.

*ip-mask* — The Subnet Mask of the switch. The default Subnet Mask is 255.255.255.0.

*gateway* — The Default Gateway of the switch. By default, it is empty.

### Command Mode

Interface Configuration Mode (interface vlan)

### Example

Configure the system IP as 192.168.0.69 and the Subnet Mask as 255.255.255.0 when the management VLAN of the switch is VLAN1:

```
T2500-28TC(config)# interface vlan 1
```

```
T2500-28TC(config-if)# ip address 192.168.0.69 255.255.255.0
```

## ip address-alloc dhcp

### Description

The **ip address-alloc dhcp** command is used to enable the DHCP Client function. When this function is enabled, the switch will obtain IP from DHCP Client server. This command should be configured in the Interface Configuration Mode of the management VLAN.

### Syntax

```
ip address-alloc dhcp
```

### Command Mode

Interface Configuration Mode (interface vlan)



### Example

Enable the DHCP Client function when the management VLAN of the switch is VLAN1:

```
T2500-28TC(config)# interface vlan 1
T2500-28TC(config-if)# ip address-alloc dhcp
```

## ip address-alloc bootp

### Description

The **ip address-alloc bootp** command is used to enable the BOOTP Protocol. When the BOOTP Protocol is enabled, the switch will obtain IP address from BOOTP Server. This command should be configured in the Interface Configuration Mode of the management VLAN.

### Syntax

```
ip address-alloc bootp
```

### Command Mode

Interface Configuration Mode (interface vlan)

### Example

Enable the BOOTP Protocol to obtain IP address from BOOTP Server when the management VLAN of the switch is VLAN1:

```
T2500-28TC(config)# interface vlan 1
T2500-28TC(config-if)# ip address-alloc bootp
```

## reset

### Description

The **reset** command is used to reset the switch's software. After resetting, all configuration of the switch will restore to the factory defaults and your current settings will be lost.

### Syntax

```
reset
```

### Command Mode

Privileged EXEC Mode

## Example

Reset the software of the switch:

```
T2500-28TC#reset
```

## reboot

### Description

The **reboot** command is used to reboot the Switch. To avoid damage, please don't turn off the device while rebooting.

### Syntax

```
reboot
```

### Command Mode

Privileged EXEC Mode

### Example

Reboot the switch:

```
T2500-28TC#reboot
```

## copy running-config startup-config

### Description

The **copy running-config startup-config** command is used to save the current settings.

### Syntax

```
copy running-config startup-config
```

### Command Mode

Privileged EXEC Mode

### Example

Save current settings:

```
T2500-28TC#copy running-config startup-config
```

## copy startup-config tftp

### Description

The **copy startup-config tftp** command is used to backup the configuration file to TFTP server.

### Syntax

```
copy startup-config tftp ip-address ip-addr filename name
```

### Parameter

*ip-addr* — IP address of the TFTP server. Both IPv4 and IPv6 addresses are supported, for example 192.168.0.1 or fe80::1234.

*name* — Specify the name for the configuration file which would be backedup.

### Command Mode

Privileged EXEC Mode

### Example

Backup the configuration files to TFTP server with the IP 192.168.0.148 and name this file config:

```
T2500-28TC# copy startup-config tftp ip-address 192.168.0.148 filename config
```

Backup the configuration files to TFTP server with the IP fe80::1234 and name this file config:

```
T2500-28TC# copy startup-config tftp ip-address fe80::1234 filename config
```

## copy tftp startup-config

### Description

The **copy tftp startup-config** command is used to download the configuration file to the switch from TFTP server.

### Syntax

```
copy tftp startup-config ip-address ip-addr filename name
```

### Parameter

*ip-addr* — IP address of the TFTP server. Both IPv4 and IPv6 addresses are supported, for example 192.168.0.1 or fe80::1234.

*name* — Specify the name for the configuration file which would be downloaded.

### Command Mode

Privileged EXEC Mode

### Example

Download the configuration file named as config to the switch from TFTP server with the IP 192.168.0.148:

```
T2500-28TC# copy tftp startup-config ip-address 192.168.0.148 filename
config
```

Download the configuration file named as config to the switch from TFTP server with the IP fe80::1234

```
T2500-28TC# copy tftp startup-config ip-address fe80::1234 filename config
```

## firmware upgrade

### Description

The **firmware upgrade** command is used to upgrade the switch system file via the TFTP server.

### Syntax

```
firmware upgrade ip-address ip-addr filename name
```

### Parameter

*ip-addr* — IP address of the TFTP server. Both IPv4 and IPv6 addresses are supported, for example 192.168.0.1 or fe80::1234.

*name* — Specify the name for the firmware file.

### Command Mode

Privileged EXEC Mode

### Example

Upgrade the switch system file named as firmware.bin via the TFTP server with the IP address 192.168.0.148:

```
T2500-28TC# firmware upgrade ip-address 192.168.0.148 filename
firmware.bin
```

Upgrade the switch system file named as firmware.bin via the TFTP server with the IP address fe80::1234

```
T2500-28TC# firmware upgrade ip-address fe80::1234 filename firmware.bin
```

## ping

### Description

The **ping** command is used to test the connectivity between the switch and one node of the network.

### Syntax

```
ping [ ip | ipv6 ] { ip_addr } [ -n count ] [ -l count ] [ -i count ]
```

### Parameter

**ip** — The type of the IP address for ping test should be IPv4.

**ipv6** — The type of the IP address for ping test should be IPv6.

**ip\_addr** — The IP address of the destination node for ping test. If the parameter ip/ipv6 is not selected, both IPv4 and IPv6 addresses are supported, for example 192.168.0.100 or fe80::1234.

**-n count** — The amount of times to send test data during Ping testing. It ranges from 1 to 10. By default, this value is 4.

**-l count** — The size of the sending data during ping testing. It ranges from 1 to 1024 bytes. By default, this value is 64.

**-i count** — The interval to send ICMP request packets. It ranges from 100 to 1000 milliseconds. By default, this value is 1000.

### Command Mode

User EXEC Mode and Privileged EXEC Mode

### Example

To test the connectivity between the switch and the network device with the IP 192.168.0.131, please specify the *count* (-l) as 512 bytes and *count* (-i) as 1000 milliseconds. If there is not any response after 8 times' Ping test, the connection between the switch and the network device is failed to establish:

```
T2500-28TC# ping 192.168.0.131 -n 8 -l 512
```

To test the connectivity between the switch and the network device with the IP fe80::1234, please specify the *count* (-l) as 512 bytes and *count* (-i) as 1000

milliseconds. If there is not any response after 8 times' Ping test, the connection between the switch and the network device is failed to establish:

```
T2500-28TC# ping fe80::1234 -n 8 -I 512
```

## tracert

### Description

The **tracert** command is used to test the connectivity of the gateways during its journey from the source to destination of the test data.

### Syntax

```
tracert [ ip | ipv6 ] ip_addr [ maxHops ]
```

### Parameter

*ip* — The type of the IP address for tracert test should be IPv4.

*ipv6* — The type of the IP address for tracert test should be IPv6.

*ip\_addr* — The IP address of the destination device. If the parameter ip/ipv6 is not selected, both IPv4 and IPv6 addresses are supported, for example 192.168.0.100 or fe80::1234.

*maxHops* — The maximum number of the route hops the test data can pass through. It ranges from 1 to 30. By default, this value is 4.

### Command Mode

User EXEC Mode and Privileged EXEC Mode

### Example

Test the connectivity between the switch and the network device with the IP 192.168.0.131. If the destination device has not been found after 20 *maxHops*, the connection between the switch and the destination device is failed to establish:

```
T2500-28TC# tracert 192.168.0.131 20
```

Test the connectivity between the switch and the network device with the IP fe80::1234. If the destination device has not been found after 20 *maxHops*, the connection between the switch and the destination device is failed to establish:

```
T2500-28TC# tracert fe80::1234 20
```

## loopback interface

### Description

The **loopback interface** command is used to test whether the port is available or not.

### Syntax

```
loopback interface { fastEthernet port | gigabitEthernet port } { internal | external }
```

### Parameter

*port* — The Fast/Gigabit Ethernet port number.

internal | external — Loopback Type. There are two options: “internal” and “external”.

### Command Mode

User EXEC Mode and Privileged EXEC Mode

### Example

Do an internal-type loopback test for Gigabit Ethernet port 25:

```
T2500-28TC# loopback interface gigabitEthernet 1/0/25 internal
```

Do an external-type loopback test for Gigabit Ethernet port 25:

```
T2500-28TC# loopback interface gigabitEthernet 1/0/25 external
```

## show system-time

### Description

The **show system-time** command is used to display the current time system and its source.

### Syntax

```
show system-time
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the time information of the switch:

```
T2500-28TC#show system-time
```

## show system-time dst

### Description

The **show system-time dst** command is used to display the DST time information of the switch.

### Syntax

```
show system-time dst
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the DST time information of the switch

```
T2500-28TC#show system-time dst
```

## show system-time ntp

### Description

The **show system-time ntp** command is used to display the NTP mode configuration information.

### Syntax

```
show system-time ntp
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the NTP mode configuration information of the switch:

```
T2500-28TC#show system-time ntp
```

## show system-info

### Description

The **show system-info** command is used to display system description, system name, device location, system contact, hardware version, firmware version, serial number, system time and running time.



## Syntax

```
show system-info
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display the system information:

```
T2500-28TC#show system-info
```

# show running-config

## Description

The **show running-config** command is used to display the current operating configuration of the system or of a specified port.

## Syntax

```
show running-config [ interface { fastEthernet port | gigabitEthernet port } ]
```

## Parameter

*port* — The Fast/Gigabit Ethernet port number.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display the system current operating configuration:

```
T2500-28TC#show running-config
```

# show cable-diagnostics interface

## Description

The **show cable-diagnostics interface** command is used to display the cable diagnostics of the connected Ethernet Port., which facilitates you to check the connection status of the cable connected to the Switch, locate and diagnose the trouble spot of the network.

## Syntax

```
show cable-diagnostics interface { fastEthernet port | gigabitEthernet port }
```

**Parameter**

*port* — The number of the port which is selected for Cable test.

**Command Mode**

Privileged EXEC Mode and Any Configuration Mode

**Example**

Show the cable-diagnostics of Gigabit Ethernet port 25:

```
T2500-28TC#show cable-diagnostics interface gigabitEthernet 1/0/25
```

## Chapter 23 IPv6 Address Configuration Commands

The IPv6 address configuration commands are provided in the Interface VLAN Mode. Type **enable** →**configure**→**interface vlan** {*vlan-id*} to enter the Interface Configuration Mode of the management VLAN. By default the management VLAN is VLAN1. You can use the command **ip management-vlan** {*vlan-id*} in the Global Configuration Mode to configure the management VLAN.

### ipv6 enable

#### Description

This command is used to enable the IPv6 function globally. The IPv6 function should be enabled before the IPv6 address configuration management. By default it is enabled. If the IPv6 function is disabled, the corresponding IPv6 netstack and IPv6-based modules will be invalid, for example SSHv6, SSLv6, TFTPv6 etc. To disable the IPv6 function, please use **no ipv6 enable** command.

#### Syntax

```
ipv6 enable
no ipv6 enable
```

#### Command Mode

Interface Configuration Mode (interface vlan)

#### Example

Enable the IPv6 function when the management VLAN of the switch is VLAN1:

```
T2500-28TC(config)# interface vlan 1
T2500-28TC(config-if)# ipv6 enable
```

### ipv6 address autoconfig

#### Description

This command is used to enable the automatic configuration of the ipv6 link-local address. The switch has only one ipv6 link-local address, which can be configured automatically or manually. The general ipv6 link-local address has the prefix as fe80::/10. IPv6 routers cannot forward packets that have link-local source or destination addresses to other links. The autoconfigured ipv6 link-local address is in EUI-64 format. To verify the uniqueness of the link-local address, the manually

configured ipv6 link-local address will be deleted when the autoconfigured ipv6 link-local address takes effect.

### Syntax

```
ipv6 address autoconfig
```

### Configuration Mode

Interface Configuration Mode (interface vlan)

### Example

Enable the automatic configuration of the ipv6 link-local address when the management VLAN of the switch is VLAN1:

```
T2500-28TC(config)# interface vlan 1
T2500-28TC(config-if)# ipv6 address autoconfig
```

## ipv6 address link-local

### Description

The **ipv6 address link-local** command is used to configure the system ipv6 link-local address manually. To delete the configured link-local address, please use **no ipv6 address link-local** command.

### Syntax

```
ipv6 address ipv6-addr link-local
no ipv6 address ipv6-addr link-local
```

### Parameter

*ipv6-addr* — The link-local address of the switch. It should be a standardized IPv6 address with the prefix fe80::/10, otherwise this command will be invalid.

### Configuration Mode

Interface Configuration Mode (Interface vlan)

### Example

Configure the link-local address as fe80::1234 when the management VLAN of the switch is VLAN1:

```
T2500-28TC(config)# interface vlan 1
T2500-28TC(config-if)# ipv6 address fe80::1234 link-local
```

## ipv6 address dhcp

### Description

The **ipv6 address dhcp** command is used to enable the DHCPv6 Client function. When this function is enabled, the switch will try to obtain IP from DHCPv6 server. To delete the allocated IP from DHCPv6 server and disable the DHCPv6 Client function, please use **no ipv6 address dhcp** command.

### Syntax

**ipv6 address dhcp**

**no ipv6 address dhcp**

### Configuration Mode

Interface Configuration Mode (interface vlan)

### Example

Enable the DHCP Client function when the management VLAN of the switch is VLAN1:

```
T2500-28TC(config)# interface vlan 1
T2500-28TC(config-if)# ipv6 address dhcp
```

## ipv6 address ra

### Description

This command is used to configure the switch's global IPv6 address according to the address prefix and other configuration parameters from its received RA(Router Advertisement) message. To disable this function, please use **no ipv6 address ra** command.

### Syntax

**ipv6 address ra**

**no ipv6 address ra**

### Configuration Mode

Interface Configuration Mode (interface vlan)

### Example

Enable the automatic ipv6 address configuration function to obtain IPv6 address through the RA message when the management VLAN of the switch is VLAN1:

```
T2500-28TC(config)# interface vlan 1
T2500-28TC(config-if)# ipv6 address ra
```

## ipv6 address eui-64

### Description

This command is used to manually configure a global IPv6 address with an extended unique identifier (EUI) in the low-order 64 bits on the interface. Specify only the network prefix. The last 64 bits are automatically computed from the switch MAC address. To remove an EUI-64 IPv6 address from the interface, please use the **no ipv6 address eui-64** command.

### Syntax

```
ipv6 address ipv6-addr eui-64
no ipv6 address ipv6-addr eui-64
```

### Parameter

*ipv6-addr* — Global IPv6 address with 64 bits network prefix, for example 3ffe::1/64.

### Configuration Mode

Interface Configuration Mode (interface vlan)

### Example

Configure an EUI-64 global address on the interface with the network prefix 3ffe::1/64

```
T2500-28TC(config)# interface vlan 1
T2500-28TC(config-if)# ipv6 address 3ffe::1/64 eui-64
```

## ipv6 address

### Description

This command is used to manually configure a global IPv6 address on the interface. To remove a global IPv6 address from the interface, please use **no ipv6 address** command.

### Syntax

```
ipv6 address ipv6-addr
```

```
no ipv6 address ipv6-addr
```

### Parameter

*ipv6-addr* — Global IPv6 address with network prefix, for example 3ffe::1/64.

### Configuration Mode

Interface Configuration Mode (interface vlan)

### Example

Configure the global address 3001::1/64 on the interface:

```
T2500-28TC(config)# interface vlan 1
T2500-28TC(config-if)# ipv6 address 3001::1/64
```

## show ipv6 interface vlan

### Description

This command is used to display the configured ipv6 information of the management vlan,interface, including ipv6 function status, link-local address and global address, ipv6 multicast groups etc.

### Syntax

```
show ipv6 interface vlan vlan-id
```

### Parameter

*vlan-id* — The VLAN ID of the management VLAN.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the ipv6 information of the management vlan interface:

```
T2500-28TC(config)# show ipv6 interface vlan 1
```

## Chapter 24 Ethernet Configuration Commands

Ethernet Configuration Commands can be used to configure the Bandwidth Control, Negotiation Mode and Storm Control for Ethernet ports.

### interface fastEthernet

#### Description

The **interface fastEthernet** command is used to enter the interface fastEthernet Configuration Mode and configure the corresponding Fast Ethernet port.

#### Syntax

```
interface fastEthernet port
```

#### Parameter

*port* — The Fast/Gigabit Ethernet port number.

#### Command Mode

Global Configuration Mode

#### Example

To enter the Interface fastEthernet Configuration Mode and configure Fast Ethernet port 2:

```
T2500-28TC(config)#interface fastEthernet 1/0/2
```

### interface range fastEthernet

#### Description

The **interface range fastEthernet** command is used to enter the interface range fastEthernet Configuration Mode and configure multiple Fast Ethernet ports at the same time.

#### Syntax

```
interface range fastEthernet port-list
```

#### Parameter

*port-list* — The list of Fast Ethernet ports.

#### Command Mode

Global Configuration Mode



## User Guidelines

Command in the **Interface Range fastEthernet** Mode is executed independently on all ports in the range. It does not effect the execution on the other ports at all if the command results in an error on one port.

## Example

To enter the Interface Range fastEthernet Configuration Mode, and configure ports 1, 2, 3, 6, 7 and 9 at the same time by adding them to one port-list:

```
T2500-28TC(config)#interface range fastEthernet 1/0/1-3,1/0/6-7,1/0/9
```

## interface gigabitEthernet

### Description

The **interface gigabitEthernet** command is used to enter the interface gigabitEthernet Configuration Mode and configure the corresponding Gigabit Ethernet port.

### Syntax

```
interface gigabitEthernet port
```

### Parameter

*port* — The Fast/Gigabit Ethernet port number.

### Command Mode

Global Configuration Mode

### Example

To enter the Interface gigabitEthernet Configuration Mode and configure Gigabit Ethernet port 25:

```
T2500-28TC(config)#interface gigabitEthernet 1/0/25
```

## interface range gigabitEthernet

### Description

The **interface range gigabitEthernet** command is used to enter the interface range gigabitEthernet Configuration Mode and configure multiple Gigabit Ethernet ports at the same time.

### Syntax

```
interface range gigabitEthernet port-list
```

**Parameter**

*port-list* — The list of Gigabit Ethernet ports.

**Command Mode**

Global Configuration Mode

**User Guidelines**

Command in the **Interface Range gigabitEthernet** Mode is executed independently on all ports in the range. It does not affect the execution on the other ports at all if the command results in an error on one port.

**Example**

To enter the Interface Range gigabitEthernet Configuration Mode, and configure Gigabit Ethernet ports 25, 26 and 28 at the same time by adding them to one port-list:

```
T2500-28TC(config)# interface range gigabitEthernet 1/0/25-26,1/0/28
```

## description

**Description**

The **description** command is used to add a description to the Ethernet port. To clear the description of the corresponding port, please use **no description** command.

**Syntax**

**description** *string*

**no description**

**Parameter**

*string* — Content of a port description, ranging from 1 to 16 characters.

**Command Mode**

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

**Example**

Add a description Port\_5 to Fast Ethernet port 5:

```
T2500-28TC(config)#interface fastEthernet 1/0/5
```

```
T2500-28TC(config-if)#description Port_5
```

## shutdown

### Description

The **shutdown** command is used to disable an Ethernet port. To enable this port again, please use **no shutdown** command.

### Syntax

**shutdown**

**no shutdown**

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

Disable Gigabit Ethernet port 25:

```
T2500-28TC(config)#interface gigabitEthernet 1/0/25
```

```
T2500-28TC(config-if)#shutdown
```

## flow-control

### Description

The **flow-control** command is used to enable the flow-control function for a port. To disable the flow-control function for this corresponding port, please use **no flow-control** command. With the flow-control function enabled, the Ingress Rate and Egress Rate can be synchronized to avoid packet loss in the network.

### Syntax

**flow-control**

**no flow-control**

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

Enable the flow-control function for Gigabit Ethernet port 25:

```
T2500-28TC(config)#interface gigabitEthernet 1/0/25
```

```
T2500-28TC(config-if)#flow-control
```

## media-type

### Description

The **media-type** command is used to configure the media type of Combo port. For a Combo port, the media type should be configured before you set its speed and mode.

### Syntax

```
media-type { rj45 | sfp }
```

### Parameter

*rj45* | *sfp* — Media type.

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

### Example

Configure the media type of Combo port 28T as “SFP”:

```
T2500-28TC(config)# interface gigabitEthernet 1/0/28
T2500-28TC(config-if)# media-type sfp
```

## duplex

### Description

The **duplex** command is used to configure the Duplex Mode for an Ethernet port. To return to the default configuration, please use **no duplex** command.

### Syntax

```
duplex { full | half }
```

```
no duplex
```

### Parameter

full | half — The duplex mode of the Ethernet port. There are two options: full-duplex mode (default) and half-duplex mode.

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

Configure the Duplex Mode as full-duplex for Gigabit Ethernet port 25:

```
T2500-28TC(config)#interface gigabitEthernet 1/0/25
T2500-28TC(config-if)#duplex full
```

## speed

### Description

The **speed** command is used to configure the Speed Mode for an Ethernet port. To return to the default configuration, please use **no speed** command.

### Syntax

```
speed { 10 | 100 | 1000 | auto }
no speed
```

### Parameter

10 | 100 | 1000 | auto — The speed mode of the Ethernet port. There are four options: 10Mbps, 100Mbps, 1000Mbps and Auto negotiation mode (default).

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

Configure the Speed Mode as 100Mbps for Gigabit Ethernet port 25:

```
T2500-28TC(config)#interface gigabitEthernet 1/0/25
T2500-28TC(config-if)#speed 100
```

## storm-control broadcast

### Description

The **storm-control broadcast** command is used to enable the broadcast control function. To disable the broadcast control function, please use **no storm-control broadcast** command. Broadcast control function allows the switch to filter broadcast in the network. If the transmission rate of the broadcast packets exceeds the set bandwidth, the packets will be automatically discarded to avoid network broadcast storm.

### Syntax

```
storm-control broadcast [rate rate]
no storm-control broadcast
```

**Parameter**

*rate* — Specify the bandwidth for receiving broadcast packets on the port. The packet traffic exceeding the bandwidth will be discarded. By default, the value is “128K”.

**Command Mode**

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

**Example**

Enable the broadcast control function for Fast Ethernet port 5:

```
T2500-28TC(config)#interface fastEthernet 1/0/5
T2500-28TC(config-if)#storm-control broadcast
```

## storm-control multicast

**Description**

The **storm-control multicast** command is used to enable the multicast control function. To disable the multicast control function, please use **no storm-control multicast** command. Multicast control function allows the switch to filter multicast in the network. If the transmission rate of the multicast packets exceeds the set bandwidth, the packets will be automatically discarded to avoid network broadcast storm.

**Syntax**

```
storm-control multicast [rate rate]
no storm-control multicast
```

**Parameter**

*rate* — Select the bandwidth for receiving multicast packets on the port. The packet traffic exceeding the bandwidth will be discarded. By default, the value is “128K”.

**Command Mode**

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

**Example**

Enable the multicast control function for Fast Ethernet port 5:

```
T2500-28TC(config)#interface fastEthernet 1/0/5
```

```
T2500-28TC(config-if)#storm-control multicast
```

## storm-control unicast

### Description

The **storm-control unicast** command is used to enable the unicast control function. To disable the unicast control function, please use **no storm-control unicast** command. Unicast control function allows the switch to filter UL frame in the network. If the transmission rate of the UL frames exceeds the set bandwidth, the packets will be automatically discarded to avoid network broadcast storm.

### Syntax

```
storm-control unicast [rate rate]
```

```
no storm-control unicast
```

### Parameter

*rate* — Select the bandwidth for receiving UL-Frame on the port. The packet traffic exceeding the bandwidth will be discarded. By default, the value is “128K”.

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

Enable the unicast control function for Fast Ethernet port 5:

```
T2500-28TC(config)#interface fastEthernet 1/0/5
```

```
T2500-28TC(config-if)#storm-control unicast
```

## bandwidth

### Description

The **bandwidth** command is used to configure the bandwidth limit for an Ethernet port. To disable the bandwidth limit, please use **no bandwidth** command.

### Syntax

```
bandwidth { [ingress ingress-rate] [egress egress-rate] }
```

**no bandwidth** { all | ingress | egress }

### Parameter

*ingress-rate* —— Specify the bandwidth for receiving packets. Range: 1-100000 for the megaport, 1-1000000 for the gigaport.

*egress-rate* —— Specify the bandwidth for sending packets. Range:1-100000 for the megaport, 1- 1000000 for the gigaport.

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

Configure the ingress-rate as 5120Kbps and egress-rate as 1024Kbps for Fast Ethernet port 5:

```
T2500-28TC(config)#interface fastEthernet 1/0/5
T2500-28TC(config-if)#bandwidth ingress 5120 egress 1024
```

## clear counters

### Description

The **clear counters** command is used to clear the statistic information of all the Ethernet ports.

### Syntax

**clear counters**

### Command Mode

Global Configuration Mode

### Example

Clear the statistic information of all Ethernet ports

```
T2500-28TC(config)#clear counters
```

## show interface status

### Description

The **show interface status** command is used to display the connective-status of an Ethernet port.



## Syntax

```
show interface [fastEthernet port | gigabitEthernet port] status
```

## Parameter

*port* — The Fast/Gigabit Ethernet port number.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display the connective-status of all Ethernet ports:

```
T2500-28TC(config)#show interface status
```

Display the connective-status of Fast Ethernet port 1:

```
T2500-28TC(config)#show interface fastEthernet 1/0/1 status
```

# show interface counters

## Description

The **show interface counters** command is used to display the statistic information of an Ethernet port.

## Syntax

```
show interface [fastEthernet port | gigabitEthernet port] counters
```

## Parameter

*port* — The Fast/Gigabit Ethernet port number. By default, the statistic information of all ports is displayed.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display the statistic information of all Ethernet ports:

```
T2500-28TC(config)#show interface counters
```

Display the statistic information of Gigabit Ethernet port 25:

```
T2500-28TC(config)#show interface gigabitEthernet 1/0/25 counters
```

## show interface description

### Description

The **show interface description** command is used to display the description of all ports or an Ethernet port.

### Syntax

```
show interface [fastEthernet port | gigabitEthernet port] description
```

### Parameter

*port* — The Fast/Gigabit Ethernet port number.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the description of all Ethernet ports:

```
T2500-28TC(config)#show interface description
```

## show interface flowcontrol

### Description

The **show interface flowcontrol** command is used to display the flow-control information of an Ethernet port.

### Syntax

```
show interface [ fastEthernet port | gigabitEthernet port ] flowcontrol
```

### Parameter

*port* — The Fast/Gigabit Ethernet port number.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the flow-control information of all Ethernet ports:

```
T2500-28TC#show interface flowcontrol
```

## show interface configuration

### Description

The **show interface configuration** command is used to display the configurations of an Ethernet port, including Port-status, Flow Control, Negotiation Mode and Port-description.

### Syntax

```
show interface [ fastEthernet port | gigabitEthernet port ] configuration
```

### Parameter

*port* — The Fast/Gigabit Ethernet port number.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the configurations of all Ethernet ports:

```
T2500-28TC(config)#show interface configuration
```

## show storm-control

### Description

The **show storm-control** command is used to display the storm-control information of an Ethernet port.

### Syntax

```
show storm-control [ interface { fastEthernet port | gigabitEthernet port |  
range fastEthernet port-list | range gigabitEthernet port-list } ]
```

### Parameter

*port* — The Fast/Gigabit Ethernet port number.

*port-list* — The list of Fast/Gigabit Ethernet ports.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the storm-control information of port Gigabit Ethernet port 25:

```
T2500-28TC(config)#show storm-control interface gigabitEthernet 1/0/25
```

Display the storm-control information of port Fast Ethernet ports 4,5,6,7:

```
T2500-28TC(config)#show storm-control interface range fastEthernet
1/0/4-7
```

## show bandwidth

### Description

The **show bandwidth** command is used to display the bandwidth-limit information of Ethernet port.

### Syntax

```
show bandwidth [ interface { fastEthernet port | gigabitEthernet port | range
fastEthernet port-list | range gigabitEthernet port-list } ]
```

### Parameter

*port* — The Fast/Gigabit Ethernet port number.

*port-list* — The list of Fast/Gigabit Ethernet ports.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the bandwidth-limit information of Gigabit Ethernet port 25:

```
T2500-28TC(config)#show bandwidth interface gigabitEthernet 1/0/25
```

Display the bandwidth-limit information of Fast Ethernet ports 2, 6, 7, 8:

```
T2500-28TC(config)#show bandwidth interface range fastEthernet
1/0/2,1/0/6-8
```

## Chapter 25 QoS Commands

QoS (Quality of Service) function is used to optimize the network performance. It provides you with network service experience of a better quality.

### qos

#### Description

The **qos** command is used to configure CoS (Class of Service) based on port. To return to the default configuration, please use **no qos** command.

#### Syntax

```
qos cos-id
```

```
no qos
```

#### Parameter

*cos-id* — The priority of port. It ranges from 0 to 7, which represent CoS0-CoS7 respectively. By default, the priority is 0.

#### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

#### User Guidelines

Port priority is one property of the port. When the port priority is specified, the data will be classified into the egress queue based on the CoS value of the ingress port and the mapping relation between the CoS and TC in IEEE 802.1P.

#### Example

Configure the priority of port 5 as 3:

```
T2500-28TC(config)#interface fastEthernet 1/0/5
T2500-28TC(config-if)#qos 3
```

### qos cos

#### Description

The **qos cos** command is used to enable the mapping relation between IEEE802.1P Priority and TC egress queue. To disable the mapping relation, please use **no qos cos** command.

## Syntax

```
qos cos
no qos cos
```

## Command Mode

Global Configuration Mode

## User Guidelines

IEEE 802.1P gives the Pri field in IEEE 802.1Q tag a recommended definition. When the mapping relation between IEEE 802.1P Priority and TC egress queue is enabled, the data will be classified into the egress queue based on this mapping relation.

## Example

Enable the mapping relation between IEEE 802.1P Priority and egress queue:

```
T2500-28TC(config)#qos cos
```

# qos dscp

## Description

The **qos dscp** command is used to enable the mapping relation between DSCP Priority and TC egress queue. To disable the mapping relation, please use **no qos dscp** command.

## Syntax

```
qos dscp
no qos dscp
```

## Command Mode

Global Configuration Mode

## User Guidelines

DSCP (DiffServ Code Point) is a new definition to IP ToS field given by IEEE. DSCP priorities are mapped to the corresponding 802.1p priorities. IP datagram will be classified into the egress queue based on the mapping relation between DSCP priority and TC egress queue.

## Example

Enable the mapping relation between DSCP Priority and egress queue:

```
T2500-28TC(config)#qos dscp
```

## qos queue cos-map

### Description

The **qos queue cos-map** command is used to configure the mapping relation between IEEE 802.1P priority tag/IEEE 802.1Q tag, CoS value and the TC egress queue. To return to the default configuration, please use **no qos queue cos-map** command. When 802.1P Priority is enabled, the packets with 802.1Q tag are mapped to different priority levels based on 802.1P priority mode. The untagged packets are mapped based on port priority mode.

### Syntax

```
qos queue cos-map tag/cos-id tc-id
```

```
no qos queue cos-map
```

### Parameter

*tag/cos-id* —— The 8 priority levels defined by IEEE 802.1P or the priority level the packets with tag are mapped to, which ranges from CoS 0 to CoS 7.

*tc-id* —— The egress queue the packets with tag are mapped to. It ranges from 0 to 3, which represents TC0, TC1, TC2, TC3 respectively.

### Command Mode

Global Configuration Mode

### User Guidelines

1. By default, the mapping relation between tag/cos and the egress queue is: 0-TC0, 1-TC0, 2-TC1, 3-TC1, 4-TC2, 5-TC2, 6-TC3, 7-TC3
2. Among the priority levels TC0-TC3, the bigger value, the higher priority.

### Example

Map CoS 5 to TC 2.:

```
T2500-28TC(config)#qos queue cos-map 5 2
```

## qos queue dscp-map

### Description

The **qos queue dscp-map** command is used to configure the mapping relation between DSCP Priority and the TC egress queue. To return to the default configuration, please use **no qos queue dscp-map** command. DSCP (DiffServ Code Point) is a new definition to IP ToS field given by IEEE. This field is used to

divide IP datagram into 64 priorities. When DSCP Priority is enabled, IP datagram are mapped to different priority levels based on DSCP priority mode; non-IP datagram with IEEE 802.1Q tag are mapped to different priority levels based on IEEE 802.1P priority mode if IEEE 802.1P Priority is enabled; the untagged non-IP datagram are mapped based on port priority mode.

### Syntax

```
qos queue dscp-map dscp-list tc-id
```

```
no qos queue dscp-map
```

### Parameter

*dscp-list* — List of DSCP value. One or several DSCP values can be typed using comma to separate. Use a hyphen to designate a range of values, for instance, 1,4-7,11 indicates choosing 1,4,5,6,7,11. The DSCP value ranges from 0 to 63.

*tc-id* — The egress queue the packets with tag are mapped to. It ranges from 0 to 3, which represents TC0, TC1, TC2, TC3 respectively.

### Command Mode

Global Configuration Mode

### User Guidelines

1. By default, the mapping relation between tag and the egress queue is:  
(0-15)-TC0, (16-31)-TC1, (32-47)-TC2, (48-63)-TC3
2. Among the priority levels TC0-TC3, the bigger value, the higher priority.

### Example

Map DSCP values 10-12 to TC 2:

```
T2500-28TC(config)#qos queue dscp-map 10-12 2
```

## qos queue mode

### Description

The **qos queue mode** command is used to configure the Schedule Mode. To return to the default configuration, please use **no qos queue mode** command. When the network is congested, the program that many packets complete for resources must be solved, usually in the way of queue scheduling. The switch will control the forwarding sequence of the packets according to the priority



queues and scheduling algorithms you set. On this switch, the priority levels are labeled as TC0, TC1... TC3.

### Syntax

**qos queue mode** { sp | wrr | sp+wrr | equ }

**no qos queue mode**

### Parameter

**sp** — Strict-Priority Mode. In this mode, the queue with higher priority will occupy the whole bandwidth. Packets in the queue with lower priority are sent only when the queue with higher priority is empty.

**wrr** — Weight Round Robin Mode. In this mode, packets in all the queues are sent in order based on the weight value for each queue. The weight value ratio of TC0, TC1, TC2 and TC3 is 1:2:4:8.

**sp+wrr** — Strict-Priority + Weight Round Robin Mode. In this mode, the switch provides two scheduling groups, SP group and WRR group. Queues in SP group and WRR group are scheduled strictly based on Strict-Priority mode while the queues inside WRR group follow the WRR mode. In SP + WRR mode, TC3 is the SP group; TC0, TC1 and TC2 belong to the WRR group and the weight value ratio of TC0, TC1 and TC2 is 1:2:4. In this way, when scheduling queues, the switch allows TC3 to occupy the whole bandwidth following the SP mode and the TC0, TC1 and TC2 in the WRR group will take up the bandwidth according to their ratio 1:2:4.

**equ** — Equal-Mode. In this mode, all the queues occupy the bandwidth equally. The weight value ratio of all the queues is 1:1:1:1.

### Command Mode

Global Configuration Mode

### Example

Specify the Schedule Mode as Weight Round Robin Mode:

```
T2500-28TC(config)#qos queue mode wrr
```

## show qos interface

### Description

The **show qos interface** command is used to display the configuration of QoS based on port priority.

## Syntax

```
show qos interface [ fastEthernet port | gigabitEthernet port | range
fastEthernet port-list | range gigabitEthernet port-list ]
```

## Parameter

*port* — The Fast/Gigabit Ethernet port number.

*port-list* — The list of Ethernet ports.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display the configuration of QoS for Fast Ethernet port 5:

```
T2500-28TC#show qos interface fastEthernet 1/0/5
```

Display the configuration of QoS for Fast Ethernet ports 7 to 16:

```
T2500-28TC#show qos interface range fastEthernet 1/0/7-16
```

# show qos cos-map

## Description

The **show qos cos-map** command is used to display the configuration of IEEE802.1P Priority and the mapping relation between cos-id and tc-id.

## Syntax

```
show qos cos-map
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display the configuration of IEEE 802.1P Priority and the mapping relation between cos-id and tc-id:

```
T2500-28TC#show qos cos-map
```

# show qos dscp-map

## Description

The **show qos dscp-map** command is used to display the configuration of DSCP Priority.

### Syntax

```
show qos dscp-map
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the configuration of DSCP Priority:

```
T2500-28TC#show qos dscp-map
```

## show qos queue mode

### Description

The **show qos queue mode** command is used to display the schedule rule of the egress queues.

### Syntax

```
show qos queue mode
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the schedule rule of the egress queues:

```
T2500-28TC#show qos queue mode
```

## show qos status

### Description

The **show qos status** command is used to display the status of IEEE 802.1P priority and DSCP priority.

### Syntax

```
show qos status
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the status of IEEE 802.1P priority and DSCP priority:

```
T2500-28TC#show qos status
```

## Chapter 26 Port Mirror Commands

Port Mirror refers to the process of forwarding copies of packets from one port to a monitoring port. Usually, the monitoring port is connected to data diagnose device, which is used to analyze the monitored packets for monitoring and troubleshooting the network.

### monitor session destination interface

#### Description

The **monitor session destination interface** command is used to configure the monitoring port. Each monitor session has only one monitoring port. To change the monitoring port, please use the **monitor session destination interface** command by changing the port value. To delete the corresponding monitor session configuration, please use **no monitor session** command.

#### Syntax

```
monitor session session_num destination interface { fastEthernet port |
gigabitEthernet port }
no monitor session session_num
```

#### Parameter

*session\_num* — The monitor session number, the value of which is 1.  
*port* — The Fast/Gigabit Ethernet port number.

#### Command Mode

Global Configuration Mode

#### Example

Create monitor session 1 and configure Fast Ethernet port 1 as the monitoring port:

```
T2500-28TC(config)#monitor session 1 destination interface fastEthernet
1/0/1
```

Delete the monitor session 1:

```
T2500-28TC(config)#no monitor session 1
```

## monitor session source interface

### Description

The **monitor session source interface** command is used to configure the monitored port. To delete the corresponding monitored port, please use **no monitor session source interface** command.

### Syntax

```
monitor session session_num source interface { fastEthernet port-list | gigabitEthernet port-list } mode
```

```
no monitor session session_num source interface { fastEthernet port-list | gigabitEthernet port-list } mode
```

### Parameter

*session\_num* —— The monitor session number, the value of which is 1.

*port-list* —— List of monitored port. It is multi-optional.

*mode* —— The monitor mode. There are three options: rx, tx and both. Rx (ingress monitoring mode), means the incoming packets received by the monitored port will be copied to the monitoring port. TX (egress monitoring mode), indicates the outgoing packets sent by the monitored port will be copied to the monitoring port. Both (ingress and egress monitoring), presents the incoming packets received and the outgoing packets sent by the monitored port will both be copied to the monitoring port.

### Command Mode

Global Configuration Mode

### User Guidelines

1. The monitoring port is corresponding to current interface configuration mode.
2. Monitored ports number is not limited, but it can't be the monitoring port at the same time.
3. Whether the monitoring port and monitored ports are in the same VLAN or not is not demanded strictly.
4. The monitoring port and monitored ports cannot be link-aggregation member.

### Example

Create monitor session 1, then configure Fast Ethernet port 4, 5, 7 as monitored ports and enable ingress monitoring:

```
T2500-28TC(config)#monitor session 1 source interface fastEthernet  
1/0/4-5,1/0/7 rx
```

Delete the Fast Ethernet port 4 in monitor session 1 and its configuration:

```
T2500-28TC(config)#no monitor session 1 source interface fastEthernet  
1/0/4 rx
```

## show monitor session

### Description

The **show monitor session** command is used to display the configuration of port monitoring.

### Syntax

```
show monitor session [session_num]
```

### Parameter

*session\_num* — The monitor session number, the value of which is 1.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the monitoring configuration of monitor session 1:

```
T2500-28TC(config)#show monitor session 1
```

## Chapter 27 Port isolation Commands

Port Isolation provides a method of restricting traffic flow to improve the network security by forbidding the port to forward packets to the ports that are not on its forwarding port list.

### port isolation

#### Description

The **port isolation** command is used to configure the forward port list of a port, so that this port can only communicate with the ports on its port list. To delete the corresponding configuration, please use **no port isolation** command.

#### Syntax

```
port isolation { [fa-forward-list fa-forward-list] [gi-forward-list gi-forward-list] }  
no port isolation
```

#### Parameter

*fa-forward-list* —— Configure Fast Ethernet ports to the forward port list. It is optional.

*gi-forward-list* —— Configure Gigabit Ethernet ports to the forward port list. It is optional.

#### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

#### Example

Set Gigabit Ethernet ports 25-27 to the forward port list of Gigabit Ethernet 28:

```
T2500-28TC(config)#interface range gigabitEthernet 1/0/28  
T2500-28TC(config-if-range)#port isolation gi-forward-list 1/0/25-27
```

Set all the Ethernet ports to forward port list of Fast Ethernet port 2, namely restore to the default setting:

```
T2500-28TC(config)#interface fastEthernet 1/0/2  
T2500-28TC(config-if-range)#no port isolation
```

## show port isolation

### Description

The **show port isolation** command is used to display the forward port list of a port.

### Syntax

```
show port isolation interface [ fastEthernet port | gigabitEthernet port ]
```

### Parameter

*port* — The number of Ethernet port you want to show its forward port list, in the format of 1/0/2.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the forward-list of Fast Ethernet port 3:

```
T2500-28TC#show port isolation interface fastEthernet 1/0/3
```

Display the forward-list of all Ethernet ports:

```
T2500-28TC#show port isolation interface
```



## Chapter 28 Loopback Detection Commands

With loopback detection feature enabled, the switch can detect loops using loopback detection packets. When a loop is detected, the switch will display an alert or further block the corresponding port according to the configuration.

### loopback-detection(global)

#### Description

The **loopback-detection** command is used to enable the loopback detection function globally. To disable it, please use **no loopback-detection** command.

#### Syntax

**loopback-detection**

**no loopback-detection**

#### Command Mode

Global Configuration Mode

#### Example

Enable the loopback detection function globally:

```
T2500-28TC(config)#loopback-detection
```

### loopback-detection interval

#### Description

The **loopback-detection interval** command is used to define the interval of sending loopback detection packets from switch ports to network, aiming at detecting network loops periodically.

#### Syntax

**loopback-detection interval** *interval-time*

#### Parameter

*interval-time* — The interval of sending loopback detection packets. It ranges from 1 to 1000 seconds. By default, this value is 30.

#### Command Mode

Global Configuration Mode

## Example

Specify the interval-time as 50 seconds:

```
T2500-28TC(config)#loopback-detection interval 50
```

## loopback-detection recovery-time

### Description

The **loopback-detection recovery-time** command is used to configure the time after which the blocked port would automatically recover to normal status.

### Syntax

```
loopback-detection recovery-time recovery-time
```

### Parameter

*recovery-time* — The time after which the blocked port would automatically recover to normal status, and the loopback detection would restart. It is integral times of detection interval, ranging from 3 to 100 and the default value is 3.

### Command Mode

Global Configuration Mode

### Example

Configure the recovery-time as 3 times of detection interval:

```
T2500-28TC(config)#loopback-detection recovery-time 3
```

## loopback-detection(interface)

### Description

The **loopback-detection** command is used to enable the loopback detection function of the specified port. To disable it, please use **no loopback-detection** command.

### Syntax

```
loopback-detection
```

```
no loopback-detection
```

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

Enable the loopback detection function of Gigabit Ethernet ports 25-27:

```
T2500-28TC(config)#interface range gigabitEthernet 1/0/25-27
T2500-28TC(config-if-range)#loopback-detection
```

## loopback-detection config

### Description

The **loopback-detection config** command is used to configure the process-mode and recovery-mode for the ports by which the switch copes with the detected loops.

### Syntax

```
loopback-detection config [ process-mode { alert | port-based } ]
[ recovery-mode { auto | manual } ]
```

### Parameter

**process-mode** — The mode how the switch processes the detected loops.

**alert:** when a loop is detected, display an alert.

**port based:** when a loop is detected, display an alert and block the port.

**recovery-mode** — The mode how the blocked port recovers to normal status.

**auto:** block status can be automatically removed after recovery time.

**manual:** block status can only be removed manually.

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

Configure the loopback detection process-mode as port-based and recovery-mode as manual for Gigabit Ethernet port 25:

```
T2500-28TC(config)#interface gigabitEthernet 1/0/25
T2500-28TC(config-if)#loopback-detection config process-mode port-based
recovery-mode manual
```

## loopback-detection recover

### Description

The **loopback-detection recover** command is used to remove the block status of selected ports, recovering the blocked ports to normal status,

### Syntax

```
loopback-detection recover
```

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

Recover the blocked Gigabit Ethernet port 25 to normal status:

```
T2500-28TC(config)#interface gigabitEthernet 1/0/25
T2500-28TC(config-if)#loopback-detection recover
```

## show loopback-detection global

### Description

The **show loopback-detection global** command is used to display the global configuration of loopback detection function such as loopback detection global status, loopback detection interval and loopback detection recovery time.

### Syntax

```
show loopback-detection global
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the global configuration of loopback detection function:

```
T2500-28TC#show loopback-detection global
```

## show loopback-detection interface

### Description

The **show loopback-detection interface** command is used to display the configuration of loopback detection function and the status of all ports or of a specified Fast/Gigabit Ethernet port.

### Syntax

```
show loopback-detection interface [ fastEthernet port | gigabitEthernet port]
```

### Parameter

*port* — The Fast/Gigabit Ethernet port number.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the configuration of loopback detection function and the status of Fast Ethernet port 5:

```
T2500-28TC#show loopback-detection interface fastEthernet 1/0/5
```

Display the configuration of loopback detection function and the status of all ports:

```
T2500-28TC#show loopback-detection interface
```

## Chapter 29 DDM Commands

The DDM (Digital Diagnostic Monitoring) function allows the user to monitor the status of the SFP modules inserted into the SFP ports on the switch. The user can choose to shut down the monitoring SFP port automatically when specified parameter exceeds the alarm threshold or warning threshold. The monitoring parameters include: Temperature, Voltage, Bias Current, Tx Power and Rx Power.

### ddm state enable

#### Description

The **ddm state enable** command is used to enable the DDM function on the specified SFP port.

Use the **no ddm state enable** command to disable the DDM function on this port.

#### Syntax

**ddm state enable**

**no ddm state enable**

#### Default Setting

Enabled on all the SFP ports.

#### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

#### Example

Enable DDM function on port 1/0/25:

```
T2500-28TC(config)#interface gigabitEthernet 1/0/25
T2500-28TC(config-if)#ddm state enable
```

### ddm shutdown

#### Description

The **ddm shutdown** command is used to configure whether to shut down the port when an exceeding alarm threshold or warning threshold event is encountered.

## Syntax

**ddm shutdown** { none | warning | alarm }

## Parameter

none — The port will never be shut down regardless of the exceeding alarm threshold and warning threshold events.

warning — Shut down the port when an exceeding warning threshold event is encountered.

alarm — Shut down the port when an exceeding alarm threshold event is encountered.

## Default Setting

none, which means the port will never be shut down regardless of the exceeding alarm threshold and warning threshold events.

## Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

Shut down the port 1/0/25 when an exceeding warning threshold event is encountered:

```
T2500-28TC(config)#interface gigabitEthernet 1/0/25
```

```
T2500-28TC(config-if)#ddm shutdown warning
```

# ddm temperature\_threshold

## Description

The **ddm temperature\_threshold** command is used to configure the threshold of the DDM temperature value.

## Syntax

**ddm temperature\_threshold** { high\_alarm | high\_warning | low\_alarm | low\_warning } *value*

## Parameter

high\_alarm — Specify the highest threshold for the alarm. When the operating parameter rises above the value hereinafter, action associated with the alarm will be taken.

`high_warning` — Specify the lowest threshold for the alarm. When the operating parameter falls below the value hereinafter, action associated with the alarm will be taken.

`low_alarm` — Specify the highest threshold for the warning. When the operating parameter rises above the value hereinafter, action associated with the warning will be taken.

`low_warning` — Specify the lowest threshold for the warning. When the operating parameter falls below the value hereinafter, action associated with the warning will be taken.

*value* — Enter the threshold value in Celsius.

### Default Setting

None.

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

Configure the `high_alarm` threshold of DDM temperature on the port 1/0/25 as 5:

```
T2500-28TC(config)#interface gigabitEthernet 1/0/25
T2500-28TC(config-if)#ddm temperature_threshold high_alarm 5
```

## ddm voltage\_threshold

### Description

The `ddm voltage_threshold` command is used to configure the threshold of the DDM voltage value.

### Syntax

```
ddm voltage_threshold { high_alarm | high_warning | low_alarm |
low_warning } value
```

### Parameter

`high_alarm` — Specify the highest threshold for the alarm. When the operating parameter rises above the value hereinafter, action associated with the alarm will be taken.

`high_warning` — Specify the lowest threshold for the alarm. When the operating parameter falls below the value hereinafter, action associated with the alarm will be taken.



`low_alarm` — Specify the highest threshold for the warning. When the operating parameter rises above the value hereinafter, action associated with the warning will be taken.

`low_warning` — Specify the lowest threshold for the warning. When the operating parameter falls below the value hereinafter, action associated with the warning will be taken.

*value* — Enter the threshold value in Volt.

### Default Setting

None.

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

Configure the `high_alarm` threshold of DDM voltage on the port 1/0/25 as 5:

```
T2500-28TC(config)#interface gigabitEthernet 1/0/25
```

```
T2500-28TC(config-if)#ddm voltage_threshold high_alarm 5
```

## ddm bias\_current\_threshold

### Description

The `ddm bias_current_threshold` command is used to configure the threshold of the DDM Bias Current value.

### Syntax

```
ddm bias_current_threshold { high_alarm | high_warning | low_alarm | low_warning } value
```

### Parameter

`high_alarm` — Specify the highest threshold for the alarm. When the operating parameter rises above the value hereinafter, action associated with the alarm will be taken.

`high_warning` — Specify the lowest threshold for the alarm. When the operating parameter falls below the value hereinafter, action associated with the alarm will be taken.

`low_alarm` — Specify the highest threshold for the warning. When the operating parameter rises above the value hereinafter, action associated with the warning will be taken.

`low_warning` — Specify the lowest threshold for the warning. When the operating parameter falls below the value hereinafter, action associated with the warning will be taken.

`value` — Enter the threshold value in mA.

### Default Setting

None.

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

Configure the `high_alarm` threshold of DDM Bias Current on the port 1/0/25 as 5:

```
T2500-28TC(config)#interface gigabitEthernet 1/0/25
T2500-28TC(config-if)#ddm bias_current_threshold high_alarm 5
```

## ddm tx\_power\_threshold

### Description

The `ddm tx_power_threshold` command is used to configure the threshold of the DDM Tx Power value.

### Syntax

```
ddm tx_power_threshold { high_alarm | high_warning | low_alarm |
low_warning } value
```

### Parameter

`high_alarm` — Specify the highest threshold for the alarm. When the operating parameter rises above the value hereinafter, action associated with the alarm will be taken.

`high_warning` — Specify the lowest threshold for the alarm. When the operating parameter falls below the value hereinafter, action associated with the alarm will be taken.

`low_alarm` — Specify the highest threshold for the warning. When the operating parameter rises above the value hereinafter, action associated with the warning will be taken.

`low_warning` — Specify the lowest threshold for the warning. When the operating parameter falls below the value hereinafter, action associated with the warning will be taken.

*value* — Enter the threshold value in mW.

### Default Setting

None.

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

Configure the `high_alarm` threshold of DDM Tx Power on the port 1/0/25 as 5:

```
T2500-28TC(config)#interface gigabitEthernet 1/0/25
T2500-28TC(config-if)#ddm tx_power_threshold high_alarm 5
```

## ddm rx\_power\_threshold

### Description

The `ddm rx_power_threshold` command is used to configure the threshold of the DDM Rx Power value.

### Syntax

```
ddm rx_power_threshold { high_alarm | high_warning | low_alarm | low_warning } value
```

### Parameter

`high_alarm` — Specify the highest threshold for the alarm. When the operating parameter rises above the value hereinafter, action associated with the alarm will be taken.

`high_warning` — Specify the lowest threshold for the alarm. When the operating parameter falls below the value hereinafter, action associated with the alarm will be taken.

`low_alarm` — Specify the highest threshold for the warning. When the operating parameter rises above the value hereinafter, action associated with the warning will be taken.

`low_warning` — Specify the lowest threshold for the warning. When the operating parameter falls below the value hereinafter, action associated with the warning will be taken.

*value* — Enter the threshold value in mW.

### Default Setting

None.

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

Configure the high\_alarm threshold of DDM Rx Power on the port 1/0/25 as 5:

```
T2500-28TC(config)#interface gigabitEthernet 1/0/25
T2500-28TC(config-if)#ddm rx_power_threshold high_alarm 5
```

## show ddm configuration

### Description

The **show ddm configuration** command is used to display the DDM configuration.

### Syntax

```
show ddm configuration { state | temperature | voltage | bias_current |
tx_power | rx_power }
```

### Parameter

state — Display the DDM configuration state.

temperature — Displays the threshold of the DDM temperature value.

voltage — Displays the threshold of the DDM Voltage value.

bias\_current — Displays the threshold of the DDM Bias Current value.

tx\_power — Displays the threshold of the DDM Tx Power value.

rx\_power — Displays the threshold of the DDM Rx Power value.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

View the DDM configuration state:

```
T2500-28TC(config)#show ddm configuration state
```

View the threshold of the DDM Voltage value:

```
T2500-28TC(config)#show ddm configuration voltage
```

## show ddm status

### Description

The **show ddm status** command is used to display the DDM status, which is the digital diagnostic monitoring status of SFP modules inserting into the switch's SFP ports.

### Syntax

```
show ddm status
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

View the DDM status:

```
T2500-28TC(config)#show ddm status
```

## Chapter 30 ACL Commands

ACL (Access Control List) is used to filter data packets by configuring a series of match conditions, operations and time ranges. It provides a flexible and secured access control policy and facilitates you to control the network security.

### time-range

#### Description

The **time-range** command is used to add Time-Range. To delete the corresponding Time-Range, please use **no time-range** command. A time-range based ACL enables you to implement ACL control over packets by differentiating the time-ranges. A time-range can be specified in each rule in an ACL. The rule takes effect only when the specified time-range is configured and the system time is within the time-range.

#### Syntax

```
time-range name  
no time-range name
```

#### Parameter

*name* — The Time-Range name, ranging from 1 to 16 characters.

#### Command Mode

Global Configuration Mode

#### Example

Add a time-range named tSeg1:

```
T2500-28TC(config)# time-range tSeg1
```

### absolute

#### Description

The **absolute** command is used to configure a time-range into an Absoluteness Mode. To delete the corresponding absolute mode time-range, please use **no absolute** command.

#### Syntax

```
absolute start start-date end end-date
```

**no absolute**

### Parameter

*start-date* — The start date in Absolute Mode, in the format of MM/DD/YYYY. By default, it is 01/01/2000.

*end-date* — The end date in Absolute Mode, in the format of MM/DD/YYYY. By default, it is 01/01/2000. The Absolute Mode will be disabled if the start date and end date are both in default value.

### Command Mode

Time-range Create Configuration Mode

### Example

Configure the time-range tSeg1 with time from May 5, 2012 to Oct. 5, 2012:

```
T2500-28TC(config)# time-range tSeg1
```

```
T2500-28TC(config-time-range)# absolute start 05/05/2012 end 10/05/2012
```

## periodic

### Description

The **periodic** command is used to configure the time-range into periodic mode. To delete the corresponding Periodic Mode time-range, please use **no periodic** command.

### Syntax

```
periodic [week-date week-day] [time-slice1 time-slice] [time-slice2 time-slice]  
[time-slice3 time-slice] [time-slice4 time-slice]
```

```
no periodic
```

### Parameter

*week-day* — Periodic Mode, in the format of 1-3,6 or daily, off-day, working-day. 1-3, 6 represent Monday, Tuesday, Wednesday and Saturday; daily represents every day; off-day represents weekend and working-day represents working day. By default, the Periodic Mode is disabled.

*time-slice* — Create the time-slice, in the format of HH:MM-HH:MM.

### Command Mode

Time-range Create Configuration Mode

### Example

Configure the time-range tSeg1 with time from 8:30 to 12:00 at weekend:

```
T2500-28TC(config)#time-range tSeg1
T2500-28TC(config-time-range)#periodic week-date off-day time-slice1
08:30-12:00
```

## holiday

### Description

The **holiday** command is used to configure the time-range into Holiday Mode under Time-range Create Configuration Mode. To delete the corresponding Holiday Mode time-range, please use **no holiday** command.

### Syntax

```
holiday
no holiday
```

### Command Mode

Time-range Create Configuration Mode

### Example

Configure the time-range tSeg1 into Holiday Mode:

```
T2500-28TC(config)#time-range tSeg1
T2500-28TC(config-time-range)#holiday
```

## holiday(global)

### Description

The **holiday** command is used to define a holiday. To delete the corresponding holiday, please use **no holiday** command.

### Syntax

```
holiday name start-date start-date end-date end-date
no holiday
```

### Parameter

*name* — The holiday name, ranging from 1 to 16 characters.

*start-date* — The start date of the holiday, in the format of MM/DD, for instance, 05/01.

*end-date* — The end date of the holiday, in the format of MM/DD, for instance, 05/03.



## Command Mode

Global Configuration Mode

## Example

Define National Day, configuring the start date as October 1st, and the end date as October 3rd:

```
T2500-28TC(config)#holiday nationalday start-date 10/01 end-date 10/03
```

# access-list create

## Description

The **access-list create** command is used to create standard-IP ACL and extend-IP ACL.

## Syntax

```
access-list create access-list-num
```

## Parameter

*access-list-num* — ACL ID, ranging from 100 to 399. 100-199 must be Standard-IP ACL, 200-299 must be Extend-IP ACL, and 300-399 must be Combined ACL.

## Command Mode

Global Configuration Mode

## Example

Create a standard-IP ACL whose ID is 123:

```
T2500-28TC(config)#access-list create 123
```

# mac access-list

## Description

The **mac access-list** command is used to create MAC ACL. To set the detailed configurations for a specified MAC ACL, please use **mac access-list** command to access Mac Access-list Configuration Mode. To delete the MAC ACL, please use **no mac access-list**.

## Syntax

```
mac access-list access-list-num
```

```
no mac access-list access-list-num
```

**Parameter**

*access-list-num* — ACL ID, ranging from 0 to 99.

**Command Mode**

Global Configuration Mode

**Example**

Create a MAC ACL whose ID is 23:

```
T2500-28TC(config)#mac access-list 23
```

## access-list standard

**Description**

The **access-list standard** command is used to add Standard-IP ACL rule. To delete the corresponding rule, please use **no access-list standard** command. Standard-IP ACLs analyze and process data packets based on a series of match conditions, which can be the source IP addresses and destination IP addresses carried in the packets.

**Syntax**

```
access-list standard acl-id rule rule-id {deny | permit} [ [sip source-ip] smask source-ip-mask] [ [dip destination-ip] dmask destination-ip-mask] [tseg time-segment] [ frag {disable | enable} ]
```

```
no access-list standard acl-id rule rule-id
```

**Parameter**

*acl-id* — The desired Standard-IP ACL for configuration.

*rule-id* — The rule ID.

deny — The operation to discard packets.

permit — The operation to forward packets. It is the default value.

*source-ip* — The source IP address contained in the rule.

*source-ip-mask* — The source IP address mask. It is required if you typed the source IP address.

*destination-ip* — The destination IP address contained in the rule.

*destination-ip-mask* — The destination IP address mask. It is required if you typed the destination IP address.

*time-segment* — The time-range for the rule to take effect. By default, it is not limited.

frag —— Enable/Disable Fragment. By default, it is disabled. If Fragment is enabled, this rule will process all the fragments and the last piece of fragment will be always forwarded.

## Command Mode

Global Configuration Mode

## Example

Create a Standard-IP ACL whose ID is 120, and add Rule 10 for it. In the rule, the source IP address is 192.168.0.100, the source IP address mask is 255.255.255.0, the time-range for the rule to take effect is tSeg1, and the packets match this rule will be forwarded by the switch:

```
T2500-28TC(config)#access-list create 120
T2500-28TC(config)#access-list standard 120 rule 10 permit sip 192.168.0.100
smask 255.255.255.0 tseg tSeg1
```

## access-list extended

### Description

The **access-list extended** command is used to add Extended-IP ACL rule. To delete the corresponding rule, please use **no access-list extended** command.

### Syntax

```
access-list extended acl-id rule rule-id {deny | permit} [ [sip source-ip] smask
source-ip-mask] [ [dip destination-ip] dmask destination-ip-mask] [tseg
time-segment] [frag {disable | enable}] [dscp dscp] [s-port s-port] [d-port d-port]
[tcpflag tcpflag] [protocol protocol] [icmptype icmptype] [icmpcode icmpcode]
[tos tos] [pri pri]
```

```
no access-list extended acl-id rule rule-id
```

### Parameter

*acl-id* —— The desired Extended-IP ACL for configuration.

*rule-id* —— The rule ID.

deny —— The operation to discard packets.

permit —— The operation to forward packets. It is the default value.

*source-ip* —— The source IP address contained in the rule.

*source-ip-mask* —— The source IP address mask. It is required if you typed the source IP address.

- destination-ip* — The destination IP address contained in the rule.
- destination-ip-mask* — The destination IP address mask. It is required if you typed the destination IP address.
- time-segment* — The time-range for the rule to take effect. By default, it is not limited.
- frag* — Enable/Disable Fragment. By default, it is disabled. If Fragment is enabled, this rule will process all the fragments and the last piece of fragment will be always forwarded.
- dscp* — Specify the dscp value, ranging from 0 to 63.
- s-port* — The source port number.
- d-port* — The destination port number.
- tcpflag* — Specify the flag value when using TCP protocol.
- protocol* — Configure the value of the matching protocol.
- icmptype* — Configure the predefined ICMP type.
- icmpcode* — Configure the predefined ICMP code.
- tos* — Enter the IP ToS contained in the rule.
- pri* — Enter the IP Precedence contained in the rule.

## Command Mode

Global Configuration Mode

## Example

Create an Extended-IP ACL whose ID is 220, and add Rule 10 for it. In the rule, the source IP address is 192.168.0.100, the source IP address mask is 255.255.255.0, the time-range for the rule to take effect is tSeg1, and the packets match this rule will be forwarded by the switch:

```
T2500-28TC(config)#access-list create 220
T2500-28TC(config)#access-list extended 220 rule 10 permit sip 192.168.0.100
smask 255.255.255.0 tseg tSeg1
```

## access-list combined

### Description

The **access-list combined** command is used to add combined ACL rule. To delete the corresponding rule, please use **no access-list combined** command.

## Syntax

```

access-list combined acl-id rule rule-id [permit | deny] [[smac source-mac]
[smask source-mac-mask]] [[dmac destination-mac] [dmask
destination-mac-mask]] [vid vlan-id] [type ethertype] [pri priority] [[sip source-ip]
[sip-mask source-ip-mask]] [[dip destination-ip] [dmask destination-ip-mask]]
[frag {disable | enable}] [tseg time-segment]

no access-list bind combined acl-id rule rule-id

```

## Parameter

*acl-id* — The desired combined ACL for configuration.

*rule-id* — The rule ID.

deny — The operation to discard packets.

permit — The operation to forward packets. It is the default value.

*source-mac* — The source source MAC address contained in the rule.

*source-mac-mask* — The source MAC address mask. It is required if you typed the source MAC address.

*destination-mac* — The destination MAC address contained in the rule.

*destination-mac-mask* — The destination MAC address mask. It is required if you typed the destination MAC address.

*vlan-id* — The VLAN ID contained in the rule.

*ethertype* — The Ethernet type contained in the rule.

*priority* — The user priority contained in the rule for the tagged packets to match. It ranges from 0 to 7.

*source-ip* — The source IP address contained in the rule.

*source-ip-mask* — The source IP address mask. It is required if you typed the source IP address.

*destination -ip-address* — The destination IP address contained in the rule.

*destination-ip-mask* — The destination IP address mask. It is required if you typed the destination IP address.

frag — Enable/Disable Fragment. By default, it is disabled. If Fragment is enabled, this rule will process all the fragments and the last piece of fragment will be always forwarded.

*time-segment* — The time-range for the rule to take effect. By default, it is not limited.

## Command Mode

Global Configuration Mode

## Example

Create a combined ACL whose ID is 320, and add Rule 10 for it. In the rule, the source IP address is 192.168.0.100, the source IP address mask is 255.255.255.0, the time-range for the rule to take effect is tSeg1, and the packets match this rule will be forwarded by the switch:

```
T2500-28TC(config)#access-list create 320
T2500-28TC(config)#access-list combined 320 rule 10 permit sip
192.168.0.100 smask 255.255.255.0 tseg tSeg1
```

## rule

### Description

The **rule** command is used to configure MAC ACL rule. To delete the corresponding rule, please use **no rule** command.

### Syntax

```
rule rule-id {deny | permit} [ smac source-mac smask source-mac-mask ]
[ dmac destination-mac dmask destination-mac-mask ] [ vid vlan-id ] [ type
ethernet-type ] [ pri user-pri ] [ tseg time-segment ]
no rule rule-id
```

### Parameter

*rule-id* — The rule ID.

deny — The operation to discard packets.

permit — The operation to forward packets. By default, it is “permit”.

*source-mac* — The source MAC address contained in the rule.

*source-mac-mask* — The source MAC address mask. It is required if you typed the source MAC address.

*destination-mac* — The destination MAC address contained in the rule.

*destination-mac-mask* — The destination MAC address mask. It is required if you typed the destination MAC address.

*vlan-id* — The VLAN ID contained in the rule, ranging from 1 to 4094.

*ethernet-type* — EtherType contained in the rule, in the format of 4-hex number.

*user-pri* — The user priority contained in the rule, ranging from 0 to 7. By default, it is not limited.

*time-segment* — The time-range for the rule to take effect. By default, it is not limited.

## Command Mode

Mac Access-list Configuration Mode

## Example

Create a MAC ACL whose ID is 20, and add Rule 10 for it. In the rule, the source MAC address is 00:01:3F:48:16:23, the source MAC address mask is 11:11:11:11:11:00, VLAN ID is 2, the user priority is 5, the time-range for the rule to take effect is tSeg1, and the packets match this rule will be forwarded by the switch:

```
T2500-28TC(config)#mac access-list 20
T2500-28TC(config-mac-acl)#rule 10 permit smac 00:01:3F:48:16:23 smask
11:11:11:11:11:00 vid 2 pri 5 tseg tSeg1
```

## access-list policy name

### Description

The **access-list policy name** command is used to add Policy. To delete the corresponding Policy, please use **no access-list policy name** command. A Policy is used to control the data packets those match the corresponding ACL rules by configuring ACLs and actions together for effect. The operations here include stream mirror, stream condition, QoS Remarking and redirect.

### Syntax

```
access-list policy name name
no access-list policy name name
```

### Parameter

*name* — The Policy Name, ranging from 1 to 16 characters.

### Command Mode

Global Configuration Mode

### Example

Add a Policy named policy1:

```
T2500-28TC(config)#access-list policy name policy1
```

## access-list policy action

### Description

The **access-list policy action** command is used to add ACLs and create actions for the policy. To set the detailed configuration of actions for a policy, please use **access-list policy action** command to access Action Configuration Mode. To delete the corresponding actions, please use **no access-list policy action** command.

### Syntax

**access-list policy action** *policy-name* *acl-id*

**no access-list policy action** *policy-name* *acl-id*

### Parameter

*policy-name* — The Policy Name, ranging from 1 to 16 characters.

*acl-id* — The ID of the ACL to which the above policy is applied.

### Command Mode

Global Configuration Mode

### Example

Add ACL whose ID is 120 to policy1 and create an action for them:

```
T2500-28TC(config)#access-list policy action policy1 120
```

## redirect interface

### Description

The **redirect interface** command is used to configure Direction function of policy action for specified ports.

### Syntax

**redirect interface** { **fastEthernet** *port* | **gigabitEthernet** *port* }

### Parameter

*port* — The Destination Port of Redirect. The data packets matching the corresponding ACL will be forwarded to the specific port. By default, it is All Ports.

### Command Mode

Action Configuration Mode

### Example



Edit the actions for policy1. Forward the data packets matching ACL 120 in the policy to Fast Ethernet port 2:

```
T2500-28TC(config)#access-list policy action policy1 120
```

```
T2500-28TC(config-action)#redirect interface fastEthernet 1/0/2
```

## redirect vlan

### Description

The **redirect vlan** command is used to configure Direction function of policy action for specified VLAN.

### Syntax

```
redirect vlan vlan-id
```

### Parameter

*vlan-id* — The VLAN ID of Redirect. The data packets matching the corresponding ACL will be forwarded in the specific VLAN. The VLAN ID ranges from 1 to 4094.

### Command Mode

Action Configuration Mode

### Example

Edit the actions for policy1. Forward the data packets matching ACL 120 in the policy to Fast Ethernet VLAN 1:

```
T2500-28TC(config)#access-list policy action policy1 120
```

```
T2500-28TC(config-action)#redirect vlan 1
```

## s-condition

### Description

The **s-condition** command is used to configure Stream Condition function of policy action.

### Syntax

```
s-condition rate rate osd {none | discard}
```

### Parameter

*rate* — The rate of Stream Condition, ranging from 0 to 100000kbps.

**osd** — Out of Band disposal of Stream Condition. It is the disposal way of the data packets those are transmitted beyond the rate. There are two options, “none” and “discard”. By default, the option is “none”.

### Command Mode

Action Configuration Mode

### Example

Edit the actions for policy1. For the data packets matching ACL 120 in the policy, if the rate beyond 1000kbps, they will be discarded by the switch:

```
T2500-28TC(config)#access-list policy action policy1 120
T2500-28TC(config-action)#s-condition rate 1000 osd discard
```

## s-mirror

### Description

The **s-mirror** command is used to configure Stream Mirror function of policy action to the specified port.

### Syntax

```
s-mirror interface { fastEthernet port | gigabitEthernet port }
```

### Parameter

*port* — The Mirror Port number of Stream Mirror.

### Command Mode

Action Configuration Mode

### Example

Edit the actions for policy1. Specify the mirror port as Fast Ethernet port 2 for the data packets matching ACL 120:

```
T2500-28TC(config)#access-list policy action policy1 120
T2500-28TC(config-action)#s-mirror interface fastEthernet 1/0/2
```

## qos-remark

### Description

The **qos-remark** command is used to configure QoS Remark function of policy action.

### Syntax

```
qos-remark dscp dscp priority pri
```

```
no qos-remark
```

### Parameter

*dscp* — DSCP of QoS Remark. Specify the DSCP region for the data packets matching the corresponding ACL. DSCP ranges from 0 to 63. By default, it is not limited.

*pri* — Local Priority of QoS Remark. Specify the local priority for the data packets matching the corresponding ACL. Local Priority ranges from 0 to 3.

### Command Mode

Action Configuration Mode

### Example

Edit the actions for policy1. For the data packets matching ACL 120, specify the DSCP region as 30 and local priority 2:

```
T2500-28TC(config)#access-list policy action policy1 120
T2500-28TC(config-action)# qos-remark dscp 30 priority 2
```

## access-list bind(interface)

### Description

The **access-list bind** command is used to bind a policy to a specified port. To cancel the bind relation, please use **no access-list bind** command.

### Syntax

```
access-list bind policy-name
no access-list bind policy-name
```

### Parameter

*policy-name* — The name of the policy desired to bind.

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

Bind policy1 to Fast Ethernet port 2:

```
T2500-28TC(config)#interface fastEthernet 1/0/2
T2500-28TC(config-if)#access-list bind policy1
```

## access-list bind(vlan)

### Description

The **access-list bind** command is used to bind a policy to a VLAN. To cancel the bind relation, please use **no access-list bind** command.

### Syntax

```
access-list bind policy-name  
no access-list bind policy-name
```

### Parameter

*policy-name* —— The name of the policy desired to bind.

### Command Mode

Interface VLAN Mode

### Example

Bind policy1 to VLAN 2:

```
T2500-28TC(config)#interface vlan 2  
T2500-28TC(config-if)#access-list bind policy1
```

## show time-range

### Description

The **show time-range** command is used to display the configuration of time-range.

### Syntax

```
show time-range
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the configuration of Time-Range:

```
T2500-28TC#show time-range
```

## show holiday

### Description

The **show holiday** command is used to display the defined holidays.

## Syntax

**show holiday**

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display the defined holidays:

```
T2500-28TC#show holiday
```

## show access-list

### Description

The **show access-list** command is used to display configuration of ACL.

### Syntax

**show access-list** [*acl-id*]

### Parameter

*acl-id* — The ID of the ACL selected to display the configuration.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the configuration of the MAC ACL whose ID is 20:

```
T2500-28TC#show access-list 20
```

## show access-list policy

### Description

The **show access-list policy** command is used to display the information of a specified policy.

### Syntax

**show access-list policy** [*name*]

### Parameter

*name* — The Policy Name desired to show.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the information of a policy named policy1:

```
T2500-28TC#show access-list policy policy1
```

## show access-list bind

### Description

The **show access-list bind** command is used to display the configuration of Policy bind.

### Syntax

```
show access-list bind
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the configuration of Policy bind:

```
T2500-28TC#show access-list bind
```

## Chapter 31 MSTP Commands

MSTP (Multiple Spanning Tree Protocol), compatible with both STP and RSTP and subject to IEEE 802.1s, can disbranch a ring network. STP is to block redundant links and backup links as well as optimize paths.

### spanning-tree(global)

#### Description

The **spanning-tree** command is used to enable STP function globally. To disable the STP function, please use **no spanning-tree** command.

#### Syntax

**spanning-tree**  
**no spanning-tree**

#### Command Mode

Global Configuration Mode

#### Example

Enable the STP function:

```
T2500-28TC(config)#spanning-tree
```

### spanning-tree(interface)

#### Description

The **spanning-tree** command is used to enable STP function for a port. To disable the STP function, please use **no spanning-tree** command.

#### Syntax

**spanning-tree**  
**no spanning-tree**

#### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

#### Example

Enable the STP function for Fast Ethernet port 2:

```
T2500-28TC(config)#interface fastEthernet 1/0/2
```

```
T2500-28TC(config-if)#spanning-tree
```

## spanning-tree common-config

### Description

The **spanning-tree common-config** command is used to configure the parameters of the ports for comparison in the CIST and the common parameters of all instances. To return to the default configuration, please use **no spanning-tree common-config** command. CIST (Common and Internal Spanning Tree) is the spanning tree in a switched network, connecting all devices in the network.

### Syntax

```
spanning-tree common-config [port-priority pri] [ext-cost ext-cost] [int-cost int-cost] [portfast {enable | disable}] [point-to-point {auto | open | close}]
```

```
no spanning-tree common-config
```

### Parameter

*pri* — Port Priority, which must be multiple of 16 ranging from 0 to 240. By default, the port priority is 128. Port Priority is an important criterion on determining if the port connected to this port will be chosen as the root port. In the same condition, the port with the highest priority will be chosen as the root port. The lower value has the higher priority.

*ext-cost* — External Path Cost, which is used to choose the path and calculate the path costs of ports in different MST regions. It is an important criterion on determining the root port. The lower value has the higher priority. It ranges from 0 to 2000000. By default, it is 0 which is mean auto.

*int-cost* — Internal Path Cost, which is used to choose the path and calculate the path costs of ports in an MST region. It is an important criterion on determining the root port. The lower value has the higher priority. By default, it is automatic. It ranges from 0 to 2000000. By default, it is 0 which is mean auto.

**portfast** — Enable/ Disable Edge Port. By default, it is disabled. The edge port can transit its state from blocking to forwarding rapidly without waiting for forward delay.

**point-to-point** — The P2P link status, with auto, open and close options. By default, the option is auto. If the two ports in the P2P link are root port or



designated port, they can transit their states to forwarding rapidly to reduce the unnecessary forward delay.

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

Enable the STP function of Fast Ethernet port 1, and configure the Port Priority as 64, ExtPath Cost as 100, IntPath Cost as 100, and then enable Edge Port:

```
T2500-28TC(config)#interface fastEthernet 1/0/1
T2500-28TC(config-if)#spanning-tree common-config port-priority 64
ext-cost 100 int-cost 100 portfast enable point-to-point open
```

## spanning-tree mode

### Description

The **spanning-tree mode** command is used to configure the STP mode of the switch. To return to the default configurations, please use **no spanning-tree mode** command.

### Syntax

```
spanning-tree mode {stp | rstp | mstp}
no spanning-tree mode
```

### Parameter

stp —— Spanning Tree Protocol, the default value.  
rstp —— Rapid Spanning Tree Protocol  
mstp —— Multiple Spanning Tree Protocol

### Command Mode

Global Configuration Mode

### Example

Configure the spanning-tree mode as “mstp”:

```
T2500-28TC(config)#spanning-tree mode mstp
```

## spanning-tree mst configuration

### Description

The **spanning-tree mst configuration** command is used to access MST Configuration Mode from Global Configuration Mode, as to configure the VLAN-Instance mapping, region name and revision level. To return to the default configuration of the corresponding Instance, please use **no spanning-tree mst configuration** command.

### Syntax

```
spanning-tree mst configuration  
no spanning-tree mst configuration
```

### Command Mode

Global Configuration Mode

### Example

Enter into the MST Configuration Mode:

```
T2500-28TC(config)#spanning-tree mst configuration  
T2500-28TC(config-mst)#
```

## instance

### Description

The **instance** command is used to configure the VLAN-Instance mapping. To remove the VLAN-instance mapping or disable the corresponding instance, please use **no instance** command. When an instance is disabled, the related mapping VLANs will be removed.

### Syntax

```
instance instance-id vlan vlan-id  
no instance instance-id [vlan vlan-id]
```

### Parameters

*instance-id* — Instance ID, ranging from 1 to 8.

*vlan-id* — The VLAN ID selected to mapping with the corresponding instance.

### Command Mode

MST Configuration Mode

## Example

Map the VLANs 1-100 to Instance 1:

```
T2500-28TC(config)#spanning-tree mst configuration
T2500-28TC(config-mst)#instance 1 vlan 1-100
```

Disable Instance 1, namely remove all the mapping VLANs 1-100:

```
T2500-28TC(config)#spanning-tree mst configuration
T2500-28TC(config-mst)#no instance 1
```

Remove VLANs 1-50 in mapping VLANs 1-100 for Instance 1:

```
T2500-28TC(config)#spanning-tree mst configuration
T2500-28TC(config-mst)#no instance 1 vlan 1-50
```

## name

### Description

The **name** command is used to configure the region name of MST instance.

### Syntax

**name** *name*

### Parameters

*name* — The region name, used to identify MST region. It ranges from 1 to 32 characters.

### Command Mode

MST Configuration Mode

### Example

Configure the region name of MST as “region1”:

```
T2500-28TC(config)#spanning-tree mst configuration
T2500-28TC(config-mst)#name region1
```

## revision

### Description

The **revision** command is used to configure the revision level of MST instance.

### Syntax

**revision** *revision*

## Parameters

*revision* — The revision level for MST region identification, ranging from 0 to 65535.

## Command Mode

MST Configuration Mode

## Example

Configure the revision level of MST as 100:

```
T2500-28TC(config)#spanning-tree mst configuration
```

```
T2500-28TC(config-mst)#revision 100
```

# spanning-tree mst instance

## Description

The **spanning-tree mst instance** command is used to configure the priority of MST instance. To return to the default value of MST instance priority, please use **no spanning-tree mst instance** command.

## Syntax

**spanning-tree mst instance** *instance-id* **priority** *pri*

**no spanning-tree mst instance** *instance-id* **priority**

## Parameter

*instance-id* — Instance ID, ranging from 1 to 8.

*pri* — MSTI Priority, which must be multiple of 4096 ranging from 0 to 61440. By default, it is 32768. MSTI priority is an important criterion on determining if the switch will be chosen as the root bridge in the specific instance.

## Command Mode

Global Configuration Mode

## Example

Enable the MST Instance 1 and configure its priority as 4096:

```
T2500-28TC(config)#spanning-tree mst instance 1 priority 4096
```

## spanning-tree mst

### Description

The **spanning-tree mst** command is used to configure MST Instance Port. To return to the default configuration of the corresponding Instance Port, please use **no spanning-tree mst** command. A port can play different roles in different spanning tree instance. You can use this command to configure the parameters of the ports in different instance IDs as well as view status of the ports in the specified instance

### Syntax

```
spanning-tree mst instance instance-id { [port-priority pri] [cost cost] }
no spanning-tree mst instance instance-id
```

### Parameter

*instance-id* —— Instance ID, ranging from 1 to 8.

*pri* —— Port Priority, which must be multiple of 16 ranging from 0 to 240. By default, it is 128. Port Priority is an important criterion on determining if the port will be chosen as the root port by the device connected to this port.

*cost* —— Path Cost, ranging from 0 to 200000. The lower value has the higher priority. Its default value is 0 meaning “auto”.

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

Configure the priority of Fast Ethernet port 1 in MST Instance 1 as 64, and path cost as 2000:

```
T2500-28TC(config)#interface fastEthernet 1/0/1
T2500-28TC(config-if)#spanning-tree mst instance 1 port-priority 64 cost
2000
```

## spanning-tree priority

### Description

The **spanning-tree priority** command is used to configure the bridge priority. To return to the default value of bridge priority, please use **no spanning-tree priority** command.

**Syntax**

**spanning-tree priority** *pri*  
**no spanning-tree priority**

**Parameter**

*pri* —— Bridge priority, ranging from 0 to 61440. It is 32768 by default.

**Command Mode**

Global Configuration Mode

**Example**

Configure the bridge priority as 4096:

```
T2500-28TC(config)#spanning-tree priority 4096
```

## spanning-tree tc-defend

**Description**

The **spanning-tree tc-defend** command is used to configure the TC Protect of Spanning Tree globally. To return to the default configuration, please use **no spanning-tree tc-defend** command. A switch removes MAC address entries upon receiving TC-BPDUs. If a malicious user continuously sends TC-BPDUs to a switch, the switch will be busy with removing MAC address entries, which may decrease the performance and stability of the network.

**Syntax**

**spanning-tree tc-defend threshold** *threshold period period*  
**no spanning-tree tc-defend**

**Parameter**

*threshold* —— TC Threshold, ranging from 1 to 100 packets. By default, it is 20. TC Threshold is the maximum number of the TC-BPDUs received by the switch in a TC Protect Cycle.

*period* —— TC Protect Cycle, ranging from 1 to 10 in seconds. By default, it is 5.

**Command Mode**

Global Configuration Mode

**Example**

Configure TC Threshold as 30 packets and TC Protect Cycle as 10 seconds:

```
T2500-28TC(config)#spanning-tree tc-defend threshold 30 period 10
```

## spanning-tree timer

### Description

The **spanning-tree timer** command is used to configure forward-time, hello-time and max-age of Spanning Tree. To return to the default configurations, please use **no spanning-tree timer** command.

### Syntax

```
spanning-tree timer { [forward-time forward-time] [hello-time hello-time]  
[max-age max-age] }
```

```
no spanning-tree timer
```

### Parameter

*forward-time* — Forward Delay, which is the time for the port to transit its state after the network topology is changed. Forward Delay ranges from 4 to 30 in seconds and it is 15 by default. Otherwise,  $2 * (\text{Forward Delay} - 1) \geq \text{Max Age}$ .

*hello-time* — Hello Time, which is the interval to send BPDU packets, and used to test the links. Hello Time ranges from 1 to 10 in seconds and it is 2 by default. Otherwise,  $2 * (\text{Hello Time} + 1) \leq \text{Max Age}$ .

*max-age* — The maximum time the switch can wait without receiving a BPDU before attempting to reconfigure, ranging from 6 to 40 in seconds. By default, it is 20.

### Command Mode

Global Configuration Mode

### Example

Configure forward-time, hello-time and max-age for Spanning Tree as 16 seconds, 3 seconds and 22 seconds respectively:

```
T2500-28TC(config)#spanning-tree timer forward-time 16 hello-time 3  
max-age 22
```

## spanning-tree hold-count

### Description

The **spanning-tree hold-count** command is used to configure the maximum number of BPDU packets transmitted per Hello Time interval. To return to the default configurations, please use **no spanning-tree hold-count** command.

## Syntax

**spanning-tree hold-count** *value*  
**no spanning-tree hold-count**

## Parameter

*value* — The maximum number of BPDU packets transmitted per Hello Time interval, ranging from 1 to 20 in pps. By default, it is 5.

## Command Mode

Global Configuration Mode

## Example

Configure the hold-count of STP as 8pps:

```
T2500-28TC(config)#spanning-tree hold-count 8
```

# spanning-tree max-hops

## Description

The **spanning-tree max-hops** command is used to configure the maximum number of hops that occur in a specific region before the BPDU is discarded. To return to the default configurations, please use **no spanning-tree max-hops** command.

## Syntax

**spanning-tree max-hops** *value*  
**no spanning-tree max-hops**

## Parameter

*value* — The maximum number of hops that occur in a specific region before the BPDU is discarded, ranging from 1 to 40 in hop. By default, it is 20.

## Command Mode

Global Configuration Mode

## Example

Configure the max-hops of STP as 30:

```
T2500-28TC(config)#spanning-tree max-hops 30
```



## spanning-tree bpdudfilter

### Description

The **spanning-tree bpdudfilter** command is used to enable the BPDU filter function for a port. With the function enabled, the port can be prevented from receiving and sending any BPDU packets. To disable the BPDU filter function, please use **no spanning-tree bpdudfilter** command.

### Syntax

**spanning-tree bpdudfilter**

**no spanning-tree bpdudfilter**

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

Enable the BPDU filter function for Fast Ethernet port 2:

```
T2500-28TC(config)#interface fastEthernet 1/0/2
```

```
T2500-28TC(config-if)#spanning-tree bpdudfilter
```

## spanning-tree bpduguard

### Description

The **spanning-tree bpduguard** command is used to enable the BPDU protect function for a port. With the BPDU protect function enabled, the port will set itself automatically as ERROR-PORT when it receives BPDU packets, and the port will disable the forwarding function for a while. To disable the BPDU protect function, please use **no spanning-tree bpduguard** command.

### Syntax

**spanning-tree bpduguard**

**no spanning-tree bpduguard**

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

Enable the BPDU protect function for Fast Ethernet port 2:

```
T2500-28TC(config)#interface fastEthernet 1/0/2
T2500-28TC(config-if)#spanning-tree bpduguard
```

## spanning-tree guard loop

### Description

The **spanning-tree guard loop** command is used to enable the Loop Protect function for a port. Loop Protect is to prevent the loops in the network brought by recalculating STP because of link failures and network congestions. To disable the Loop Protect function, please use **no spanning-tree guard loop** command.

### Syntax

```
spanning-tree guard loop
no spanning-tree guard loop
```

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

Enable the Loop Protect function for Fast Ethernet port 2:

```
T2500-28TC(config)#interface fastEthernet 1/0/2
T2500-28TC(config-if)#spanning-tree guard loop
```

## spanning-tree guard root

### Description

The **spanning-tree guard root** command is used to enable the Root Protect function for a port. With the Root Protect function enabled, the root bridge will set itself automatically as ERROR-PORT when receiving BPDU packets with higher priority, in order to maintain the role of root bridge. To disable the Root Protect function, please use **no spanning-tree guard root** command.

### Syntax

```
spanning-tree guard root
no spanning-tree guard root
```

## Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

Enable the Root Protect function for Fast Ethernet port 2:

```
T2500-28TC(config)#interface fastEthernet 1/0/2
T2500-28TC(config-if)#spanning-tree guard root
```

# spanning-tree guard tc

## Description

The **spanning-tree guard tc** command is used to enable the TC Protect of Spanning Tree function for a port. To disable the TC Protect of Spanning Tree function, please use **no spanning-tree guard tc** command. A switch removes MAC address entries upon receiving TC-BPDUs. If a malicious user continuously sends TC-BPDUs to a switch, the switch will be busy with removing MAC address entries, which may decrease the performance and stability of the network. With the Protect of Spanning Tree function enabled, you can configure the number of TC-BPDUs in a required time, so as to avoid the process of removing MAC addresses frequently.

## Syntax

```
spanning-tree guard tc
no spanning-tree guard tc
```

## Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

Enable the TC Protect of Spanning Tree for Fast Ethernet port 2:

```
T2500-28TC(config)#interface fastEthernet 1/0/2
T2500-28TC(config-if)#spanning-tree guard tc
```

# spanning-tree mcheck

## Description

The **spanning-tree mcheck** command is used to enable MCheck.

## Syntax

**spanning-tree mcheck**

## Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

Enable MCheck for Fast Ethernet port 2:

```
T2500-28TC(config)#interface fastEthernet 1/0/2
T2500-28TC(config-if)#spanning-tree mcheck
```

# show spanning-tree active

## Description

The **show spanning-tree active** command is used to display the active information of spanning-tree.

## Syntax

**show spanning-tree active**

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display the active information of spanning-tree:

```
T2500-28TC(config)#show spanning-tree active
```

# show spanning-tree bridge

## Description

The **show spanning-tree bridge** command is used to display the bridge parameters.

## Syntax

**show spanning-tree bridge** [ forward-time | hello-time | hold-count | max-age | max-hops | mode | priority | state ]

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display the bridge parameters:

```
T2500-28TC(config)#show spanning-tree bridge
```

## show spanning-tree interface

### Description

The **show spanning-tree interface** command is used to display the spanning-tree information of all ports or a specified port.

### Syntax

```
show spanning-tree interface [ fastEthernet port | gigabitEthernet port ]
[edge | ext-cost | int-cost | mode | p2p | priority | role | state | status]
```

### Parameter

*port* — The Fast/Gigabit Ethernet port number.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the spanning-tree information of all ports:

```
T2500-28TC(config)#show spanning-tree interface
```

Display the spanning-tree information of Gigabit Ethernet port 25:

```
T2500-28TC(config)#show spanning-tree interface gigabitEthernet 1/0/25
```

Display the spanning-tree mode information of Gigabit Ethernet port 25:

```
T2500-28TC(config)#show spanning-tree interface gigabitEthernet 1/0/25
mode
```

## show spanning-tree interface-security

### Description

The **show spanning-tree interface-security** command is used to display the protect information of all ports or a specified port.

### Syntax

```
show spanning-tree interface-security [ fastEthernet port | gigabitEthernet
port ] [ bpdudfilter | bpduguard | loop | root | tc | tc-defend ]
```

**Parameter**

*port* — The Fast/Gigabit Ethernet port number.

**Command Mode**

Privileged EXEC Mode and Any Configuration Mode

**Example**

Display the protect information of all ports:

```
T2500-28TC(config)#show spanning-tree interface-security
```

Display the protect information of Gigabit Ethernet port 25:

```
T2500-28TC(config)#show spanning-tree interface-security gigabitEthernet
1/0/25
```

Display the interface security bpdufilter information:

```
T2500-28TC(config)# show spanning-tree interface-security bpdufilter
```

## show spanning-tree mst

**Description**

The **show spanning-tree mst** command is used to display the related information of MST Instance.

**Syntax**

```
show spanning-tree mst {configuration [digest] | instance instance-id
[interface [ fastEthernet port | gigabitEthernet port] ] }
```

**Parameter**

*instance-id* — Instance ID desired to show, ranging from 1 to 8.

*port* — The Fast/Gigabit Ethernet port number.

**Command Mode**

Privileged EXEC Mode and Any Configuration Mode

**Example**

Display the region information and mapping information of VLAN and MST Instance:

```
T2500-28TC(config)#show spanning-tree mst configuration
```

Display the related information of MST Instance 1:

```
T2500-28TC(config)#show spanning-tree mst instance 1
```

Display all the ports information of MST Instance 1:

```
T2500-28TC(config)#show spanning-tree mst instance 1 interface
```

## Chapter 32 Ethernet OAM Commands

Ethernet OAM (standing for Operation, Administration, and Maintenance) is Layer 2 protocol that is used for monitoring and troubleshooting Ethernet networks. It can report the network status to network administrators through the OAMPDUs exchanged between two OAM entities. The operation of OAM on an Ethernet interface does not adversely affect data traffic as OAM is a slow protocol with very limited bandwidth potential.

### ethernet-oam

#### Description

The **ethernet-oam** command is used to enable the Ethernet OAM function for the desired port. To disable the Ethernet OAM function, please use **no ethernet-oam** command.

#### Syntax

```
ethernet-oam
no ethernet-oam
```

#### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

#### Example

Enable the Ethernet OAM function for Fast Ethernet port 2:

```
T2500-28TC(config)# interface fastEthernet 1/0/2
T2500-28TC(config-if)#ethernet-oam
```

### ethernet-oam mode

#### Description

The **ethernet-oam mode** command is used to configure the OAM mode for the desired port. To return to the default configurations, please use **no ethernet-oam mode** command. The default mode is active.



## Syntax

```

ethernet-oam mode { passive | active }
no ethernet-oam mode

```

## Parameter

**passive** — Specify the OAM mode as passive.

**active** — Specify the OAM mode as active.

## Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

Configure Ethernet OAM client to operate in passive mode for Fast Ethernet port 2:

```

T2500-28TC(config)# interface fastEthernet 1/0/2
T2500-28TC(config-if)#ethernet-oam mode passive

```

# ethernet-oam link-monitor symbol-period

## Description

The **ethernet-oam link-monitor symbol-period** command is used to configure the parameters about one of the link events, error symbol period event. To return to the default configurations, please use **no ethernet-oam link-monitor symbol-period** command.

## Syntax

```

ethernet-oam link-monitor symbol-period { threshold threshold | window window | notify { disable | enable }}
no ethernet-oam link-monitor symbol-period { threshold | window | notify }

```

## Parameter

*threshold* — Configure the error threshold for generating error symbol-period event. The range is from 1 to 4294967295 and the default value is 1.

*window* — Configure the error symbol-period event detection interval. The range is from 10 to 600, in terms of 100 ms intervals. The default value is 10.

notify — Enable/Disable the event notification. By default, it is enabled.

threshold | window | notify — The parameter that you want to return to the default configuration.

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

For error symbol-period event, configure the error threshold as 5 and the event detection interval as 3 seconds on Fast Ethernet port 2:

```
T2500-28TC(config)# interface fastEthernet 1/0/2
T2500-28TC(config-if)# ethernet-oam link-monitor symbol-period
threshold 5 window 30
```

## ethernet-oam link-monitor frame

### Description

The **ethernet-oam link-monitor frame** command is used to configure the parameters about one of the link events, error frame event. To return to the default configurations, please use **no ethernet-oam link-monitor frame** command.

### Syntax

```
ethernet-oam link-monitor frame { [threshold threshold] [window window]
[notify { disable | enable } ] }
```

```
no ethernet-oam link-monitor frame { threshold | window | notify }
```

### Parameter

*threshold* — Configure the error threshold for generating error frame event. The range is from 1 to 4294967295 and the default value is 1.

*window* — Configure the error symbol-period event detection interval. The range is from 10 to 600, in terms of 100 ms intervals. The default value is 10.

notify — Enable/Disable the event notification. By default, it is enabled.

threshold | window | notify — The parameter that you want to return to the default configuration.

## Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

For error frame event, configure the error threshold as 6 and the event detection interval as 9 seconds on Fast Ethernet port 3:

```
T2500-28TC(config)# interface fastEthernet 1/0/3
T2500-28TC(config-if)# ethernet-oam link-monitor frame threshold 6
window 90
```

# ethernet-oam link-monitor frame-period

## Description

The **ethernet-oam link-monitor frame-period** command is used to configure the parameters about one of the link events, error frame period event. To return to the default configurations, please use **no ethernet-oam link-monitor frame-period** command.

## Syntax

```
ethernet-oam link-monitor frame-period { [threshold threshold ] [ window window ] [notify { disable | enable } ] }
```

```
no ethernet-oam link-monitor frame-period { threshold | window | notify }
```

## Parameter

*threshold* — Configure the error threshold for generating error frame period event. The range is from 1 to 4294967295 and the default value is 1.

*window* — Configure the error frame period event detection interval. The range is from 148810 to 89286000. The default value is 148810 for Fast Ethernet port and 1488100 for Gigabit Ethernet port.

notify — Enable/Disable the event notification. By default, it is enabled.

threshold | window | notify — The parameter that you want to return to the default configuration.

## Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

For error frame period event, configure the error threshold as 6 and the event detection interval as 150000 frames on Fast Ethernet port 4:

```
T2500-28TC(config)# interface fastEthernet 1/0/4
T2500-28TC(config-if)# ethernet-oam link-monitor frame-period threshold
6 window 150000
```

# ethernet-oam link-monitor frame-seconds

## Description

The **ethernet-oam link-monitor frame-seconds** command is used to configure the parameters about one of the link events, error frame seconds event. To return to the default configurations, please use **no ethernet-oam link-monitor frame-seconds** command.

## Syntax

```
ethernet-oam link-monitor frame-seconds { [threshold threshold] [window window] [notify { disable | enable } ] }
```

```
no ethernet-oam link-monitor frame-seconds { threshold | window | notify }
```

## Parameter

*threshold* — Configure the error threshold for generating error frame seconds event. The range is from 1 to 900 and the default value is 1.

*window* — Configure the error frame seconds event detection interval. The range is from 100 to 9000, in terms of 100 ms intervals. The default value is 600.

*notify* — Enable/Disable the event notification. By default, it is enabled.

*threshold | window | notify* — The parameter that you want to return to the default configuration.

## Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

For error frame seconds event, configure the error threshold as 8 and the event detection interval as 30 seconds on Fast Ethernet port 5:

```
T2500-28TC(config)# interface fastEthernet 1/0/5
T2500-28TC(config-if)# ethernet-oam link-monitor frame-seconds
threshold 8 window 300
```

## ethernet-oam remote-failure

### Description

The ethernet-oam remote-failure command is used to configure whether to notify the link faults or not. The link faults include dying gasp and critical event. To return to the default configurations, please use **no ethernet-oam remote-failure** command.

### Syntax

```
ethernet-oam remote-failure { dying-gasp | critical-event } notify { disable |
enable }
no ethernet-oam remote-failure { dying-gasp | critical-event } notify
```

### Parameter

dying-gasp — Dying Gasp link event. Dying gasp means an unrecoverable fault, such as power failure, occurs.

critical-event — Critical Event. Critical-event means unspecified critical event occurs.

notify — Enable/Disable the event notification. By default, it is enabled.

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

Disable the Dying Gasp link event notification on Fast Ethernet port 7:

```
T2500-28TC(config)# interface fastEthernet 1/0/7
```

```
T2500-28TC(config-if)# ethernet-oam remote-failure dying-gasp notify
disable
```

## ethernet-oam remote-loopback received-remote-loopback

### Description

The **ethernet-oam remote-loopback received-remote-loopback** command is used to configure the client to process or to ignore the received remote loopback request. To return to the default configurations, please use **no ethernet-oam remote-loopback received-remote-loopback** command.

### Syntax

```
ethernet-oam remote-loopback received-remote-loopback { process |
ignore }
no ethernet-oam remote-loopback received-remote-loopback
```

### Parameter

process — Process the received remote loopback request.  
ignore — Ignore the received remote loopback request.

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

Configure the client to process the received remote loopback request on Fast Ethernet port 1:

```
T2500-28TC(config)# interface fastEthernet 1/0/1
T2500-28TC(config-if)# ethernet-oam remote-loopback received
-remote-loopback process
```

## ethernet-oam remote-loopback

### Description

The **ethernet-oam remote-loopback** command is used to request the remote peer to start or stop the Ethernet OAM remote loopback mode.

### Syntax

```
ethernet-oam remote-loopback { start | stop }
```

### Parameter

start — Request the remote peer to start the Ethernet OAM remote loopback mode.

stop — Request the remote peer to stop the Ethernet OAM remote loopback mode.

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

Request the remote peer to start the Ethernet OAM remote loopback mode on Fast Ethernet port 3:

```
T2500-28TC(config)# interface fastEthernet 1/0/3
T2500-28TC(config-if)# ethernet-oam remote-loopback start
```

## clear ethernet-oam statistics

### Description

The **clear ethernet-oam statistics** command is used to clear Ethernet OAM statistics.

### Syntax

```
clear ethernet-oam statistics [ interface { fastEthernet | gigabitEthernet }
port ]
```

### Parameter

*port* — The Fast/Gigabit Ethernet port number. By default, the Ethernet OAM statistics of all ports are cleared.

### Command Mode

Global Configuration Mode

### Example

Clear Ethernet OAM statistics of Fast Ethernet port 3:

```
T2500-28TC(config)# clear ethernet-oam statistics interface fastEthernet
1/0/3
```

## clear ethernet-oam event-log

### Description

The **clear ethernet-oam event-log** command is used to clear the Ethernet OAM event log.

### Syntax

```
clear ethernet-oam event-log [ interface { fastEthernet | gigabitEthernet }
port ]
```

### Parameter

*port* — The Fast/Gigabit Ethernet port number. By default, the Ethernet OAM event logs of all ports are cleared.

### Command Mode

Global Configuration Mode

### Example

Clear Ethernet OAM event log of Fast Ethernet port 3:

```
T2500-28TC(config)# clear ethernet-oam event-log interface fastEthernet
1/0/3
```



## show ethernet-oam configuration

### Description

The **show ethernet-oam configuration** command is used to display Ethernet OAM configuration information.

### Syntax

```
show ethernet-oam configuration [ interface { fastEthernet | gigabitEthernet } port ]
```

### Parameter

*port* — The Fast/Gigabit Ethernet port number. By default, the Ethernet OAM configuration information of all ports is displayed.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display Ethernet OAM configuration information of Fast Ethernet port 2:

```
T2500-28TC(config)# show ethernet-oam configuration interface fastEthernet 1/0/2
```

## show ethernet-oam event-log

### Description

The **show ethernet-oam event-log** command is used to display the Ethernet OAM event log.

### Syntax

```
show ethernet-oam event-log [ interface { fastEthernet | gigabitEthernet } port ]
```

### Parameter

*port* — The Fast/Gigabit Ethernet port number. By default, the Ethernet OAM event logs of all ports are displayed.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display Ethernet OAM event log of Fast Ethernet port 2:

```
T2500-28TC(config)# show ethernet-oam event-log interface fastEthernet  
1/0/2
```

# show ethernet-oam statistics

## Description

The **show ethernet-oam statistics** command is used to display the Ethernet OAM statistics.

## Syntax

```
show ethernet-oam statistics [ interface { fastEthernet | gigabitEthernet }  
port ]
```

## Parameter

*port* — The Fast/Gigabit Ethernet port number. By default, the Ethernet OAM statistics of all ports are displayed.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display Ethernet OAM statistics of Fast Ethernet port 2:

```
T2500-28TC(config)# show ethernet-oam statistics interface fastEthernet  
1/0/2
```

# show ethernet-oam status

## Description

The **show ethernet-oam status** command is used to display the Ethernet OAM status of both the local and the remote client.

## Syntax

```
show ethernet-oam status [ interface { fastEthernet | gigabitEthernet }  
port ]
```

## Parameter

*port* — The Fast/Gigabit Ethernet port number. By default, the Ethernet OAM status of all ports is displayed.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display Ethernet OAM status of Fast Ethernet port 2:

```
T2500-28TC(config)# show ethernet-oam status interface fastEthernet  
1/0/2
```

## Chapter 33 DLDP Commands

DLDP (Device Link Detection Protocol) is used to monitor the link state of fiber-optic or twisted-pair Ethernet cables. When a unidirectional link is detected, the corresponding port will be shut down automatically or manually (depending on the shut mode configured).

### dldp(global)

#### Description

The **dldp** command is used to enable the DLDP function globally. To disable it, please use **no dldp** command.

#### Syntax

**dldp**  
**no dldp**

#### Command Mode

Global Configuration Mode

#### Example

Enable the DLDP function globally:

```
T2500-28TC(config)# dldp
```

### dldp interval

#### Description

The **dldp interval** command is used to define the interval of sending advertisement packets on ports that are in the advertisement state.

#### Syntax

**dldp interval** *interval-time*

#### Parameter

*interval-time* — The interval of sending advertisement packets. It ranges from 1 to 30 seconds. By default, it is 5 seconds.

#### Command Mode

Global Configuration Mode

## Example

Specify the interval of sending advertisement packets as 10 seconds:

```
T2500-28TC(config)# dldp interval 10
```

## dldp shut-mode

### Description

The **dldp shut-mode** command is used to configure the shutdown mode when a unidirectional link is detected.

### Syntax

```
dldp shut-mode { auto | manual }
```

### Parameter

**auto** — The switch automatically shuts down ports when a unidirectional link is detected. By default, the shut-mode is auto.

**manual** — The switch displays an alert when a unidirectional link is detected.

### Command Mode

Global Configuration Mode

### Example

Configure the shut-mode as manual:

```
T2500-28TC(config)# dldp shut-mode manual
```

## dldp reset(global)

### Description

The **dldp reset** command is used to reset all the unidirectional links and restart the link detect process.

### Syntax

```
dldp reset
```

### Command Mode

Global Configuration Mode

## Example

Reset the DLDP function globally:

```
T2500-28TC(config)# dldp reset
```

## dldp(interface)

### Description

The **dldp** command is used to enable the DLDP function of the specified port. To disable it, please use **no dldp** command.

### Syntax

**dldp**

**no dldp**

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

Enable the DLDP function of ports 2-4:

```
T2500-28TC (config)# interface range fastEthernet 1/0/2-4
```

```
T2500-28TC (config-if-range)# dldp
```

## dldp reset(interface)

### Description

The **dldp reset** command is used to reset the specified port and restart the link detect process.

### Syntax

**dldp reset**

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

Reset the DLDP function of ports 2-4:

```
T2500-28TC (config)# interface range fastEthernet 1/0/2-4
T2500-28TC (config-if-range)# dldp reset
```

## show dldp

### Description

The **show dldp** command is used to display the global configuration of DLDP function such as DLDP global state, DLDP interval and shut mode.

### Syntax

```
show dldp
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the global configuration of DLDP function:

```
T2500-28TC# show dldp
```

## show dldp interface

### Description

The **show dldp interface** command is used to display the configuration and state of the specified Ethernet port. By default, the configuration and state of all the ports will be displayed.

### Syntax

```
show dldp interface [ fastEthernet port | gigabitEthernet port ]
```

### Parameter

*port* — The Fast/Gigabit Ethernet port number.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

**Example**

Display the configuration and state of all ports:

```
T2500-28TC# show dldp interface
```

Display the configuration and state of port 5:

```
T2500-28TC# show dldp interface fastEthernet 1/0/5
```



## Chapter 34 IGMP Snooping Commands

IGMP Snooping (Internet Group Management Protocol Snooping) is a multicast control mechanism running on Layer 2 switch. It can effectively prevent multicast groups being broadcasted in the network.

### ip igmp snooping(global)

#### Description

The **ip igmp snooping** command is used to configure IGMP Snooping globally. To disable the IGMP Snooping function, please use **no ip igmp snooping** command.

#### Syntax

**ip igmp snooping**  
**no ip igmp snooping**

#### Command Mode

Global Configuration Mode

#### Example

Enable IGMP Snooping function:

```
T2500-28TC(config)#ip igmp snooping
```

### ip igmp snooping(interface)

#### Description

The **ip igmp snooping** command is used to enable the IGMP Snooping function for the desired port. To disable the IGMP Snooping function, please use **no ip igmp snooping** command.

#### Syntax

**ip igmp snooping**  
**no ip igmp snooping**

#### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

Enable IGMP Snooping function of Gigabit Ethernet port 25:

```
T2500-28TC(config)#interface gigabitEthernet 1/0/25
T2500-28TC(config-if)#ip igmp snooping
```

## ip igmp snooping immediate-leave

### Description

The **ip igmp snooping immediate-leave** command is used to configure the Fast Leave function for port. To disable the Fast Leave function, please use **no ip igmp snooping immediate-leave** command.

### Syntax

```
ip igmp snooping immediate-leave
no ip igmp snooping immediate-leave
```

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

Enable the Fast Leave function for Fast Ethernet port 3:

```
T2500-28TC(config)#interface fastEthernet 1/0/3
T2500-28TC(config-if)#ip igmp snooping immediate-leave
```

## ip igmp snooping drop-unknown

### Description

The **ip igmp snooping drop-unknown** command is used to process the unknown multicast as “discard”. To disable the operation of processing the unknown multicast as “discard”, please use **no ip igmp snooping drop-unknown** command.

### Syntax

```
ip igmp snooping drop-unknown
no ip igmp snooping drop-unknown
```

### Command Mode

Global Configuration Mode

## Example

Specify the operation of processing unknown multicast as “discard”:

```
T2500-28TC(config)#ip igmp snooping drop-unknown
```

## ip igmp snooping vlan-config

### Description

The **ip igmp snooping vlan-config** command is used to enable VLAN IGMP Snooping function or to modify IGMP Snooping parameters, and to create static multicast IP entry. To disable the VLAN IGMP Snooping function, please use **no ip igmp snooping vlan-config** command.

### Syntax

```
ip igmp snooping vlan-config vlan-list [ rtime router-time | mtime member-time | ltime leave-time | rport interface { fastEthernet port | gigabitEthernet port } ]
```

```
ip igmp snooping vlan-config vlan-id static ip interface { fastEthernet port | gigabitEthernet port }
```

```
no ip igmp snooping vlan-config vlan-id list
```

```
no ip igmp snooping vlan-config vlan-id static ip
```

### Parameter

*vlan-list* — The ID list of the VLAN desired to modify configuration, ranging from 1 to 4094, in the format of 1-3, 5.

*router-time* — Router Port Time. Within this time, if the switch does not receive IGMP query message from the router port, it will consider this port is not a router port any more. Router Port Time ranges from 60 to 600 in seconds. By default, it is 300.

*member-time* — Member Port Time. Within this time, if the switch does not receive IGMP report message from the member port, it will consider this port is not a member port any more. Member Port Time ranges from 60 to 600 in seconds. By default, it is 260.

*leave-time* — Leave Time, which is the interval between the switch receiving a leave message from a host and the switch removing the host from the multicast groups. Leave Time ranges from 1 to 30 in seconds. By default, it is 1.

*port* — Static Router Port, which is mainly used in the network with stable topology. There are two types of port: Fast Ethernet port, ranging from 1 to 24, in

the format of 1/0/2; Gigabit Ethernet port, ranging from 1-4, in the format of 1/0/2.

*vlan-id* — The VLAN ID of the multicast IP, ranging from 1 to 4094.

*ip* — The static multicast IP address.

*port-list* — The forward port list of the multicast group.

### Command Mode

Global Configuration Mode

### Example

Enable the IGMP Snooping function and modify Member Port Time as 200 seconds for VLAN1-3:

```
T2500-28TC(config)#ip igmp snooping vlan-config 1-3 mtime 200
```

## ip igmp snooping multi-vlan-config

### Description

The **ip igmp snooping multi-vlan-config** command is used to create and configure a Multicast VLAN. To delete the corresponding Multicast VLAN, please use **no ip igmp snooping multi-vlan-config** command.

### Syntax

```
ip igmp snooping multi-vlan-config [vlan-id] { rtime router-time | mtime member-time | itime leave-time | rport interface { fastEthernet port | gigabitEthernet port } }
```

```
no ip igmp snooping multi-vlan-config
```

### Parameter

*vlan-id* — The ID of the VLAN desired to modify configuration, ranging from 2 to 4094.

*router-time* — Router Port Time. Within this time, if the switch does not receive IGMP query message from the router port, it will consider this port is not a router port any more. Router Port Time ranges from 60 to 600 in seconds. By default, it is 300.

*member-time* — Member Port Time. Within this time, if the switch does not receive IGMP report message from the member port, it will consider this port is not a member port any more. Member Port Time ranges from 60 to 600 in seconds. By default, it is 260.

*leave-time* — Leave Time, which is the interval between the switch receiving a leave message from a host and the switch removing the host from the multicast groups. Leave Time ranges from 1 to 30 in seconds. By default, it is 1.

*port* — Static Router Port, which is mainly used in the network with stable topology. There are two types of port: Fast Ethernet port, ranging from 1 to 24, in the format of 1/0/2; Gigabit Ethernet port, ranging from 25 to 28, in the format of 1/0/25.

### Command Mode

Global Configuration Mode

### Example

Enable Multicast VLAN 3, and configure Router Port Time as 100 seconds:

```
T2500-28TC(config)#ip igmp snooping multi-vlan-config 3 rtime 100
```

## ip igmp snooping filter add-id

### Description

The **ip igmp snooping filter add-id** command is used to configure the multicast IP-range desired to filter. To delete the corresponding IP-range, please use **no ip igmp snooping filter add-id** command. When IGMP Snooping is enabled, you can specified the multicast IP-range the ports can join so as to restrict users ordering multicast programs via configuring multicast filter rules. Multicast IP addresses ranges from 224.0.0.0 to 239.255.255.255. The range for receivers to join is from 224.0.1.0 to 239.255.255.255.

### Syntax

```
ip igmp snooping filter add-id addr-id list
```

```
no ip igmp snooping filter add-id addr-id list
```

### Parameter

*addr-id list* — The filtering address ID to be bound.

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

Bind the filtering address ID 2-6 to Fast Ethernet port 3:

```
T2500-28TC(config)#interface fastEthernet 1/0/3
```

```
T2500-28TC(config-if)#ip igmp snooping filter add-id 2-6
```

## ip igmp snooping filter(global)

### Description

The **ip igmp snooping filter** command is used to add or modify the multicast filtering IP-range. To delete the multicast filtering IP-range, please use **no ip igmp snooping filter** command.

### Syntax

```
ip igmp snooping filter id start-ip end-ip
```

```
no ip igmp snooping filter id
```

### Parameter

*id* —— IP-range ID, ranging from 1 to 30.

*start-ip* —— The start multicast IP of the IP-range.

*end-ip* —— The end multicast IP of the IP-range.

### Command Mode

Global Configuration Mode

### Example

Modify the multicast IP-range whose ID is 3 as 225.1.1.1 – 226.3.2.1:

```
T2500-28TC(config)#ip igmp snooping filter 3 225.1.1.1 226.3.2.1
```

## ip igmp snooping filter(interface)

### Description

The **ip igmp snooping filter** command is used to configure Port Filter. To return to the default configuration, please use **no igmp snooping filter** command. When the switch receives IGMP report message, it examines the multicast filtering IP ID configured on the access port to determine if the port can join the multicast group. If the multicast IP is not filtered, the switch will add the port to the forward port list of the multicast group. Otherwise, the switch will drop the IGMP report message. In that way, you can control the multicast groups that users can access.

### Syntax

```
ip igmp snooping filter
```

```
no ip igmp snooping filter
```

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

Enable IGMP Snooping filter function for Gigabit Ethernet port 26:

```
T2500-28TC(config)#interface gigabitEthernet 1/0/26
T2500-28TC(config-if)#ip igmp snooping filter
```

## ip igmp snooping filter maxgroup

### Description

The **ip igmp snooping filter maxgroup** command is used to specify the maximum number of multicast groups for a port to join in.

### Syntax

```
ip igmp snooping filter maxgroup maxgroup
```

### Parameter

*maxgroup* — The maximum number of multicast groups for a port to join in. It is used to prevent some ports taking up too much bandwidth.

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

Specify the maximum number of multicast groups for Fast Ethernet ports 2-5 to join in as 10:

```
T2500-28TC(config)#interface range fastEthernet 1/0/2-5
T2500-28TC(config-if-range)#ip igmp snooping filter maxgroup 10
```

## ip igmp snooping filter mode

### Description

The **ip igmp snooping filter mode** command is used to configure the Action mode for the desired port.

### Syntax

```
ip igmp snooping filter mode mode
```

**Parameter**

*mode* — Action Mode, with “refuse” and “accept” options. “Refuse” indicates only the multicast packets whose multicast IP is not in the IP-range will be processed, while “accept” indicates only the multicast packets whose multicast IP is in the IP-range will be processed. By default, the option is “accept”.

**Command Mode**

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

**Example**

Specify the Action Mode as “accept” for Fast Ethernet port 3:

```
T2500-28TC(config)#interface fastEthernet 1/0/3
T2500-28TC(config-if)#ip igmp snooping filter mode accept
```

## ip igmp snooping querier vlan

**Description**

The **ip igmp snooping querier vlan** command is used to enable the IGMP Snooping Querier function of the VLAN(s). To disable the IGMP Snooping Querier function of certain VLANs, please use **no ip igmp snooping querier vlan** command; to disable the IGMP Snooping Querier function of all VLANs, please use **no ip igmp snooping querier** command.

**Syntax**

```
ip igmp snooping querier vlan vlan-list
no ip igmp snooping querier [vlan vlan-list ]
```

**Parameter**

*vlan-list* — VLAN ID list, ranging from 1 to 4094, in the format of 1-3, 5. It is multi-optional.

**Command Mode**

Global Configuration Mode

**Example**

Enable the IGMP Snooping Querier function of VLAN1-3:

```
T2500-28TC(config)#ip igmp snooping querier vlan 1-3
```



## ip igmp snooping querier vlan (general query)

### Description

The **ip igmp snooping querier vlan** command is used to configure the parameters for IGMP Snooping Querier to send a general query frame. To return to the default configuration, please use **no ip igmp snooping querier vlan** command.

### Syntax

```
ip igmp snooping querier vlan vlan-list {query-interval interval |
max-response-time response-time | general-query source-ip ip-addr}
no ip igmp snooping querier vlan vlan-list {query-interval |
max-response-time | general-query source-ip}
```

### Parameter

*vlan-list*—— VLAN ID list, ranging from 1 to 4094, in the format of 1-3, 5. It is multi-optional.

*interval*—— The time interval to send a general query frame by IGMP Snooping Querier, ranging from 1 to 300 (Seconds). By default, it is 60 seconds.

*response-time*—— The maximal time for the host to respond to a general query frame, ranging from 1 to 25 (Seconds). By default, it is 10 Seconds.

*ip-addr*—— The source IP of the general query frame sent by IGMP Snooping Querier. It should not be a multicast IP or a broadcast IP. By default, it is 192.168.0.1.

### Command Mode

Global Configuration Mode

### Example

For VLAN 2, specify its query-interval as 200 seconds, and the response-time as 20 seconds:

```
T2500-28TC(config)#ip igmp snooping querier vlan 2 query-interval 200
T2500-28TC(config)#ip igmp snooping querier vlan 2 max-response-time
20
```

## ip igmp snooping querier vlan (specific query)

### Description

The **ip igmp snooping querier vlan** command is used to configure the parameters for IGMP Snooping Querier to send a specific query frame. To return to the default configuration, please use **no ip igmp snooping querier vlan** command.

### Syntax

```
ip igmp snooping querier vlan vlan-list {last-member-query-interval interval
| last-member-query-count count | special-query source-ip ip-addr }
no ip igmp snooping querier vlan vlan-list {last-member-query-interval |
last-member-query-count | special-query source-ip}
```

### Parameter

*vlan-list*— VLAN ID list, ranging from 1 to 4094, in the format of 1-3, 5. It is multi-optional.

*interval*— The time interval of sending specific query frames by IGMP Snooping Querier, ranging from 1 to 5 (Seconds). By default, it is 1. A specific query will be sent on condition that “immediate-leave” is not enabled and a leave frame is received.

*count*— The times of sending specific query frames by IGMP Snooping Querier, ranging from 1 to 5. By default, it is 2. The switch will still treat the port as group member until the specific frames number sent by the querier reaches “last-member-query-count” and no report frame is received from the port.

*ip-addr*— The source IP of the specific query frame sent by IGMP Snooping Querier. It should not be a multicast IP or a broadcast IP. By default, it is 192.168.0.1.

### Command Mode

Global Configuration Mode

### Example

For VLAN 2, specify its last-member-query-interval as 2:

```
T2500-28TC(config)#ip igmp snooping querier vlan 2
last-member-query-interval 2
```

## ip igmp snooping authentication

### Description

The **ip igmp snooping authentication** command is used to enable IGMP Authentication for the desired port. To disable the IGMP Authentication function, please use **no ip igmp snooping authentication** command. By default, it is disabled.

### Syntax

**ip igmp snooping authentication**

**no ip igmp snooping authentication**

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### User Guidelines

The IGMP Authentication feature will take effect only when AAA function is enabled and the RADIUS server is configured. For how to enable AAA function and configure RADIUS server, please refer to [aaa enable](#) and [radius-server host](#).

### Example

Enable the IGMP Authentication of port 1:

```
T2500-28TC(config)# interface fastEthernet 1/0/1
```

```
T2500-28TC(config-if)# ip igmp snooping authentication
```

## show ip igmp snooping

### Description

The **show ip igmp snooping** command is used to display the global configuration of IGMP Snooping.

### Syntax

**show ip igmp snooping**

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the global configuration of IGMP Snooping:

```
T2500-28TC#show ip igmp snooping
```

## show ip igmp snooping interface

### Description

The **show ip igmp snooping interface** command is used to display the port configuration of IGMP.

### Syntax

```
show ip igmp snooping interface { fastEthernet port | gigabitEthernet port }  
{ basic-config | filter | packet-stat }
```

```
show ip igmp snooping interface { fastEthernet port-list | gigabitEthernet  
port-list } { basic-config | filter | packet-stat }
```

### Parameter

*port* — The Fast/Gigabit Ethernet port number. By default, the configuration of all ports is displayed.

*basic-config* | *filter* | *packet-stat* — The related configuration information selected to display.

*port-list* — The list group of Ethernet ports.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the IGMP basic configuration of Fast Ethernet port 2:

```
T2500-28TC#show ip igmp snooping interface fastEthernet 1/0/2 basic-config
```

Display the IGMP filter configuration of Fast Ethernet ports 2-4:

```
T2500-28TC#show ip igmp snooping interface fastEthernet 1/0/2-4 filter
```

## show ip igmp snooping vlan

### Description

The **show ip igmp snooping vlan** command is used to display the VLAN configuration of IGMP.

### Syntax

```
show ip igmp snooping vlan [vlan-id]
```

### Parameter

*vlan-id* —The VLAN ID selected to display.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the IGMP snooping configuration information of VLAN 2:

```
T2500-28TC#show ip igmp snooping vlan 2
```

## show ip igmp snooping multi-vlan

### Description

The **show ip igmp snooping multi-vlan** command is used to display the Multicast VLAN configuration.

### Syntax

```
show ip igmp snooping multi-vlan
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the Multicast VLAN configuration:

```
T2500-28TC#show ip igmp snooping multi-vlan
```

## show ip igmp snooping groups

### Description

The **show ip igmp snooping groups** command is used to display the information of all IGMP snooping groups. It can be extended to some other commands to display the dynamic and static multicast information of a selected VLAN.

### Syntax

```
show ip igmp snooping groups [vlan vlan-id] [count | dynamic | dynamic count | static | static count]
```

### Parameter

*vlan-id* —The VLAN ID selected to display the information of all multicast items.

count— The numbers of all multicast groups.

dynamic—— Display dynamic multicast groups.

dynamic count—— The numbers of all dynamic multicast groups.

static—— Display static multicast groups.

static count—— The numbers of all static multicast groups.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the information of all IGMP snooping groups:

```
T2500-28TC#show ip igmp snooping groups
```

Display all the multicast entries in VLAN 5:

```
T2500-28TC(config)#show ip igmp snooping groups vlan 5
```

Display the count of multicast entries in VLAN 5:

```
T2500-28TC(config)#show ip igmp snooping groups vlan 5 count
```

## show ip igmp snooping filter

### Description

The **show ip igmp snooping filter** command is used to display the Multicast Filter Address table.

### Syntax

```
show ip igmp snooping filter [filter-addr-id-list]
```

### Parameter

*filter-addr-id-list* ——The multicast ID selected to display the multicast filter address information. It is optional.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display all the multicast filter address information:

```
T2500-28TC(config)#show ip igmp snooping filter
```

## show ip igmp snooping querier vlan

### Description

The **show ip igmp snooping querier vlan** command is used to display the configurations of IGMP Snooping Querier of the specified VLAN.

### Syntax

```
show ip igmp snooping querier vlan vlan-list
```

### Parameter

*vlan-list* —The ID of the VLAN selected to display the configurations of IGMP Snooping Querier. It is multi-optional.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the configurations of IGMP Snooping Querier of VLAN 2, 4 and 5:

```
T2500-28TC(config)# show ip igmp snooping querier vlan 2, 4-5
```

## show ip igmp snooping querier

### Description

The **show ip igmp snooping querier** command is used to display the IGMP Snooping Querier configurations of all VLANs.

### Syntax

```
show ip igmp snooping querier
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the configurations of IGMP Snooping Querier of all VLANs:

```
T2500-28TC(config)# show ip igmp snooping querier
```

## show ip igmp snooping interface authentication

### Description

The **show ip igmp snooping interface authentication** command is used to display the IGMP Snooping authentication configurations of all ports.

## Syntax

**show ip igmp snooping querier**

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display the IGMP Snooping authentication configurations of all ports:

```
T2500-28TC(config)# show ip igmp snooping interface authentication
```



## Chapter 35 MLD Snooping Commands

MLD Snooping (Multicast Listener Discovery Snooping) is a multicast control mechanism running on Layer 2 switch. It can effectively prevent multicast groups being broadcasted in the IPv6 network.

### ipv6 mld snooping

#### Description

The **ipv6 mld snooping** command is used to enable MLD Snooping function globally. If this function is disabled, all related MLD Snooping function would not work. To disable this function, please use **no ipv6 mld snooping** command.

#### Syntax

```
ipv6 mld snooping
no ipv6 mld snooping
```

#### Command Mode

Global Configuration Mode

#### Example

Enable MLD Snooping:

```
T2500-28TC(config)# ipv6 mld snooping
```

### ipv6 mld snooping router-aging-time

#### Description

The **ipv6 mld snooping router-aging-time** command is used to specify router port aging time globally. The default aging time is 260 seconds. To restore the default timer, please use **no ipv6 mld snooping router-aging-time** command.

#### Syntax

```
ipv6 mld snooping router-aging-time timer
no ipv6 mld snooping router-aging-time
```

#### Parameter

*timer* — Specify the aging time in seconds, ranging from 1 to 1000.

#### Command Mode

Global Configuration Mode

## Example

Specify MLD Snooping router port aging time as 100 seconds globally:

```
T2500-28TC(config)# ipv6 mld snooping router-aging-time 100
```

## ipv6 mld snooping member-aging-time

### Description

The **ipv6 mld snooping member-aging-time** command is used to specify member port aging time globally. The default aging time is 260 seconds. To restore the default timer, please use **no ipv6 mld snooping member-aging-time** command.

### Syntax

```
ipv6 mld snooping member-aging-time timer  
no ipv6 mld snooping member-aging-time
```

### Parameter

*timer* — Specify the aging time in seconds, ranging from 200 to 1000.

### Command Mode

Global Configuration Mode

### Example

Specify MLD Snooping member port aging time as 100 seconds globally:

```
T2500-28TC(config)# ipv6 mld snooping member-aging-time 100
```

## ipv6 mld snooping report-suppression

### Description

The **ipv6 mld snooping report-suppression** command is used to enable the Report message suppression function. By default, it is enabled. To disable this function, please use **no ipv6 mld snooping report-suppression** command.

### Syntax

```
ipv6 mld snooping report-suppression  
no ipv6 mld snooping report-suppression
```

### Command Mode

Global Configuration Mode

### Example

Disable Report message suppression function:

```
T2500-28TC(config)# no ipv6 mld snooping report-suppression
```

## ipv6 mld snooping unknown-filter

### Description

The **ipv6 mld snooping unknown-filter** command is used to enable the unknown multicast packets filter function. To disable this function, please use **no ipv6 mld snooping unknown-filter** command. By default, it is disabled.

### Syntax

```
ipv6 mld snooping unknown-filter  
no ipv6 mld snooping unknown-filter
```

### Command Mode

Global Configuration Mode

### Example

Enable unknown multicast filter function:

```
T2500-28TC(config)# ipv6 mld snooping unknown-filter
```

## ipv6 mld snooping last-listener query-inteval

### Description

The **ipv6 mld snooping last-listener query-inteval** command is used to specify the interval to send Specific Query Message. The default value is 1 second. To restore the default interval, please use **no ipv6 mld snooping last-listener query-inteval** command.

### Syntax

```
ipv6 mld snooping last-listener query-inteval interval  
no ipv6 mld snooping last-listener query-inteval
```

### Parameter

*interval* — Specify the interval to send Specific Query Message in seconds, ranging from 1 to 5.

### Command Mode

Global Configuration Mode

### Example

Specify the interval of Specific Query Message to 3 seconds:

```
T2500-28TC(config)# ipv6 mld snooping last-listener query-inteval 3
```

## ipv6 mld snooping last-listener query-count

### Description

The **ipv6 mld snooping last-listener query-count** command is used to specify the numbers of Specific Query Message to be sent. The default value is 2. To restore the default number, please use **no ipv6 mld snooping last-listener query-count** command.

### Syntax

```
ipv6 mld snooping last-listener query-count num  
no ipv6 mld snooping last-listener query-count
```

### Parameter

*num* — Specify the numbers of Specific Query Message to be sent, ranging from 1 to 7.

### Command Mode

Global Configuration Mode

### Example

Specify the number of Specific Query Message to 3:

```
T2500-28TC(config)# ipv6 mld snooping last-listener query-count 3
```

## ipv6 mld snooping multicast-vlan

### Description

The **ipv6 mld snooping multicast-vlan** command is used to enable the multicast VLAN function. To disable this function, please use **no ipv6 mld snooping multicast-vlan** command. By default it is disabled.

### Syntax

```
ipv6 mld snooping multicast-vlan  
no ipv6 mld snooping multicast-vlan
```

### Command Mode

Global Configuration Mode

### Example

Enable multicast VLAN:

```
T2500-28TC(config)# ipv6 mld snooping multicast-vlan
```

## ipv6 mld snooping multicast-vlan vlan-id

### Description

The **ipv6 mld snooping multicast-vlan vlan-id** command is used to specify the multicast VLAN ID. The default multicast VLAN is VLAN1. To restore the default VLAN, please use **no ipv6 mld snooping multicast-vlan vlan-id** command.

### Syntax

```
ipv6 mld snooping multicast-vlan vlan-id vid  
no ipv6 mld snooping multicast-vlan vlan-id
```

### Parameter

*vid* — The specified IEEE 802.1Q VLAN ID, ranging from 1 to 4094.

### Command Mode

Global Configuration Mode

### Example

Specify multicast VLAN as VLAN 2:

```
T2500-28TC(config)# ipv6 mld snooping multicast-vlan vlan-id 2
```

## ipv6 mld snooping vlan

### Description

The **ipv6 mld snooping vlan** command is used to enable MLD Snooping function on a specified VLAN. To disable it, please use **no ipv6 mld snooping vlan** command.

### Syntax

```
ipv6 mld snooping vlan vlan-id  
no ipv6 mld snooping vlan vlan-id
```

### Parameter

*vlan-id* — The specified VLAN ID to enable MLD Snooping function, ranging from 1 to 4094.

### Command Mode

Global Configuration Mode

### Example

Enable MLD Snooping function on VLAN 2:

```
T2500-28TC(config)# ipv6 mld snooping vlan 2
```

## ipv6 mld snooping vlan router-aging-time

### Description

The **ipv6 mld snooping vlan router-aging-time** command is used to specify router port aging time for a specified VLAN. If this time is set to 0, then the global router port aging time will be used. The default time is 0. To restore the default timer, please use **no ipv6 mld snooping vlan router-aging-time** command.

### Syntax

```
ipv6 mld snooping vlan vlan-id router-aging-time timer  
no ipv6 mld snooping vlan vlan-id router-aging-time
```

### Parameter

*vlan-id* — The specified IEEE 802.1Q VLAN ID, ranging from 1 to 4094.  
*timer* — Aging time of the router port in seconds, ranging from 0 to 1000.

### Command Mode

Global Configuration Mode

### Example

Specify the router port aging time as 100 seconds in VLAN 2:

```
T2500-28TC(config)# ipv6 mld snooping vlan 2 router-aging-time 100
```

## ipv6 mld snooping vlan member-aging-time

### Description

The **ipv6 mld snooping vlan member-aging-time** command is used to specify member port aging time for a specified VLAN. If this time is set to 0, then the global member port aging time will be used. The default time is 0. To restore the default timer, please use **no ipv6 mld snooping vlan member-aging-time** command.

### Syntax

```
ipv6 mld snooping vlan vlan-id member-aging-time timer  
no ipv6 mld snooping vlan vlan-id member-aging-time
```

### Parameter

*vlan-id* — The specified IEEE 802.1Q VLAN ID, ranging from 1 to 4094.  
*timer* — Aging time of the member port in seconds, ranging from 200 to 1000 and 0.

### Command Mode

Global Configuration Mode

## Example

Specify the member port aging time as 100 seconds in VLAN 2:

```
T2500-28TC(config)# ipv6 mld snooping vlan 2 member-aging-time 100
```

## ipv6 mld snooping vlan immediate-leave

### Description

The **ipv6 mld snooping vlan immediate-leave** command is used to enable the immediate leave function on a specified VLAN. To disable this function, please use **no ipv6 mld snooping vlan immediate-leave** command. By default, it is disabled.

### Syntax

```
ipv6 mld snooping vlan vlan-id immediate-leave  
no ipv6 mld snooping vlan vlan-id immediate-leave
```

### Parameter

*vlan-id* — The specified IEEE 802.1Q VLAN ID to enable the immediate leave function, ranging from 1 to 4094.

### Command Mode

Global Configuration Mode

### Example

Enable immediate leave function on VLAN 2:

```
T2500-28TC(config)# ipv6 mld snooping vlan 2 immediate-leave
```

## ipv6 mld snooping vlan mrouter

### Description

The **ipv6 mld snooping vlan mrouter** command is used to configure the static router port in a specified VLAN. To disable the static router port, please use **no mld snooping vlan mrouter** command.

### Syntax

```
ipv6 mld snooping vlan vlan-id mrouter interface gigabitEthernet port  
no ipv6 mld snooping vlan vlan-id mrouter [interface gigabitEthernet port]
```

### Parameter

*vlan-id* — The specified IEEE 802.1Q VLAN ID, ranging from 1 to 4094.  
*port* — Interface number of the router port(s).

## Command Mode

Global Configuration Mode

## Example

Configure the gigabitEthernet 1/0/2 as static router port in VLAN 2:

```
T2500-28TC(config)# ipv6 mld snooping vlan 2 mrouter interface
gigabitEthernet 1/0/2
```

# ipv6 mld snooping vlan static

## Description

The **ipv6 mld snooping vlan static** command is used to configure the static multicast groups. To disable the static multicast group, please use **no ipv6 mld snooping vlan static** command.

## Syntax

```
ipv6 mld snooping vlan vlan-id static ipv6_multicast_addr interface
gigabitEthernet port
```

```
no ipv6 mld snooping vlan vlan-id static ipv6_multicast_addr [interface
gigabitEthernet port]
```

## Parameter

*vlan-id* — The multicast group VLAN ID, ranging from 1 to 4094.

*ipv6\_multicast\_addr* — IPv6 address of the static multicast group.

*port* — Interface number of the member port(s).

## Command Mode

Global Configuration Mode

## Example

Configure the static multicast group ff80::1234 in VLAN 2 with the member port gigabitEthernet 1/0/2:

```
T2500-28TC(config)# ipv6 mld snooping vlan 2 static ff80::1234 interface
gigabitEthernet 1/0/2
```

# ipv6 mld snooping querier vlan

## Description

The **ipv6 mld snooping querier vlan** command is used to enable the MLD Querier function. To disable this function, please use **no ipv6 mld snooping querier vlan** command.



## Syntax

```
ipv6 mld snooping querier vlan vlan-id  
no ipv6 mld snooping querier vlan vlan-id
```

## Parameter

*vlan-id* — The VLAN that enables the MLD querier function, ranging from 1 to 4094.

## Command Mode

Global Configuration Mode

## Example

Enable MLD Querier function on VLAN 2:

```
T2500-28TC(config)# ipv6 mld snooping querier vlan 2
```

# ipv6 mld snooping querier vlan max-response-time

## Description

The **ipv6 mld snooping querier vlan max-response-time** command is used to specify the max response time of the Query message. The default value is 10 seconds. To restore the default value, please use **no ipv6 mld snooping querier vlan max-response-time** command.

## Syntax

```
ipv6 mld snooping querier vlan vlan-id max-response-time time  
no ipv6 mld snooping querier vlan vlan-id max-response-time
```

## Parameter

*vlan-id* — The VLAN that enables the MLD Querier function, ranging from 1 to 4094.

*time* — Specify the time in seconds, ranging from 1 to 25.

## Command Mode

Global Configuration Mode

## Example

Specify the max response time as 10s on VLAN 2:

```
T2500-28TC(config)# ipv6 mld snooping querier vlan 2 max-response-time  
10
```

## ipv6 mld snooping querier vlan query-interval

### Description

The **ipv6 mld snooping querier vlan query-interval** command is used to specify the interval to send the Query Message. The default value is 25 seconds. To restore the default value, please use **no ipv6 mld snooping querier vlan query-interval** command.

### Syntax

```
ipv6 mld snooping querier vlan vlan-id query-interval interval  
no ipv6 mld snooping querier vlan vlan-id query-interval
```

### Parameter

*vlan-id* — The VLAN that enables the MLD Querier function, ranging from 1 to 4094.

*interval* — Specify the interval to send the Query message in seconds, ranging from 2 to 300.

### Command Mode

Global Configuration Mode

### Example

Specify the interval to send the Query Message as 10s on VLAN 2:

```
T2500-28TC(config)# ipv6 mld snooping querier vlan 2 query-interval 10
```

## ipv6 mld snooping querier vlan query-source

### Description

The **ipv6 mld snooping querier vlan query-source** command is used to specify the source address which sends the Query message. The default value is FE80::02FF:FFFF:FE00:0001. To restore the default value, please use **no ipv6 mld snooping querier vlan query-source** command.

### Syntax

```
ipv6 mld snooping querier vlan vlan-id query-source ipv6-addr  
no ipv6 mld snooping querier vlan vlan-id query-source
```

### Parameter

*vlan-id* — IEEE 802.1Q VLAN ID, ranging from 1 to 4094.

*ipv6-addr* — Specify the IPv6 source address.

### Command Mode

Global Configuration Mode

## Example

Specify the source address which sends the Query message as fe80::1234 on VLAN 2:

```
T2500-28TC(config)# ipv6 mld snooping querier vlan 2 query-source  
fe80::1234
```

## ipv6 mld snooping filter(global)

### Description

The **ipv6 mld snooping filter** command is used to configure the multicast group filter entries in the format of ip-range. To disable the filter entry, please use **no ipv6 mld snooping filter** command.

### Syntax

```
ipv6 mld snooping filter filter-id start-ipv6 end-ipv6  
no ipv6 mld snooping filter filter-id
```

### Parameter

*filter-id* —— Specify the filter ID, ranging from 1 to 30.  
*start-ipv6* —— Start IPv6 multicast address of the filter entry.  
*end-ipv6* —— End IPv6 multicast address of the filter entry.

### Command Mode

Global Configuration Mode

### Example

Create filter entry with filter ID as 2, start IP as ff80::1234 and end IP as ff80::1235:

```
T2500-28TC(config)# ipv6 mld snooping filter 2 ff80::1234 ff80::1235
```

## ipv6 mld snooping filter(interface)

### Description

The **ipv6 mld snooping filter** command is used to enable the filter function on the interface. To disable the filter function, please use **no ipv6 mld snooping filter** command.

### Syntax

```
ipv6 mld snooping filter  
no ipv6 mld snooping filter
```

### Command Mode

Interface Configuration Mode

### Example

Enable filter function on interface gigabitEthernet 1/0/2:

```
T2500-28TC(config)# interface gigabitEthernet 1/0/2
T2500-28TC(config-if)# ipv6 mld snooping filter
```

## ipv6 mld snooping filter-mode

### Description

The **ipv6 mld snooping filter-mode** command is used to configure the filter mode of the interface. The default mode is accept. To restore the default mode, please use **no ipv6 mld snooping filter-mode** command.

### Syntax

```
ipv6 mld snooping filter-mode {accept | refuse}
no ipv6 mld snooping filter-mode
```

### Parameter

accept — Accept the multicast groups within the filter entry.  
refuse — Refuse the multicast groups within the filter entry.

### Command Mode

Interface Configuration Mode

### Example

Configure the filter mode as refuse on interface gigabitEthernet 1/0/2:

```
T2500-28TC(config)# interface gigabitEthernet 1/0/2
T2500-28TC(config-if)# ipv6 mld snooping filter-mode refuse
```

## ipv6 mld snooping filter-id

### Description

The **ipv6 mld snooping filter-id** command is used to specify the filter id on the interface. To disable this configuration, please use **no ipv6 mld snooping filter-id** command.

### Syntax

```
ipv6 mld snooping filter-id filter-list
no ipv6 mld snooping filter-id
```

### Parameter

*filter-list* — Specify the filter id list, in format of 1,3,10.

### Command Mode

Interface Configuration Mode

### Example

Specify the filter id as 1 and 10 on interface gigabitEthernet 1/0/2:

```
T2500-28TC(config)# interface gigabitEthernet 1/0/2
T2500-28TC(config-if)# ipv6 mld snooping filter-id 1,10
```

## ipv6 mld snooping max-group

### Description

The **ipv6 mld snooping max-group** command is used to specify the limit number of groups for a port to join in. The default value is 256. To restore the default value, please use **no ipv6 mld snooping max-group** command.

### Syntax

```
ipv6 mld snooping max-group limit
no ipv6 mld snooping max-group
```

### Parameter

*limit* — Specify the max number of multicast groups on a port, ranging from 0 to 256.

### Command Mode

Interface Configuration Mode

### Example

Specify the limit group as 128 on interface gigabitEthernet 1/0/2:

```
T2500-28TC(config)# interface gigabitEthernet 1/0/2
T2500-28TC(config-if)# ipv6 mld snooping max-group 128
```

## clear ipv6 mld snooping statistics

### Description

The **clear ipv6 mld snooping statistics** command is used to clear the statistics of the MLD packets.

### Syntax

```
clear ipv6 mld snooping statistics
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Clear the statistics of the MLD packets:

```
T2500-28TC(config)# clear ipv6 mld snooping statistics
```

## show ipv6 mld snooping

### Description

The **show ipv6 mld snooping** command is used to display the global configuration of MLD Snooping.

### Syntax

```
show ipv6 mld snooping
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the global configuration of MLD Snooping:

```
T2500-28TC(config)# show ipv6 mld snooping
```

## show ipv6 mld snooping vlan

### Description

The **show ipv6 mld snooping vlan** command is used to display VLAN information of MLD Snooping.

### Syntax

```
show ipv6 mld snooping vlan [vlan-id]
```

### Parameter

*vlan-id* — The VLAN ID selected to display, ranging from 1 to 4094.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display all of the VLAN information:

```
T2500-28TC(config)# show ipv6 mld snooping vlan
```

## show ipv6 mld snooping static-mcast

### Description

The **show ipv6 mld snooping static-mcast** command is used to display the static multicast groups configured by users.

### Syntax

```
show ipv6 mld snooping static-mcast
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display static multicast groups:

```
T2500-28TC(config)# show ipv6 mld snooping static-mcast
```

## show ipv6 mld snooping group

### Description

The **show ipv6 mld snooping group** command is used to display multicast groups.

### Syntax

```
show ipv6 mld snooping group [ dynamic | static ][ vlan vlan-id ]
```

### Parameter

*dynamic* — Display dynamic groups.

*static* — Display static groups.

*vlan-id* — The VLAN ID selected to display, ranging from 1 to 4094.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display all of the multicast groups:

```
T2500-28TC(config)# show ipv6 mld snooping group
```

## show ipv6 mld snooping filter

### Description

The **show ipv6 mld snooping filter** command is used to display the filter entries.

### Syntax

```
show ipv6 mld snooping filter
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the filter entries:

```
T2500-28TC(config)# show ipv6 mld snooping filter
```

## show ipv6 mld snooping interface

### Description

The **show ipv6 mld snooping interface** command is used to display the interface information of MLD Snooping.

### Syntax

```
show ipv6 mld snooping interface [ gigabitEthernet port ]
```

### Parameter

*port* — Specify the port number.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display all of the interface information:

```
T2500-28TC(config)# show ipv6 mld snooping interface
```

## show ipv6 mld snooping interface filter

### Description

The **show ipv6 mld snooping interface filter** command is used to display the filter ids bounded to the interface.



### Syntax

```
show ipv6 mld snooping interface filter [gigabitEthernet port]
```

### Parameter

*port* — Specify the port number.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display all filter ids bounded to all interface:

```
T2500-28TC(config)# show ipv6 mld snooping interface filter
```

## show ipv6 mld snooping querier

### Description

The **show ipv6 mld snooping querier** command is used to display the Querier configuration of VLAN.

### Syntax

```
show ipv6 mld snooping querier [vlan vlan-id]
```

### Parameter

*vlan-id* — The VLAN ID selected to display, ranging from 1 to 4094.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display all Querier information:

```
T2500-28TC(config)# show ipv6 mld snooping querier
```

## show ipv6 mld snooping statistics

### Description

The **show ipv6 mld snooping statistics** command is used to display the statistics of the MLD packets.

### Syntax

```
show ipv6 mld snooping statistics [interface gigabitEthernet port]
```

### Parameter

*port* — Specify the port number.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display statistics of MLD packets:

```
T2500-28TC(config)# show ipv6 mld snooping statistics
```

## Chapter 36 SNMP Commands

SNMP (Simple Network Management Protocol) functions are used to manage the network devices for a smooth communication, which can facilitate the network administrators to monitor the network nodes and implement the proper operation.

### snmp-server

#### Description

The **snmp-server** command is used to enable the SNMP function. By default, it is disabled. To return to the default configuration, please use **no snmp-server** command.

#### Syntax

```
snmp-server
no snmp-server
```

#### Command Mode

Global Configuration Mode

#### Example

Enable the SNMP function:

```
T2500-28TC(config)#snmp-server
```

### snmp-server view

#### Description

The **snmp-server view** command is used to add View. To delete the corresponding View, please use **no snmp-server view** command. The OID (Object Identifier) of the SNMP packets is used to describe the managed objects of the switch, and the MIB (Management Information Base) is the set of the OIDs. The SNMP View is created for the SNMP management station to manage MIB objects.

#### Syntax

```
snmp-server view name mib-oid {include | exclude}
no snmp-server view name mib-oid
```

## Parameter

*name* — The entry name of View, ranging from 1 to 16 characters. Each View can include several entries with the same name.

*mib-oid* — MIB Object ID. It is the Object Identifier (OID) for the entry of View, ranging from 1 to 61 characters.

*include* | *exclude* — View Type, with “include” and “exclude” options. They represent the view entry can/cannot be managed by the SNMP management station individually.

## Command Mode

Global Configuration Mode

## Example

Add a View named *view1*, configuring the OID as 1.3.6.1.6.3.20, and this OID can be managed by the SNMP management station:

```
T2500-28TC(config)#snmp-server view view1 1.3.6.1.6.3.20 include
```

# snmp-server group

## Description

The **snmp-server group** command is used to manage and configure the SNMP group. To delete the corresponding SNMP group, please use **no snmp-server group** command. SNMP v3 provides the VACM (View-based Access Control Model) and USM (User-Based Security Model) mechanisms for authentication. The users in the SNMP Group can manage the device via the Read View, Write View and Notify View. And the authentication mode and the privacy mode guarantee the high security for the communication between the management station and the managed device.

## Syntax

```
snmp-server group name [smode { v1 | v2c | v3 }] [slev { noAuthNoPriv | authNoPriv | authPriv }] [read read-view] [write write-view] [notify notify-view]
```

```
no snmp-server group name smode { v1 | v2c | v3 } slev { noAuthNoPriv | authNoPriv | authPriv }
```

## Parameter

*name* — The SNMP Group name, ranging from 1 to 16 characters. The Group Name, Security Model and Security Level compose the identifier of the SNMP Group. These three items of the Users in one group should be the same.

*smode* — Security Model, with v1、v2c and v3 options. They represent SNMP v1, SNMP v2c and SNMP v3.

*slev* — The Security Level of SNMP v3 Group. There are three options, including *noAuthNoPriv* (no authorization and no encryption)、*authNoPriv* (authorization and no encryption) and *authPriv*(authorization and encryption). By default, the Security Level is *noAuthNoPriv*. There is no need to configure this in SNMP v1 Model and SNMP v2c Model.

*read* — Read-only view. The management access is restricted to read-only, and changes cannot be made to the assigned SNMP View.

*write* — Write-only view. The management access is writing only and changes can be made to the assigned SNMP View. The View defined both as the Read View and the Write View can be read and modified.

*notify* — Notify view. The management station software can receive trap messages of the assigned SNMP view generated by the Switch's SNMP agent.

## Command Mode

Global Configuration mode

## Example

Add group 1, and configure the Security Model as SNMP v3, the security level as *authNoPriv*, the management access to the assigned View *viewDefault* as read-write, besides the trap messages sent by View *viewDefault* can be received by Management station:

```
T2500-28TC(config)#snmp-server group group1 smode v3 slev authNoPriv
read viewDefault write viewDefault notify viewDefault
```

Delete Group group 1:

```
T2500-28TC(config)#no snmp-server group group1 smode v3 slev authNoPriv
```

## snmp-server user

### Description

The **snmp-server user** command is used to add User. To delete the corresponding User, please use **no snmp-server user** command. The User in an SNMP Group can manage the switch via the management station software. The User and its Group have the same security level and access right.

## Syntax

```
snmp-server user name { local | remote } group-name [smode { v1 | v2c | v3 }]
[slev { noAuthNoPriv | authNoPriv | authPriv }] [cmode { none | MD5 | SHA }]
[cpwd confirm-pwd] [emode { none | DES }] [epwd encrypt-pwd]
```

```
no snmp-server user name
```

## Parameter

*name* — User Name, ranging from 1 to 16 characters.

local | remote — User Type, with local and remote options. Local indicates that the user is connected to a local SNMP engine, while remote indicates that the user is connected to a remote SNMP engine.

*group-name* — The Group Name of the User. The User is classified to the corresponding Group according to its Group Name, Security Model and Security Level.

*smode* — The Security Model of the User, with v1, v2c and v3 options. By default, the option is v1. The Security Model of the User must be the same with that of the Group which the User belongs to.

*slev* — The Security Level of SNMP v3 Group. There are three options, including noAuthNoPriv (no authorization and no encryption), authNoPriv (authorization and no encryption) and authPriv (authorization and encryption). By default, the option is noAuthNoPriv. The Security Level of the User must be the same with that of the Group which the User belongs to.

*cmode* — The Authentication Mode of the SNMP v3 User, with “none”, “MD5” and “SHA” options. “None” indicates no authentication method is used, “MD5” indicates the port authentication is performed via HMAC-MD5 algorithm and “SHA” indicates the port authentication is performed via SHA (Secure Hash Algorithm). SHA authentication mode has a higher security than MD5 mode. By default, the Authentication Mode is “none”.

*confirm-pwd* — Authentication Password, ranging from 1 to 16 characters.

*emode* — The Privacy Mode of the SNMP v3 User, with “none” and “DES” options. “None” indicates no privacy method is used, and “DES” indicates DES encryption method is used. By default, the Privacy Mode is none.

*encrypt-pwd* — Privacy Password, ranging from 1 to 16 characters.

## Command Mode

Global Configuration Mode

## Example

Add Local User admin to Group group2, and configure the Security Model of the user as v3, the Security Level of the group as authPriv, the Authentication Mode of the user as MD5, the Authentication Password as 11111, the Privacy Mode as DES, and the Privacy Password as 22222:

```
T2500-28TC(config)#snmp-server user admin local group2 smode v3 slew
authPriv cmode MD5 cpwd 11111 emode DES epwd 22222
```

# snmp-server community

## Description

The **snmp-server community** command is used to add Community. To delete the corresponding Community, please use **no snmp-server community** command. SNMP v1 and SNMP v2c adopt community name authentication. The community name can limit access to the SNMP agent from SNMP network management station, functioning as a password.

## Syntax

```
snmp-server community name { read-only | read-write } mib-view
no snmp-server community name
```

## Parameter

*name* —— Community Name, ranging from 1 to 16 characters.

read-only | read-write —— The access rights of the community, with “read-only” and “read-write” options.

*mib-view* —— The MIB View for the community to access.

## Command Mode

Global Configuration Mode

## Example

Add community public, and the community has read-write management right to View viewDefault:

```
T2500-28TC(config)#snmp-server community public read-write viewDefault
```

## snmp-server host

### Description

The **snmp-server host** command is used to add Notification. To delete the corresponding Notification, please use **no snmp-server host** command. With the Notification function enabled, the switch can initiatively report to the management station about the important events that occur on the Views, which allows the management station to monitor and process the events in time.

### Syntax

```
snmp-server host ip udp-port user-name [ smode { v1 | v2c | v3 } ] [slev
{ noAuthNoPriv | authNoPriv | authPriv }] [type { trap | inform }] [retries retries ]
[timeout timeout ]
```

```
no snmp-server host ip user-name
```

### Parameter

*ip* — The IP address of the management Host. Both IPv4 and IPv6 addresses are supported, for example 192.168.0.100 or fe80::1234.

*udp-port* — UDP port, which is used to send notifications. The UDP port functions with the IP address for the notification sending. By default, it is 162.

*user-name* — The User name of the management station.

*smode* — The Security Model of the management station, with v1, v2c and v3 options. By default, the option is v1.

*slev* — The Security Level of SNMP v3 Group. There are three options, including noAuthNoPriv (no authorization and no encryption), authNoPriv (authorization and no encryption) and authPriv (authorization and encryption). By default, the option is “noAuthNoPriv”.

*type* — The type of the notifications, with trap and inform options. Trap indicates traps are sent, while inform indicates informs are sent. The inform type has a higher security than the trap type and resend and timeout need to be configured if you select this option. You can only select the trap type in Security Model v1. By default, the type of the notifications is “trap”.

*retries* — The amount of times the switch retries an inform request, ranging from 1 to 255. The switch will resend the inform request if it doesn't get the response from the management station during the Timeout interval, and it will terminate resending the inform request if the resending times reach the specified Retry times.



*timeout* — The maximum time for the switch to wait for the response from the management station before resending a request, ranging from 1 to 3600 in seconds.

### Command Mode

Global Configuration Mode

### Example

Add a Notification entry, and configure the IP address of the management Host as 192.168.0.146, the UDP port as 162, the User name of the management station as admin, the Security Model of the management station as v2c, the type of the notifications as inform, the maximum time for the switch to wait as 1000 seconds, and the retries time as 100:

```
T2500-28TC(config)#snmp-server host 192.168.0.146 162 admin smode v2c
type inform retries 100 timeout 1000
```

## snmp-server engineID

### Description

The **snmp-server engineID** command is used to configure the local and remote engineID of the switch. To restore to the default setting, please use **no snmp-server engineID** command.

### Syntax

```
snmp-server engineID { [local local-engineID] [remote remote-engineID] }
no snmp-server engineID
```

### Parameter

*local* — Local Engine ID for local clients. The Engine ID is a unique alphanumeric string used to identify the SNMP engine on the switch. Its length ranges from 10 to 64 hexadecimal characters, which must be even number meanwhile.

*remote* — Remote Engine ID for the switch. The Engine ID is a unique alphanumeric string used to identify the SNMP engine on the remote device which receives informs from the switch. Its length ranges from 10 to 64 hexadecimal characters, which must be even number meanwhile.

### Command Mode

Global Configuration Mode

## Example

Specify the local engineID as 1234567890, and the remote engineID as abcdef123456:

```
T2500-28TC(config)#snmp-server engineID local 1234567890 remote
abcdef123456
```

## snmp-server traps snmp

### Description

The **snmp-server traps snmp** command is used to enable SNMP standard traps which include five types: linkup, linkdown, warmstart, coldstart, and auth-failure. To disable the sending of SNMP standard traps, please use **no snmp-server traps snmp** command.

#### Note:

The **snmp-server traps snmp** command without any parameter is used to enable all the five types of traps. And the **no snmp-server traps snmp** command without any parameter is used to disable all the five types of traps.

### Syntax

```
snmp-server traps snmp [ linkup | linkdown | warmstart | coldstart |
auth-failure ]
```

```
no snmp-server traps snmp [ linkup | linkdown | warmstart | coldstart |
auth-failure ]
```

### Parameter

linkup — Enable the linkup trap. It is sent when port status changes from linkdown to linkup. By default, it is enabled.

linkdown — Enable the linkdown trap. It is sent when port status changes from linkup to linkdown. By default, it is enabled.

warmstart — Enable the warmstart trap. It is sent upon SNMP function reboot. By default, it is enabled.

coldstart — Enable the coldstart trap. It is sent upon switch reboot. By default, it is enabled.

auth-failure — Enable the auth-failure trap. It is sent when a received SNMP request fails the authentication. By default, it is enabled.

### Command Mode

Global Configuration Mode

## Example

Enable the linkup trap for the switch:

```
T2500-28TC(config)# snmp-server traps snmp linkup
```

## snmp-server traps security

### Description

The **snmp-server traps security** command is used to enable SNMP security traps which include four types: dhcp-filter, ip-duplicate, ip-mac-binding, and port-access. To disable the sending of SNMP security traps, please use **no snmp-server traps security** command.

#### Note:

The **snmp-server traps security** command without any parameter is used to enable all the four types of traps. And the **no snmp-server traps security** command without any parameter is used to disable all the four types of traps.

### Syntax

```
snmp-server traps security [dhcp-filter | ip-duplicate | ip-mac-binding | port-access ]
```

```
no snmp-server traps security [dhcp-filter | ip-duplicate | ip-mac-binding | port-access ]
```

### Parameter

dhcp-filter — Enable the dhcp-filter trap. It is sent when the device receives a DHCP packet from an untrusted port. By default, it is disabled.

ip-duplicate — Enable the ip-duplicate trap. It is sent when another host uses the switch's IP address. By default, it is disabled.

ip-mac-binding — Enable the ip-mac-binding trap. It is sent when it receives a packet from the host that does not match the entries in IP-MAC binding table. By default, it is disabled. To view the IP-MAC binding table, please enter the [show ip source binding](#) command.

port-access — Enable the port-access trap. It is sent when some users try to log on to the web management page via ports that have no authority. By default, it is disabled.

### Command Mode

Global Configuration Mode

## Example

Enable the dhcp-filter trap for the switch:

```
T2500-28TC(config)# snmp-server traps security dhcp-filter
```

## snmp-server traps link-status

### Description

The **snmp-server traps link-status** command is used to enable SNMP link status trap for the specified port. To disable the sending of SNMP link status trap, please use **no snmp-server traps link-status** command.

### Syntax

```
snmp-server traps link-status
```

```
no snmp-server traps link-status
```

### Command Mode

Interface Configuration Mode (interface gigabitEthernet / interface range gigabitEthernet)

### Example

Enable SNMP link status trap for port 3:

```
T2500-28TC(config)# interface gigabitEthernet 1/0/3
```

```
TL-SG3424P(config-if)# snmp-server traps link-status
```

## snmp-server traps

### Description

The **snmp-server traps** command is used to enable SNMP extended traps. To disable the sending of SNMP extended traps, please use **no snmp-server traps** command.

### Syntax

```
snmp-server traps { bandwidth-control | cpu | flash | ipaddr-change | lldp |  
loopback-detection | storm-control | spanning-tree | memory }
```

```
no snmp-server traps { bandwidth-control | cpu | flash | ipaddr-change | lldp |  
loopback-detection | storm-control | spanning-tree | memory }
```

## Parameter

**bandwidth-control** — Enable bandwidth-control trap. It is sent when the rate limit function is enabled and the bandwidth exceeds the predefined value.

**cpu** — Allow CPU-related trap. It is sent when CPU usage exceeds the predefined threshold. By default, the CPU usage threshold of the switch is 80%.

**flash** — Enable flash trap. It is sent when flash is modified during operations such as backup, reset, firmware upgrade, configuration import, etc.

**ipaddr-change** — Enable ipaddr-change trap. It is sent when IP address is changed such as user manually modifies the IP address or the switch obtains a new IP address from DHCP.

**lldp** — Enable LLDP trap. It is sent when the port's neighbor changes.

**loopback-detection** — Enable loopback-detection trap. It is sent when the switch detects loopback or loopback is cleared.

**storm-control** — Enable storm-control trap. It is sent when the multicast or broadcast rate exceeds the predefined value.

**spanning-tree** — Enable spanning-tree trap. It is sent when the port forwarding status changes or the port receives TCN packet or packet with TC flag.

**memory** — Enable memory trap. It is sent when memory usage exceeds 80%.

## Command Mode

Global Configuration Mode

## Example

Enable SNMP extended bandwidth-control trap for the switch:

```
T2500-28TC(config)# snmp-server traps bandwidth-control
```

# snmp-server traps ddm

## Description

The **snmp-server traps ddm** command is used to enable SNMP DDM traps. DDM function is used to monitor the status of the SFP modules inserted into the SFP ports on the switch.

To disable the sending of SNMP DDM traps, use **no snmp-server traps ddm** command.

## Syntax

```
snmp-server traps ddm [ temperature | voltage | bias_current | tx_power | rx_power ]
```

```
no snmp-server traps ddm [ temperature | voltage | bias_current | tx_power | rx_power ]
```

### Parameter

temperature — Enable DDM Temperature trap. It is sent when the DDM temperature value exceeds the alarm threshold or warning threshold.

voltage — Enable DDM Voltage trap. It is sent when the DDM voltage value exceeds the alarm threshold or warning threshold.

bias\_current — Enable DDM Bias Current trap. It is sent when the DDM bias current value exceeds the alarm threshold or warning threshold.

tx\_power — Enable DDM Tx Power trap. It is sent when the DDM Tx power value exceeds the alarm threshold or warning threshold.

rx\_power — Enable DDM Rx Power trap. It is sent when the DDM Rx power value exceeds the alarm threshold or warning threshold.

### User guidelines

The **snmp-server traps ddm** command without any parameter is used to enable all the types of DDM traps. And the **no snmp-server traps ddm** command without any parameter is used to disable all the types of DDM traps.

For more instructions about the alarm threshold or warning threshold, refer to [Chapter 29 DDM Commands](#).

### Command Mode

Global Configuration Mode

### Example

Enable all the SNMP DDM traps for the switch:

```
T2500-28TC(config)# snmp-server traps ddm
```

## snmp-server traps mac

### Description

The **snmp-server traps mac** command is used to enable SNMP extended MAC-address-related traps which include four types: new, full, learn-mode-change and max-learned. To disable the sending of SNMP extended MAC-address-related traps, please use **no snmp-server traps mac** command.

**Note:**

The **snmp-server traps mac** command without any parameter is used to enable all the four types of traps. And the **no snmp-server traps mac** command without any parameter is used to disable all the four types of traps

**Syntax**

```
snmp-server traps mac [ new | full | learn-mode-change | max-learned ]
```

```
no snmp-server traps mac [ new | full | learn-mode-change | max-learned ]
```

**Parameter**

**new** — Enable new MAC address trap. It is sent when the switch learns new MAC address including dynamic address, static address and filter address.

**full** — Enable MAC address table trap. It is sent when the MAC address table is full.

**learn-mode-change** — Enable MAC address learn-mode-change trap. It is sent when MAC address learning mode of the switch changes.

**max-learned** — Enable MAC address max-learned trap. It is sent when the amount of learned MAC address reaches the limit which is configured in port security module.

**Command Mode**

Global Configuration Mode

**Example**

Enable all SNMP extended MAC address-related traps for the switch:

```
T2500-28TC(config)# snmp-server traps mac
```

Enable new MAC address trap only for the switch:

```
T2500-28TC(config)# snmp-server traps mac new
```

## snmp-server traps vlan

**Description**

The **snmp-server traps vlan** command is used to enable SNMP extended VLAN-related traps which include two types: create and delete. To disable this function, please use **no snmp-server traps vlan** command.

**Note:**

The **snmp-server traps vlan** command without any parameter is used to enable the both traps. And the **no snmp-server traps vlan** command without any parameter is used to disable the the both traps.

**Syntax**

```
snmp-server traps vlan [ create | delete ]
```

```
no snmp-server traps vlan [create | delete ]
```

**Parameter**

**create** — Enable VLAN-created trap. It is sent when new VLAN is created successfully.

**delete** — Enable VLAN-deleted traps. It is sent when VLAN is deleted successfully.

**Command Mode**

Global Configuration Mode

**Example**

Enable all SNMP extended VLAN-related traps for the switch:

```
T2500-28TC(config)# snmp-server traps vlan
```

Enable VLAN-created trap only for the switch:

```
T2500-28TC(config)# snmp-server traps vlan create
```

## rmon history

**Description**

The **rmon history** command is used to configure the history sample entry. To return to the default configuration, please use **no rmon history** command. RMON (Remote Monitoring), basing on SNMP architecture, functions to monitor the network. History Group is one of the commonly used RMON Groups. After a history group is configured, the switch collects network statistics information periodically, based on which the management station can monitor network effectively.

**Syntax**

```
rmon history index interface { fastEthernet port | gigabitEthernet port }  
[ interval seconds ] [ owner owner-name ]
```

```
no rmon history index
```



## Parameter

*index* — The index number of the entry, ranging from 1 to 12, in the format of 1-3,5.

*port* — The Fast/Gigabit Ethernet port number.

*seconds* — The interval to take samplings from the port, ranging from 10 to 3600 in seconds. By default, it is 1800.

*owner-name* — The owner of the history sample entry, ranging from 1 to 16 characters. By default, it is “monitor”.

## Command Mode

Global Configuration Mode

## Example

Configure the sample port as 2 and the sample interval as 100 seconds for the entry 1-3:

```
T2500-28TC(config)#rmon history 1-3 interface fastEthernet 1/0/2 interval
100 owner owner1
```

# rmon event

## Description

The **rmon event** command is used to configure the entries of SNMP-RMON Event. To return to the default configuration, please use **no rmon event** command. Event Group, as one of the commonly used RMON Groups, is used to define RMON events. Alarms occur when an event is detected.

## Syntax

```
rmon event index { [ user user-name ] [ description descript ] [ type {none |
log | notify | log-notify } ] [ owner owner-name ] }
```

```
no rmon event index
```

## Parameter

*index* — The index number of the event entry, ranging from 1 to 12. You can only select one entry for each command.

*user-name* — The name of the User to which the event belongs, ranging from 1 to 16 characters. By default, it is “public”.

*descript* — The description of the event, ranging from 1 to 16 characters. By default, it is empty.

*type* — The event type, with “none”, “log”, “notify” and “both” options. “None” indicates no processing, “log” indicates logging the event, “notify” indicates sending trap messages to the management station, and “both” indicates logging the event and sending trap messages to the management station.

*owner-name* — The owner of the event entry, ranging from 1 to 16 characters. By default, it is “monitor”.

## Command Mode

Global Configuration Mode

## Example

Configure the user name of entry 1, 2, 3 and 4 as user1, the description of the event as “description1”, the type of event as log and the owner of the event as “owner1”:

```
T2500-28TC(config)#rmon event 1-4 user user1 description description1
type log owner owner1
```

## rmon alarm

### Description

The **rmon alarm** command is used to configure SNMP-RMON Alarm Management. To return to the default configuration, please use **no rmon alarm** command. Alarm Group is one of the commonly used RMON Groups. RMON alarm management allows monitoring the specific alarm variables. When the value of a monitored variable exceeds the threshold, an alarm event is generated, which triggers the switch to act in the set way.

### Syntax

```
rmon alarm index interface { fastEthernet port | gigabitEthernet port }
[ alarm-variable { drop | revbyte | revpkt | bpkt | mpkt | crc-lign | undersize |
oversize | fragment | jabber | collision | 64 | 65-127 | 128-511 | 512-1023 |
1024-10240 } ] [ s-type { absolute | delta } ] [ rising-threshold r-hold ]
[ rising-event-index r-eventf ] [ falling-threshold f-hold ] [ falling-event-index
f-eventf ] [ a-type {rise | fall | all} ] [ owner owner-name ] [ interval interval ]
no rmon alarm index
```

### Parameter

*index* — The index number of the Alarm Management entry, ranging from 1 to 12, in the format of 1-3,5.

*port* — String for the port on which the Alarm entry acts, format as module/slot/port, for example 1/0/24.

*alarm-variable* — The alarm variable. By default, the option is drop.

*s-type* — Sample Type, which is the sampling method for the selected variable and comparing the value against the thresholds. There are two options, absolute and delta. Absolute indicates comparing the values directly with the thresholds at the end of the sampling interval. Delta indicates subtracting the last sampled value from the current value, and then comparing the difference in the values with the threshold. By default, the Sample Type is absolute.

*r-hold* — The rising counter value that triggers the Rising Threshold alarm, ranging from 1 to 65535. By default, it is 100.

*r-event* — Rise Event, which is the index of the corresponding event which will be triggered if the sampled value is larger than the Rising Threshold. It ranges from 1 to 12.

*f-hold* — The falling counter value that triggers the Falling Threshold alarm, ranging from 1 to 65535. By default, it is 100.

*f-event* — Fall Event, which is the index of the corresponding event which will be triggered if the sampled value is lower than the Falling Threshold. It ranges from 1 to 12.

*a-type* — Alarm Type, with rise, fall and all options. Rise indicates that the alarm event will be triggered when the sampled value exceeds the Rising Threshold, fall indicates that the alarm event will be triggered when the sampled value is under the Falling Threshold, and all indicates that the alarm event will be triggered either the sampled value exceeds the Rising Threshold or is under the Falling Threshold. By default, the Alarm Type is all.

*owner-name* — The owner of the entry, ranging from 1 to 16 characters. By default, it is monitor.

*interval* — The alarm interval time, ranging from 10 to 3600 in seconds. By default, it is 1800.

## Command Mode

Global Configuration Mode

## Example

Configure the ports of entries of 1-3 as Gi1/0/2, the owners as owner1 and the alarm intervals as 100 seconds:

```
T2500-28TC(config)#rmon alarm 1-3 interface fastEthernet 1/0/2 owner  
owner1 interval 100
```

## show snmp-server

### Description

The **show snmp-server** command is used to display SNMP configuration globally.

### Syntax

```
show snmp-server
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display SNMP configuration globally:

```
T2500-28TC#show snmp-server
```

## show snmp-server view

### Description

The **show snmp-server view** command is used to display the View table.

### Syntax

```
show snmp-server view
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the View table:

```
T2500-28TC#show snmp-server view
```

## show snmp-server group

### Description

The **show snmp-server group** command is used to display the Group table.

### Syntax

```
show snmp-server group
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display the Group table:

```
T2500-28TC#show snmp-server group
```

## show snmp-server user

### Description

The **show snmp-server user** command is used to display the User table.

### Syntax

```
show snmp-server user
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the User table:

```
T2500-28TC#show snmp-server user
```

## show snmp-server community

### Description

The **show snmp-server community** command is used to display the Community table.

### Syntax

```
show snmp-server community
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the Community table:

```
T2500-28TC#show snmp-server community
```

## show snmp-server host

### Description

The **show snmp-server host** command is used to display the Host table.

### Syntax

```
show snmp-server host
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the Host table:

```
T2500-28TC#show snmp-server host
```

## show snmp-server engineID

### Description

The **show snmp-server engineID** command is used to display the engineID of the SNMP.

### Syntax

```
show snmp-server engineID
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the engineID:

```
T2500-28TC#show snmp-server engineID
```

## show rmon history

### Description

The **show rmon history** command is used to display the configuration of the history sample entry.

### Syntax

```
show rmon history [index]
```

### Parameter

*index* — The index number of the entry selected to display the configuration, ranging from 1 to 12, in the format of 1-3, 5. You can select more than one entry for each command. By default, the configuration of all history sample entries is displayed.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the configuration of all history sample entries:

```
T2500-28TC#show rmon history
```

## show rmon event

### Description

The **show rmon event** command is used to display the configuration of SNMP-RMON Event.

### Syntax

```
show rmon event [index]
```

### Parameter

*index* — The index number of the entry selected to display the configuration, ranging from 1 to 12, in the format of 1-3, 5. You can select more than one entry for each command. By default, the configuration of all SNMP-RMON enabled entries is displayed.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the Event configuration of entry1-4:

```
T2500-28TC#show rmon event 1-4
```

## show rmon alarm

### Description

The **show rmon alarm** command is used to display the configuration of the Alarm Management entry.

## Syntax

```
show rmon alarm [index]
```

## Parameter

*index* — The index number of the entry selected to display the configuration, ranging from 1 to 12, in the format of 1-3, 5. You can select more than one entry for each command. By default, the configuration of all Alarm Management entries is displayed.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display the configuration of the Alarm Management entry 1-2:

```
T2500-28TC#show rmon alarm 1-2
```



## Chapter 37 LLDP Commands

LLDP function enables network devices to advertise their own device information periodically to neighbors on the same LAN. The information of the LLDP devices in the LAN can be stored by its neighbor in a standard MIB, so it is possible for the information to be accessed by a Network Management System (NMS) using SNMP.

### Ildp

#### Description

The **ildp** command is used to enable LLDP function. To disable the LLDP function, please use **no ildp** command.

#### Syntax

**ildp**  
**no ildp**

#### Command Mode

Global Configuration Mode

#### Example

Enable LLDP function globally:

```
T2500-28TC(config)#ildp
```

### Ildp hold-multiplier

#### Description

The **ildp hold-multiplier** command is used to configure the Hold Multiplier parameter. The aging time of the local information in the neighbor device is determined by the actual TTL value used in the sending LLDPDU.  $TTL = \text{Hold Multiplier} * \text{Transmit Interval}$ . To return to the default configuration, please use **no ildp hold-multiplier** command.

#### Syntax

**ildp hold-multiplier** *multiplier*  
**no ildp hold-multiplier**

## Parameter

*multiplier* — Configure the Hold Multiplier parameter. It ranges from 2 to 10. By default, it is 4.

## Command Mode

Global Configuration Mode

## Example

Specify Hold Multiplier as 5:

```
T2500-28TC(config)#lldp hold-multiplier 5
```

# lldp timer

## Description

The **lldp timer** command is used to configure the parameters about transmission. To return to the default configuration, please use **no lldp timer** command.

## Syntax

```
lldp timer { tx-interval tx-interval | tx-delay tx-delay | reinit-delay reinit-delay | notify-interval notify-interval | fast-count fast-count }
```

```
no lldp timer { tx-interval | tx-delay | reinit-delay | notify-interval | fast-count }
```

## Parameter

*tx-interval* — Configure the interval for the local device to transmit LLDPDU to its neighbors. The value ranges from 5 to 32768 and the default value is 30 seconds.

*tx-delay* — Configure a value from 1 to 8192 in seconds to specify the time for the local device to transmit LLDPDU to its neighbors after changes occur so as to prevent LLDPDU being sent frequently. By default, it is 2 seconds.

*reinit-delay* — This parameter indicates the amount of delay from when LLDP status becomes "disable" until re-initialization will be attempted. The value ranges from 1 to 10 and the default value is 3.

*notify-interval* — Specify the interval of Trap message which will be sent from local device to network management system. The value ranges from 5 to 3600 and the default value is 5 seconds.

*fast-count* — When the port's LLDP state transforms from Disable (or Rx\_Only) to Tx&Rx (or Tx\_Only), the fast start mechanism will be enabled, that

is, the transmit interval will be shorten to a second, and several LLDPDUs will be sent out (the number of LLDPDUs equals this parameter). The value ranges from 1 to 10 and the default value is 3.

### Command Mode

Global Configuration Mode

### Example

Specify the Transmit Interval of LLDPDU as 45 seconds and Trap message to NMS as 120 seconds:

```
T2500-28TC(config)#lldp timer tx-interval 45
T2500-28TC(config)#lldp timer notify-interval 120
```

## Ildp receive

### Description

The **lldp receive** command is used to enable the designated port to receive LLDPDU. To disable the function, please use **no lldp receive** command.

### Syntax

```
lldp receive
no lldp receive
```

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

Enable Fast Ethernet port 1 to receive LLDPDU:

```
T2500-28TC(config)#interface fastEthernet 1/0/1
T2500-28TC(config-if)#lldp receive
```

## Ildp transmit

### Description

The **lldp transmit** command is used to enable the designated port to transmit LLDPDU. To disable the function, please use **no lldp transmit** command.

## Syntax

**lldp transmit**  
**no lldp transmit**

## Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

Enable Fast Ethernet port 1 to transmit LLDPDU:

```
T2500-28TC(config)# interface fastEthernet 1/0/1
T2500-28TC(config-if)#lldp transmit
```

# lldp snmp-trap

## Description

The **lldp snmp-trap** command is used to enable the port's SNMP notification. If enabled, the port will notify the trap event to network management system. To disable the ports' SNMP notification, please use **no lldp snmp-trap** command.

## Syntax

**lldp snmp-trap**  
**no lldp snmp-trap**

## Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

Enable the SNMP notification for Fast Ethernet port 1:

```
T2500-28TC(config)#interface fastEthernet 1/0/1
T2500-28TC(config-if)#lldp snmp-trap
```

## Ildp tlv-select

### Description

The **ildp tlv-select** command is used to configure TLVs to be included in outgoing LLDPDU. To exclude TLVs, please use **no ildp tlv-select** command. By default, All TLVs are included in outgoing LLDPDU.

### Syntax

**ildp tlv-select** [port-description | system-capability | system-description | system-name | management-address | port-vlan | protocol-vlan | vlan-name | link-aggregation | mac-phy-cfg | max-frame-size | power | all]

**no ildp tlv-select** [port-description | system-capability | system-description | system-name | management-address | port-vlan | protocol-vlan | vlan-name | link-aggregation | mac-phy-cfg | max-frame-size | power | all]

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

Exclude “management-address” and “port-vlan-id” TLVs in LLDPDU outgoing from Fast Ethernet port 1:

```
T2500-28TC(config)# interface fastEthernet 1/0/1
T2500-28TC(config-if)# no ildp tlv-select management-address port-vlan
```

## Ildp med-fast-count

### Description

The **ildp med-fast-count** command is used to configure the number of the LLDP-MED frames that will be sent out. When LLDP-MED fast start mechanism is activated, multiple LLDP-MED frames will be transmitted based on this parameter. The default value is 4. To return to the default configuration, please use **no ildp med-fast-count** command.

### Syntax

**ildp med-fast-count** *count*

**no ildp med-fast-count**

### Parameter

*count* — Configure the Fast Start Count parameter. It ranges from 1 to 10. By default, it is 4.

### Command Mode

Global Configuration Mode

### Example

Specify Fast Start Count as 5:

```
T2500-28TC(config)# lldp med-fast-count 5
```

## lldp med-status

### Description

The **lldp med-status** command is used to enable the LLDP-MED feature for the corresponding port. After the LLDP-MED feature is enabled, the port's Admin Status will be changed to Tx&Rx. To disable the LLDP-MED feature for the corresponding port, please use **no lldp med-status** command.

### Syntax

**lldp med-status**

**no lldp med-status**

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

### Example

Enable the LLDP-MED feature for port 1/0/2:

```
T2500-28TC(config)# interface fastEthernet 1/0/2
```

```
T2500-28TC(config-if)# lldp med-status
```

## lldp med-tlv-select

### Description

The **lldp med-tlv-select** command is used to configure LLDP-MED TLVs to be included in outgoing LLDPDU for the corresponding port. To exclude LLDP-MED TLVs, please use **no lldp med-tlv-select** command. By default, All TLVs are included in outgoing LLDPDU.

## Syntax

```
lldp med-tlv-select { [inventory-management] [location] [network-policy]
[power-management] [all] }
```

```
no lldp med-tlv-select { [inventory-management] [location] [network-policy]
[power-management] [all] }
```

## Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

Exclude “network policy” and “inventory” TLVs in LLDPDU outgoing from port 1/0/2:

```
T2500-28TC(config)# interface fastEthernet 1/0/2
```

```
T2500-28TC(config-if)# no lldp med-tlv-select network-policy inventory-
management
```

# lldp med-location

## Description

The lldp med-location command is used to configure the Location Identification TLV's content in outgoing LLDPDU of the port.

## Syntax

```
lldp med-location { emergency-number identifier | civic-address [ [ language
language ] [ province-state province-state ] [ county county ] [ city city ] [ street
street ] [ house-number house-number ] [ name name ] [ postal-zipcode
postal-zipcode ] [ room-number room-number ] [ post-office-box post-office-box ]
[ additional additional ] [ country-code country-code ] [ what { dhcp-server |
endpoint | switch } ] ] }
```

## Parameter

**emergency-number** — Emergency Call Service ELIN identifier, which is used during emergency call setup to a traditional CAMA or ISDN trunk-based PSAP. The length of this field ranges from 10 to 25 characters.

**civic-address** — The civic address is defined to reuse the relevant sub-fields of the DHCP option for civic Address based Location Configuration Information as specified by IETF.

## Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

Configure the civic address in the Location Identification TLV's content in outgoing LLDPDU of port 1/0/2. Configure the language as English and city as London:

```
T2500-28TC (config)# interface fastEthernet 1/0/2
T2500-28TC(config-if)# lldp med-location civic-address language English
city London
```

## show lldp

### Description

The **show lldp** command is used to display the global configuration of LLDP.

### Syntax

```
show lldp
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the global configuration of LLDP:

```
T2500-28TC#show lldp
```

## show lldp interface

### Description

The **show lldp interface** command is used to display LLDP configuration of the corresponding port. By default, the LLDP configuration of all the ports will be displayed.

### Syntax

```
show lldp interface [ fastEthernet port | gigabitEthernet port]
```

### Parameter



*port* — The Fast/Gigabit Ethernet port number.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the LLDP configuration of Fast Ethernet port 1:

```
T2500-28TC#show lldp interface fastEthernet 1/0/1
```

## show lldp local-information interface

### Description

The **show lldp local-information interface** command is used to display the LLDP information of the corresponding port. By default, the LLDP information of all the ports will be displayed.

### Syntax

```
show lldp local-information interface [fastEthernet port | gigabitEthernet  
port]
```

### Parameter

*port* — The Fast/Gigabit Ethernet port number.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the LLDP information of Fast Ethernet port 1:

```
T2500-28TC#show lldp local-information interface fastEthernet 1/0/1
```

## show lldp neighbor-information interface

### Description

The **show lldp neighbor-information interface** command is used to display the neighbor information of the corresponding port. By default, the neighbor information of all the ports will be displayed.

### Syntax

```
show lldp neighbor-information interface [fastEthernet port |  
gigabitEthernet port]
```

### Parameter

*port* — The Fast/Gigabit Ethernet port number.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the neighbor information of Fast Ethernet port 1:

```
T2500-28TC#show lldp neighbor-information interface fastEthernet 1/0/1
```

## show lldp traffic interface

### Description

The **show lldp traffic interface** command is used to display the LLDP statistic information between the local device and neighbor device of the corresponding port. By default, the LLDP statistic information of all the ports will be displayed.

### Syntax

```
show lldp traffic interface [ fastEthernet port | gigabitEthernet port ]
```

### Parameter

*port* — The Fast/Gigabit Ethernet port number.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the LLDP statistic information of Fast Ethernet port 1:

```
T2500-28TC#show lldp traffic interface fastEthernet 1/0/1
```

## Chapter 38 Cluster Commands

Cluster Management function enables a network administrator to manage the scattered devices in the network via a management device. After a commander switch is configured, management and maintenance operations intended for the member devices in a cluster is implemented by the commander device.

### cluster ndp

#### Description

The **cluster ndp** command is used to configure NDP globally. To disable this function, please use **no cluster ndp** command. NDP (Neighbor Discovery Protocol) is used to discover the information of the directly connected neighbor devices to support cluster establishing. An NDP-enabled device sends NDP packets regularly to neighbor devices as well as receives NDP packets from neighbor devices. An NDP packet carries the aging time, which indicates the period of the receiving devices to keep the NDP packet.

#### Syntax

```
cluster ndp
```

```
cluster ndp timer { [hello hello-time ] [aging aging-time] }
```

```
no cluster ndp
```

```
no cluster ndp timer { [hello hello-time ] [aging aging-time] }
```

#### Parameter

*hello-time* —— Hello Time, which is the interval to send NDP packets. Hello Time ranges from 5 to 254 in seconds. By default, it is 60. Hello Time should be smaller than Aging Time.

*aging-time* —— Aging Time, which is the period for the neighbor switch to keep the NDP packets from this switch. Aging Time ranges from 5 to 255 in seconds. By default, it is 180.

#### Command Mode

Global Configuration Mode

#### Example

Enable NDP function globally, and configure Aging Time as 120 seconds, Hello Time as 50 seconds:

```
T2500-28TC(config)#cluster ndp
```

```
T2500-28TC(config)#cluster ndp timer hello 50 aging 120
```

## cluster ndp

### Description

The **cluster ndp** command is used to configure NTDP globally. To return to the default configuration, please use **no cluster ndp** command. NTDP (Neighbor Topology Discovery Protocol) is used to collect the NDP information and neighboring connection information of each device in a specific network range. It provides the commander switch with the information of devices which can join the cluster and collects topology information of devices within the specified hops.

### Syntax

```
cluster ndp
```

```
cluster ndp timer { [interval-time time] [hop-delay value] [port-delay value] }
```

```
cluster ndp hop hop-value
```

```
no cluster ndp
```

```
no cluster ndp timer { [interval-time time] [hop-delay value] [port-delay value] }
```

```
no cluster ndp hop hop-value
```

### Parameter

*time* —— NTDP Interval Time, which is the interval to collect topology information. NTDP Interval Time ranges from 1 to 60 in minutes. By default, it is 1.

**hop-delay** *value* —— NTDP Hop Delay, which is the time between the switch receiving NTDP request packets and the switch forwarding NTDP request packets for the first time. NTDP Hop Delay ranges from 1 to 1000 in milliseconds. By default, it is 200.

**port-delay** *value* —— NTDP Port Delay, which is the time between the port forwarding NTDP request packets and its adjacent port forwarding NTDP request packets over. NTDP Port Delay ranges from 1 to 100 in milliseconds. By default, it is 20.

*hop-value* —— NTDP Hops, which is the hop count the switch topology collects. NTDP Hops ranges from 1 to 16. By default, it is 3.

### Command Mode

Global Configuration Mode

## Example

Enable NTDP function globally, and specify NTDP Hops as 5, NTDP Interval Time as 30 minutes:

```
T2500-28TC(config)#cluster ntdp
T2500-28TC(config)#cluster ntdp timer interval-timer 30
T2500-28TC(config)#cluster ntdp hop 5
```

## cluster explore

### Description

The **cluster explore** command is used to enable the topology information collecting function manually.

### Syntax

```
cluster explore
```

### Command Mode

Global Configuration Mode

### Example

Enable the topology information collecting function manually:

```
T2500-28TC(config)#cluster explore
```

## cluster

### Description

The **cluster** command is used to configure cluster functions of a specified port. To return to the default configuration, please use **no cluster** command.

### Syntax

```
cluster [ndp { disable | enable }] [ntdp { disable | enable }]
no cluster
```

### Parameter

ndp —— Enable/ Disable NDP function for the port. By default, it is enabled.

ntdp —— Enable/ Disable NTDP function for the port. By default, it is enabled.

### Command Mode

Interface Configuration Mode (interface fastEthernet / interface range fastEthernet / interface gigabitEthernet / interface range gigabitEthernet)

## Example

Enable NDP and NTDP function for Fast Ethernet port 5:

```
T2500-28TC(config)#interface fastEthernet 1/0/5
T2500-28TC(config-if)#cluster ndp enable ntdp enable
```

## cluster ip pool

### Description

The **cluster ip pool** command is used to create a new cluster. If no specified cluster name is set through **cluster commander** command, the newly created cluster will enjoy the system default name “tplink-cluster”.

### Syntax

**cluster ip pool** *ip mask*

### Parameter

*ip* —— The cluster IP address pool.

*mask* —— The cluster IP address mask.

### Command Mode

Global Configuration Mode

### Example

Create a cluster and configure its IP address pool as 192.168.10.1 - 192.168.0.254:

```
T2500-28TC(config)#cluster ip pool 192.168.10.1 255.255.255.0
```

## cluster commander

### Description

The **cluster commander** command is used to specify the cluster name, and you can only specify the cluster name when you create the cluster. To delete a cluster, please use **no cluster commander** command.

### Syntax

**cluster commander** *name*

**no cluster commander**

### Parameter

*name* —— The cluster name, ranging from 1 to 16 characters.

## Command Mode

Global Configuration Mode

## Example

Configure the newly created cluster name as tp:

```
T2500-28TC(config)#cluster commander tp
```

# cluster manage

## Description

The **cluster manage** command is used to configure the hold time and interval to send handshake packets of the cluster. To return to the default configuration, please use **no cluster manage** command.

## Syntax

```
cluster manage [ holdtime hold-time | timer interval-time ]
```

```
no cluster manage [ holdtime | timer ]
```

## Parameter

*hold-time* — Hold Time, which is the time for the switch to keep the cluster information. Hold Time ranges from 1 to 255 in seconds. It is 20 by default.

*interval-time* — Interval Time, which is the interval to send handshake packets. Interval Time ranges from 1 to 255 in seconds. It is 20 by default.

## Command Mode

Global Configuration Mode

## Example

Specify the Hold Time and Interval Time of the cluster as 50 seconds:

```
T2500-28TC(config)#cluster manage holdtime 50
```

```
T2500-28TC(config)#cluster manage timer 50
```

# cluster member

## Description

The **cluster member** command is used to add member switch. To delete the corresponding member, please use **no cluster member** command. The add/delete operations of member switches should be implemented by the commander switch according to the MAC address.

## Syntax

**cluster member** {**mac-address** *mac-address*}

**no cluster member** {**mac-address** *mac-address*}

## Parameter

*mac-address* — The MAC address of the member switch desired to join in or to be deleted from the cluster.

## Command Mode

Global Configuration Mode

## Example

Add the switch whose MAC address is 0e-3f-4g-5e-6d-7b to the cluster:

```
T2500-28TC(config)#cluster member mac address 0e-3f-4g-5e-6d-7b
```

# cluster candidate

## Description

The **cluster candidate** command is used to specify the current switch as candidate switch.

## Syntax

**cluster candidate**

## Command Mode

Global Configuration Mode

## Example

Specify the current switch as candidate switch:

```
T2500-28TC(config)#cluster candidate
```

# cluster individual

## Description

The **cluster individual** command is used to specify the current switch as individual switch.

## Syntax

**cluster individual**

## Command Mode

Global Configuration Mode



## Example

Specify the current switch as individual switch:

```
T2500-28TC(config)#cluster individual
```

## show cluster ndp

### Description

The **show cluster ndp** command is used to display the NDP information.

### Syntax

```
show cluster ndp [ interface [ fastEthernet port | gigabitEthernet port |  
ten-gigabitEthernet port ] ]
```

### Parameter

*port* — Specify the Ethernet port number. The NDP information of all ports will be displayed if the port number is not specified here.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the global NDP information of the switch:

```
T2500-28TC(config)#show cluster ndp
```

Display the NDP information of all the ports of the switch:

```
T2500-28TC(config)#show cluster ndp interface
```

## show cluster ntdp

### Description

The **show cluster ntdp** command is used to display NTDP configuration information.

### Syntax

```
show cluster ntdp [ interface [fastEthernet port | gigabitEthernet port ] |  
device-list ]
```

### Parameter

*port* — The Fast/Gigabit Ethernet port number. By default, the configuration of all Fast / Gigabit Ethernet ports is displayed.

*device-list* — To display the device table of NTDP.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display the global information of NTDP:

```
T2500-28TC#show cluster ntdp
```

Display the NTDP configuration of all Ethernet ports:

```
T2500-28TC#show cluster ntdp interface
```

Display the device table of NTDP:

```
T2500-28TC#show cluster ntdp device-list
```

# show cluster

## Description

When the current switch is Commander Switch, the **show cluster** command is used to display the global configuration of Cluster.

## Syntax

```
show cluster
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display the global configuration of Cluster:

```
T2500-28TC#show cluster
```

# show cluster member

## Description

The **show cluster member** command is used to display the member information.

## Syntax

```
show cluster member
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the member information:

```
T2500-28TC#show cluster member
```

## show cluster manage role

### Description

The **show cluster manage role** command is used to display the role of the current switch.

### Syntax

```
show cluster manage role
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the role of the current switch:

```
T2500-28TC(config)#show cluster manage role
```

## show cluster neighbor

### Description

The **show cluster neighbor** command is used to display the cluster's neighbor information.

### Syntax

```
show cluster neighbor
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the cluster's neighbor information:

```
T2500-28TC(config)#show cluster neighbor
```

## Chapter 39 AAA Commands

AAA stands for authentication, authorization and accounting. This feature is used to authenticate users trying to log in to the switch or trying to access the administrative level privilege.

### ➤ **Applicable Access Application**

The authentication can be applied on the following access applications: Console, Telnet, SSH and HTTP.

### ➤ **Authentication Method List**

A method list describes the authentication methods and their sequence to authenticate a user. The switch supports Login List for users to gain access to the switch, and Enable List for normal users to gain administrative privileges.

### ➤ **RADIUS/TACACS+ Server**

User can configure the RADIUS/TACACS+ servers for the connection between the switch and the server.

### ➤ **Server Group**

User can define the authentication server group with up to several servers running the same secure protocols, either RADIUS or TACACS+. Users can set these servers in a preferable order, which is called the server group list. When a user tries to access the switch, the switch will ask the first server in the server group list for authentication. If no response is received, the second server will be queried, and so on.

## aaa enable

### Description

The **aaa enable** command is used to enable the AAA function globally. To disable the AAA function globally, please use the **no aaa enable** command. The global AAA function is disabled by default.

### Syntax

```
aaa enable
no aaa enable
```

### Command Mode

Global Configuration Mode

### Example

Enable the AAA function globally:

```
T2500-28TC(config)# aaa enable
```

## tacacs-server host

### Description

The **tacacs-server host** command is used to configure a new TACACS+ server. To delete the specified TACACS+ server, please use **no tacacs-server host** command.

### Syntax

```
tacacs-server host ip-address [ port port-id ] [ timeout time ] [ key { [ 0 ] string | 7 encrypted-string } ]
```

```
no tacacs-server host ip-address
```

### Parameter

*ip-address* — Specify the IP address of the TACACS+ server.

*port-id* — Specify the server's port number for AAA. By default it is 49.

*time* — Specify the time in seconds the switch waits for the server's response before it times out. The time ranges from 1 to 9 seconds. The default is 5 seconds.

[ 0 ] *string* | 7 *encrypted-string* — 0 and 7 are the encryption type. 0 indicates that an unencrypted key will follow. 7 indicates that a symmetric encrypted key with a fixed length will follow. By default, the encryption type is 0. "*string*" is the shared key for the switch and the authentication servers to exchange messages which contains 31 characters at most. The question marks and spaces are not allowed. "*encrypted-string*" is a symmetric encrypted key with a fixed length, which you can copy from another switch's configuration file. The key or encrypted-key you configured here will be displayed in the encrypted form. Always configure the key as the last item of this command.

### Command Mode

Global Configuration Mode

### User Guidelines

The TACACS+ servers you configured are added in the server group "tacacs" by default.

## Example

Configure a TACACS+ server with the IP address as 1.1.1.1, TCP port as 1500, timeout as 6 seconds, and the unencrypted key string as 12345.

```
T2500-28TC(config)# tacacs-server host 1.1.1.1 port 1500 timeout 6 key
12345
```

## show tacacs-server

### Description

This **show tacacs-server** command is used to display the summary information of the TACACS+ servers.

### Syntax

```
show tacacs-server
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the information of all the TACACS+ servers:

```
T2500-28TC(config)# show tacacs-server
```

## radius-server host

### Description

The **radius-server host** command is used to configure a new RADIUS server. To delete the specified RADIUS server, please use **no radius-server host** command.

### Syntax

```
radius-server host ip-address [ auth-port port-id ] [ acct-port port-id ]
[ timeout time ] [ retransmit number ] [ key { [ 0 ] string | 7 encrypted-string } ]
no radius-server host ip-address
```

### Parameter

*ip-address* — Specify the IP address of the RADIUS server.

**auth-port** *port-id* — Specify the UDP destination port for authentication requests. By default it is 1812.

**acct-port** *port-id* — Specify the UDP destination port for accounting requests. By default it is 1813.

**time** — Specify the time in seconds the switch waits for the server's response before it times out. The time ranges from 1 to 9 seconds. The default is 5 seconds.

**number** — Specify the number of times a RADIUS request is resent to a server if the server is not responding in time. By default it is 2 times.

[ 0 ] *string* | 7 *encrypted-string* — 0 and 7 are the encryption type. 0 indicates that an unencrypted key will follow. 7 indicates that a symmetric encrypted key with a fixed length will follow. By default, the encryption type is 0. "*string*" is the shared key for the switch and the authentication servers to exchange messages which contains 31 characters at most. The question marks and spaces are not allowed. "*encrypted-string*" is a symmetric encrypted key with a fixed length, which you can copy from another switch's configuration file. The key or encrypted-key you configured here will be displayed in the encrypted form. Always configure the key as the last item of this command.

## Command Mode

Global Configuration Mode

## User Guidelines

The RADIUS servers you configured are added in the server group "radius" by default.

## Example

Configure a RADIUS server with the IP address as 1.1.1.1, authentication port as 1200, timeout as 6 seconds, retransmit times as 3, and the unencrypted key string as 12345.

```
T2500-28TC(config)# radius-server host 1.1.1.1 auth-port 1200 timeout 6
retransmit 3 key 12345
```

# show radius-server

## Description

This **show radius-server** command is used to display the summary information of the RADIUS servers.

## Syntax

```
show radius-server
```

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display the information of all the RADIUS servers:

```
T2500-28TC(config)# show radius-server
```

# aaa group

## Description

This **aaa group** command is used to create AAA server groups to group existing TACACS+/RADIUS servers for authentication. This command puts the switch in the server group subconfiguration mode.

To delete the corresponding AAA group, please use the **no aaa group** command.

## Syntax

```
aaa group { radius | tacacs } group-name  
no aaa group { radius | tacacs } group-name
```

## Parameter

*radius | tacacs* — Specify the server group type as RADIUS or TACACS+.

*group-name* — Specify the server group name.

## Command Mode

Global Configuration Mode

## Example

Create a RADIUS server group with the name radius1:

```
T2500-28TC(config)# aaa group radius radius1
```



## server

### Description

This **server** command is used to add the existing server in the defined server group. To remove the specified server from the server group, please use the **no server** command.

### Syntax

```
server ip-address  
no server ip-address
```

### Parameter

*ip-address* — Specify the server's IP address.

### Command Mode

Server Group Configuration Mode

### Example

Create the RADIUS server 1.1.1.1 to RADIUS server group "radius1":

```
T2500-28TC(config)# aaa group radius radius1  
T2500-28TC(aaa-group)# server 1.1.1.1
```

## show aaa group

### Description

This **show aaa group** command is used to display the summary information of the AAA groups. All the servers in this group will be listed if you specify the group name.

### Syntax

```
show aaa group [ group-name ]
```

### Parameter

*group-name* — Specify the server group name.

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the information of all the server groups:

```
T2500-28TC(config)# show aaa group
```

## aaa authentication login

### Description

This **aaa authentication login** command is used to configure a login authentication method list. A method list describes the authentication methods and their sequence to authenticate a user. To delete the specified authentication method list, please use the **no aaa authentication login** command.

### Syntax

```
aaa authentication login { method-list } { method1 } [ method2 ] [ method3 ]  
[ method4 ]
```

```
no aaa authentication login method-list
```

### Parameter

*method-list* — Specify the method list name.

*method1, method2, method3, method4* — Specify the authentication methods in order. The next authentication method is tried only if the previous method does not respond, not if it fails.

The preset methods include radius, tacacs, local and none. “radius” means the RADIUS server group “radius”; “tacacs” means the RACACS+ server group “tacacs”; “local” means local username database are used; “none” means no authentication is used for login.

Users can also define new method with the [aaa group](#) command.

### Command Mode

Global Configuration Mode

### User Guidelines

By default the login authentication method list is “default” with “local” as method1.

### Example

Configure a login authentication method list “list1” with the priority1 method as radius and priority2 method as local:

```
T2500-28TC(config)# aaa authentication login list1 radius local
```

## aaa authentication enable

### Description

This **aaa authentication enable** command is used to configure a privilege authentication method list. A method list describes the authentication methods and their sequence to elevate a user's privilege. To delete the specified authentication method list, please use the **no aaa authentication enable** command.

### Syntax

```
aaa authentication enable { method-list } { method1 } [ method2 ] [ method3 ]
[ method4 ]
no aaa authentication enable method-list
```

### Parameter

*method-list* — Specify the method list name.

*method1, method2, method3, method4* — Specify the authentication methods in order. The next authentication method is tried only if the previous method does not respond, not if it fails.

The preset methods include radius, tacacs, local and none. "radius" means the RADIUS server group "radius"; "tacacs" means the RACACS+ server group "tacacs"; "local" means local username database are used; "none" means no authentication is used for privilege elevation.

Users can also define new method with the [aaa group](#) command.

### Command Mode

Global Configuration Mode

### User Guidelines

By default the enable authentication method is "default" with "none" as method1.

### Example

Configure a privilege authentication method list "list2" with the priority1 method as radius and priority2 method as local:

```
T2500-28TC(config)# aaa authentication enable list2 radius local
```

## aaa authentication dot1x default

### Description

This **aaa authentication dot1x default** command is used to configure an 802.1X authentication method list. A method list describes the authentication methods for users' login in 802.1X. To delete the default authentication method list, please use the **no aaa authentication dot1x default** command.

### Syntax

```
aaa authentication dot1x default { method }
```

```
no aaa authentication dot1x default
```

### Parameter

*method* — Specify the method name. Only RADIUS server group is supported, and the default method is server group “radius”.

### Command Mode

Global Configuration Mode

### Example

Configure the default 802.1X authentication method as “radius1”:

```
T2500-28TC(config)# aaa authentication dot1x default radius1
```

## aaa accounting dot1x default

### Description

This **aaa accounting dot1x default** command is used to configure an 802.1X accounting method list. To delete the default accounting method list, please use the **no aaa accounting dot1x default** command.

### Syntax

```
aaa accounting dot1x default { method }
```

```
no aaa accounting dot1x default
```

### Parameter

*method* — Specify the method name. Only RADIUS server group is supported, and the default method is server group “radius”.

## Command Mode

Global Configuration Mode

## Example

Configure the default 802.1X accounting method as "radius1":

```
T2500-28TC(config)# aaa accounting dot1x default radius1
```

# show aaa authentication

## Description

This **show aaa authentication** command is used to display the summary information of the authentication login, enable and dot1x method list.

## Syntax

```
show aaa authentication [ login | enable | dot1x ]
```

## Parameter

login | enable | dot1x — Specify the method list type.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display the information of all the authentication method lists:

```
T2500-28TC(config)# show aaa authentication
```

# show aaa accounting

## Description

This **show aaa accounting** command is used to display the summary information of the accounting method list.

## Syntax

```
show aaa accounting [ dot1x ]
```

## Parameter

dot1x — Specify the method list type.

## Command Mode

Privileged EXEC Mode and Any Configuration Mode

## Example

Display the information of the default 802.1X accounting method list:

```
T2500-28TC(config)# show aaa accounting
```

# line console

## Description

The **line console** command is used to enter the Line Configuration Mode configure the console port to which you want to apply the authentication list.

## Syntax

```
line console { linenum }
```

## Parameter

*linenum* — The number of users allowed to login through console port. Its value is 0 in general, for the reason that console input is only active on one console port at a time.

## Command Mode

Global Configuration Mode

## Example

Enter the Console port configuration mode and configure the console port 0:

```
T2500-28TC(config)#line console 0
```

# login authentication(console)

## Description

The **login authentication** command is used to apply the login authentication method list to the console port. To restore to the default authentication method list, please use the **no login authentication** command.

## Syntax

```
login authentication { method-list }
```

```
no login authentication
```

## Parameter

*method-list* — Specify the login method list on the console port. It is “default” by default, which contains the method “local”.

## Command Mode

Line Configuration Mode

## Example

Configure the login authentication method list on the console port as “list1”:

```
T2500-28TC(config)# line console 0
T2500-28TC(config-line)# login authentication list1
```

# enable authentication(console)

## Description

The **enable authentication** command is used to apply the privilege authentication method list to the console port. To restore to the default authentication method list, please use the **no enable authentication** command.

## Syntax

**enable authentication** { *method-list* }

**no enable authentication**

## Parameter

*method-list* — Specify the enable method list on the console port. It is “default” by default, which contains the method “none”.

## Command Mode

Line Configuration Mode

## Example

Configure the enable authentication method list on the console port as “list2”:

```
T2500-28TC(config)# line console 0
T2500-28TC(config-line)# enable authentication list2
```

## line telnet

### Description

The **line telnet** command is used to enter the Line Configuration Mode configure the telnet terminal line to which you want to apply the authentication list.

### Syntax

```
line telnet
```

### Command Mode

Global Configuration Mode

### Example

Enter the telnet terminal line configuration mode:

```
T2500-28TC(config)#line telnet
```

## login authentication(telnet)

### Description

The **login authentication** command is used to apply the login authentication method list to the telnet terminal line. To restore to the default authentication method list, please use the **no login authentication** command.

### Syntax

```
login authentication { method-list }
```

```
no login authentication
```

### Parameter

*method-list* — Specify the login method list on the telnet terminal line. It is “default” by default, which contains the method “local”.

### Command Mode

Line Configuration Mode

### Example

Configure the login authentication method list on the telnet terminal line as “list1”:



```
T2500-28TC(config)#line telnet
T2500-28TC(config-line)# login authentication list1
```

## enable authentication(telnet)

### Description

The **enable authentication** command is used to apply the privilege authentication method list to the telnet terminal line. To restore to the default authentication method list, please use the **no enable authentication** command.

### Syntax

```
enable authentication { method-list }
no enable authentication
```

### Parameter

*method-list* — Specify the enable method list on the telnet terminal line. It is “default” by default, which contains the method “none”.

### Command Mode

Line Configuration Mode

### Example

Configure the enable authentication method list on the telnet terminal line as “list2”:

```
T2500-28TC(config)#line telnet
T2500-28TC(config-line)# enable authentication list2
```

## line ssh

### Description

The **line ssh** command is used to enter the Line Configuration Mode configure the ssh terminal line to which you want to apply the authentication list.

### Syntax

```
line ssh
```

### Command Mode

Global Configuration Mode

## Example

Enter the ssh terminal line configuration mode:

```
T2500-28TC(config)#line ssh
```

# login authentication(ssh)

## Description

The **login authentication** command is used to apply the login authentication method list to the ssh terminal line. To restore to the default authentication method list, please use the **no login authentication** command.

## Syntax

```
login authentication { method-list }
```

```
no login authentication
```

## Parameter

*method-list* — Specify the login method list on the ssh terminal line. It is “default” by default, which contains the method “local”.

## Command Mode

Line Configuration Mode

## Example

Configure the login authentication method list on the ssh terminal line as “list1”:

```
T2500-28TC(config)# line ssh
```

```
T2500-28TC(config-line)# login authentication list1
```

# enable authentication(ssh)

## Description

The **enable authentication** command is used to apply the privilege authentication method list to the ssh terminal line. To restore to the default authentication method list, please use the **no enable authentication** command.

## Syntax

```
enable authentication { method-list }
```

```
no enable authentication
```

### Parameter

*method-list* — Specify the enable method list on the ssh terminal line. It is “default” by default, which contains the method “none”.

### Command Mode

Line Configuration Mode

### Example

Configure the enable authentication method list on the ssh terminal line as “list2”:

```
T2500-28TC(config)# line ssh
T2500-28TC(config-line)# enable authentication list2
```

## ip http login authentication

### Description

The **ip http login authentication** command is used to apply the login authentication method list to users accessing through HTTP. To restore to the default authentication method list, please use the **no ip http login authentication** command.

### Syntax

```
ip http login authentication { method-list }
no ip http login authentication
```

### Parameter

*method-list* — Specify the login method list on the HTTP access. It is “default” by default, which contains the method “local”.

### Command Mode

Global Configuration Mode

### Example

Configure the login authentication method list on the HTTP access as “list1”:

```
T2500-28TC(config)# ip http login authentication list1
```

## ip http enable authentication

### Description

The **ip http enable authentication** command is used to apply the privilege authentication method list to users accessing through HTTP. To restore to the default authentication method list, please use the **no ip http enable authentication** command.

### Syntax

```
ip http enable authentication { method-list }  
no ip http enable authentication
```

### Parameter

*method-list* — Specify the enable method list on the HTTP access. It is “default” by default, which contains the method “none”.

### Command Mode

Line Configuration Mode

### Example

Configure the enable authentication method list on the HTTP access as “list2”:

```
T2500-28TC(config)# ip http enable authentication list2
```

## show aaa global

### Description

This **show aaa global** command is used to display global status of AAA function and the login/enable method lists of different application modules: console, telnet, ssh and HTTP.

### Syntax

```
show aaa global
```

### Command Mode

Privileged EXEC Mode and Any Configuration Mode

### Example

Display the AAA function’s global status and each application’s method list:

```
T2500-28TC(config)# show aaa global
```

## Chapter 40 DHCP Relay Commands

A DHCP Relay is a Layer 3 device that forwards DHCP packets between clients and servers. DHCP Relay forward requests and replies between clients and servers when they are not on the same physical subnet.

### ip dhcp relay

#### Description

The **ip dhcp relay** command is used to enable DHCP Relay function globally. To disable DHCP Relay function, please use **no ip dhcp relay** command.

#### Syntax

```
ip dhcp relay
no ip dhcp relay
```

#### Command Mode

Global Configuration Mode

#### Example

Enable DHCP Relay function globally:

```
T2500-28TC(config)# ip dhcp relay
```

### ip dhcp relay helper-address

#### Description

The **ip dhcp relay helper-address** command is used to specify the DHCP server address. The switch will forward DHCP packets to the specified DHCP server. To delete the server address, please use **no ip dhcp relay helper-address** command.

#### Syntax

```
ip dhcp relay helper-address ip-address [server-name]
no ip dhcp relay helper-address ip-address
```

#### Parameter

*ip-address* — DHCP Server address.

*server-name* — Specify the DHCP Server name.

## Command Mode

Global Configuration Mode

## Example

Add two DHCP Servers with IP addresses 192.168.2.1 and 192.168.3.1 to the switch:

```
T2500-28TC (config)# ip dhcp relay helper-address 192.168.2.1
```

```
T2500-28TC (config)# ip dhcp relay helper-address 192.168.3.1
```

## ip dhcp relay information option

### Description

The **ip dhcp relay information option** command is used to enable option 82 support in DHCP Relay. To disable this function, please use **no ip dhcp relay information option** command.

### Syntax

```
ip dhcp relay information option
no ip dhcp relay information option
```

### Command Mode

Global Configuration Mode

### Example

Enable option 82 support in DHCP Relay:

```
T2500-28TC(config)# ip dhcp relay information option
```

## ip dhcp relay information strategy

### Description

The **ip dhcp relay information strategy** command is used to specify the operation for the Option 82 field of the DHCP request packets from the Host. To restore to the default option, please use **no ip dhcp relay information strategy** command.

### Syntax

```
ip dhcp relay information strategy { drop | keep | replace }
no ip dhcp relay information strategy
```

### Parameter

drop | keep | replace —The operations for Option 82 field of the DHCP request packets from the Host. The default operation is keep.

drop: Discard the packet with the Option 82 field.

keep: Keep the Option 82 field in the packet.

replace: Replace the option 82 field with the system option defined by the switch.

## Command Mode

Global Configuration Mode

## Example

Specify the option 82 policy as replace to replace the Option 82 field with the local parameter on receiving the DHCP request packet:

```
T2500-28TC(config)# ip dhcp relay information strategy replace
```

# ip dhcp relay information circuit-id

## Description

The **ip dhcp relay information circuit-id** command is used to specify the custom circuit ID when option 82 customization is enabled. To clear the circuit ID, please use **no ip dhcp relay information circuit-id** command.

## Syntax

```
ip dhcp relay information circuit-id circuitID  
no ip dhcp relay information circuit-id
```

## Parameter

*circuitID* — Specify the circuit ID, ranging from 1 to 63 characters.

## Command Mode

Global Configuration Mode

## Example

Specify the circuit ID as “TP-Link”:

```
T2500-28TC(config)# ip dhcp relay information circuit-id TP-Link
```

# ip dhcp relay information remote-id

## Description

The **ip dhcp relay information remote-id** command is used to specify the custom remote ID when option 82 customization is enabled. To clear the remote ID, please use **no ip dhcp relay information remote-id** command.

## Syntax

```
ip dhcp relay information remote-id remoteID  
no ip dhcp relay information remote-id
```

**Parameter**

*remoteID* — Specify the remote ID, ranging from 1 to 63 characters.

**Command Mode**

Global Configuration Mode

**Example**

Specify the remote ID as "TP-Link":

```
T2500-28TC(config)# ip dhcp relay information remote-id TP-Link
```

## show ip dhcp relay

**Description**

The **show ip dhcp relay** command is used to display the global status and Option 82 configuration of DHCP Relay.

**Syntax**

```
show ip dhcp relay
```

**Command Mode**

Privileged EXEC Mode and Any Configuration Mode

**Example**

Display the configuration of DHCP Relay:

```
T2500-28TC(config)# show ip dhcp relay
```

## show ip dhcp relay helper-address

**Description**

The **show ip dhcp relay helper-address** command is used to display the IP address of the DHCP server.

**Syntax**

```
show ip dhcp relay helper-address
```

**Command Mode**

Privileged EXEC Mode and Any Configuration Mode

**Example**

Display the IP address of the DHCP server:

```
T2500-28TC(config)# show ip dhcp relay helper-address
```