


Hello. Meet your new Range Extender.

Follow this guide to extend your Wi-Fi network.



LEDs and Buttons



Option 1 Setup Using the Mobile App


1 TP-LINK Kasa App

Search for and download the TP-LINK Kasa mobile app in the App Store or Google play, or simply scan the QR code.




2 Connect to your Wi-Fi Network

Go to your mobile device's Settings and connect to your home Wi-Fi network that you wish to extend.



3 Extend your Wi-Fi Network

Launch Kasa and follow the app instructions to extend your Wi-Fi network.



4 Connect to Extended Networks

Unless you customized the extended network names during the configuration, the extender adds **_EXT** to the end of the main network's SSIDs and uses the same Wi-Fi password.



Wireless Adapter

The range extender can also be used as a wireless adapter to connect any Ethernet-only device, such as a Blu-ray® player, game console, DVR, or Smart TV, to your Wi-Fi network.

Simply set up the extender using Option 1 or Option 2, and then connect your Ethernet-only device to the extender using an Ethernet cable.




Technical Support

If you encounter any problem during configuration, go to www.tp-link.com for web support and other troubleshooting information.

Option 2 Setup Using a Computer


1 Plug In

Plug in the range extender to an electrical wall outlet near your router. Toggle the Power switch to On and wait until the Power  LED is lit a solid green.



3 Log In

Launch a web browser and type: **http://tplinkrepeater.net** in the address field. Enter **admin** (all lowercase) for both username and password to log in.



5 Relocate your Extender


- A** Plug in the extender to an outlet around the midpoint between your Wi-Fi router and the Wi-Fi “dead” zone.
- B** Wait for the extender to reconnect and both Wi-Fi LEDs are lit a solid green. If not, relocate the extender closer to the router.

 To minimize signal interference, choose a location away from Bluetooth® devices and other household electronics such as cordless phones, microwave ovens, baby monitors, etc.




2 Connect via Wireless

Disconnect the Ethernet connection from your computer (if any). Click the Wi-Fi icon on the taskbar and select the extender’s default SSID (network name), e.g. *TP-LINK_2G_EXT*. No password is needed to connect.



4 Extend your Wi-Fi Network

Follow the [Quick Setup](#) wizard to extend your 2.4GHz and 5GHz Wi-Fi networks.



6 Connect to Extended Networks

Unless you customized the extended network names during the configuration, the extender adds *_EXT* to the end of the main network’s SSIDs and uses the same Wi-Fi password.



Frequently Asked Questions

1. How do I reset my Range Extender to factory defaults?

With the Range Extender plugged in, press and hold the Reset button until the Power LED turn off and turn back on (about 2 seconds).

2. How to troubleshoot if the App-Config process fails?

Follow Kasa’s instruction to reinitiate the App-Config process or use Option 2 to set up the extender using a computer.

3. What should I do if I cannot access the extender’s web interface?

- Make sure that you only use either Ethernet or Wi-Fi connection when accessing the extender’s web interface but not both.
- Make sure that your computer is set to obtain an IP address automatically (DHCP).

4. What should I do if the Wi-Fi LEDs are not on after completing the setup process?

You may have entered the incorrect W-Fi password of your main network. Log into the extender’s web interface to check the password and try again.

5. Why does the range extender sometimes slow down my Wi-Fi connection?

With the addition of the range extender into your network, performance between the extender and your Wi-Fi device is affected. We recommend that you connect to the main router when you are within its Wi-Fi range, and only connect to the extender when your Wi-Fi device is in the Wi-Fi “dead” zone.