

**TP-LINK®**

Enterprise Networking Solution

# Installation Guide

Gigabit Load Balance Broadband Router  
TL-ER5120

## COPYRIGHT & TRADEMARKS

Specifications are subject to change without notice. **TP-LINK®** is a registered trademark of TP-LINK TECHNOLOGIES CO., LTD. Other brands and product names are trademarks of their respective holders.

No part of the specifications may be reproduced in any form or by any means or used to make any derivative such as translation, transformation, or adaptation without permission from TP-LINK TECHNOLOGIES CO., LTD. Copyright © 2013 TP-LINK TECHNOLOGIES CO., LTD. All rights reserved.

<http://www.tp-link.com>

## FCC STATEMENT



This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference.
  - 2) This device must accept any interference received, including interference that may cause undesired operation.
- Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## CE Mark Warning



This is a class A product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

## Related Document

---

The User Guide of this product is provided in the resource CD.

To obtain the latest product information, please visit the Official Website:

<http://www.tp-link.com>

## About this Installation Guide

---

This Installation Guide describes the hardware characteristics, installation methods and the points that should be attended to during installation.

This Installation Guide is structured as follows:

**Chapter 1 Introduction.** This chapter describes the External Components of the router.

**Chapter 2 Installation.** This chapter illustrates how to install the router.

**Chapter 3 Lightning Protection.** This chapter illustrates how to prevent lightning damage.

**Chapter 4 Connection.** This chapter illustrates how to do the physical connection of the router.

**Chapter 5 Configuration.** This chapter illustrates how to login and set up the router.

**Appendix A Troubleshooting.**

**Appendix B Hardware Specifications.**

**Appendix C Technical Support.**

## Audience

---

This Installation Guide is for:

Network Engineer

Network Administrator

## Conventions

---

This guide uses the specific formats to highlight special messages. The following table lists the notice icons that are used throughout this guide.

	Remind to be careful. A caution indicates a potential which may result in device damage.
	Remind to take notice. The note contains the helpful information for a better use of the router.

# Contents

---

Chapter 1 Introduction	01
1.1 Product Overview	01
1.2 Appearance	01
Chapter 2 Installation	03
2.1 Package Contents	03
2.2 Safety Precautions	03
2.3 Installation Tools	05
2.4 Product Installation	05
Chapter 3 Lightning Protection	07
3.1 Cabling Reasonably	07
3.2 Connect to Ground	09
3.3 Equipotential Bonding	10
3.4 Use Lightning Arrester	11
Chapter 4 Connection	12
4.1 WAN Port	12
4.2 LAN Port	12
4.3 Console Port	12
4.4 Verify Installation	13
4.5 Power On	13
4.6 Initialization	14
Chapter 5 Configuration	15
5.1 Preparations	15
5.2 Login	15
5.3 WAN/LAN Ports Configuration	17
Appendix A Troubleshooting	18
Appendix B Hardware Specifications	19
Appendix C Technical Support	20

# Chapter 1 Introduction

## 1.1 Product Overview

The Gigabit Load Balance Broadband Router TL-ER5120 providing three adjustable gigabit ports, which enable the users to configure the amount of WAN ports based on need and connect multiple Internet lines for bandwidth expansion. The router possesses excellent data processing capability and multiple powerful functions including Load Balance, Access Control, Bandwidth Control, Session Limit, IM/P2P Blocking, PPPoE Server and so on, which consumedly meet the needs of small and medium enterprise, hotels and communities with volumes of users demanding a efficient and easy-to-manage network with high security.

## 1.2 Appearance

### ■ Front Panel

The front panel of TL-ER5120 is shown as the following figure.




Figure 1-1 Front Panel

### LEDs

LED	Status	Indication
PWR	On	The router is powered on
	Off	The router is powered off or power supply is abnormal
SYS	Flashing	The router works properly
	On/Off	The router works improperly
Link/Act	On	There is a device linked to the corresponding port
	Off	There is no device linked to the corresponding port
	Flashing	The corresponding port is transmitting or receiving data
Speed	On (Green)	The port is running at 1000Mbps
	On (Yellow)	The port is running at 100Mbps
	Off	There is no device linked to the corresponding port or the port is running at 10Mbps
WAN	On	The port is working in WAN mode
	Off	The port is working in LAN mode
DMZ	On	The port is working in DMZ mode
	Off	The port is working in LAN mode

### Interface Description

Interface	Description
WAN	The WAN port is designed to connect the router to a DSL/Cable modem or Ethernet by the RJ45 cable
LAN	The LAN port is designed to connect the router to the local PCs or switches by the RJ45 cable
DMZ	The DMZ port is designed to connect the router to the servers
Console	The Console port is designed to connect with the serial port of a computer or terminal to monitor and configure the router

### Reset

Use the button to restore the router to the factory defaults. With the router powered on, use a pin to press and hold the Reset button (about 4~5 seconds). After the SYS LED goes out, release the Reset button. If the SYS LED is flashing with a high frequency about two or three seconds, it means the router is restored successfully.

### ■ Rear Panel

The rear panel of TL-ER5120 is shown as the following figure.




Figure 1-2 Rear Panel

### Power Socket

Connect the female connector of the power cord here, and the male connector to the AC power outlet. Please make sure the voltage of the power supply meets the requirement of the input voltage (100-240V~ 50/60Hz).

### Grounding Terminal

The router already comes with lightning protection mechanism. You can also ground the router through the PE (Protecting Earth) cable of AC cord or with Ground Cable. For detailed information, please refer to **Chapter 3 Lightning Protection**.




**Caution:** Please use the provided power cord.

## Chapter 2 Installation

---

### 2.1 Package Contents

Make sure that the package contains the following items. If any of the listed items is damaged or missing, please contact your distributor.



### 2.2 Safety Precautions

To avoid any device damage and bodily injury caused by improper use, please observe the following rules.

#### ■ Safety Precautions

- Keep the power off during the installation.
- Wear an ESD-preventive wrist strap, and make sure that the wrist strap has a good skin contact and is well grounded.
- Use only the power cord provided with the router.
- Make sure the operating voltage of the power supply is the same one labeled on the router.
- Ensure the vent hole is well ventilated and unblocked.
- Do not open or remove the cover of the router.
- Before cleaning the device, cut off the power supply. Do not clean it by the waterish cloth, and never use any other liquid cleaning method.

#### ■ Site Requirements

To ensure normal operation and long service life of the device, please install it in an environment that meets the requirements described in the following subsection.


#### Temperature/Humidity



Please keep a proper temperature and humidity in the equipment room. Too high/low humidity may lead to bad insulation, electricity leakage, mechanical property changes and corrosions. Too high temperature may accelerate aging of the insulation materials and can thus significantly shorten the service life of the device. For normal temperature and humidity of the device, please check the following table.

Environment	Temperature	Humidity
Operating	0°C ~ 40°C	10% ~ 90%RH Non-condensing
Storage	-40°C ~ 70°C	5% ~ 90%RH Non-condensing


### Cleanness



The dust accumulated on the router can be absorbed by static electricity and result in poor contact of metal contact points. Some measures have been taken for the device to prevent static electricity, but too strong static electricity can cause deadly damage to the electronic elements on the internal circuit board. To avoid the effect of static electricity on the operation of the router, please attach much importance to the following items:

- Dust the device regularly, and keep the indoor air clean.
- Keep the device well grounded and ensure static electricity has been transferred.


### Electromagnetic Interference



Electronic elements including capacitance and inductance on the device can be affected by external interferences, such as conducted emission by capacitance coupling, inductance coupling, and impedance coupling. To decrease the interferences, please make sure to take the following measures:

- Use the power supply that can effectively filter interference from the power grid.
- Keep the device far from high-frequency, strong-current devices, such as radio transmitting station.
- Use electromagnetic shielding when necessary.

### Lightening Protection



Extremely high voltage currents can be produced instantly when lightning occurs and the air in the electric discharge path can be instantly heated up to 20,000°C. As this instant current is strong enough to damage electronic devices, more effective lightning


protection measures should be taken.

- Ensure the rack and device are well earthed.
- Make sure the power socket has a good contact with the ground.
- Keep a reasonable cabling system and avoid induced lightning.
- Use the signal SPD (Surge Protective Device) when wiring outdoor.



**Note:** For detailed lightning protection measures, please refer to **Chapter 3 Lightning Protection**.

### Installation Site



When installing the device on a rack or a flat workbench, please note the following items:

- The rack or workbench is flat and stable, and sturdy enough to support the weight of 5.5kg at least.
- The rack or workbench has a good ventilation system. The equipment room is well ventilated.
- The rack is well grounded. Keep the power socket less than 1.5 meters away from the device.

## 2.3 Installation Tools

- Phillips screwdriver
- ESD-preventive wrist wrap
- Cables



**Note:** These tools are not provided with our product. If needed, please self purchase them.

## 2.4 Product Installation

### ▪ Desktop Installation

To install the device on the desktop, please follow the steps:

1. Set the device on a flat surface strong enough to support the entire weight of the device with all fittings.
2. Remove the adhesive backing papers from the rubber feet.
3. Turnover the device and attach the supplied rubber feet to the recessed areas on the bottom at each corner of the device.




Figure 2-1 Desktop Installation

### ■ Rack Installation

To install the device in an EIA standard-sized, 19-inch rack, follow the instructions described below:

1. Check the grounding and stability of the rack.
2. Secure the supplied rack-mounting brackets to each side of the device with supplied screws, as illustrated in the following figure.




Figure 2-2 Bracket Installation

3. After the brackets are attached to the device, use suitable screws (not provided) to secure the brackets to the rack, as illustrated in the following figure.




Figure 2-3 Rack Installation



#### Caution:

- Please set 5~10cm gaps around the device for air circulation.
- Please avoid any heavy thing placed on the device.
- Please mount devices in sequence from the bottom to top of the rack and ensure a certain clearance between devices for the purpose of heat dissipation.

## Chapter 3 Lightning Protection

### 3.1 Cabling Reasonably


In the actual network environment, you may need cable outdoors and indoors, and the requirements for cabling outdoors and indoors are different. A reasonable cabling system can decrease the damage of induced lightning to devices.




**Note:** It's not recommended using Ethernet cables outdoors. When cabling outdoors, please use a signal lightning arrester.

#### ■ Requirements for Cabling Outdoors

- Aerial cabling without safeguard is not allowed.



- It's not allowed cabling down the building to connect network devices in different floors.



- Outdoor cables should be buried and paved to the indoor through basement. A piece of steel wire should be paved underground along the pipe and connected to the lightning protection terminal of the building for shielding. Before connecting the cable to the device, install a signal lightning arrester on the corresponding port.
- When an aerial cable is set up, the cable should be through a metal pipe (15m long at least) before coming into the building. The two ends of this metal pipe should be grounded. Before connecting the cable to the device, install a signal lightning arrester on the corresponding port.
- It's not necessary to pave STP cables through pipes. The shielded layer of STP cable should be well grounded. Before connecting the cable to the device, install a signal lightning arrester on the corresponding port.

#### ■ Requirements for Cabling Indoors


When cabling indoors, keep a certain distance away from the devices that may cause high-frequency interferences, such as down-conductor cable, powerline, power transformer and electromotor.

- The main cable should be paved in the metal raceway of the access shaft. When cabling, keep the loop area formed by the cable itself as small as possible.

- Requirements for the distance between Ethernet cable and other pipelines are shown in the table.

Other Pipelines	Ethernet Cable	
	Min Parallel Net Length L (mm)	Min Parallel-overlapping Net Height H (mm)
Down-conductor	1000	300
PE	50	20
Service pipe	150	20
Compressed air pipe	150	20
Thermal pipe (not wrapped)	500	500
Thermal pipe (wrapped)	300	300
Gas pipe	300	20

The two diagrams below demonstrate parallel net length and parallel-overlapping net height.



**Note:** The above minimum net length/height is required when metal raceway is not used. If any requirements cannot be met, you can add a steel tube or metal raceway for shielding.

- Requirements for the distance between Ethernet cable and high-power electric devices are in following tables.

Cable	Pave Way	Min Parallel Length (mm)
<2kVA powerline	Parallel cabling	130
	One is in the grounded metal raceway or metal pipe	70
	The both are in the grounded metal raceway or metal pipe	10
2~5kVA powerline	Parallel cabling	300
	One is in the grounded metal raceway or metal pipe	150
	The both are in the grounded metal raceway or metal pipe	80
>5kVA powerline	Parallel cabling	600
	One is in the grounded metal raceway or metal pipe	300
	The both are in the grounded metal raceway or metal pipe	150

Device	Min Distance (m)
Switch case	1.00
Transformer room	2.00
Elevator tower	2.00
Air-conditioner room	2.00

### 3.2 Connect to Ground

Connecting the device to ground is to quickly release the lightning over-voltage and over-current of the device, which is also a necessary measure to protect the body from electric shock.

In different environments, the device may be grounded differently. The following will instruct you to connect the device to the ground in two ways, connecting to the grounding bar or connecting to the ground via the power cord. Please connect the device to ground in the optimum way according to your specific operation environment.

#### ■ Connecting to the Grounding Bar

If the device is installed in the Equipment Room, where a grounding bar is available, you are recommended to connect the device to the grounding bar as shown in the following figure.




Figure 3-1 Connecting to the Grounding Bar



**Note:** The grounding bar and the ground cable are not provided with our product. If needed, please self purchase them.

#### ■ Connecting to the Ground via the Power Supply

If the device is installed in the normal environment, the device can be grounded via the PE (Protecting Earth) cable of the AC power supply as shown in the following figure.




Figure 3-2 Connecting to the Ground

**Note:**

- The figure is to illustrate the application and principle. The power plug you get from the package and the socket in your situation will comply with the regulation in your country, so they may differ from the figure above.
- If you intend to connect the device to the ground via the PE (Protecting Earth) cable of AC power cord, please make sure the PE (Protecting Earth) cable in the electrical outlet is well grounded in advance.

### 3.3 Equipotential Bonding

Equipotential Bonding is the practice of intentionally electrically connecting all earthed systems to the same grounding grid or connecting the grounding grids of all the earthed systems together through the ground or overground metal so as to create an earthed equipotential zone. When lightning occurs, the high voltage produced by lightning current in all systems will meanwhile exist in their ground cables, and thus all ground cables have the same electrical potential and basically eliminate the electric strikes between the systems.

The figure below illustrates how to practice equipotential bonding in a network.




Figure 3-3 Equipotential Bonding

When equipotential bonding, please note that the cable should be copper wrapped Kelly with its area being  $6\text{mm}^2$  at least. The shorter cable the better, and use a grounding bar to establish an equipotential bonding point.



**Note:** The equipotential bonding cable is not provided with our product. If needed, please self purchase it.

### 3.4 Use Lightning Arrester

Power lightning arrester and signal lightning arrester are used for lightning protection.

Power lightning arrester is used for limiting the voltage surge due to a lightning. If an outdoor AC power cord should be directly connected to the device, please use a power lightning arrester.



**Note:** Power lightning arrester is not provided with our product. If needed, please self purchase it.

Signal lightning arrester is used to protect RJ45 ports of the device from lightning. When cabling outdoors, please install a signal lightning arrester before connecting the cable to the device.

When purchasing or using a signal lightning arrester, please observe the following rules:

- The port rate of the signal lightning arrester should match the rate of the desired port on the device. If it is not matched, this signal lightning arrester will not work. Purchase a standard lightning arrester.
- Install signal lightning arrester near the protected device and connect it to the ground via a shorter ground cable.




Figure 3-4 Lightning Arrester Connection



**Note:** Signal lightning arrester is not provided with our product. If needed, please self purchase it.

## Chapter 4 Connection

---

### 4.1 WAN Port

---

Please connect the WAN port of the router to the interface provided by ISP via Ethernet cable.

### 4.2 LAN Port

---

Connect a LAN port of the router to the computer by RJ45 cable as the following figure shown.




Figure 4-1 Connecting the LAN Port



**Note:** If the router is connecting with Server/Switch or other Ethernet devices, please make sure the RJ45 cable is less than 100m.

---

### 4.3 Console Port

---

CLI (Command Line Interface) enables you to do some simple operations to the router, thus you can load the CLI after connecting the PCs or Terminals to the console port on the router via the provided cable.

Connect the console port of the device with your computer by the console cable as the following figure shown.




Figure 4-2 Connecting the Console Port

You can also manage the device through the console port, for details please refer to the User Guide on the resource CD.



**Note:**

- The console port is the first port on the right of the front panel.
- Please keep the device power off when you plugging the console cable.
- Do not connect the console port with other ports by RJ45 cable.

#### 4.4 Verify Installation

After completing the installation, please verify the following items:

- There are 5~10cm of clearance around the sides of the device for ventilation and the air flow is adequate.
- The voltage of the power supply meets the requirement of the input voltage of the device.
- The power socket, device and rack are well grounded.
- The device is correctly connected to other network devices.

#### 4.5 Power On

Plug in the negative connector of the provided power cord into the power socket of the device, and the positive connector into a power outlet as the following figure shown.




Figure 4-3 Connecting to Power Supply



**Note:** The figure is to illustrate the application and principle. The power plug you get from the package and the socket in your situation will comply with the regulation in your country, so they may differ from the figure above.

---

## 4.6 Initialization

---

After the device is powered on, it begins the Power-On Self-Test. A series of tests run automatically to ensure the device functions properly. During this time, its LED indicators will respond as follows:

- The Power LED will light on all the time.
- All LEDs except PWR LED will flash momentarily and then turn off.
- The SYS LED flashes every second continuously, which means the initialization is finished.

## Chapter 5 Configuration

---

### 5.1 Preparations

---

1. Connect a PC to a LAN port of the router with a RJ45 cable properly.
2. Set the Internet Protocol (TCP/IP) properties of the PC as the following figure shown.




Figure 5-1 Internet Protocol (TCP/IP) Properties

### 5.2 Login

---

1. To access the GUI (Graphical User Interface) of the router, open a web browser and type the default management address `http://192.168.0.1` in the address field of the browser, then press the Enter key.



Figure 5-2 Web Browser

2. Enter `admin` for the default User Name and Password, both in lower case letters. Then click the Login button or press the Enter key.



Copyright © 2011 TP-LINK TECHNOLOGIES CO.,LTD. All Rights Reserved.

Figure 5-3 Login

3. After a successful login, the main page will appear as the following figure, and you can configure the function by clicking the setup menu on the left side of the screen.

The image displays the main configuration page of a TP-LINK router. The page is titled 'TP-LINK TL-ER5120' and is divided into several sections. On the left, there is a navigation menu with options like Network, System Mode, WAN, LAN, DMZ, MAC Address, Switch, User Group, Advanced, Firewall, Services, Maintenance, and Logout. The main content area is titled 'System Status' and contains the following information:

- Device Info:** Firmware Version: 1.0.0 Build 20110512 Ref.34676; Hardware Version: TL-ER5120 v1.0
- System Time:** System Time: 2010-02-10 00:01:18 Wednesday; Running Time: 1 Min, 22 Sec
- WAN:**
  - WAN1:** Link Up; Primary Connection: Static IP; Status: connected; IP Address: 98.137.125.56; Subnet Mask: 255.0.0.0; Gateway: 98.137.125.1; MAC Address: 40-61-86-FC-75-C3
  - WAN2:** Link Down; Primary Connection: Dynamic IP; Status: Connecting...; IP Address: 0.0.0.0; Subnet Mask: 0.0.0.0; Gateway: 0.0.0.0; MAC Address: AA-00-01-02-03-07
  - WAN3:** N/A; Primary Connection: Dynamic IP; Status: Disabled; IP Address: 0.0.0.0; Subnet Mask: 0.0.0.0; Gateway: 0.0.0.0; MAC Address: AA-00-01-02-03-08
  - WAN4:** N/A; Primary Connection: Dynamic IP; Status: Disabled; IP Address: 0.0.0.0; Subnet Mask: 0.0.0.0; Gateway: 0.0.0.0; MAC Address: AA-00-01-02-03-09
- LAN/DHCP:**

Interface	IP Address	Subnet Mask	DHCP Server	MAC Address
LAN	192.168.1.1	255.255.255.0	Enabled	AA-00-01-02-03-05
- CPU Usage:** Core Usage: Core0 2%

At the bottom of the page, there is a 'Refresh' button and a copyright notice: Copyright © 2011 TP-LINK TECHNOLOGIES CO., LTD. All Rights Reserved.

Figure 5-4 Main Page of the Router

### 5.3 WAN/LAN Ports Configuration

This Gigabit Load Balance Broadband router provides the function to assign the number of WAN/LAN ports flexibly. When you want to increase the Internet access to extend your bandwidth, it's no need for you to purchase another router, because this router can support four connections of Internet access in maximum, which provides you an extremely cost-effective network solution.

This router provides three adjustable WAN/LAN ports which can work in WAN mode or LAN mode. By the factory defaults, it is set to Dual-WAN mode with port 1 and port 2 as WAN ports, while port 3~5 are LAN ports. Ports are identified as WAN or LAN on the front panel's LEDs.




Figure 5-5 Default Front Panel of the Router

The port works in WAN mode when the LED "WAN" is lit up, and works in LAN mode when the LED "WAN" is not lit. To set the WAN/LAN ports, please follow the steps:

1. After a successful login, choose menu "Network→ WAN→ WAN Mode".
2. Select the total number of WAN ports on the following screen according to your demand.




Figure 5-6 WAN Mode setting



**Note:** The router will adjust the physical ports according to the specified number of WAN ports, which is illustrated by the port sketch on the configuration screen. In the web UI, the red color indicates that the port works as a WAN port while green color indicates the LAN port.

## Appendix A Troubleshooting

---

### Q1. What could I do if I forgot the username and password of the router?

Connect the console port and log in the user mode of CLI. Run the command "user get", as following:

```
TP-LINK > user get
```

```
Username: admin
```

```
Password: admin
```

```
TP-LINK >
```

For the method of how to log in the CLI, please refer to the User Guide on the resource CD.

Furthermore, you can also restore the router to factory defaults, Please refer to **1.2 Appearance** of this Installation Guide for detail. The default management address of the router is http://192.168.0.1, default username and password are both admin. All your current settings will be cleared after the router is restored. If you have backup configuration, please import it now.

### Q2. Why does the PWR LED work abnormally?

The PWR LED should be lit up when the power system works normally. If the PWR LED worked abnormally, please check as follows:

1. Make sure that the power cable is connected properly, and the power contact is normal.
2. Make sure the voltage of the power supply meets the requirement of the input voltage of the router.

### Q3. What could I do if I could not access the web-based configuration page?

You are recommended to check the following items:

1. Check every port LED on the router and make sure the cable is installed properly.
2. Try another port on the router and make sure the cable meets the requirement and works normally.
3. Turn off the power. After a while, turn on the power again.
4. Make sure the IP address of your PC is set within the subnet of the router.
5. If you still cannot access the configuration page, please restore the router to its factory defaults. Then the IP address should be set as 192.168.0.x ("x" is any number from 2 to 254) and Subnet Mask as 255.255.255.0.

### Q4. Why does the page display abnormally?

Please check as follows:

1. Update your browser or replace it with another browser, and try again.
2. If the pop-up is blocked, please lower the security level of the browser.

## Appendix B Hardware Specifications

---

Item	Content
Standards	IEEE 802.3, IEEE 802.3u, IEEE 802.3ab, IEEE 802.3x, TCP/ IP, DHCP, ICMP, NAT, PPPoE, SNTP, HTTP, DNS
Transmission Medium	10Base-T: UTP/STP of Cat. 3 or above 100Base-TX: UTP/STP of Cat. 5 or above 1000Base-T: UTP/STP of Cat.5, Cat.5e, Cat.6 or above
LEDs	PWR, SYS, Link/Act, Speed, WAN, DMZ
Power	100-240V~ 50/60Hz 0.6A
Operating Temperature	0°C~40°C
Storage Temperature	-40°C~70°C
Operating Humidity	10%~90%RH Non-condensing
Storage Humidity	5%~90%RH Non-condensing
Size (L×W×H)	440mm x 220mm x 44mm

## Appendix C Technical Support

---

- For more help, please go to: <http://www.tp-link.com/en/support/faq>
- To download the latest Firmware, Driver, Utility and User Guide, please go to:  
<http://www.tp-link.com/en/support/download>
- For all other technical support, please contact us by using the following details:

Global	Tel: +86 755 2650 4400 Fee: Depending on rate of different carriers, IDD. E-mail: <a href="mailto:support@tp-link.com">support@tp-link.com</a> Service time: 24hrs, 7 days a week
Singapore	Tel: +65 6284 0493 Fee: Depending on rate of different carriers. E-mail: <a href="mailto:support.sg@tp-link.com">support.sg@tp-link.com</a> Service time: 24hrs, 7 days a week
USA/Canada	Toll Free: +1 866 225 8139 E-mail: <a href="mailto:support.usa@tp-link.com">support.usa@tp-link.com</a> (USA) <a href="mailto:support.ca@tp-link.com">support.ca@tp-link.com</a> (Canada) Service time: 24hrs, 7 days a week
UK	Tel: +44 (0) 845 147 0017 Fee: Landline: 1p-10.5p/min, depending on the time of day. Mobile: 15p-40p/min, depending on your mobile network. E-mail: <a href="mailto:support.uk@tp-link.com">support.uk@tp-link.com</a> Service time: 24hrs, 7 days a week
Turkey	Tel: 0850 7244 488 (Turkish Service) Fee: Depending on rate of different carriers. E-mail: <a href="mailto:support.tr@tp-link.com">support.tr@tp-link.com</a> Service time: 09:00 to 21:00, 7 days a week
Italy	Tel: +39 023 051 9020 Fee: Depending on rate of different carriers. E-mail: <a href="mailto:support.it@tp-link.com">support.it@tp-link.com</a> Service time: Monday to Friday, 09:00 to 13:00; 14:00 to 18:00
Ukraine	Tel: 0800 505 508 Fee: Free for Landline; Mobile: Depending on rate of different carriers E-mail: <a href="mailto:support.ua@tp-link.com">support.ua@tp-link.com</a> Service time: Monday to Friday, 10:00 to 22:00
Malaysia	Toll Free: 1300 88 875 465 Email: <a href="mailto:support.my@tp-link.com">support.my@tp-link.com</a> Service time: 24hrs, 7 days a week
Brazil	Toll Free: 0800 608 9799 (Portuguese Service) E-mail: <a href="mailto:suporte.br@tp-link.com">suporte.br@tp-link.com</a> Service time: Monday to Friday, 09:00 to 20:00; Saturday, 09:00 to 15:00

Poland	<p>Tel: +48 (0) 801 080 618                  +48 223 606 363 (if calls from mobile phone)                  Fee: Depending on rate of different carriers.                  E-mail: support.pl@tp-link.com                  Service time: Monday to Friday, 09:00 to 17:00. GMT+1 or GMT+2 (DST)</p>
Indonesia	<p>Tel: (+62) 021 6386 1936                  Fee: Depending on rate of different carriers.                  E-mail: support.id@tp-link.com                  Service time: Sunday to Friday, 09:00 to 12:00, 13:00 to 18:00 *Except public holidays</p>
France	<p>Tel: 0820 800 860 (French service)                  Fee: 0.118 EUR/min from France                  Email: support.fr@tp-link.com                  Service time: Monday to Friday, 09:00 to 18:00 *Except French Bank holidays</p>
Australia/New Zealand	<p>Tel: NZ 0800 87 5465 (Toll Free)                  AU 1300 87 5465 (Depending on 1300 policy.)                  E-mail: support.au@tp-link.com (Australia)                  support.nz@tp-link.com (New Zealand)                  Service time: 24hrs, 7 days a week</p>
Switzerland	<p>Tel: +41 (0) 848 800 998 (German Service)                  Fee: 4-8 Rp/min, depending on rate of different time.                  E-mail: support.ch@tp-link.com                  Service time: Monday to Friday, 09:00 to 12:30 and 13:30 to 18:00. GMT+1 or GMT+2 (DST)</p>
Germany/Austria	<p>Tel: +49 1805 875 465 (German Service)                  +49 1805 TPLINK                  +43 820 820 360                  Fee: Landline from Germany: 0.14EUR/min.                  Landline from Austria: 0.20EUR/min.                  E-mail: support.de@tp-link.com                  Service time: Monday to Friday, 09:00 to 12:30 and 13:30 to 18:00. GMT+1 or GMT+2 (DST in Germany)                  *Except bank holidays in Hesse</p>
Russian Federation	<p>Tel: 8 (499) 754 5560 (Moscow NO.)                  8 (800) 250 5560 (Toll-free within RF)                  E-mail: support.ru@tp-link.com                  Service time: From 09:00 to 21:00 (Moscow time)                  *Except weekends and holidays in RF</p>



