

Instructions for using web emergency mode

Materials and devices below are required before the operation.

1. A computer that supported Ethernet connection
2. Two Ethernet cables (At least one)
3. Problematic Tapo camera
4. Camera firmware (The .bin file)

The operation steps are as follows:

1. Download the camera firmware according to your camera's model number.

[Tapo C310 V1](#)

[Tapo C310 V2](#)

[TC65 V1](#)

[Tapo C320WS V1](#)

After downloading the firmware, unzip it, and you will see the .bin file.

2. Connect the problem Tapo camera to the computer:

Two types of connection are available (Choose the one that is convenient for you):

➤ **Connection topology 1:**

Tapo camera--<Ethernet>--Router--<Ethernet or Wireless>--PC

After the connection is completed, change the IP settings of the computer network card (Figure 1-1).

Set a fixed IP address for the PC:

IP address: in the 0 (Zero) network segment, e.g. 192.168.0.123

Subnet mask: 255.255.255.0




Figure 1-1 Change IP settings

➤ **Connection topology 2:**

Tapo camera--Ethernet>--PC

After the connection is completed, change the IP settings of the computer network card (Figure 1-1).

Set a fixed IP address for the PC:

IP address: in the 0 (Zero) network segment, e.g. 192.168.0.123

Subnet mask: 255.255.255.0

3. Upgrading via web interface:

Note: the web interface may vary from different models, hardware, or firmware versions.

- Launch a browser on the computer, visit <http://192.168.0.10>
- Click Browse to find the path of the firmware to be upgraded, and then click Upgrade. **Do not interrupt the power supply during the upgrade process.**
- Done, Upgrade Success (Figure 3-2-2)




Figure 3-1 Firmware upgrade interface



Figure 3-2-1 Camera is being upgraded



Figure 3-2-2 Firmware upgrade completed