

## How to update the firmware using tpPLC Utility (new logo)?

We will release the latest firmware at TP-Link official website (<http://www.tp-link.com>). You can download and upgrade the latest firmware for your device.


**Tips:** For a powerline extender, it's better to back up your current settings and update the firmware on the web management interface.

To update the firmware, follow the steps below:

1. Download the latest firmware package specific to your product model from the support page at <http://www.tp-link.com>.
2. Decompress the package to obtain the update file(s).


**Note:** You may obtain simply a BIN file, a GGL file or a combination of NVM and PIB files, depending on the product model.

3. Open the utility, move your mouse over a device, and click the  (**Advanced**) icon.



4. Go to the **Update** page.

You may see either of the following pages, depending on the product model.



Advanced - DEVICE-0001

Update the firmware with the downloaded GGL file.

GGL:  

**Update**

Advanced - DEVICE-2705

Update the firmware with the downloaded BIN file. If you have already logged in to the web management page, please log out before updating.

BIN:  

**Update**

5. Select the obtained update file(s), and click **Update**.

6. Wait for the upgrading to complete.

**Note:** During the upgrading process, do not turn off or reset the powerline device.

**Get to know more details of each function and configuration please go to [Download Center](#) to download the manual of your product.**