

How to Upgrade TP-LINK Wireless AC Access Point?

Notices for upgrading:

1. Please verify the firmware version is corresponded to your hardware version.

Wrong firmware upgrading may damage your device and void the warranty.

For how to check the hardware version of the device please refer to

<http://www.tp-link.com/en/article/?faqid=46> .



2. After you download the firmware from TP-LINK website, please use unzip tools such as WinZIP or WinRAR to extract the firmware file to a folder on your computer;
3. It's recommended to upgrade the firmware via Ethernet cable connection but not wireless connection;
4. Internet Explorer (IE) is recommended when upgrade the firmware;
5. Do NOT turn off the power or unplug the Ethernet cable during upgrade process.


Steps for Upgrading:

Step1


Connect your computer to the Ethernet port of the device by Ethernet cable.
Make sure your network card is set to DHCP.

Step2

1. Open a web browser (such as Internet Explorer, Firefox) and input 192.168.0.254 or <http://tplinkap.net> into the address bar, then press **Enter**.




2. Type in the Username and Password (both **admin** by default) and click **Login**.

A login form with two input fields. The first field is labeled 'Username' and the second is labeled 'Password'. To the left of each field is a small icon: a person icon for the username field and a key icon for the password field. Below the password field is a green button with the text 'Login' in white.

Step3

Go to **Advanced->System Tools->Firmware Upgrade**, click **Browse** button to choose the firmware file you have unzipped before and click **Upgrade**.



Notes:

The device will reboot automatically after upgrading successfully, please wait for 2~3 minutes.