

TP-LINK[®] The Polishie Choice

User Guide



How do I use the Power Bank to charge other portable devices?

Connect your device(s) via the charging cable to the Power Bank.



The 5V/2A USB port can automatically adjust its current to charge your 5V/1A devices.

Press the

the LEDs \

automatica


seconds.

power check the attery level, will turn off ally after 5		LED Display	Battery Level
		* * * *	75%~100%
		$\bullet \bullet \bullet \diamond$	50%~75%
		$\bullet \bullet \diamond \diamond$	25%~50%
	◆ 1 LED on	$\bullet \diamond \diamond \diamond$	10%~25%
	 1 LED blinking Off 	$\bullet \diamond \diamond \diamond$	0%~10%
		$\diamond \diamond \diamond \diamond$	0



How do I recharge the Power Bank?

Connect the Power Bank via a power adapter to an electrical power outlet.




Note:

- 1. The Power Bank is compatible with 5V DC adapters. For more efficiency, we suggest using a 5V/2A power adapter to charge the Power Bank.
- 2. You can also charge the Power Bank via a computer's USB port, but it will take longer to charge.

3. The Power Bank cannot charge other devices while it is charging.

	LED Display	Battery Level
	$\diamond \diamond \diamond \diamond$	0%~25%
	$\bullet \bullet \bullet \bullet$	25%~50%
	$\bullet \bullet \bullet \bullet$	50%~75%
◆ 1 LED on	$\bullet \bullet \bullet \bullet$	75%~100%
 1 LED blinking Off 	* * * *	100%



Attention

 Keep this device away from water, fire, humidity or hot environments.

• Do not heavily drop or impact this device.

 Do not attempt to extrude or pierce this device, which may cause it to short-circuit.

• Do not attempt to disassemble, modify or repair this device by yourself.

 Do not use a damaged power adapter or USB cable to charge this device.

 If the product appears to be bulging or shows other undesirable phenomena, stop using the product immediately and contact us or your dealer.

 Please recycle this device at an appointed disposal location.

 This product is not suitable for those lacking relevant knowledge and experience, please use under the supervision and guidance of professionals.

 Please charge this device once every three months to avoid shortening its battery life.

 Please use the recommended power adapter to charge this device. Power adapter is not provided by TP-LINK.