



Quick Installation Guide


300Mbps Wireless N Router

TL-WR841N / TL-WR841ND

7106505289 REV6.0.1

Connecting the Hardware

If your Internet connection is through an Ethernet cable from the wall instead of through a DSL / Cable / Satellite modem, connect the Ethernet cable directly to the router's WAN port.



Power adapter Connect to the computer 4 Turn on the router.

> 5 Verify that the hardware connection is correct by checking these LEDs.


Note: If the WLAN LED is not flashing, please press the WIFI ON/OFF button for 4 seconds.



Configuring the router

 Connecting your computer to the router (Wired or Wireless)

Wired



Wireless

Use the default network name (SSID) and password printed on the product label on the rear panel of the router to connect wirelessly.




2. Configuring the router with a web browser or CD setup wizard


Option 1: via a web browser

A Enter 'http://tplinkwifi.net' or 'http://192.168.0.1' in the address bar of a web browser. **Use 'admin' for both user name and password**, and then click on 'Login'.

Note: If the login window does not appear, please refer to FAQ->Q1



B Click 'Quick Setup' on the left menu, and click 'Next'. Select your Connection Type and if you are unsure what your connection type is, select 'Auto-Detect'. Click 'Next' and follow the instruction to continue.




Verify or Change the Wireless Network Settings. Click 'Next' to continue.

Note: You may rename your wireless network name and create your own password. If you do, please note down the new wireless network name and password.




D Finish the configuration.



Option 2: via CD setup wizard

A Insert the Resource CD and run the **Autorun.exe**. Select **TL-WR841N** or **TL-WR841ND** and click **Easy Setup Assistant**.



B Choose your language and click **START**. Follow the step-by-step screen instructions to complete the configuration.



Tether App

TP-LINK's Tether app lets you conveniently access the router and:

- View information about the clients on your network.
- Block network access from specific users or devices.
- Set up Parental Control with access time and content restrictions.
- Change the basic wireless network settings easily.

Then, how to begin?

- 1 Scan the QR code and download the TP-LINK Tether app from the Apple App Store or Google Play.
- 2 Ensure your smart device is wirelessly connected to the home network.
- 3 Launch the Tether app and start managing your home network.



FAQ (Frequently Asked Questions)

Q1. What can I do if the login window does not appear?

- If the computer is set to a static or fixed IP address, change it to obtain an IP address automatically.
- Verify that 'http://tplinkwifi.net' is correctly entered in the web browser. Alternatively, enter 'http://192.168.0.1' in the web browser and press 'Enter'.
- Use another web browser and try again.
- Reboot your router and try again.
- Disable the network adapter used currently and then enable it again.

Q2. What can I do if I cannot access the Internet?

- Check if the Internet is working properly by connecting a computer directly to the modem via Ethernet cable. If not, contact your Internet Service Provider.
- Open a web browser, enter 'http://tplinkwifi.net' and try to set up again.
- Reboot your router and try again.

Note: For cable modem users, reboot the modem first. If the problem still exists, go to Network>MAC Clone, then click Clone MAC Address and Save.

Q3. How do I restore the router to its factory default settings?

- While the router is powered on, press and hold the 'WPS/RESET' button on the rear panel of the router for approximately 8 seconds.
- Log in Web Management page of the router, and go to System tools->Factory Defaults, click Restore, and then wait until the progress bar loading finished.

Q4. What can I do if I forget my web management page password?

• Restore the router to its factory default settings and then use the default User Name 'admin' and Password 'admin' to log in.

Q5. What can I do if I forget my wireless network password?

- The factory default password can be found on the product label printed on the bottom of the router.
- If you have changed your password, log in to the router's Web Management page, go to Wireless>Wireless Security to obtain or reset your password.

Note: If your questions are not answered here, please refer to http://www.tp-link.com/en/support/faq and click Contact Technical Support for further assistance.

©2015 TP-LIN