User Guide

Power Bank



Technical Support

Tel: +86 755 2650 4400 E-mail: support@tp-link.com Web: http://www.tp-link.com/support







Charge Your Devices Plug in the USB charging cable to the Smart port to charge your devices.

Recharge the Power Bank

Plug in your Power Bank to a wall charger or your computer's USB port via a Micro-USB charging cable.





Safety Information

- . Keep the device away from water, fire, humidity or hot environments.
- Do not attempt to disassemble, repair, or modify the device.
- Do not use damaged charger or USB cable to charge the device.
- Do not deliberately drop or impact this device.
- Do not attempt to extrude or pierce this device, which may cause it to short circuit.
- If the product appears to be bulging or any other visible abnormalities, stop
 using the product immediately and contact us or distributor.
- Please recycle this device at an approved disposal location.
- This product is not suitable for those lacking relevant knowledge and experience, please use under the supervision and quidance of professionals.
- Please charge this device once every three months to avoid shortening its battery life.
 CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF ILISTS BATTERIES ACCORDING TO THE INSTRUCTIONS.

Please read and follow the above safety information when operating the device. We cannot guarantee that no accidents or damage will occur due to improper use of the device. Please use this product with care and operate at your rown rick.

COPYRIGHT & TRADEMARKS

- Specifications are subject to change without notice. TP-Link is a registered trademark of TP-Link Technologies Co., Ltd. Other brands and product names are registered trademarks of their respective holders.
- No part of the specification may be produced in any form or by any means or used to make any derivative such as translation, transformation, or adaptation withput permission from TP-Link Technologies Co., Ltd.

Copyright @ 2018 TP-Link Technologies Co., Ltd. All rights reserved.

Explanation of the symbols on the product label

Symbol Explanation

DC voltage

RECYCLING

X

This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environment.

User has the choice to give his product to a competent recycling organization or to the retailer when he buys a new electrical or electronic equipment.

CE Mark Warning

 ϵ

This is a class B product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

stement

This device complies with part 15 of the FCC Rules.

FCC States



Operation is subject to the following two conditions:

1) This device may not cause harmful interference:

2) This device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Industry Canada Statement CAN ICES-3 (B)/NMB-3(B)