



Настройка по видео:


Отсканируйте QR-код или перейдите на <https://www.tp-link.com/ru/support/setup-video/#wi-fi-routers>



1 Физическое подключение




- **Отключите питание**, чтобы отключить модем (если он есть), и извлеките резервный аккумулятор (если он есть).
- Горизонтально разместите роутер и приведите антенны в вертикальное положение.



Если интернет-подключение идёт напрямую через кабель Ethernet без использования DSL/кабельного/спутникового модема, подключите кабель Ethernet к порту WAN роутера, после чего выполните шаги 3 и 4 для завершения физического подключения.

* Реальный продукт может отличаться от изображённого.



2 Включите модем и подождите 2 минуты, пока он загрузится.

3 Подключите адаптер питания к роутеру и включите роутер.

4 Verify that the hardware connection is correct by checking the following LEDs.




Примечание: если индикаторы 2,4 ГГц и 5 ГГц не горят, нажмите и удерживайте дольше 2 секунд кнопку WPS/Wi-Fi на задней панели, после этого оба индикатора должны загореться.

2 Настройка сети


Способ 1: через приложение TP-Link Tether

1. Скачайте приложение Tether.



2. Откройте приложение Tether и войдите, используя свой TP-Link ID. Примечание: если у вас нет учётной записи, сначала её нужно создать.

3. Нажмите кнопку **+** в приложении Tether и выберите **Роутер > Wi-Fi роутер**. Следуйте инструкциям для завершения настройки и подключения к интернету.



Интернет готов к работе!

Способ 2: через веб-браузер


1. Подключите устройство к роутеру по Wi-Fi или по кабелю Ethernet.

Имена Wi-Fi сетей (SSID) и пароль по умолчанию напечатаны на этикетке на нижней панели роутера.



2. Запустите веб-браузер и введите в адресной строке <http://tplinkwifi.net> или <http://192.168.0.1> и создайте пароль для входа.

Примечание: если окно входа не появляется, воспользуйтесь пунктом **B1** в разделе **Нужна помощь?** этого руководства.



3. Follow the step-by-step instructions to set up the internet connection and register for the TP-Link Cloud service.

Интернет готов к работе!

писание кнопок

Кнопка WPS/Wi-Fi

Press the button for 1 second, and immediately press the WPS button on your client to start the WPS process.

Press and hold the button for more than 2 seconds to turn on or off the wireless function of your router.

Кнопка Reset

Press and hold the button until all LEDs turn on to reset the router to its factory default settings.

Кнопка LED

Press the button for 1 second to turn on or off the LEDs of your router.

USB Applications

With the USB port, it's easy to share files and media with multiple devices. Visit <https://www.tp-link.com/app/usb> to learn more about the USB applications.



Local Storage Sharing

Share files from the USB drive with devices on your home network



Media Server

Play media from the USB drive on your computer and smart devices



Remote Access

Access the USB drive when you are away from home



To communicate with TP-Link users or engineers, visit <https://community.tp-link.com> to join TP-Link Community.



For technical support, replacement services, user guides and more, please visit <https://www.tp-link.com/support>



Email techwriter@tp-link.com.cn to give suggestions.

- Keep the device away from water, fire, humidity or hot environments.
- Do not attempt to disassemble, repair, or modify the device.
- Do not use any other chargers than those recommended.
- Do not use damaged charger or USB cable to charge the device.
- Do not use the device where wireless devices are not allowed.
- Adapter shall be installed near the equipment and shall be easily accessible.

Need Help?



Q1. What should I do if I can't access the web management page?

- Reboot your router and try again.
- If the computer is set to a static IP, change its settings to obtain an IP address automatically.
- Verify that <http://tplinkwifi.net> is correctly entered in the web browser. Alternatively, enter <http://192.168.0.1> or <http://192.168.1.1> in the web browser.
- Use another web browser and try again.
- Disable and enable the network adapter in use.

Q2. What should I do if I can't access the internet?

- Reboot your modem and router, then try again.
- Check if the internet is working normally by connecting a computer directly to the modem via an Ethernet cable. If it is not, contact your internet service provider.
- Log in to the web management page of the router, and go to the **Basic > Network Map** page to check whether the internet IP address is valid or not. If it is, please run the Quick Setup again; otherwise, check the hardware connection.
- For cable modem users, log in to the web management page of the router and go to **Advanced > Network > Internet > MAC Clone**. Select **Clone Current Computer MAC Address** and click **Save**. Then reboot both the modem and the router.

Q3. What should I do if I forget my wireless password?

- If you have not changed the default wireless password, it can be found on the label at the bottom of the router.
- Connect a computer directly to the router using an Ethernet cable. Log in to the router's web management page at <http://tplink>, and go to **Basic > Wireless** to retrieve or reset your wireless password.

Q4. What should I do if I forget my web management page password?

- If you are using a TP-Link ID to log in, click **Forgot password** on the login page and then follow the instructions to reset it.
- Alternatively, press and hold the Reset button on the back until all LEDs turn on. Then visit <http://tplinkwifi.net> to create a new login password.

©2020 TP-Link 7106508709 REV1.0.3

Руководство по быстрой настройке



AX3000 Гигабитный роутер Wi-Fi 6

