


TL-PB2600



	LED Display	Battery Level
Recharge the Power Bank	Blinking	Charging
	On	Fully charged
Charge other devices	Off	Sufficient battery
	Blinking	Low battery
Press the Battery Button	On	Sufficient battery
	Blinking thrice	Low battery

Note: The Power Bank cannot charge another device while it is charging.

Attention

- Keep this device away from water, fire, humidity or hot environments.
- Do not heavily drop or impact this device.
- Do not attempt to extrude or pierce this device, which may cause it to short-circuit.
- Do not attempt to disassemble, modify or repair this device by yourself.
- Do not use a damaged power adapter or USB cable to charge this device.
- If the product appears to be bulging or shows other undesirable phenomena, stop using the product immediately and contact us or your dealer.
- Please recycle this device at an appointed disposal location.
- This product is not suitable for those lacking relevant knowledge and experience, please use under the supervision and guidance of professionals.
- Please charge this device once every three months to avoid shortening its battery life.
- Please use the recommended power adapter to charge this device. Power adapter is not provided by TP-LINK.

If you have any questions related to this product, please refer to the support page at www.tp-link.com