

Printer Manufacture	Printer Model	Type of Printer	Language	Function	TL-PS110U 2.0	TL-PS110P	TL-WPS510U
				MFP (P: Print S: Scan F: Fax C: Card Reader)	716U2	7119A+	DWP2020
HP	Business InkJet 1000	USB	PCL 3	P	OK		OK
HP	Color LaserJet 1500L	USB	Host-based	P	OK		OK
HP	Color LaserJet 1600	USB	Host-based	P	OK		OK
HP	Color LaserJet 2500	Parallel/USB	PCL6/5C	P	OK	OK	OK
HP	Color LaserJet 2550	USB	PCL6/PS level 3	P	OK	OK	OK
HP	Color LaserJet	USB	PCL6/PS level 3	P	OK		OK
HP	Color LaserJet 2600	USB	Host-based	P	OK		OK
HP	Color LaserJet 2605	USB	PCL6/5E	P	OK	OK	OK
HP	Color LaserJet 2700n	USB	PCL6/PCL5c/PS level 3	P	OK		OK
HP	Color LaserJet 2840	USB	PCL6/PS level 3	P	OK		OK
HP	Color LaserJet 3700	Parallel/USB	PCL6/PCL5c/PS level 3	P	OK	OK	OK
HP	Color LaserJet 4000	Parallel		P		OK	
HP	Color LaserJet 4100	Parallel		P		OK	
HP	Color LaserJet 4500	Parallel	PCL5c/PS level 2	P		OK	
HP	Color LaserJet 4650	Parallel	PCL6/PCL5c/PS level 3	P	OK	OK	OK
HP	Color LaserJet 8550	Parallel	PCL5c/PS level 3	P		OK	
HP	Color LaserJet	USB	Host-based	P	OK		OK
HP	Color LaserJet	USB	PCL6/PCL5c/PS level 3	P	OK		OK
HP	Color LaserJet	USB	PCL6/PCL5c/PS level 3	P	OK		OK
HP	Color LaserJet	USB	PCL6/PCL5c/PS level 3	P	OK		OK
HP	DesignJet 100	Parallel/USB	PCL4	P	OK	OK	OK
HP	DesignJet 600	Parallel	HP-GL,HP-GL/2,HP RTL	P		OK	
HP	DesignJet 650C	Parallel	HP-GL,HP-GL/2,HP	P		OK	
HP	DesignJet 700	Parallel	HP-GL,HP-GL/2,HP	P		OK	
HP	DesignJet 750C+	Parallel	HP-GL,HP-GL/2,HP	P		OK	
HP	DeskJet 1120C	Parallel	PCL3	P		OK	
HP	Deskjet 1125C	Parallel/USB	PCL3	P	OK	OK	OK
HP	Deskjet 1180C	Parallel/USB	PCL3	P	OK	OK	OK
HP	DeskJet 1280	Parallel/USB	PCL3	P	OK	OK	OK
HP	Deskjet 2000 J210		PCL3	P	OK		OK
HP	Deskjet 2050	USB	PCL3	P	OK		OK
HP	Deskjet 2510	USB	PCL3	P	OK		OK
HP	Deskjet 3000	USB	PCL3	P	OK		OK
HP	Deskjet 3070A	USB		P	OK		OK
HP	Deskjet 3050	USB	PCL3	P	OK		OK
HP	Deskjet 3325	USB	LIDIL	P	OK		OK
HP	DeskJet 3420	USB	LIDIL	P	OK		OK
HP	Deskjet 3520	USB	PCL3	P	OK		OK
HP	Deskjet 3535	USB	LIDIL	P	OK		OK
HP	Deskjet 3650	USB	LIDIL	P	OK		OK
HP	Deskjet 3743	USB	LIDIL	P	OK		OK
HP	Deskjet 3748	USB	LIDIL	P	OK		OK
HP	Deskjet 3820	Parallel/USB	LIDIL	P	OK	OK	OK
HP	DeskJet 3920		LIDIL	P	OK		OK
HP	DeskJet 3940		LIDIL	P	OK		OK
HP	DeskJet 400/420	Parallel	PCL3	P		OK	
HP	Deskjet 450C		PCL3	P	OK	OK	OK
HP	DeskJet 5440		PCL3	P	OK		OK
HP	DeskJet 5500	Parallel	PCL3	P		OK	
HP	Deskjet 5550	Parallel/USB	PCL3	P	OK	OK	OK
HP	Deskjet 5652	Parallel/USB	PCL3	P	OK	OK	OK
HP	Deskjet 670C	Parallel	PCL3	P		OK	
HP	Deskjet 680C	Parallel	PCL3	P		OK	
HP	Deskjet 720C	Parallel	PPA-PCL3	P		OK	
HP	Deskjet 810C	Parallel/USB	PCL3	P	OK	OK	OK
HP	Deskjet 830C		PCL3	P	OK	OK	OK
HP	Deskjet 845C	USB	PCL3	P	OK		OK
HP	DeskJet 9300	Parallel/USB	PCL3	P	OK	OK	OK
HP	Deskjet 948c	Parallel/USB		P	OK	OK	OK
HP	Deskjet 9600		PCL3	P	OK	OK	OK
HP	Deskjet 9650	Parallel/USB	PCL3	P	OK	OK	OK
HP	Deskjet 970c Xi	Parallel/USB	PCL3	P	OK	OK	OK
HP	Deskjet 9800	Parallel/USB	PCL3	P	OK	OK	OK
HP	Deskjet D1560	USB	LIDIL	P	OK		OK
HP	Deskjet D2560	USB	PCL3	P	OK		OK
HP	Deskjet D5560	USB	PCL3	P	OK		OK
HP	DeskJet F370	USB	LIDIL	P	OK		OK
HP	DeskJet F380	USB	LIDIL	P	OK		OK
HP	DeskJet F4185	USB	LIDIL	P	OK		OK
HP	DeskJet F4280	USB	PCL3	P	OK		OK
HP	Deskjet F4480	USB	PCL3	P	OK		OK
HP	LaserJet Pro M401n	USB		P	OK		OK
HP	LaserJet M1005 MFP		Host-based	P	OK		OK
HP	LaserJet 1010	USB	Host-based	P			
HP	LaserJet 1022	USB	PCL5E	P	OK		OK
HP	LaserJet 1022N		PCL5E	P	OK		OK
HP	LaserJet 1100	Parallel	PCL5E	P		OK	
HP	LaserJet 1160	USB	PCL5e/GDI	P	OK	OK	OK
HP	LaserJet 1200	Parallel/USB	PCL6/5e	P	OK	OK	OK
HP	LaserJet 1220		PCL6/PCL5e/PS level 2	P	OK	OK	OK
HP	LaserJet 1300	Parallel/USB	PCL6/5e	P	OK	OK	OK
HP	LaserJet 1320	Parallel/USB	PCL6/5e	P	OK	OK	OK
HP	LaserJet M1522n MFP		PCL6/PCL5e/PS level 3	P	OK		OK
HP	LaserJet 2100	Parallel	HP-GL/2,PCL6,PS Level 2	P		OK	
HP	LaserJet 2200d	Parallel/USB	PCL6/PCL5e/PS level 2	P	OK	OK	OK
HP	LaserJet 2300	Parallel/USB	PCL6/PCL5e/PS level 2	P	OK	OK	OK

Printer Manufacture	Printer Model	Type of Printer	Language	Function	TL-PS110U 2.0	TL-PS110P	TL-WPS510U
HP	LaserJet 2410	USB	PCL6/PCL5e/PS level 3	P	OK	OK	OK
HP	LaserJet 2420	Parallel/USB	PCL6/PCL5e/PS level 3	P	OK	OK	OK
HP	LaserJet 2550			P	OK	OK	OK
HP	LaserJet 3015	Parallel/USB	PCL6/PCL5e/PS level 2	P	OK	OK	OK
HP	LaserJet 3050	USB	PCL6/PCL5e/PS level 3	P	OK		OK
HP	LaserJet 3055		PCL6/PCL5e/PS level 3	P	OK		OK
HP	LaserJet 3200	Parallel/USB	PCL6/PCL5e	P	OK	OK	OK
HP	LaserJet 3330		PCL6/PCL5e/PS level 2	P	OK	OK	OK
HP	LaserJet 3330mfp	Parallel/USB	PCL6/PCL5e/PS level 2	P	OK	OK	OK
HP	LaserJet 3380	Parallel/USB	PCL6/PCL5e/PS level 2	P	OK		OK
HP	LaserJet 4000	Parallel	PCL6/PS level 2	P		OK	
HP	LaserJet 4050	Parallel	PCL6/PCL5e/PS level 2	P		OK	
HP	LaserJet 4100 /4100n	Parallel	PCL6/PCL5e/PS level 3	P		OK	
HP	LaserJet 4250	Parallel/USB	PCL6/PCL5e/PS level 3	P	OK	OK	OK
HP	LaserJet 4300n	Parallel	PCL6/PCL5e/PS level	P		OK	
HP	LaserJet 4300tn/dtn	Parallel	PCL6/PCL5e/PS level	P		OK	
HP	LaserJet Color 4500	Parallel	PCL5c/PS level 2	P		OK	
HP	LaserJet 4650			P	OK	OK	OK
HP	LaserJet 5100fn/tn	Parallel	PCL6/5E	P		OK	
HP	LaserJet 5100le/se	Parallel	PCL6/5E	P		OK	
HP	LaserJet 6P / 6L	Parallel		P		OK	
HP	LaserJet 8100	Parallel		P		OK	
HP	LaserJet M1005			P	OK		OK
HP	LaserJet M1005 MFP			P	OK		OK
HP	LaserJet M1120 MFP			P	OK		OK
HP	LaserJet M1319F	USB		P	OK		OK
HP	LaserJet P2015	USB	PCL6/5e/PS Level 3	P	OK		OK
HP	OfficeJet J3608 150 Mobile L511	USB		P	OK		OK
HP	OfficeJet J3608	USB		P	OK		OK
HP	OfficeJet 4255	USB		P	OK		OK
HP	OfficeJet 4500			P	OK		OK
HP	OfficeJet 4610	USB		P	OK		OK
HP	OfficeJet 4620	USB		P	OK		OK
HP	OfficeJet 5610	USB		P	OK		OK
HP	OfficeJet J5780	USB		P	OK		OK
HP	OfficeJet 6210	USB		P	OK		OK
HP	OfficeJet 6310	USB		P	OK		OK
HP	OfficeJet 6000	USB		P	OK		OK
HP	OfficeJet 6100 eP	USB		P	OK		OK
HP	OfficeJet 6500	USB		P	OK		OK
HP	OfficeJet 6600	USB		P	OK		OK
HP	OfficeJet 6700	USB		P	OK		OK
HP	OfficeJet 7000	USB		P			OK
HP	OfficeJet 7500A	USB		P	OK		OK
HP	OfficeJet 7210	USB		P	OK		OK
HP	OfficeJet J4580	USB		P	OK		OK
HP	OfficeJet J4660			P	OK		OK
HP	OfficeJet J6480	USB		P	OK		OK
HP	OfficeJet K7100	USB		P	OK		OK
HP	OfficeJet K850	USB		P	OK	OK	OK
HP	OfficeJet Pro K5300	USB		P	OK		OK
HP	OfficeJet Pro K550	USB		P	OK		OK
HP	OfficeJet Pro K8600	USB		P	OK		OK
HP	OfficeJet Pro L7380	USB		P	OK		OK
HP	OfficeJet Pro L7590	USB		P	OK		OK
HP	OfficeJet Pro 6500A	USB		P	OK		OK
HP	OfficeJet Pro 7000	USB		P	OK		OK
HP	OfficeJet Pro 8000	USB		P	OK		OK
HP	OfficeJet Pro 8100	USB		P	OK		OK
HP	OfficeJet Pro 8500A	USB		P	OK		OK
HP	OfficeJet Pro 8500W	USB		P	OK		OK
HP	OfficeJet Pro 8600	USB		P	OK		OK
HP	OfficeJet Pro 8600	USB		P	OK		OK
HP	Photosmart 2610	USB		P	OK		OK
HP	Photosmart 3110	USB		P	OK		OK
HP	Photosmart 5510	USB		P	OK		OK
HP	Photosmart 5520	USB		P	OK		OK
HP	Photosmart 6510	USB		P	OK		OK
HP	Photosmart 6520	USB		P	OK		OK
HP	Photosmart 7150	USB		P	OK		OK
HP	Photosmart 7200	USB		P	OK		OK
HP	Photosmart 7510	USB		P	OK		OK
HP	Photosmart 7550	Parallel/USB		P	OK		OK
HP	Photosmart 7660	USB	PCL3	P	OK		OK
HP	Photosmart 7830	USB		P	OK		OK
HP	Photosmart 7900	USB		P	OK		OK
HP	Photosmart 8200	USB		P	OK		OK
HP	Photosmart Plus	USB		P	OK		OK
HP	Photosmart Plus	USB		P	OK		OK
HP	Photosmart Plus	USB		P	OK		OK
HP	Photosmart A520			P	OK		OK
HP	Photosmart B109a			P	OK		OK
HP	Photosmart B110a			P	OK		OK
HP	Photosmart C309a			P	OK		OK
HP	Photosmart C410a	USB		P	OK		OK
HP	Photosmart C3180	USB		P	OK		OK
HP	Photosmart C4180	USB		P	OK		OK
HP	Photosmart C4280	USB		P	OK		OK
HP	Photosmart C4385	USB		P	OK		OK
HP	Photosmart C4480	USB		P	OK		OK

Printer Manufacture	Printer Model	Type of Printer	Language	Function	TL-PS110U 2.0	TL-PS110P	TL-WPS510U
HP	Photosmart C4580	USB		P	OK		OK
HP	Photosmart C5180	USB		P	OK		OK
HP	Photosmart C5280	USB		P	OK		OK
HP	Photosmart C5380	USB		P	OK		OK
HP	Photosmart C6180	USB		P	OK		OK
HP	Photosmart C6280	USB		P	OK		OK
HP	Photosmart C6380	USB		P	OK		OK
HP	Photosmart C7180	USB		P	OK		OK
HP	Photosmart C7280	USB		P	OK		OK
HP	Photosmart C8180	USB		P	OK		OK
HP	Photosmart D5160	USB		P	OK		OK
HP	Photosmart D5360	USB		P	OK		OK
HP	Photosmart D5460	USB		P	OK		OK
HP	Photosmart D7160	USB		P	OK		OK
HP	Photosmart D7260	USB		P	OK		OK
HP	Photosmart D7360	USB		P	OK		OK
HP	Photosmart Premium	USB		P	OK		OK
HP	Photosmart Premium	USB		P	OK		OK
HP	PSC 1210	USB		P			OK
HP	PSC 1315	USB		P	OK		OK
HP	PSC 1350	USB	LIDIL	P	OK		OK
HP	PSC 1410	USB		P	OK		OK
HP	PSC 1610	USB		P	OK		OK
HP	PSC 2210	USB		P	OK		OK
HP	PSC 2310	USB		P	OK		OK
EPSON	Aculaser C1100SE			P	OK	OK	OK
EPSON	Aculaser C1600			P	OK		OK
EPSON	Aculaser C1700	USB		P	OK		OK
EPSON	Aculaser C1750N	USB		P	OK		OK
EPSON	Aculaser C1750W	USB		P	OK		OK
EPSON	Aculaser C1900	Parallel/USB		P	OK	OK	OK
EPSON	Aculaser C2900	USB		P	OK		OK
EPSON	Aculaser C3800	USB		P	OK		OK
EPSON	Aculaser C3900N	USB		P	OK		OK
EPSON	Aculaser C9100			P	OK		OK
EPSON	Aculaser CX16NF	USB		P	OK		OK
EPSON	Aculaser CX17NF	USB		P	OK		OK
EPSON	Aculaser M1400	USB		P	OK		OK
EPSON	Aculaser M2010DN			P	OK		OK
EPSON	Aculaser M2010D			P	OK	OK	OK
EPSON	Aculaser M2310D	Parallel/USB		P	OK	OK	OK
EPSON	Aculaser M2310DN	USB		P	OK		OK
EPSON	Aculaser M2410D	Parallel/USB		P	OK	OK	OK
EPSON	Aculaser M2410DN	USB		P	OK		OK
EPSON	Aculaser MX14	USB		P	OK		OK
EPSON	Aculaser MX14NF	USB		P	OK		OK
EPSON	AL-M200DN	USB		P	OK		OK
EPSON	AL-M7000	USB		P	OK		OK
EPSON	AL-M8000	Parallel/USB		P	OK	OK	OK
EPSON	AL-MX200DWF	USB		P	OK		OK
EPSON	B-508DN			P	OK		OK
EPSON	B-518DN			P	OK		OK
EPSON	C750			P	OK	OK	OK
EPSON	CC-500L			P	OK		OK
EPSON	CL-760			P	OK		OK
EPSON	E-300L			P	OK		OK
EPSON	E-520			P	OK		OK
EPSON	E-720			P	OK		OK
EPSON	EC-01			P	OK		OK
EPSON	EPL 5700	Parallel		P		OK	
EPSON	EPL 5700	Parallel	ESC/Pages	P		OK	
EPSON	EPL 5800			P	OK	OK	OK
EPSON	EPL 5800	Parallel/USB	PCL6/5e	P	OK	OK	OK
EPSON	EPL 5900	Parallel/USB		P	OK	OK	OK
EPSON	EPL 6100	Parallel/USB	PCL6/5e	P	OK	OK	OK
EPSON	EPL 6200	Parallel/USB		P	OK	OK	OK
EPSON	EPL N2120	Parallel		P		OK	
EPSON	K100	USB		P	OK		OK
EPSON	L110	USB		P	OK		OK
EPSON	L200	USB		P	OK		OK
EPSON	L210	USB		P	OK		OK
EPSON	L350	USB		P	OK		OK
EPSON	L355	USB		P	OK		OK
EPSON	L300	USB		P	OK		OK
EPSON	L550	USB		P	OK		OK
EPSON	L800	USB		P	OK		OK
EPSON	LP2500			P	OK		OK
EPSON	LP-7700			P	OK		OK
EPSON	LP-8700			P	OK		OK
EPSON	LP-8800C			P	OK		OK
EPSON	LP8900			P	OK		OK
EPSON	LP-9500C			P	OK		OK
EPSON	LQ 100	Parallel		P		OK	
EPSON	LQ 1000C	Parallel		P		OK	
EPSON	LQ 1170+	Parallel		P		OK	
EPSON	LQ 1170C	Parallel		P		OK	
EPSON	LQ 1170C+	Parallel		P		OK	
EPSON	LQ 2070C	Parallel		P		OK	
EPSON	LQ 2080C	Parallel		P		OK	
EPSON	LQ 2090	Parallel		P		OK	
EPSON	LQ 2090C			P	OK	OK	OK

Printer Manufacture	Printer Model	Type of Printer	Language	Function	TL-PS110U 2.0	TL-PS110P	TL-WPS510U
EPSON	LQ 2170C	Parallel	ESC/P	P		OK	
EPSON	LQ 2180C			P		OK	
EPSON	LQ 2190C	Parallel/USB		P	OK	OK	OK
EPSON	LQ 2550			P		OK	
EPSON	LQ 300	Parallel	ESC/P	P		OK	
EPSON	LQ 300+			P		OK	
EPSON	LQ 300+II			P	OK	OK	OK
EPSON	LQ-310	Parallel/USB		P	OK	OK	OK
EPSON	LQ 3500C	Parallel		P		OK	
EPSON	LQ 570C	Parallel		P		OK	
EPSON	LQ 670	Parallel		P		OK	
EPSON	LQ 680	Parallel	ESC/P	P		OK	
EPSON	LQ 680C	Parallel		P		OK	
EPSON	M105	USB		P	OK		OK
EPSON	ME 320			P	OK		OK
EPSON	ME 340	USB		P	OK		OK
EPSON	ME Office 82WD	USB		P	OK		OK
EPSON	ME Office 900WD	USB		P	OK		OK
EPSON	ME Office 940FW	USB		P	OK		OK
EPSON	ME Office 960FWD	USB		P	OK		OK
EPSON	MC-2000			P	OK		OK
EPSON	PictureMate PM250			P	OK		OK
EPSON	PLQ-20C			P	OK		OK
EPSON	PLQ-20CM			P	OK		OK
EPSON	PM-860PT			P	OK		OK
EPSON	PM-890C			P	OK		OK
EPSON	PM-920C			P	OK		OK
EPSON	PM-930C			P	OK		OK
EPSON	PM-950C			P	OK		OK
EPSON	PM-970C			P	OK		OK
EPSON	PM-980C			P	OK		OK
EPSON	PM-A550			P	OK		OK
EPSON	PM-A620			P	OK		OK
EPSON	PM-A650			P	OK		OK
EPSON	PM-A720			P	OK		OK
EPSON	PM-A820			P	OK		OK
EPSON	PM-A840			P	OK		OK
EPSON	PM-A850			P	OK		OK
EPSON	PM-A890			P	OK		OK
EPSON	PM-A900			P	OK		OK
EPSON	PM-A920			P	OK		OK
EPSON	PM-A940			P	OK		OK
EPSON	PM-A950			P	OK		OK
EPSON	PM-A970			P	OK		OK
EPSON	PM-2200C			P	OK		OK
EPSON	PM-3500C			P	OK		OK
EPSON	PM-3700C			P	OK		OK
EPSON	PM-4000PX			P	OK		OK
EPSON	PM-D800			P	OK		OK
EPSON	PM-D870			P	OK		OK
EPSON	PM-D1000			P	OK		OK
EPSON	PM-FA700			P	OK		OK
EPSON	PM-G800			P	OK		OK
EPSON	PM-G820			P	OK		OK
EPSON	PM-G850			P	OK		OK
EPSON	PM-G860			P	OK		OK
EPSON	PM-G4500			P	OK		OK
EPSON	PM-T960			P	OK		OK
EPSON	PM-T990			P	OK		OK
EPSON	PX-5000			P	OK		OK
EPSON	PX-A640			P	OK		OK
EPSON	PX-A740			P	OK		OK
EPSON	PX-G5300			P	OK		OK
EPSON	PX-G5100			P	OK		OK
EPSON	PX-G930			P	OK		OK
EPSON	PX-G5000			P	OK		OK
EPSON	PX-V780			P	OK		OK
EPSON	RX 510			P	OK		OK
EPSON	RX 530			P	OK		OK
EPSON	RX 590			P	OK		OK
EPSON	RX 630			P	OK		OK
EPSON	RX 690			P	OK		OK
EPSON	Stylus C20			P	OK		OK
EPSON	Stylus C40			P	OK		OK
EPSON	Stylus C41UX/SX	USB		P	OK		OK
EPSON	Stylus C43UX			P	OK		OK
EPSON	Stylus C45			P	OK		OK
EPSON	Stylus C59			P	OK		OK
EPSON	Stylus C60	Parallel/USB		P	OK	OK	OK
EPSON	Stylus C63			P	OK	OK	OK
EPSON	Stylus C67			P	OK	OK	OK
EPSON	Stylus C79			P	OK		OK
EPSON	Stylus C83	Parallel		P		OK	
EPSON	Stylus C90			P	OK		OK
EPSON	Stylus Color 1160	Parallel/USB		P	OK		OK
EPSON	Stylus Color 1500			P	OK		OK
EPSON	Stylus Color 1520			P	OK		OK
EPSON	Stylus Color 400	Parallel		P		OK	
EPSON	Stylus Color 600	Parallel		P		OK	
EPSON	Stylus Color 670	Parallel/USB	ESC/P	P	OK	OK	OK
EPSON	Stylus Color 800	Parallel	ESC/P2	P	OK	OK	OK

Printer Manufacture	Printer Model	Type of Printer	Language	Function	TL-PS110U 2.0	TL-PS110P	TL-WPS510U
EPSON	Stylus Color 810			P	OK	OK	OK
EPSON	Stylus Color 850	Parallel	ESC/P2	P	OK	OK	OK
EPSON	Stylus Color 900	Parallel/USB	ESC/P2	P	OK		OK
EPSON	Stylus CX-1500			P	OK		OK
EPSON	Stylus CX-2900			P	OK		OK
EPSON	Stylus CX-3500			P	OK		OK
EPSON	Stylus CX-3700			P	OK		OK
EPSON	Stylus CX-3900			P	OK		OK
EPSON	Stylus CX-4100			P	OK		OK
EPSON	Stylus CX-4700			P	OK		OK
EPSON	Stylus CX-4900			P	OK		OK
EPSON	Stylus CX-5300			P	OK		OK
EPSON	Stylus CX-5500			P	OK		OK
EPSON	Stylus CX-5505			P	OK		OK
EPSON	Stylus CX-5900			P	OK		OK
EPSON	Stylus CX-6900F			P	OK		OK
EPSON	Stylus CX-7300			P	OK		OK
EPSON	Stylus CX-7800			P	OK		OK
EPSON	Stylus CX-8300			P	OK		OK
EPSON	Stylus CX-9300F			P	OK		OK
EPSON	Stylus Office T30			P	OK		OK
EPSON	Stylus Office T40W	USB		P	OK		OK
EPSON	Stylus Office TX300F			P	OK		OK
EPSON	Stylus Office TX320F	USB		P	OK		OK
EPSON	Stylus Office	USB		P	OK		OK
EPSON	Stylus Office			P	OK		OK
EPSON	Stylus Office	USB		P	OK		OK
EPSON	Stylus Office T1100	USB		P	OK		OK
EPSON	Stylus Photo 915			P	OK		OK
EPSON	Stylus Photo 1270	Parallel/USB		P	OK	OK	OK
EPSON	Stylus Photo 1290	Parallel/USB		P	OK		OK
EPSON	Stylus Photo 1390			P	OK		OK
EPSON	Stylus Photo 2100			P	OK		OK
EPSON	Stylus Photo 710	Parallel/USB		P	OK		OK
EPSON	Stylus Photo 720	Parallel/USB		P	OK		OK
EPSON	Stylus Photo 790			P	OK		OK
EPSON	Stylus Photo 810			P	OK	OK	OK
EPSON	Stylus Photo 830U			P	OK		OK
EPSON	Stylus Photo 900			P	OK	OK	OK
EPSON	Stylus Photo 915			P	OK		OK
EPSON	Stylus Photo EX2	Parallel		P	OK	OK	OK
EPSON	Stylus Photo EX3	Parallel/USB		P	OK	OK	OK
EPSON	Stylus Photo R1800			P	OK	OK	OK
EPSON	Stylus Photo R210	USB		P	OK		OK
EPSON	Stylus Photo R230	USB		P	OK		OK
EPSON	Stylus Photo R250	USB		P	OK		OK
EPSON	Stylus Photo R270	USB	ESC/P	P	OK		OK
EPSON	Stylus Photo R310	USB		P	OK		OK
EPSON	Stylus Photo R350			P	OK		OK
EPSON	Stylus Photo R2400	USB		P	OK		OK
EPSON	Stylus Photo R800			P	OK		OK
EPSON	Stylus Photo RX430	USB		P	OK		OK
EPSON	Stylus Photo RX 510			P	OK		OK
EPSON	Stylus Photo RX 530			P	OK		OK
EPSON	Stylus Photo RX 590			P	OK		OK
EPSON	Stylus Photo RX 630			P	OK		OK
EPSON	Stylus Photo RX 650			P	OK		OK
EPSON	Stylus Photo RX 690			P	OK		OK
EPSON	Stylus Photo R2880			P	OK		OK
EPSON	Stylus Photo TX700W	USB		P	OK		OK
EPSON	Stylus Photo	USB		P	OK		OK
EPSON	Stylus Photo	USB		P	OK		OK
EPSON	Stylus Pro 7600	Parallel/USB		P	OK	OK	OK
EPSON	Stylus TX550W	USB		P	OK		OK
EPSON	Stylus TX420W			P	OK		OK
EPSON	Stylus TX410	USB		P	OK		OK
EPSON	Stylus TX430	USB		P	OK		OK
EPSON	Stylus TX235	USB		P	OK		OK
EPSON	Stylus TX220			P	OK		OK
EPSON	Stylus TX200	USB		P	OK		OK
EPSON	Stylus TX210	USB		P	OK		OK
EPSON	Stylus TX130	USB		P	OK		OK
EPSON	Stylus TX110	USB		P	OK		OK
EPSON	Stylus TX100	USB		P	OK		OK
EPSON	Stylus T22			P	OK		OK
EPSON	Stylus T20	USB		P	OK		OK
EPSON	Stylus T21	USB		P	OK		OK
EPSON	Stylus Photo T50	USB		P	OK		OK
EPSON	TM883 (III)	Parallel		P		OK	
EPSON	TM T88III	Parallel		P		OK	
EPSON	WorkForce AL-	Parallel/USB		P	OK	OK	OK
EPSON	WorkForce AL-	USB		P	OK		OK
EPSON	WorkForce AL-	USB		P	OK		OK
EPSON	WF-2521	USB		P	OK		OK
EPSON	WF-2531	USB		P	OK		OK
EPSON	WF-2541	USB		P	OK		OK
EPSON	WF-3521	USB		P	OK		OK
EPSON	WorkForce WF-3541	USB		P	OK		OK
EPSON	WF-7011	USB		P	OK		OK
EPSON	WF-7511	USB		P	OK		OK
EPSON	WF-7521	USB		P	OK		OK

Printer Manufacture	Printer Model	Type of Printer	Language	Function	TL-PS110U 2.0	TL-PS110P	TL-WPS510U
EPSON	WP-4531	USB		P	OK		OK
EPSON	WP-4091	USB		P	OK		OK
EPSON	XP30	USB		P	OK		OK
EPSON	XP-102	USB		P	OK		OK
EPSON	XP-202	USB		P	OK		OK
EPSON	XP-302	USB		P	OK		OK
EPSON	XP-402	USB		P	OK		OK
EPSON	XP-701	USB		P	OK		OK
EPSON	GP-C830	Parallel/USB		P	OK	OK	OK
EPSON	GP-M800	Parallel/USB		P	OK	OK	OK
EPSON	GP-C800	Parallel/USB		P	OK	OK	OK
EPSON	AL-C500	USB		P	OK		OK
EPSON	AL-C9300	USB		P	OK		OK
EPSON	TM-U220	Parallel/USB		P	Fail	OK	Fail
Canon	BJ-330	Parallel		P		OK	
Canon	BJC-4200	Parallel		P		OK	
Canon	BJC-4300	Parallel		P		OK	
Canon	BJC-4500	Parallel		P			
Canon	BJC-4550	Parallel		P		OK	
Canon	BJC-4600	Parallel		P		OK	
Canon	BJF9000			P	OK		OK
Canon	D380			P	OK		OK
Canon	E600			P	OK		OK
Canon	I-255			P	OK		OK
Canon	I-355			P	OK		OK
Canon	I-450			P	OK		OK
Canon	I-455			P	OK		OK
Canon	I-470D			P	OK		OK
Canon	I-475D			P	OK		OK
Canon	I-550			P	OK		OK
Canon	I-560			P	OK		OK
Canon	I-850	IEEE 1284/USB		P	OK		OK
Canon	I-865			P	OK		OK
Canon	I-950	USB		P	OK		OK
Canon	I-6100			P	OK	OK	OK
Canon	I-6500			P	OK	OK	OK
Canon	I-9100	USB		P	OK		OK
Canon	I-9950	USB		P	OK		OK
Canon	IX4000	USB		P	OK		OK
Canon	IX5000	USB		P	OK		OK
Canon	Imageclass D380	USB		P	OK		OK
Canon	MP-160	USB		P	OK		OK
Canon	MP-638	USB		P	OK		OK
Canon	MP 770	USB		P	OK		OK
Canon	PIXMA MX318	USB		P	OK		OK
Canon	PIXMA MX320	USB		P	OK		OK
Canon	PIXMA MX357	USB		P	OK		OK
Canon	PIXMA MX377	USB		P	OK		OK
Canon	PIXMA MX416	USB		P	OK		OK
Canon	PIXMA MX457	USB		P	OK		OK
Canon	PIXMA MX527	USB		P	OK		OK
Canon	PIXMA MX700	USB		P	OK		OK
Canon	PIXMA MX727	USB		P	OK		OK
Canon	PIXMA MX927	USB		P	OK		OK
Canon	PIXUS IP2500	USB		P	OK		OK
Canon	PIXUS 990i	USB		P	OK		OK
Canon	PIXMA E510	USB		P	OK		OK
Canon	PIXMA iP1000	USB		P	OK		OK
Canon	PIXMA iP1700			P	OK		OK
Canon	PIXMA iP1800			P	OK		OK
Canon	PIXMA Ip1880	USB		P	OK		OK
Canon	PIXMA Ip1980			P	OK		OK
Canon	PIXMA Ip2000			P	OK		OK
Canon	PIXMA iP3000	USB		P	OK		OK
Canon	PIXMA Ip3300			P	OK		OK
Canon	PIXMA Ip3500	USB		P	OK		OK
Canon	PIXMA Ip3680	USB		P	OK		OK
Canon	PIXMA iP4000	USB/IEEE1284		P	OK	OK	OK
Canon	PIXMA Ip4200			P	OK		OK
Canon	PIXMA Ip4300			P	OK		OK
Canon	PIXMA Ip4500			P	OK		OK
Canon	PIXMA Ip4760			P	OK		OK
Canon	PIXMA ip4970	USB		P	OK		OK
Canon	PIXMA Ip5000	USB		P	OK		OK
Canon	PIXMA Ip6000	USB		P	OK		OK
Canon	PIXMA Ip8500	USB		P	OK		OK
Canon	PIXMA MG2570	USB		P	OK		OK
Canon	PIXMA MG3170	USB		P	OK		OK
Canon	PIXMA MG3570	USB		P	OK		OK
Canon	PIXMA MG5470	USB		P	OK		OK
Canon	PIXMA MG6170	USB		P	OK		OK
Canon	PIXMA MG6270	USB		P	OK		OK
Canon	PIXMA MG2270	USB		P	OK		OK
Canon	PIXMA MG3270	USB		P	OK		OK
Canon	PIXMA MG4270	USB		P	OK		OK
Canon	PIXMA MG6370	USB		P	OK		OK
Canon	PIXMA MP110	USB		P	OK		OK
Canon	PIXMA MP130			P	OK		OK
Canon	PIXMA MP145			P	OK		OK
Canon	PIXMA MP150	USB	GDI	P	OK		OK

Printer Manufacture	Printer Model	Type of Printer	Language	Function	TL-PS110U 2.0	TL-PS110P	TL-WPS510U
Canon	PIXMA MP180			P	OK		OK
Canon	PIXMA MP258	USB		P	OK		OK
Canon	PIXMA MP450			P	OK		OK
Canon	PIXMA MP730			P	OK		OK
Canon	PIXMA MP780			P	OK		OK
Canon	PIXMA MP830			P	OK		OK
Canon	S-200SPX			P	OK		OK
Canon	S-520	Parallel/USB		P		OK	
Lexmark	C720	Parallel		P		OK	
Lexmark	E230	Parallel/USB		P	OK		OK
Lexmark	E322	USB		P	OK	OK	OK
Lexmark	Optra S1250	Parallel		P		OK	
Lexmark	P4350			P	OK		OK
Lexmark	P6250			P	OK		OK
Lexmark	T420			P	OK	OK	OK
Lexmark	T620			P	OK	OK	OK
Lexmark	W812	Parallel/USB		P	OK	OK	OK
Lexmark	Z42			P	OK		OK
Lexmark	Z43	USB		P	OK	OK	OK
Lexmark	Z45	USB		P	OK		OK
Lexmark	Z55			P	OK	OK	OK
Lexmark	Z515			P	OK	OK	OK
Lexmark	Z615	USB		P	OK		OK
Lexmark	Z705			P	OK	OK	OK
FUJI Xerox	Able 3321	Parallel		P		OK	
FUJI Xerox	DL700	Parallel		P		OK	
FUJI Xerox	DL900	Parallel		P		OK	
FUJI Xerox	DL-3400	Parallel		P		OK	
FUJI Xerox	DL-3800	Parallel		P		OK	
FUJI Xerox	DL-3850	Parallel		P		OK	
FUJI Xerox	DL-5800	Parallel		P		OK	
FUJI Xerox	DL-6400Pro	Parallel		P		OK	
FUJI Xerox	DL-6800	Parallel		P		OK	
FUJI Xerox	DocuP 2050	Parallel/USB	GDI	P	OK	OK	OK
FUJI Xerox	DocuP 240A			P	OK	OK	OK
FUJI Xerox	DocuP C1110B			P	OK		OK
FUJI Xerox	DocuP CM205 f	USB		P	OK		OK
FUJI Xerox	DocuP CP105 b	USB		P	OK		OK
FUJI Xerox	DocuP P205 b	USB		P	OK		OK
FUJI Xerox	DocuP M205 b	USB		P	OK		OK
FUJI Xerox	DocuP M205 f	USB		P	OK		OK
FUJI Xerox	DocuP M205 fw	USB		P	OK		OK
FUJI Xerox	FP 410			P		OK	
FUJI Xerox	Jet Wind 500C	Parallel		P		OK	
FUJI Xerox	Phaser 3310			P	OK	OK	OK
FUJI Xerox	PP 10	Parallel		P		OK	
Konica Minolta	Di 152		PCL5	P		OK	
Konica Minolta	Di 200/Di 250/Di 251		PCL5	P		OK	
Konica Minolta	magicolor 2450	USB	PCL5	P	OK	OK	OK
Konica Minolta	magicolor 5450	Parallel/USB	PCL5	P	OK	OK	OK
Konica Minolta	magicolor 7300			P	OK		OK
Konica Minolta	Magicolor 7300	IEEE1284/USB		P	OK		OK
Konica Minolta	PagePro 1350W			P	OK		OK
Konica Minolta	PagePro 9100	IEEE1284/USB		P	OK		OK
Samsung	CLP-315			P	OK		OK
Samsung	CLP-500		SPL	P	OK	OK	OK
Samsung	CLP-510			P	OK	OK	OK
Samsung	CLP-620ND			P	OK		OK
Samsung	CLX2160	USB		P	OK		OK
Samsung	ML-1510/1710		SPL	P	OK	OK	
Samsung	ML-1520			P	OK		OK
Samsung	ML-1660			P	OK		OK
Samsung	ML-1710			P	OK		OK
Samsung	ML-1750	IEEE1284/USB	PCL6	P	OK	OK	OK
Samsung	ML-1915	USB		P	OK		OK
Samsung	ML-2010	USB	SPL	P	OK		OK
Samsung	ML-2165W			P	OK		OK
Samsung	ML-2250			P	OK	OK	OK
Samsung	ML-2550			P	OK	OK	OK
Samsung	ML-2580N			P	OK		OK
Samsung	ML-3471ND			P	OK	OK	OK
Samsung	SCX-4016			P	OK	OK	OK
Samsung	SCX-4100/4106/4116/	IEEE-1284/USB	SPL	P	OK	OK	OK
Samsung	SRP 270			P		OK	
Panasonic	KX-MB1500TW	USB		P	OK		OK
Panasonic	KX-MB1520TW	USB		P	OK		OK
Panasonic	KX-MB1530TW	USB		P	OK		OK
Panasonic	KX-P1121	Parallel		P		OK	
Panasonic	KX-P1123	Parallel		P		OK	
Panasonic	KX-P1124	Parallel		P		OK	
Panasonic	KX-P1624	Parallel		P		OK	
Panasonic	KX-P6500	Parallel		P		OK	

Printer Manufacture	Printer Model	Type of Printer	Language	Function	TL-PS110U 2.0	TL-PS110P	TL-WPS510U
TOSHIBA	Estudio-25	Parallel		P		OK	
TOSHIBA	E-161	Parallel	GDI	P		OK	
NEC	NEC P2200	Parallel		P		OK	
NEC	NEC P3200	Parallel		P		OK	
NEC	NEC P5300	Parallel		P		OK	
NEC	NEC P8000	Parallel		P		OK	
IBM	IBM InforP 20	IEEE1284/Parallel		P		OK	
IBM	InfoP 1116			P	OK	OK	OK
IBM	InfoP 1312			P	OK	OK	OK
IBM	InfoP 1316			P	OK	OK	OK
IBM	InfoP 1332			P	OK	OK	OK
IBM	InfoP 1412			P	OK	OK	OK
Star	NX-2420	Parallel		P		OK	
Sharp	AR-255			P		OK(Parallel only)	
Sharp	AR-265FG			P		OK(Parallel only)	
Sharp	AR-M160(AR-NB2)	IEEE1284/USB		P		OK(Parallel only)	
Sharp	AR-M205	IEEE/1284USB		P		OK(Parallel only)	
Sharp	AR-M207			P		OK(Parallel only)	
Sharp	AR-M209	IEEE/1284USB		P		OK(Parallel only)	
Sharp	AR-M235			P		OK(Parallel only)	
Sharp	AR-M236	IEEE/1284USB		P		OK(Parallel only)	
Sharp	AR-M275			P		OK(Parallel only)	
Sharp	AR-M276	IEEE/1284USB		P		OK(Parallel only)	
Sharp	AR-M350			P		OK(Parallel only)	
Sharp	AR-M400			P		OK(Parallel only)	
Sharp	AR-M450			P		OK(Parallel only)	
RICOH	NF3570			P		OK	
Brother	MFC 4800			P	OK	OK	OK
Brother	MFC 4800J			P	OK	OK	OK
Brother	MFC 6800			P	OK	OK	OK
Brother	MFC 7220	Parallel/USB	GDI	P	OK	OK	OK
Brother	MFC 7420	Parallel/USB	GDI	P	OK	OK	OK
Brother	MFC 7820N			P	OK	OK	OK
Brother	MFC 8840D			P	OK	OK	OK
Brother	MFC 210C			P	OK		OK
Brother	MFC 240C			P	OK		OK
Brother	MFC-J430W			P	OK		OK
Brother	MFC-J825DW			P	OK		OK
Brother	DCP-7030	USB		P	OK		OK
Brother	HL1260			P		OK	
Brother	HL-2040	Parallel/USB	PCL6	P			
Brother	HL-2140			P	OK		OK
Brother	HL-2170W	USB		P	OK		OK
Brother	IntelliFax 2820			P	OK		OK
Others	AURORA AD-166 MFF	USB	GDI	P			
Others	AURORA AD-216 MFF	USB	GDI	P			
Others	AURORA AD-226 MFF	USB	GDI	P			
Others	DELL 1100	Parallel/USB	GDI	P			
Others	Zonerich AB-80K mini Per			P			
Others	OKI 5530	Parallel		P			
Others	OKI Microline 391			P		OK	
Others	OKI B4350			P	OK	OK	OK
Others	GSAN 5890 thermal P	Parallel		P			
Others	MITAC MP-6600C			P		OK	
Others	BENQ CM3000			P	OK		OK
Avision	MF 3200			P	OK		OK
Avision	MF 3230			P	OK		OK
Citizen	GSX230			P		OK	
DATAMAX	I-4208			P		OK	
DATAMAX	I-4308			P		OK	
DOCUJET	1610F			P	OK	OK	OK
DOCUJET	UA1610			P	OK	OK	OK
FUTEK	F8000			P		OK	
FUTEK	F84+			P		OK	
FUTEK	F86+			P		OK	
Kyocera	FS-1010			P	OK	OK	OK
	FS-1010KX			P	OK		OK
	FS-1020			P	OK	OK	OK
	FS-1920			P	OK	OK	OK
	FS-2000D			P	OK	OK	OK
	FS-820			P	OK	OK	OK
	FS-920			P	OK	OK	OK
FS-6020			P	OK	OK	OK	
FS-6026			P	OK	OK	OK	