



Quick Installation Guide


150Mbps Wireless N USB Adapter

MODEL NO. TL-WN727N






You may see the **Found New Hardware Wizard** (Found New Hardware), when the adapter is plugged. Please click **Cancel**.



Software Installation (The installtion procedures in Windows 8/7/Vista/XP are similar. Here takes the procedures in Windows 7 for example.)


Insert the TP-LINK resource CD into the CD-ROM drive.




Find the model TL-WN727N and select **Install Driver&Utility**.




The **InstallShield Wizard** window will appear. Click **Next** to continue.




Select Install TP-LINK Wireless Configuration Utility and Driver and then click Next.



5 Click **Change** to specify the destination location or you can leave it default. Click **Next** to continue.




6 Click **Install** to install the driver and utility for your adapter.



The installation of the driver and utility may take 1~2 minutes.



The following screen will then appear. Click **Finish** to complete the setup.




3 Connect to Network (You can skip to Appendix: Connect to Wireless Router by WPS to quickly connect to a network if your Router or Access Point features WPS/QSS function.)

After installation, the configuration page will pop up on your desktop.



The icon ኛ will appear on your desktop. Double-clicking on the icon can start the utility.

Click **Network** in the tools section to display a list of available wireless networks. Highlight the target network name (e.g. TP-LINK Network1) and then click Connect to build a connection.



Here we only choose a wireless network with the security type of WPA/WPA2-Personal as an example to elaborate the following steps.


If you want to know more about the connection to a wireless network with the security type of WPA/WPA2-**Enterprise**, please refer to the User Guide on the resource CD included.

If the network is unsecured, you will directly connect to it. If it is security-enbaled, you can input the security key into the tield beside Security Key and then click OK to continue.



Without entering a key, you can press the WPS button on your router if the prompt You can also connect by pushing the button on the router appears.

The following screen indicates successful connectivity. Click Close to enjoy the Internet.



To view more information about the network connected, click Status in the tools section.



Appendix: Connect to Wireless Router by WPS


If your wireless Router features the WPS/QSS function, you can also set up a wireless connection in this way.

Push the WPS/RESET button on the back panel of the Router. Here we take Router TL-WR841ND for example.



For detailed instructions of WPS, please refer to the User Guide on the resource CD.

With the adapter plugged into the USB port on your computer, push the WPS button on the adapter.



Wait a while for the connection progress to be completed. The following screen indicates that the connection has been successfully built.Click **OK** to finish the WPS connection.



Technical Support

- For more troubleshooting help, go to www.tp-link.com/en/support/faq
- To download the latest Firmware, Driver, Utility and User Guide, go to http://www.tp-link.com/en/support/download/
- For all other technical support, please contact us by using the following details:

Global Tel: +86 755 2650 4400

E-mail: support@tp-link.com Service time: 24hrs, 7 days a week Singapore Tel: +65 6284 0493

E-mail: support.sg@tp-link.com Service time: 24hrs, 7 days a week

Tel: +44 (0) 845 147 0017 E-mail: support.uk@tp-link.com Service time: 24hrs, 7days a week

Tel: 0800 505 508 E-mail: support.ua@tp-link.com Service time: Monday to Friday 10:00 to 22:00

Toll Free: 0800 608 9799 (Portuguese Service) E-mail: suporte.br@tp-link.com Service time: Monday to Friday, 09:00 to 20:00; Saturday, 09:00 to 15:00

Tel: +39 023 051 9020 E-mail: support.it@tp-link.com Service time: Monday to Friday 09:00 to 13:00; 14:00 to 18:00

Tel: (+62) 021 6386 1936 E-mail: support.id@tp-link.com Service time: Monday to Friday, 09:00

* Except public holidays

Germany / Austria

Tel:+49 1805 875 465 (German Service) E-mail: support.de@tp-link.com Fee: 0.14 EUR/min from the German fixed phone network and up to 0.42 FUR/min from mobile phone. Service Time: Monday to Friday, 09:00 to 12:30 and 13:30 to 17:30, GMT+1 or GMT +2 (Daylight Saving Time in Germany)
* Except bank holidays in Hesse

E-mail: support.au@tp-link.com (AU) support.nz@tp-link.com (NZ) Service time: 24hrs, 7 days a week

Australia / New Zealand Tel: AU 1300 87 5465

NZ 0800 87 5465

Tel: 0850 7244 488 (Turkish Service) E-mail: support.tr@tp-link.com
Service time: 09:00 to 21:00, 7days a week

USA / Canada

Toll Free: +1 866 225 8139 E-mail: support.usa@tp-link.com Service time: 24hrs, 7days a week

Malaysia Tel: 1300 88 875 465

E-mail: support.my@tp-link.com Service time: 24hrs, 7days a week

Tel: +48 (0) 801 080 618 / +48 227 217 563 (if calls from mobile phone)

E-mail: support.pl@tp-link.com Service time: Monday to Friday 09:00 to 17:00 PM. GMT+1 or GMT+2 (Daylight Saving Time)

Tel: +41 (0) 848 800 998 (German Service) E-mail: support.ch@tp-link.com Fee: 4-8 Rp/min, depending on rate of Service time: Monday to Friday, 09:00 to 12:30

and 13:30 to 17:30. GMT+ 1 or GMT+ 2 (Daylight Saving Time)

Tel: +33 (0) 820 800 860 (French service) Email: support.fr @tp-link.com Fee: 0.118 EUR/min from France

Service time: Monday to Friday 09:00 to 18:00 (Except French Bank holidays) Russian Federation

Tel: 8 (499) 754 5560 / 8 (800) 250 5560 (toll-free call from any RF region) E-mail: support.ru@tp-link.com Service time: From 10:00 to 18:00 (Moscow time *Except weekends and holidays in

TP-LINK TECHNOLOGIES CO., LTD.

www.tp-link.com