

Printer Compatibility List for TL-PS110U/TL-PS110P/TL-WPS510U

Update:2011-08-09

Note: "OK" means the print server is compatible with the printer;

" \" means the print server is not compatible with the printer;

"—" means the function is not tested;

The product only support the **printing function** of the Multi Function Printer.

No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U
1	HP	Business InkJet 1000	OK		OK
2	HP	Color Laserjet 1500L	OK		
3	HP	Color Laserjet 1600	OK		OK
4	HP	Color Laserjet 2500	OK	OK	OK
5	HP	Color LaserJet 2550	OK	OK	OK
6	HP	Color LaserJet 2550L/LN	OK		OK
7	HP	Color LaserJet 2600	OK		OK
8	HP	Color LaserJet 2605	OK	OK	OK
9	HP	Color LaserJet 2700n	OK		OK
10	HP	Color LaserJet 2840	OK		OK
11	HP	Color LaserJet 3700	OK	OK	OK
12	HP	Color LaserJet 4000		OK	
13	HP	Color LaserJet 4100		OK	
14	HP	Color LaserJet 4500		OK	
15	HP	Color Laserjet 4650	OK	OK	OK
16	HP	Color LaserJet 8550 Color		OK	
17	HP	Color Laserjet CP1215	OK		OK
18	HP	Color Laserjet CM1312 MFP	OK		OK
19	HP	Color Laserjet CM1015 MFP	OK		OK
20	HP	Designjet 100	OK	OK	OK
21	HP	Designjet 600		OK	
22	HP	Designjet 650C		OK	
23	HP	Designjet 700		OK	
24	HP	Designjet 750C+		OK	
25	HP	DeskJet 1120C		OK	
26	HP	Deskjet 1125C	OK	OK	OK
27	HP	Deskjet 1180C	OK	OK	OK
28	HP	DeskJet 1280	OK	OK	OK
29	HP	Deskjet 2000 J210	OK		OK
30	HP	Deskjet 3000	OK		OK
31	HP	Deskjet 3325	OK		OK
32	HP	DeskJet 3420	OK		OK
33	HP	Deskjet 3535	OK		OK
34	HP	Deskjet 3650	OK		OK
35	HP	Deskjet 3743	OK		OK
36	HP	Deskjet 3748	OK		OK
37	HP	Deskjet 3820	OK	OK	OK
38	HP	DeskJet 3920	OK		OK

39	HP	DeskJet 3940	OK		OK
40	HP	DeskJet 400/420		OK	
41	HP	Deskjet 450C	OK	OK	OK
42	HP	DeskJet 5440	OK		OK
43	HP	DeskJet 5500		OK	
44	HP	Deskjet 5550	OK	OK	OK
45	HP	Deskjet 5652	OK	OK	OK
46	HP	Deskjet 670C		OK	
47	HP	Deskjet 680C		OK	
48	HP	Deskjet 720C		OK	
49	HP	Deskjet 810C	OK	OK	OK
No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U
50	HP	Deskjet 830C	OK	OK	OK
51	HP	Deskjet 845C	OK		OK
52	HP	DeskJet 9300	OK	OK	OK
53	HP	Deskjet 948c	OK	OK	OK
54	HP	Deskjet 9600	OK	OK	OK
55	HP	Deskjet 9650	OK	OK	OK
56	HP	Deskjet 970c XI	OK	OK	OK
57	HP	Deskjet 9800	OK	OK	OK
58	HP	Deskjet D1560	OK		OK
59	HP	Deskjet D2560	OK		OK
60	HP	Deskjet D5560	OK		OK
61	HP	DeskJet F370	OK		OK
62	HP	DeskJet F380	OK		OK
63	HP	DeskJet F4185	OK		OK
64	HP	DeskJet F4280	OK		OK
65	HP	Deskjet F4480	OK		OK
66	HP	Laserjet M1005 MFP	OK		OK
67	HP	LaserJet 1022	OK		OK
68	HP	LaserJet 1022N	OK		OK
69	HP	Laserjet 1100		OK	
70	HP	Laserjet 1010	OK		
71	HP	LaserJet 1160	OK	OK	OK
72	HP	LaserJet 1200	OK	OK	OK
73	HP	LaserJet 1220	OK	OK	OK
74	HP	Laserjet 1300	OK	OK	OK
75	HP	Laserjet 1320	OK	OK	OK
76	HP	Laserjet M1522n MFP	OK		OK
77	HP	LaserJet 2100		OK	
78	HP	Laserjet 2200d	OK	OK	OK
79	HP	Laserjet 2300	OK	OK	OK
80	HP	LaserJet 2410	OK	OK	OK
81	HP	LaserJet 2420	OK	OK	OK
82	HP	LaserJet 2550	OK	OK	OK

83	HP	LaserJet 3015	OK	OK	OK
84	HP	LaserJet 3050	OK		OK
85	HP	LaserJet 3055	OK		OK
86	HP	Laserjet 3200	OK	OK	OK
87	HP	Laserjet 3330	OK	OK	OK
88	HP	LaserJet 3330mfp	OK	OK	OK
89	HP	LaserJet 3380	OK		OK
90	HP	Laserjet 4000		OK	
91	HP	LaserJet 4050		OK	
92	HP	Laserjet 4100 /4100n		OK	
93	HP	LaserJet 4250	OK	OK	OK
94	HP	Laserjet 4300n		OK	
95	HP	Laserjet 4300tn/dtn		OK	
96	HP	Laserjet 4500		OK	
97	HP	Laserjet 4650	OK	OK	OK
98	HP	Laserjet 5100fn/tn		OK	
No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U
99	HP	Laserjet 5100le/se		OK	
100	HP	Laserjet 6P / 6L		OK	
101	HP	Laserjet 8100		OK	
102	HP	Laserjet M1005	OK		OK
103	HP	Laserjet M1005 MFP	OK		OK
104	HP	Laserjet M1120 MFP	OK		OK
105	HP	LaserJet M1319F MFP	OK		OK
106	HP	LaserJet P2015	OK		OK
107	HP	Officejet J3608	OK		OK
108	HP	OfficeJet 4255	OK		OK
109	HP	OfficeJet 4255	OK		OK
110	HP	Officejet 4500	OK		OK
111	HP	OfficeJet 5610	OK		OK
112	HP	Officejet J5780	OK		OK
113	HP	OfficeJet 6210	OK		OK
114	HP	OfficeJet 6310	OK		OK
115	HP	Officejet 6000	OK		OK
116	HP	Officejet 6500	OK		OK
117	HP	Officejet 7000			OK
118	HP	OfficeJet 7210	OK		OK
119	HP	OfficeJet J4580	OK		OK
120	HP	Officejet J4660	OK		OK
121	HP	Officejet J6480	OK		OK
122	HP	Officejet K7100	OK		OK
123	HP	OfficeJet K850	OK	OK	OK
124	HP	OfficeJet Pro K5300	OK		OK
125	HP	OfficeJet Pro K550	OK		OK
126	HP	OfficeJet Pro K8600	OK		OK

127	HP	Officejet Pro L7380	OK		OK
128	HP	Officejet Pro L7590	OK		OK
129	HP	Officejet Pro 7000	OK		OK
130	HP	Officejet Pro 8000	OK		OK
131	HP	Officejet Pro 8500W	OK		OK
132	HP	Photosmart 2610	OK		OK
133	HP	Photosmart 3110	OK		OK
134	HP	Photosmart 7150	OK		OK
135	HP	Photosmart 7200	OK		OK
136	HP	Photosmart 7550	OK		OK
137	HP	Photosmart 7660	OK		OK
138	HP	Photosmart 7830	OK		OK
139	HP	Photosmart 7900	OK		OK
140	HP	Photosmart 8200	OK		OK
141	HP	Photosmart Plus B209a	OK		OK
142	HP	Photosmart Plus B210a	OK		OK
143	HP	Photosmart Plus C310a	OK		OK
144	HP	Photosmart A520	OK		OK
145	HP	Photosmart B109a	OK		OK
146	HP	Photosmart B110a AIO	OK		OK
147	HP	Photosmart C309a	OK		OK
No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U
148	HP	Photosmart C3180	OK		OK
149	HP	Photosmart C4180	OK		OK
150	HP	Photosmart C4280	OK		OK
151	HP	Photosmart C4385	OK		OK
152	HP	Photosmart C4480	OK		OK
153	HP	Photosmart C4580	OK		OK
154	HP	Photosmart C5180	OK		OK
155	HP	Photosmart C5280	OK		OK
156	HP	Photosmart C5380	OK		OK
157	HP	Photosmart C6180	OK		OK
158	HP	Photosmart C6280	OK		OK
159	HP	Photosmart C6380	OK		OK
160	HP	Photosmart C7180	OK		OK
161	HP	Photosmart C7280	OK		OK
162	HP	Photosmart C8180	OK		OK
163	HP	Photosmart D5160	OK		OK
164	HP	Photosmart D5360	OK		OK
165	HP	Photosmart D5460	OK		OK
166	HP	Photosmart D7160	OK		OK
167	HP	Photosmart D7260	OK		OK
168	HP	Photosmart D7360	OK		OK
169	HP	Photosmart Premium C309g	OK		OK
170	HP	Photosmart Premium C310g	OK		OK

171	HP	PSC 1210			OK
172	HP	PSC 1315	OK		OK
173	HP	PSC 1350	OK		OK
174	HP	PSC 1410	OK		OK
175	HP	PSC 1610	OK		OK
176	HP	PSC 2210	OK		OK
177	HP	PSC 2310	OK		OK
178	EPSON	Aculaser C1100SE	OK	OK	OK
179	EPSON	AcuLaser C1900	OK	OK	OK
180	EPSON	AcuLaser C3800	OK		OK
181	EPSON	AcuLaser C9100	OK		OK
182	EPSON	Aculaser M2010DN	OK		OK
183	EPSON	Aculaser M2010D	OK	OK	OK
184	EPSON	Aculaser M2310D	OK	OK	OK
185	EPSON	Aculaser M2310DN	OK		OK
186	EPSON	Aculaser M2410D	OK	OK	OK
187	EPSON	Aculaser M2410DN	OK		OK
188	EPSON	B-508DN	OK		OK
189	EPSON	C750	OK	OK	OK
190	EPSON	CC-500L	OK		OK
191	EPSON	CL-760	OK		OK
192	EPSON	E-300L	OK		OK
193	EPSON	E-520	OK		OK
194	EPSON	E-720	OK		OK
195	EPSON	EC-01	OK		OK
196	EPSON	EPL 5700		OK	
No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U
197	EPSON	EPL 5700		OK	
198	EPSON	EPL 5800	OK	OK	OK
199	EPSON	EPL 5800	OK	OK	OK
200	EPSON	EPL 5900	OK	OK	OK
201	EPSON	EPL 5900	OK	OK	OK
202	EPSON	EPL 6100	OK	OK	OK
203	EPSON	EPL 6200	OK	OK	OK
204	EPSON	Aculaser C1600	OK		OK
205	EPSON	AL-C1700	OK		OK
206	EPSON	AL-M1400	OK		OK
207	EPSON	AL-MX14	OK		OK
208	EPSON	B-518DN	OK		OK
209	EPSON	EPL 6200	OK	OK	OK
210	EPSON	EPL N2120		OK	
211	EPSON	K100	OK		OK
212	EPSON	L200	OK		OK
213	EPSON	L800	OK		OK
214	EPSON	LP2500	OK		OK

215	EPSON	LP-7700	OK		OK
216	EPSON	LP-8700	OK		OK
217	EPSON	LP-8800C	OK		OK
218	EPSON	LP8900	OK		OK
219	EPSON	LP-9500C	OK		OK
220	EPSON	LQ 100		OK	
221	EPSON	LQ 1000C		OK	
222	EPSON	LQ 1170+		OK	
223	EPSON	LQ 1170C		OK	
224	EPSON	LQ 1170C+		OK	
225	EPSON	LQ 2070C		OK	
226	EPSON	LQ 2080C		OK	
227	EPSON	LQ 2090		OK	
228	EPSON	LQ 2090C	OK	OK	OK
229	EPSON	LQ 2170C		OK	
230	EPSON	LQ 2180C		OK	
231	EPSON	LQ 2550		OK	
232	EPSON	LQ 300		OK	
233	EPSON	LQ 300+		OK	
234	EPSON	LQ 300+II	OK	OK	OK
235	EPSON	LQ 3500C		OK	
236	EPSON	LQ 570C		OK	
237	EPSON	LQ 670		OK	
238	EPSON	LQ 680		OK	
239	EPSON	LQ 680C		OK	
240	EPSON	ME 320	OK		OK
241	EPSON	ME 340	OK		OK
242	EPSON	ME Office 900WD	OK		OK
243	EPSON	ME Office 960FWD	OK		OK
244	EPSON	MC-2000	OK		OK
245	EPSON	PictureMate PM250	OK		OK
No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U
246	EPSON	PLQ-20C	OK		OK
247	EPSON	PLQ-20CM	OK		OK
248	EPSON	PM-860PT	OK		OK
249	EPSON	PM-890C	OK		OK
250	EPSON	PM-920C	OK		OK
251	EPSON	PM-930C	OK		OK
252	EPSON	PM-950C	OK		OK
253	EPSON	PM-970C	OK		OK
254	EPSON	PM-980C	OK		OK
255	EPSON	PM-A550	OK		OK
256	EPSON	PM-A620	OK		OK
257	EPSON	PM-A650	OK		OK
258	EPSON	PM-A720	OK		OK

259	EPSON	PM-A820	OK		OK
260	EPSON	PM-A840	OK		OK
261	EPSON	PM-A850	OK		OK
262	EPSON	PM-A890	OK		OK
263	EPSON	PM-A900	OK		OK
264	EPSON	PM-A920	OK		OK
265	EPSON	PM-A940	OK		OK
266	EPSON	PM-A950	OK		OK
267	EPSON	PM-A970	OK		OK
268	EPSON	PM-2200C	OK		OK
269	EPSON	PM-3500C	OK		OK
270	EPSON	PM-3700C	OK		OK
271	EPSON	PM-4000PX	OK		OK
272	EPSON	PM-D800	OK		OK
273	EPSON	PM-D870	OK		OK
274	EPSON	PM-D1000	OK		OK
275	EPSON	PM-FA700	OK		OK
276	EPSON	PM-G800	OK		OK
277	EPSON	PM-G820	OK		OK
278	EPSON	PM-G850	OK		OK
279	EPSON	PM-G860	OK		OK
280	EPSON	PM-G4500	OK		OK
281	EPSON	PM-T960	OK		OK
282	EPSON	PM-T990	OK		OK
283	EPSON	PX-5000	OK		OK
284	EPSON	PX-A640	OK		OK
285	EPSON	PX-A740	OK		OK
286	EPSON	PX-G5300	OK		OK
287	EPSON	PX-G5100	OK		OK
288	EPSON	PX-G930	OK		OK
289	EPSON	PX-G5000	OK		OK
290	EPSON	PX-V780	OK		OK
291	EPSON	RX 510	OK		OK
292	EPSON	RX 530	OK		OK
293	EPSON	RX 590	OK		OK
294	EPSON	RX 630	OK		OK
No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U
295	EPSON	RX 690	OK		OK
296	EPSON	Stylus C20	OK		OK
297	EPSON	Stylus C40	OK		OK
298	EPSON	Stylus C41UX/SX	OK		OK
299	EPSON	Stylus C43UX	OK		OK
300	EPSON	Stylus C45	OK		OK
301	EPSON	Stylus C59	OK		OK
302	EPSON	Stylus C60	OK	OK	OK

303	EPSON	Stylus C63	OK	OK	OK
304	EPSON	Stylus C67	OK	OK	OK
305	EPSON	Stylus C79	OK		OK
306	EPSON	Stylus C83		OK	
307	EPSON	Stylus C90	OK		OK
308	EPSON	Stylus Color 1160	OK		OK
309	EPSON	Stylus Color 1500	OK		OK
310	EPSON	Stylus Color 1520	OK		OK
311	EPSON	Stylus Color 400		OK	
312	EPSON	Stylus Color 600		OK	
313	EPSON	Stylus Color 670	OK	OK	OK
314	EPSON	Stylus Color 800	OK	OK	OK
315	EPSON	Stylus Color 810	OK	OK	OK
316	EPSON	Stylus Color 850	OK	OK	OK
317	EPSON	Stylus Color 900	OK		OK
318	EPSON	Stylus CX-1500	OK		OK
319	EPSON	Stylus CX-2900	OK		OK
320	EPSON	Stylus CX-3500	OK		OK
321	EPSON	Stylus CX-3700	OK		OK
322	EPSON	Stylus CX-3900	OK		OK
323	EPSON	Stylus CX-4100	OK		OK
324	EPSON	Stylus CX-4700	OK		OK
325	EPSON	Stylus CX-4900	OK		OK
326	EPSON	Stylus CX-5300	OK		OK
327	EPSON	Stylus CX-5500	OK		OK
328	EPSON	Stylus CX-5505	OK		OK
329	EPSON	Stylus CX-5900	OK		OK
330	EPSON	Stylus CX-6900F	OK		OK
331	EPSON	Stylus CX-7300	OK		OK
332	EPSON	Stylus CX-7800	OK		OK
333	EPSON	Stylus CX-8300	OK		OK
334	EPSON	Stylus CX-9300F	OK		OK
335	EPSON	Stylus Office T30	OK		OK
336	EPSON	Stylus Office T40W	OK		OK
337	EPSON	Stylus Office TX300F	OK		OK
338	EPSON	Stylus Office TX510FN	OK		OK
339	EPSON	Stylus Office TX600FW	OK		OK
340	EPSON	Stylus Office TX610FW	OK		OK
341	EPSON	Stylus Office T1100	OK		OK
342	EPSON	Stylus Photo 915	OK		OK
343	EPSON	Stylus Photo 1270	OK	OK	OK
No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U
344	EPSON	Stylus Photo 1290	OK		OK
345	EPSON	Stylus Photo 1390	OK		OK
346	EPSON	Stylus Photo 2100	OK		OK

347	EPSON	Stylus Photo 710	OK		OK
348	EPSON	Stylus Photo 720	OK		OK
349	EPSON	Stylus Photo 790	OK		OK
350	EPSON	Stylus Photo 810	OK	OK	OK
351	EPSON	Stylus Photo 830U	OK		OK
352	EPSON	Stylus Photo 900	OK	OK	OK
353	EPSON	Stylus Photo 915	OK		OK
354	EPSON	Stylus Photo EX2	OK	OK	OK
355	EPSON	Stylus Photo EX3	OK	OK	OK
356	EPSON	Stylus Photo R1800	OK	OK	OK
357	EPSON	Stylus Photo R210	OK		OK
358	EPSON	Stylus Photo R230	OK		OK
359	EPSON	Stylus Photo R250	OK		OK
360	EPSON	Stylus Photo R270	OK		OK
361	EPSON	Stylus Photo R310	OK		OK
362	EPSON	Stylus Photo R350	OK		OK
363	EPSON	Stylus Photo R2400	OK		OK
364	EPSON	Stylus Photo R800	OK		OK
365	EPSON	Stylus Photo RX430	OK		OK
366	EPSON	Stylus Photo RX 510	OK		OK
367	EPSON	Stylus Photo RX 530	OK		OK
368	EPSON	Stylus Photo RX 590	OK		OK
369	EPSON	Stylus Photo RX 630	OK		OK
370	EPSON	Stylus Photo RX 650	OK		OK
371	EPSON	Stylus Photo RX 690	OK		OK
372	EPSON	Stylus Photo R2880	OK		OK
373	EPSON	Stylus Photo TX700W	OK		OK
374	EPSON	Stylus Photo TX800FW	OK		OK
375	EPSON	Stylus Photo TX820FWD	OK		OK
376	EPSON	Stylus Pro 7600	OK	OK	OK
377	EPSON	Stylus TX550W	OK		OK
378	EPSON	Stylus TX420W	OK		OK
379	EPSON	Stylus TX410	OK		OK
380	EPSON	Stylus TX220	OK		OK
381	EPSON	Stylus TX200	OK		OK
382	EPSON	Stylus TX210	OK		OK
383	EPSON	Stylus TX100	OK		OK
384	EPSON	Stylus TX110	OK		OK
385	EPSON	Stylus T22	OK		OK
386	EPSON	Stylus T20	OK		OK
387	EPSON	Stylus T21	OK		OK
388	EPSON	Stylus Photo T50	OK		OK
389	EPSON	TM883 (III)		OK	
390	EPSON	TM T88III		OK	
391	EPSON	TX130	OK		OK

392	EPSON	TX235	OK		OK
393	EPSON	TX430	OK		OK
No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U
394	Canon	BJ-330		OK	
395	Canon	BJC-4200		OK	
396	Canon	BJC-4300		OK	
397	Canon	BJC-4500			
398	Canon	BJC-4550		OK	
399	Canon	BJC-4600		OK	
400	Canon	BJF9000	OK		OK
401	Canon	D380	OK		OK
402	Canon	I-255	OK		OK
403	Canon	I-355	OK		OK
404	Canon	I-450	OK		OK
405	Canon	I-455	OK		OK
406	Canon	I-470D	OK		OK
407	Canon	I-475D	OK		OK
408	Canon	I-550	OK		OK
409	Canon	I-560	OK		OK
410	Canon	I-850	OK		OK
411	Canon	I-865	OK		OK
412	Canon	I-950	OK		OK
413	Canon	I-6100	OK	OK	OK
414	Canon	I-6500	OK	OK	OK
415	Canon	I-9100	OK		OK
416	Canon	I-9950	OK		OK
417	Canon	IX4000	OK		OK
418	Canon	IX5000	OK		OK
419	Canon	Imageclass D380	OK		OK
420	Canon	MP-160	OK		OK
421	Canon	MP-638	OK		OK
422	Canon	MP 770	OK		OK
423	Canon	MX318	OK		OK
424	Canon	MX320	OK		OK
425	Canon	MX700	OK		OK
426	Canon	PIXUS IP2500	OK		OK
427	Canon	PIXUS 990i	OK		OK
428	Canon	PIXMA iP1000	OK		OK
429	Canon	PIXMA iP1700	OK		OK
430	Canon	PIXMA iP1800	OK		OK
431	Canon	PIXMA Ip1880	OK		OK
432	Canon	PIXMA Ip1980	OK		OK
433	Canon	PIXMA Ip2000	OK		OK
434	Canon	PIXMA iP3000	OK		OK
435	Canon	PIXMA Ip3300	OK		OK

436	Canon	PIXMA Ip3500	OK		OK
437	Canon	PIXMA Ip3680	OK		OK
438	Canon	PIXMA iP4000	OK	OK	OK
439	Canon	PIXMA Ip4200	OK		OK
440	Canon	PIXMA Ip4300	OK		OK
441	Canon	PIXMA Ip4500	OK		OK
No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U
442	Canon	PIXMA Ip4760	OK		OK
443	Canon	PIXMA Ip5000	OK		OK
444	Canon	PIXMA Ip6000	OK		OK
445	Canon	PIXMA Ip8500	OK		OK
446	Canon	PIXMA MP110	OK		OK
447	Canon	PIXMA MP130	OK		OK
448	Canon	PIXMA MP145	OK		OK
449	Canon	PIXMA MP150	OK		OK
450	Canon	PIXMA MP180	OK		OK
451	Canon	PIXMA MP258	OK		OK
452	Canon	PIXMA MP450	OK		OK
453	Canon	PIXMA MP730	OK		OK
454	Canon	PIXMA MP780	OK		OK
455	Canon	PIXMA MP830	OK		OK
456	Canon	PIXMA MP960	OK		
457	Canon	PIXMA MX357	OK		OK
458	Canon	S-200SPX	OK		OK
459	Canon	S-520		OK	
460	Lexmark	C720		OK	
461	Lexmark	E230	OK		OK
462	Lexmark	E322	OK	OK	OK
463	Lexmark	Optra S1250		OK	
464	Lexmark	P4350	OK		OK
465	Lexmark	P6250	OK		OK
466	Lexmark	T420	OK	OK	OK
467	Lexmark	T620	OK	OK	OK
468	Lexmark	W812	OK	OK	OK
469	Lexmark	Z42	OK		OK
470	Lexmark	Z43	OK	OK	OK
471	Lexmark	Z45	OK		OK
472	Lexmark	Z55	OK	OK	OK
473	Lexmark	Z515	OK	OK	OK
474	Lexmark	Z615	OK		OK
475	Lexmark	Z705	OK	OK	OK
476	FUJI Xerox	Able 3321		OK	
477	FUJI Xerox	DL700		OK	
478	FUJI Xerox	DL900		OK	
479	FUJI Xerox	DL-3400		OK	

480	FUJI Xerox	DL-3800		OK	
481	FUJI Xerox	DL-3850		OK	
482	FUJI Xerox	DL-5800		OK	
483	FUJI Xerox	DL-6400Pro		OK	
484	FUJI Xerox	DL-6800		OK	
485	FUJI Xerox	DocuPrint 2050	OK	OK	OK
486	FUJI Xerox	DocuPrint 240A	OK	OK	OK
487	FUJI Xerox	Docuprint C1110B	OK		OK
488	FUJI Xerox	FP 410		OK	
489	FUJI Xerox	Jet Wind 500C		OK	
490	FUJI Xerox	Phaser 3310	OK	OK	OK
491	FUJI Xerox	PP 10		OK	
No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U
492	Konica Minolta	Di 152		OK	
493	Konica Minolta	Di 200/Di 250/Di 251		OK	
494	Konica Minolta	magicolor 2450	OK	OK	OK
495	Konica Minolta	magicolor 5450	OK	OK	OK
496	Konica Minolta	magicolor 7300	OK		OK
497	Konica Minolta	Magicolor 7300	OK		OK
498	Konica Minolta	PagePro 1350W	OK		OK
499	Konica Minolta	PagePro 9100	OK		OK
500	Samsung	CLP-315	OK		OK
501	Samsung	CLP-500	OK	OK	OK
502	Samsung	CLP-510	OK	OK	OK
503	Samsung	CLP-620ND	OK		OK
504	Samsung	CLX2160	OK		OK
505	Samsung	ML-1510/1710	OK	OK	OK
506	Samsung	ML-1520	OK		OK
507	Samsung	ML-1660	OK		OK
508	Samsung	ML-1710	OK		OK
509	Samsung	ML-1750	OK	OK	OK
510	Samsung	ML-1915	OK		OK
511	Samsung	ML-2010	OK		OK
512	Samsung	ML-2250	OK	OK	OK
513	Samsung	ML-2550	OK	OK	OK
514	Samsung	ML-2580N	OK		OK
515	Samsung	ML-3471ND	OK	OK	OK
516	Samsung	SCX-4016	OK	OK	OK
517	Samsung	SCX-4100/4106/4116/4216F	OK	OK	OK

518	Samsung	SCX-421			OK
519	Samsung	SRP 270		OK	
520	Panasonic	KX-P1121		OK	
521	Panasonic	KX-P1123		OK	
522	Panasonic	KX-P1124		OK	
523	Panasonic	KX-P1624		OK	
524	Panasonic	KX-P6500		OK	
525	TOSHIBA	E-161	OK(Parallel only)	OK	OK
526	TOSHIBA	Estudio-25		OK	
527	NEC	NEC P2200		OK	
528	NEC	NEC P3200		OK	
529	NEC	NEC P5300		OK	
530	NEC	NEC P8000		OK	
531	IBM	IBM Inforprint 20		OK	
532	IBM	Infoprint 1116	OK	OK	OK
533	IBM	Infoprint 1312	OK	OK	OK
534	IBM	Infoprint 1316	OK	OK	OK
535	IBM	Infoprint 1332	OK	OK	OK
536	IBM	Infoprint 1412	OK	OK	OK
537	Star	NX-2420		OK	
538	Sharp	AR-255		OK(Parallel only)	
539	Sharp	AR-265FG		OK(Parallel only)	
No.	Manufacture	Model	TL-PS110U	TL-PS110P	TL-WPS510U
540	Sharp	AR-M160(AR-NB2)		OK(Parallel only)	
541	Sharp	AR-M205		OK(Parallel only)	
542	Sharp	AR-M207		OK(Parallel only)	
543	Sharp	AR-M209			
544	Sharp	AR-M235		OK(Parallel only)	
545	Sharp	AR-M236			
546	Sharp	AR-M275		OK(Parallel only)	
547	Sharp	AR-M276			
548	Sharp	AR-M350		OK(Parallel only)	
549	Sharp	AR-M400		OK(Parallel only)	
550	Sharp	AR-M450		OK(Parallel only)	
551	Sharp	MX-M260			OK
552	RICOH	NF3570		OK	
553	Brother	MFC 4800	OK	OK	OK
554	Brother	MFC 4800J	OK	OK	OK
555	Brother	MFC 6800	OK	OK	OK
556	Brother	MFC 7220	OK	OK	OK
557	Brother	MFC 7420	OK	OK	OK
558	Brother	MFC 7820N	OK	OK	OK
559	Brother	MFC 8840D	OK	OK	OK
560	Brother	MFC 210C	OK		OK
561	Brother	MFC 240C	OK		OK

562	Brother	HL1260		OK	
563	Brother	HL-2040			
564	Brother	HL-2140	OK		OK
565	Brother	HL-2170W	OK		OK
566	Brother	IntelliFax 2820	OK		OK
567	Zhendan	AD-166			
568	Zhendan	AD-216			
569	Zhendan	AD-226			
570	DELL	DELL 1100			
571	Zonerich	AB-80K			
572	OKI	OKI 5530			
573	OKI	OKI Microline 391		OK	
574	OKI	OKI B4350	OK	OK	OK
575	Jicheng	Jicheng 5890			
576	MITAC	MITAC		OK	
577	BENQ	BENQ CM3000	OK		OK
578	Avision	MF 3200	OK		OK
579	Avision	MF 3230	OK		OK
580	Citizen	GSX230		OK	
581	DATAMAX	I-4208		OK	
582	DATAMAX	I-4308		OK	
583	DOCUJET	1610F	OK	OK	OK
584	DOCUJET	UA1610	OK	OK	OK
585	FUTEK	F8000		OK	
586	FUTEK	F84+		OK	
587	FUTEK	F86+		OK	
588	Kyocera	FS-1010	OK	OK	OK
589	Kyocera	FS-1010KX	OK		OK
590	Kyocera	FS-1020	OK	OK	OK
591	Kyocera	FS-1920	OK	OK	OK
592	Kyocera	FS-2000D	OK	OK	OK
593	Kyocera	FS-820	OK	OK	OK
594	Kyocera	FS-920	OK	OK	OK
595	Kyocera	FS-6020	OK	OK	OK
596	Kyocera	FS-6026	OK	OK	OK