How to update the firmware of TP-LINK Powerline Adapters using the tpPLC Utility?

TP-LINK is dedicated to improving and richening the product features, giving you a better network experience. We will release the latest firmware at TP-LINK official website (http://www.tp-link.com). You can download and upgrade the latest firmware for your device.

To update the firmware, follow the steps below:

Step 1
Decompress the package to obtain the update file(s).
For a powerline adapter, you may obtain a combination of **NVM** and **PIB files**, or simply a **GGL file**, depending on the product model.

Note: The upgraded firmware version must correspond to the hardware.

Step 2

Open the **tpPLC utility**, move your mouse over a device, and click the ⚙ **(Advanced)** icon.
For your reference: How to prepare for using the tpPLC Utility on Windows?

Step 3
Go to the **Update** page. You may see either of the following pages, depending on the product model.

Step 4
Select the obtained update file(s), and click **Update**.

Step 5
Wait for the upgrading to complete.
Note: During the upgrading process, do not turn off or reset the powerline device.

Get to know more details of each function and configuration please go to Download Center to download the manual of your product.