


## Charge the Battery


Method 1: Battery



- Charging: Solid amber
- Fully charged: Solid green

## Method 2: Battery Inside Camera

\*Check the battery status in the Tapo app after setup.



#### Note:

1. Charge the battery before use. It will take about 5~6 hours. 2. If you want to use the camera while charging the battery, we recommend purchasing another battery for your convenience. 1. Twist anti-clockwise and then pull to remove the cover of the camera. Insert the battery.


Battery

Insert the



7

2. Align the indicator line on the cover with the arrow icon on the camera body. Press and rotate clockwise to the lock position to replace the cover.



Closed



1. Get the **Tapo** app from the App Store or Google Play.

Set Up Hub


and Camera



2. Follow the instructions in the Tapo app to set up vour hub.



3. Follow the instructions in the Tapo app to set up your camera.







©2022 TP-Link 7106509614 REV1.0.0 \*Images may differ from your actual product.


**Quick Start Guide** 

Smart Wire-Free Security


Camera System

## Installation Options

## Option 1. Set on a Table




## **Option 2. Mount to the Wall**



## Mount 05 to the Wall


## 1. Drill Holes

Stick the mounting template to the desired mounting place. Drill 3 holes according to the template.




## 2. Install the Bracket

Insert three anchors into the holes and use the screws to affix the bracket over the anchors.




## 3. Install the Camera

Install the camera on the mounting bracket, and adjust the camera angle.



## Camera Appearance




4 Status LED

5 Microphone

6 Lens

Indicate the status of your camera.



#### 1 Spotlights

## 2 Light Sensor

3 Motion Sensor

## SYNC/RESET Button

While the camera is powered on: Press for 1 second: Pair with the hub Press and hold for about 5 seconds: Reset the camera

## Hub Appearance



## 1 SYNC Button

Press to pair with the camera, or silence the hub when it rings.

## 2 RESET

Use a pin to press and hold for about 5 seconds until the hub LED guickly blinks red to reset the hub.

### 3 microSD Card Slot

Insert a microSD card to record camera videos locally. Initialize the microSD card within the Tapo app first. \*microSD card not included.

## 4 Status LED

Indicate the status of your hub.

## Light Indications

## Hub Status LED

Solid red	Starting up
Blinking red and green	Ready for setup
Solid amber	Connected to router
Solid green	Connected to the cloud
Blinking green slowly	Pairing
Blinking red quickly	Hub resetting
Blinking green quickly	Hub updating

## Camera Status LED

Solid Red	Starting up
Blinking red and green	Ready for pairing
Blinking green slowly	Pairing
Solid amber	Connected to the hub
Solid green	Connected to the cloud
Blinking red quickly	Camera resetting
Blinking green quickly	Camera updating
nking red once a minute	Low battery
Blinking red slowly	Offline

#### Safety Information

electric shock.

electrician.

external RF energy.

Risk of fire or explosion if the battery is replaced by an incorrect type

- Do not use damaged charger or USB cable to charge the device. Do not use any other chargers than those recommended.
- Do not use the device where wireless devices are not allowed. Adapter shall be easily accessible.
- Use only power supplies which are provided by manufacturer and in the original packing of this product. If you have any questions, please don't hesitate to contact us.
- Keep the device away from fire or hot environments. DO NOT immerse in water or any other liquid.
- Do not disassemble, repair or modify the product.
- Do not use the product if the casing has been broken. Danger of
- Never touch the product with wet hands.
- Do not place near automatically controlled devices such as fire alarms. Radio waves emitted from this product may cause such devices to malfunction resulting in an accident.
- Observe restrictions on using wireless products in fuel depots, chemical plants or when blasting operations are in progress. • Do not use liquid to clean the product. Only use a dry cloth. Never put metal objects inside the product. If a metal object enters the product turn off the circuit breaker and contact an authorised
- This product is not intended to be used when providing medical care. Consult the manufacturer of any personal medical devices, such as pacemakers or hearing aids to determine if they are adequality shielded from external RF (radio frequency) energy.
- Do not use this product in health care facilities. Hospitals or health care facilities may be using equipment that could be sensitive to
- Do not place heavy objects on top of the product.
- When you leave the product unused for a long time unplug the product from the power outlet.
- Product should be kept away from heat sources such as radiators, cookers etc. - it should not be placed in places where the temperature is less than -20 degrees or greater than 45 degrees.
- This product may interfere with other electronic products such as TV, radios, personal computers, phones or other wireless devices.

#### CAUTION!

#### CAUTION!

Avoid replacement of a battery with an incorrect type that can defeat a safeguard.

Avoid disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.

Do not leave a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas; Do not leave a battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

Camera Operating Temperature: -20 °C ~ 45°C (-4°F ~ 113°F) Camera Operating Humidity: 10%~90%RH, Non-condensing Hub Operating Temperature: 0 °C ~ 40°C (32°F ~ 104°F) Hub Operating Humidity: 10%~90%RH, Non-condensing Please read and follow the above safety information when operating the device. We cannot guarantee that no accidents or damage will occur due to improper use of the device. Please use this product with care and operate at your own risk.

TP-Link hereby declares that the device is in compliance with the essential requirements and other relevant provisions of directives 2014/53/EU, 2009/125/EC, 2011/65/EU and (EU)2015/863.

The original EU declaration of conformity may be found at https://www.tapo.com/support/ce

TP-Link hereby declares that the device is in compliance with the essential requirements and other relevant provisions of the Radio Equipment Regulations 2017.

The original UK declaration of conformity may be found at https://www.tapo.com/support/ukca/

# C € ĽK EAE ⊛



For technical support, user guides, FAQs, warranty and more, please visit www.tapo.com/support/

