



Can't connect wirelessly to Wi-Fi 6 products?

Some older driver or software versions for wireless devices may be incompatible with Wi-Fi 6 products.

If you are having trouble connecting to your Wi-Fi 6 products, update the driver or software for your wireless devices.

How to update the driver?

1. Check your wireless adapter model.
2. Visit the manufacturer's website to obtain the latest driver version.
3. Update the driver. You can contact them for further assistance in upgrading.

For more detailed instructions, see <https://www.tp-link.com/faq-2303.html>