

## Third-Party Services

Tapo works with Alexa, Google Assistant, Samsung SmartThings, and other third-party services to control your smart plug by voice. You can go to **Me > Third-Party Services** in the Tapo app to set up as you need.



## Safety Information

- Please keep this instruction manual.
- This device is intended for indoor use only. Plug the device into a suitable outlet.
- Keep the device away from heat sources and enclosed spaces with poor ventilation.
- To Reduce the Hazardous Condition, unplug the appliance before servicing. Electronic switch integrated in this product is only intended for functional purpose.
- Keep the device away from water, fire, humidity or hot environments.
- Do not attempt to disassemble, repair, or modify the device.
- Do not use the device where wireless devices are not allowed.
- The socket-outlet shall be installed near the equipment and shall be easily accessible.
- The devices are not intended for use in locations where the temperature may be less than actual room conditions, such as unheated warehouses or garages.
- For passthrough devices, plug the power strips into the integrated electrical sockets of the devices, but devices of the same or another type not be stacked in normal use. Do not plug in a row.



Please read and follow the above safety information when operating the device. We cannot guarantee that no accidents or damage will occur due to improper use of the device. Please use this product with care and operate at your own risk.

## Support

For technical support, the user guide, warranty, and more, please visit <https://www.tapo.com/support/>



# Quick Start Guide

## Mini Smart Wi-Fi Plug

Images may differ from actual product.


©2024 TP-Link 7106511551 REV1.0.0

# Get Started with the Tapo App

## STEP 1

### DOWNLOAD Tapo


Get the **Tapo** app from App Store or Google Play, and log in.




## STEP 2

### SET UP

Tap the ⊕ button in the **Tapo** app. Select **Plugs** and then your model. Follow the app instructions to complete the setup.



## How to Reset the Plug



Rating: 220-240V, 50/60Hz, 10A

## Supported Load Types

Load Type	Max Current	Max Power (at 230V~)
Steam Iron	10 A	2300 W
Kettle	10 A	2300 W
Heater	10 A	2300 W
Toaster	10 A	2000 W
Coffee Maker	10 A	2000 W
Desk Lamp	0.5 A	50 W
TV	1.2 A	200 W
PC	2.5 A	450 W
Fan	0.5 A	70 W
Water Pump	0.5 A	70 W
Power Adapter/ USB Charger*	1.2 A	200 W

### Note:

- \*Power Adapters/USB Chargers rated under 75W do not support PFC (Power Factor Correction). PFC can reduce the inrush current generated when the relay is turned on. Therefore, using a 60-75W Power Adapter/USB Charger may damage the device due to inrush currents.
- Avoid plugging your appliances with a motor/compressor higher than 1/10 HP, such as an air conditioner. Frequent on/off switching may damage the compressor. You can check the motor/compressor value listed on your appliances or consult their customer support.
- EV charging is not supported as it demands higher power and a charging current that surpasses the plug's rated capacity.