



Plug your Powerline Deco directly into a wall socket instead of a power strip or converter.

*Some power strips and converters have filtering capabilities, which may disrupt Powerline signals.



Recommended





Ensure all the Powerline Decos are on the same service panel.

*Different service panels may prevent communication, especially with complex wiring (e.g., duplexes and warehouses).



Recommended





Keep your Deco away from large electrical appliances, such as microwave ovens and fridges, to minimize interference.

*Appliances can interfere with Powerline signals during operation.



Recommended








Scan the QR code to receive multi-language tips.
*Images may differ from your actual product.

Tips for a Smooth Start

Avoid coiling or crossing the network cables with power cords.



Recommended



Use with Deco units, not other powerline devices.

*Mixing different Powerline systems can cause interference, reducing speed and stability.



Recommended



Electrical Wiring



Electrical Wiring



Other powerline device



Other powerline device

Ethernet cable