


Quick Installation Guide

AX1500 Dual Band Gigabit Wi-Fi 6 Router


* Images may differ from actual products.

Router Mode

- If your internet comes from an Ethernet outlet, connect the router's **WAN** port to it, then follow step 4 and 5 to complete the hardware connection.
- If you want to configure this new router to extend your network, refer to the **Access Point Mode** section on the back page.



- 5 Verify that the following LED stay solid white/green or flashing blue to confirm the hardware is connected correctly.



- 6 Configure the router


1. Connect your computer to the router (Wired or Wireless)

• **Wired**

Turn off the Wi-Fi on your computer and connect it to the router via an Ethernet cable.

• **Wireless**

Connect your device to the router's Wi-Fi using the **SSID** (network name) and **Wireless Password** printed on the label at the bottom of the router.



2. Launch a web browser, and enter <http://tplinkwifi.net> or <http://192.168.0.1> in the address bar. Create a password or enter the default login information printed on the label to get start.

Note: If the login window does not appear, please refer to FAQ > Q1.




3. Follow the step-by-step instructions of the **Quick Setup** to complete the initial configuration.

😊 Enjoy the internet !

Access Point Mode

If you already have a router, you can switch this new router to an access point to extend your existing network. Follow the steps below.



1. Power on the router.
2. Connect the router’s **WAN** port to your wired router’s Ethernet port via an Ethernet cable as shown above.
3. Connect a computer to the router via an Ethernet cable or wirelessly by using the **SSID (Network Name)** and **Wireless Password**.
4. Launch a web browser and enter **http://tplinkwifi.net** in the address bar. Use your password or username/password to log in.
5. Go to **Advanced > Operation Mode**, select **Access Point** and click **Save**.
6. Wait for the router to reboot, then log in to the router and run the **Quick Setup** to complete the setup.

😊 Enjoy the internet!

Aginet APP

You can easily manage your network through the Aginet app. Download and install the Aginet app. Search for Aginet on the Apple App Store or Google Play, or simply scan the QR code.



Button Explanation

Button	Explanation
Reset	Press and hold the button for about 5 seconds to reset the router to its factory default settings.
WPS/Wi-Fi	Press the button for 1 second to start a WPS process. Press and hold down for about 2 seconds to turn both 2.4GHz and 5GHz wireless function on or off.

LED Indicators

Status	Indication
Flashing yellow	The device is starting up or resetting.
Yellow	The connection quality of the device is normal.
Flashing blue	The device is ready for setup.
Fast flashing blue	The device is establishing a WPS or mesh connection.
Blue	The device has been set up, but the internet is unavailable.
Flashing white/green	The device is upgrading firmware.
White/green	The device is all set up and connected to internet.
Flashing red	The device has lost connection.
Red	The device has an issue.

FAQ (Frequently Asked Questions)

- Q1. What should I do if I cannot access the web management page?**
- If the computer is set to a static IP address, change its setting to obtain an IP address and DNS service address automatically.
 - Verify that **http:// tplinkwifi.net** or **http://192.168.0.1** is correctly entered in the web browser and press **Enter**.
 - Use another web browser and try again.
 - Reboot your router and try again.
 - Disable and then enable the network adapter being used.
- Q2. What should I do if I cannot access the internet?**
- Check if the internet is working normally by connecting a computer directly to the modem via an Ethernet cable. If it is not, contact your internet service provider.
 - Log in to the web management page of the router, and go to the **Advanced > Status** page to check whether the Internet IP address is valid or not. If it is, please run the **Quick Setup** again; otherwise, recheck the hardware connection.
 - Reboot your router and try again.
 - For cable modem users, log in to the web management page of the router. Go to **Advanced > Network > Internet**, and click the edit icon to find the **MAC Clone** section, select **Clone Current Computer MAC Address** and click **Save**. Then reboot both the modem and the router.

- Q3. How do I restore the router to its factory default settings?**
- With the router powered on, use a pin to press and hold the **Reset** button on the back panel of the router for about 5 seconds until the Power LED blinks.
 - Log in to the web management page of the router. Go to **System Tools > Backup & Restore** , and click **Factory Restore**. The router will restore and reboot automatically.
- Q4. What should I do if I forget my web management page password?**
- Refer to FAQ > Q3 to reset the router, create a new password or use the default username/password printed on the label.
- Q5. What should I do if I forget my wireless network password?**
- If you have not changed the default wireless password, it can be found on the label at the bottom of the router.
 - Connect a computer to the router via an Ethernet cable. Log in to the web management page, and go to **Basic > Wireless** to retrieve or reset your wireless password.

- EU Declaration of Conformity**
- TP-Link hereby declares that the device is in compliance with the essential requirements and other relevant provisions of directives 2014/53/EU, 2009/125/EC, 2011 /65/EU and (EU) 2015/863.
The original EU declaration of conformity may be found at <https://www.tp-link.com/en/support/ce/>
- UK Declaration of Conformity**
- TP-Link hereby declares that the device is in compliance with the essential requirements and other relevant provisions of the Radio Equipment Regulations 2017.
The original UK declaration of conformity may be found at <https://www.tp-link.com/support/ukca/>

- Safety Information**
- Keep the device away from water, fire, humidity or hot environments.
 - Do not attempt to disassemble, repair, or modify the device. If you need service, please contact us.
 - Do not use the device where wireless devices are not allowed.
 - Do not use damaged charger or USB cable to charge the device.
 - Do not use any other chargers than those recommended.
 - Adapter shall be installed near the equipment and shall be easily accessible.
- Please read and follow the above safety information when operating the device. We cannot guarantee that no accidents or damage will occur due to improper use of device. Please use this product with care and operate at your own risk.