

Quick Installation Guide








Ceiling Mount Access Point



Scan for
Campus AP Start Guide

Note: AP9788 is used as an example throughout the guide. Images may differ from your actual product.
©2026 TP-Link 7100003310 REV1.0.1

Package Contents



Note: Accessories may vary by region and model.


1. Install

Notes:

- Ensure the ceiling, wall, or junction box can support at least four times the combined weight of the AP and mounting kit.
- The AP locks in place once installed. To remove it, refer to **Uninstalling** on the back page.


Option 1

Ceiling Mounting (on a Tile)




Option 2

Ceiling Mounting (on a T-Bar)




Option 3

Wall Mounting





Option 4


Junction Box Mounting




Option 1




1




2




3





4




5




Option 2




1




2




3




4



5



6



Option 3

1×4×4×

1

4× Φ 19/64 in
(4× Φ 7.6 mm)

2

A/F

3

Refer to 2. Connect to connect cables.

Φ ≤ 5/32 in
(Φ ≤ 8 mm)

4

Cable through wallOrCable along wall

5

Refer to 2. Connect to connect cables.

Φ ≤ 5/32 in
(Φ ≤ 8 mm)

Option 4

1×2×2×2×

Compatible wall junctions:

Screws and mounting holes vary with junction boxes.
For simplicity, a single-gang outlet box (US) is used as an example.

1

Refer to 2. Connect to connect cables.

Φ ≤ 5/32 in
(Φ ≤ 8 mm)

2

Refer to 2. Connect to connect cables.

Φ ≤ 5/32 in
(Φ ≤ 8 mm)

3


Refer to 2. Connect to connect cables.

Φ ≤ 5/32 in
(Φ ≤ 8 mm)

2. Connect

1. Connect to the Internet


Connect to the internet via Ethernet or fiber.




* If SFP modules are used, ensure they are compatible with your uplink device.

2. Connect to Power

Option 1: Single/Dual PoE In




Option 2: DC Input



3. Configure


Option 1: Standalone Mode

Configure and manage each AP on its standalone page.



Option 2: Controller Mode

Configure and manage APs centrally with an Omada Controller.



Omada App

With the TP-Link Omada app, access and manage your devices at a local site or remotely with a tap of your phone.




More Configurations

For more configurations, refer to the User Guides of the Access Point and Controllers at: <https://support.omadanetworks.com/document/>

Uninstalling

The AP locks in place once installed. To uninstall, unlock with the provided L-Key.



Safety Information

- Keep the device away from water, fire, humidity, or hot environments.
- Do not attempt to disassemble, repair, or modify the device. If you need service, please contact us.
- Do not use the device where wireless devices are not allowed.
- (For IN version) The AP can be powered only by a power adapter or a PSE device (such as a PoE switch) which complies with Limited Power Source (LPS) defined in the standard of IEC 60950-1.
- (For other versions) The AP can be powered only by a power adapter or a PSE device (such as a PoE switch) which complies with Power Source Class 2 (PS2) or Limited Power Source (LPS) defined in the standard of IEC 62368-1.
- Use only power supplies listed in the user instructions. Refer to the User Manual on the product support page.
- Plug the product into wall outlets with earthing connections through the plug.

TP-Link hereby declares that the Access Point is in compliance with the essential requirements and other relevant provisions of directives 2014/53/EU, 2009/125/EC, 2011/65/EU, and (EU) 2015/863. The original EU Declaration of Conformity may be found at <https://www.tp-link.com/en/support/ce/>
TP-Link hereby declares that the Access Point is in compliance with the essential requirements and other relevant provisions of the Radio Equipment Regulations 2017. The original UK Declaration of Conformity may be found at <https://www.tp-link.com/support/ukca/>

More Resources

Main Site	https://www.omadanetworks.com/
Video Center	https://support.omadanetworks.com/video/
Documents	https://support.omadanetworks.com/document/
Product Support	https://support.omadanetworks.com/product/
Technical Support	https://support.omadanetworks.com/contact-support/

Warranty

For details on the warranty period, policy, and procedures, visit <https://support.omadanetworks.com/warranty-services/>.

Support

For technical support, user guides, and other information, visit <https://support.omadanetworks.com/>, or simply scan the QR code.

