deco™ | Whole Home Mesh Wi-Fi System
Seamless Roaming | Parental Controls | Antivirus

tp-link

User Guide

AC1300 Whole Home Mesh Wi-Fi System
Deco M5

1910012596 REV2.1.0

Contents

About This Guide 1
Appearance 2
Set Up Your Deco 3
Dashboard 5
Overview 6
Shortcut 8
Automation 9
Wi-Fi Settings 10
Internet Speed Test 11
Blacklist 12
WPS 13
Parental Controls 14
Antivirus 15
QoS 16
Monthly Report 17
Managers 18
Advanced Features 19
Online Upgrade 24
Authentication 25

Set Up Your Deco

Follow the steps below to set up your Deco Whole Home Mesh Wi-Fi system.

4. Select a location

Select a location for this Deco. If its location is not listed, you can create a new one by choosing Custom.



5. Create your Wi-Fi network

Set a network name and a password. These will be the name and password you use to connect your devices to Wi-Fi.



6. Add more Decos

You can add more Decos to expand Wi-Fi coverage. The app will guide you through the process of adding more Decos one by one.