Ptp-link | Quick Installation Guide

Connect to a Computer

a. Turn off your computer, unplug the power cable then remove the case panel.

b. Connect the provided Bluetooth USB cable to the adapter.

20

Bluetooth USB cable

c. Locate an available PCIE X1 slot and carefully insert the adapter.

Note:

If the bracket is not suitable for your computer, detach it from the adapter's board and replace it with the low-profile bracket.

d. Locate an available F_USB connector and carefully plug the Bluetooth USB cable into it.

Note:

If the Bluetooth USB cable is not correctly connected to the motherboard, Bluetooth function won't work even after driver installation.



To continue, flip the page over.

WLAN Bluetooth PCI Express Adapter



3 Join a Wireless Network

a. Click the network icon (📶 or) on the taskbar.

b. Select your Wi-Fi network, click Connect, and enter the password when prompted.



4 Pair With Bluetooth Devices

- a. Right click the 🖇 (Bluetooth) icon on the taskbar. If it's not displayed, turn on Bluetooth in your PC settings first.
- b. Select Add a Bluetooth Device or Add a Device to scan for available devices.

c. Select your Bluetooth device from the list and follow the onscreen instructions to complete pairing.

Note[.] Make sure your device's Bluetooth is enabled and discoverable.

	Anna's Phone	Pair
	Jack's Pad	
(Mouse	

FHI 🕢

To communicate with TP-Link users or engineers, please visit https://community.tp-link.com to joinTP-Link Community.

If you have any suggestions or needs on the product guides, welcome to email techwriter@tp-link.com.cn.

Safety Information

Support

 Keep the device away from water, fire, humidity or hot environments. · Do not attempt to disassemble, repair, or modify the device. Do not use the device where wireless devices are not allowed.

For technical support, the user guide and other information, simply scan the QR code or visit https://www.tp-link.com/support/

©2019 TP-Link 7106508548 REV1.0.2

e. Connect the antenna(s) to the adapter. a. Insert the CD and run the Autorun.exe

Tip:

To maximize performance, make sure the path between

f. Replace the case panel, plug in the power

the antenna(s) and your router is clear.

cable and turn on your computer.

Tip: You can also check the new release and download the driver at https://www.tp-link.com/support/download/

b. Install the Wi-Fi and Bluetooth drivers.

(1) Wi-Fi: Click and follow the onscreen instructions to complete the Wi-Fi installation.

② Bluetooth: Click 🚢 and follow the onscreen instructions to complete the Bluetooth installation.

