


# Quick Installation Guide

300Mbps Wireless N USB VDSL/ADSL Modem Router TD-W9970/TD-W9970B


\*TD-W9970 is used for demonstration in this QIG.



## 1. Connecting the Hardware



### 2. Configuring the Modem Router




### **USB Features**

The USB port can be used for media sharing, storage sharing and printer sharing across your local network. You can also set up the FTP server to access your files remotely by connecting to the Internet.

Note: To learn more about the USB features, please visit http://tp-link.com/app/usb, or simply scan the QR code.













Printer Sharing

# Frequently Asked Questions (FAQ)

#### Q1. What can I do if the login window does not appear?


- A1. If the computer is set to a static or fixed IP address, change it to obtain an IP address automatically.
- A2. Verify http://tplinkmodem.net or http://192.168.1.1 is correctly entered in the web browser and press Enter.
- A3. Use another web browser and try again.
- A4. Reboot your modem router and try again.
- A5. Disable the network adapter used currently then enable it again.

#### Q2. What can I do if I cannot access the Internet?

- A1. Check your cables and make sure they are all plugged in correctly, including the telephone line, Ethernet cable and power adapter.
- A2. Check to see if you can log on to the Web-Management page of the modern router. The default address of the Web-Management page is http://tplinkmodem.net or http://192.168.1.1. If you can, try the following steps. (If you can not, please set your computer to obtain an IP address automatically and then try to access the Internet again.)
- A3. Consult your ISP and make sure all the VPIVCI, Connection Type, account username and password are correct. If they are not, please replace them with the correct settings and try again.
- A4. If you still cannot access the Internet, please restore your modem router to its factory default settings and reconfigure your modem router following the instructions in this OIC.
- A5. Please contact our Technical Support if the problem still exists.

#### Q3. How do I restore the modem router to its factory default settings?

- A1. With the modem router powered on, press and hold down the WPS/RESET Button on the rear panel of the modem router for approximately 5 seconds.
- A2. Log in Web Management page of the modem router, and go to System Tools->Factory Defaults, click Restore, then wait until the progress bar loading finished.



#### Q4. What can I do if I forget my password?

Web Management page password:

Restore the modern router to its factory default settings and then use the default Username 'admin' and Password 'admin' to log in.

- Wireless Network password:
- A1. The factory default password can be found on the product label printed on the bottom of the
- A2. If you have changed your password, log on to the modern router's Web Management page, go to Wireless->Wireless Security to obtain or reset your password.

### **LED Indicators**

	Name	Status	Indication	
	(Power)	On Flash Off	System start-up complete. System starting up or device updating. Power is off.	
Ÿ	(DSL)	On Flash Off	DSL line is synchronized and ready to use. The DSL negotiation is in progress. There is no connection to the DSL Port or DSL synchronization fails.	
	(Internet)	On Off	The network is available with a successful Internet connection.  There is no successful Internet connection or the modem router is operating in Bridge mode.	
	(Wireless)	On Off	The wireless function is working properly.  The wireless function is disabled.	
	(WPS)	On/Off Flash	It turns on when a wireless device has been successfully connected to the network via WPS. After about 5 minutes, the WPS LED will turn off. WPS handshaking is in process and will continue for about 2 minutes.	
	(USB)	On Flash Off	The USB device is identified and ready to use. The USB device is being identified. No USB device is plugged in to the USB port.	
	(LAN 1-4)	On Off	There is a device connected to this LAN Port.  There is no device connected to this LAN Port.	