# **Quick Installation Guide**

### \* TL-WPA4220 KIT (European version) is used for demonstration in this guide. \* Images may differ from actual products.



Router

### Adapter 1 . TL-PA4010 Powerline

### 2

**企** On

Plug the adapter into a power outlet

and connect it to the router's LAN

port via an Ethernet cable.

0

Extender TL-WPA4220

Ethernet Cable

Plug the extender into a power outlet on the same electrical circuit. Wait until the extender's Powerline LED  $\hat{\boldsymbol{\omega}}$  turns on.

Note: If the LED is off, please refer to FAQ > Q2.

### 3 Enjoy!

Connect your devices to the internet using the default SSID (network name) and password on the label at the top of the extender.



Want to unify or personalize your network? See the back page for instructions.

### Attention

 $\bigcirc$ 

1. Use the product only in the upright direction.



2. Plug powerline devices into wall outlets instead of power strips. Note: Using power strip will affect network performance or even cause connection drops.

③ Wall Outlet

🔅 Power Strip





### Unify Your Wi-Fi Networks via WPS

Copy SSID and password from your router via WPS to create one unified Wi-Fi network throughout your home.

Note: If your router doesn't have a WPS button, manually change the extender's Wi-Fi settings via the toPLC app, toPLC Utility, or web interface.

- 1 Plug in the extender in the same room as your router. Wait
- 2 Press your router's WPS button. Within 2 minutes, press the extender's Wi-Fi button for 1 second. The extender's Wi-Fi LED 🕿 starts blinking. When it stays on, Wi-Fi settings are copied.

Note: If Wi-Fi settings are not copied within 2 minutes, manually change the extender's Wi-Fi settings.

**3** Relocate the extender and enjoy the internet using your router's SSID and password.

## Create a Secure Powerline Network by Pairing

Note: You can only pair two devices at a time. We recommend that you plug in the powerline devices near each other when pairing.

- 1 Press the Pair button on the adapter for 1 second. Its Power LED U should start blinking. Note: If the Power LED does not blink, press the Pair button again.
- 2 (Within 2 minutes) press the extender's Pair button for 1 second. Its Power LED U should start blinking.
- **3** When the extender's Powerline LED  $\widehat{}$  turns on, a powerline network has been successfully created.

### Sync Wi-Fi Settings to More Extenders

1  $\hat{}$ Adapter Extender TL-PA4010 TL-WPA4220

If you have more extenders, simply plug in and pair each one with the existing adapter to join the network. Then the Wi-Fi settings will automatically sync from the existing extender to the new ones.

### **Physical Appearance**



LED	STATUS	DESCRIPTION
U Power	On	The powerline adapter/extender is on.
	Blinking	Quickly: Pairing is in process. Slowly: Power-Saving Mode is on.* (TL-PA4010 Only)
	Off	The powerline adapter/extender is off.
Powerline	On	The powerline adapter/extender is connected to a powerline network.
	Off	The powerline adapter/extender is not connected to any powerline network
Ethernet	On/Off	The Ethernet port is connected or not connected.
	On	The wireless function is enabled.
	Blinking	Slowly: The powerline extender is cloning 2.4G Hz wireless network settings from the main router.
		Quickly: The powerline extender is syncing 2.4G Hz wireless network settings.
	Off	The wireless function is disabled.

\* If the device connected to TL-PA4010 is turned off or inactive for more than 5 minutes, TL-PA4010 will automatically switch to Power-Saving Mode.

ITEM	DESCRIPTION Press and hold for 1 second to set up or join a secure powerline network.	
Pair Button		
Wi-Fi Button	Press for 1 second to start copying Wi-Fi settings from the router. Press and hold for about 5 seconds to turn Wi-Fi on or off.	
Reset Button	Press and hold until all LEDs turn off to reset the adapter/extender to factory default settings	

### Personalize Your Network

#### tpPLC App

For easy management via your smartphone or tablet, download the app from the App Store or Google Play, or simply scan the QR code.



Scan to download

#### tpPLC Utility

For easy management via your computer, download the utility on the product's

Note: For detailed instructions, refer to the utility manual on the product's Support page.

#### Web Interface

#### To access all settings, connect to an extender wirelessly and visit http://tplinkplc.net.

Note: For detailed instructions, refer to the product manual on the product's Support page.

### Frequently Asked Questions

#### Q1. How do I reset my adapter and extender to factory default settings?

A1. For TL-PA4010, press and hold the Pair button until all LEDs turn off and then come back on. A2. For TL-WPA4220, press and hold the Reset button for at least 2 seconds. Release the button and all LEDs turn off. When the LEDs turn back on, the reset process is complete.

#### Q2. What should I do if the Powerline LED 1 is off?

A1. Try another wall socket and make sure all powerline devices are on the same electrical circuit. A2. Try to set up a powerline network by pairing. Refer to the section above for instructions. A3. If the problem persists, contact our Technical Support.

#### Q3. What should I do if there is no internet connection in my powerline network?

A1. Make sure all powerline adapters and extenders are on the same electrical circuit. A2. Make sure the Powerline LEDs 🏠 are lit on all of your powerline devices. If they are not, pair all devices

- again.
- A3. Make sure all devices are correctly and securely connected.
- A4. Check if you have an internet connection by connecting the computer directly to the modern or router.

#### Q4. What should I do if a successfully-paired extender does not reconnect after it is

- relocated? A1. Make sure all powerline adapters and extenders are on the same electrical circuit.
- A2. Try to pair the extender again, and make sure the Powerline LED  $\widehat{\mathbf{\omega}}$  is on.
- A3. Check for possible interference due to a washing machine, air conditioner or other household appliances that may be too close to one of the powerline devices. Plug the appliance into the integrated electrical socket to remove the electrical noise if your powerline device has an integrated electrical socket.



### To communicate with TP-Link users or engineers, please join the TP-Link Community at https://community.tp-link.com.

If you have any suggestions or needs for our product guides, you are welcome to email techwriter@tp-link.com.cn.

TP-Link hereby declares that the device is in compliance with the essential requirements and other relevant provisions of directives 2014/53/EU, 2009/125/EC, 2011/65/EU and (EU)2015/863. The original EU Declaration of Conformity may be found at https://www.tp-link.com/en/support/ce/ TP-Link hereby declares that the device is in compliance with the essential requirements and other relevant

provisions of the Radio Equipment Regulations 2017. The original UK Declaration of Conformity may be found at https://www.tp-link.com/support/ukca/

#### Safety Information

- · Keep the device away from water, fire, humidity or hot environments.
- Do not attempt to disassemble, repair, or modify the device. If you need service, please contact us. · Do not use the device where wireless devices are not allowed.
- The socket-outlet shall be installed near the equipment and shall be easily accessible.
- · Plug the powerline devices directly into the wall outlets but not the power strips.

Please read and follow the above safety information when operating the device. We cannot guarantee that no accidents or damage will occur due to improper use of the device. Please use this product with care and operate at your own risk.



# tpPLC App

Support page at https://www.tp-link.com.