




Hardware Installation

Note The product model shown in this QIG is TL-WN350G, as an example.

1. Power down your computer and unplug its power cord;
2. Open the case and locate an available PCI slot on the motherboard;
3. Insert the PCI Adapter into the PCI slot. Make sure that all of its pins are touching the slot's contacts. You may have to apply a bit of pressure to slide the adapter all the way in. After the adapter is firmly in place, secure its fastening tab to your computer's chassis with a mounting screw;



4. Close the case and insert the power cable into the computer, then turn on the computer.



Software Installation

Note If you are running **Windows 2000**, please install the device by referring to the "Installation Guide" part of the User Guide on the included Resource CD.

1 For Windows XP

1 Installing Adapter Driver

You may see the **Found New Hardware Wizard** when the computer boots up. This is the default setup wizard of Windows XP. For a smoother installation, please click "Cancel" and insert the provided TP-LINK Resource CD.





Click **Cancel**


After inserting the provided Resource CD into your CD-ROM drive, the Setup Wizard will automatically pop up on your computer's screen.

Please select the model number of your product and click **Driver (Win2000_XP)**








If prompted to 'The software has not passed Windows Logo testing to verify its compatibility with Windows XP', click **Continue Anyway**.



2 Connecting to the Wireless Router/Access Point

After you have successfully installed the driver software, the icon  will appear on the bottom right-hand corner of your desktop.




Click  on the taskbar.

Click **Refresh network list**.

Select your network by the network name.

Click **Connect**.



Input the Network key of your wireless network.

Click **Connect**.


The screenshot shows the 'Wireless Network Connection II' dialog box with the 'Refresh network list' button highlighted. Below it, the 'Wireless Network Connection' dialog box is shown with the 'Network key' and 'Confirm network key' fields filled with asterisks and the 'Connect' button highlighted.

Note If you don't know the wireless network key, please consult the network administrator or login to the setup page of your Wireless Router/Access Point with an Ethernet cable to check the wireless security settings. Please refer to the manual of your Wireless Router/Access Point or contact the manufacturer's technical support for more details.

Note If your network is an unsecured network, you will not be prompted to input the network key. You will be connected to your network automatically.



You have now successfully connected to your wireless network.




2

For Windows Vista

1 Installing Adapter Driver

You may see the **Found New Hardware Wizard** when the computer boots up. This is the default setup wizard of Windows Vista. For a smoother installation, **please click "Cancel" and insert the provided TP-LINK Resource CD.**

Click **Cancel**






After inserting the provided Resource CD into your CD-ROM drive, the Setup Wizard will automatically pop up on your computer's screen.

Please select the model number of your product and click **Driver (Vista)**




Click **Next**






If prompted to 'Windows can't verify the publisher of this driver software', click **Install this driver software anyway**.

Click **Finish**



2 Connecting to the Wireless Router/Access Point




Note If you don't know the wireless network key, please consult the network administrator or login to the setup page of your Wireless Router/Access Point with an Ethernet cable to check the wireless security settings. Please refer to the manual of your Wireless Router/Access Point or contact the manufacturer's technical support for more details.



Note If your network is an unsecured network, you will not be prompted to input the Network key. It will connect to your network automatically.

You have now successfully connected to your wireless network.

Save this network for automatically connecting



Click Close

3


For Windows 7

1 Installing Adapter Driver


After inserting the provided Resource CD into your CD-ROM drive, the Setup Wizard will automatically pop up on your computer's screen.

Please select the model number of your product. Click **Install Driver&Utility**






If prompted to 'Windows can't verify the publisher of this driver software', click **Install this driver software anyway**.



2 Connecting to the Wireless Router/Access Point

Click the icon  at the bottom of your screen in your system tray.





Click this button to refresh the network list


Select your network by the network name

Click **Connect**



Input the Network Key of your wireless network

Click **OK**



Note If you don't know the wireless network key, please consult the network administrator or login to the setup page of your Wireless Router/Access Point with an Ethernet cable to check the wireless security settings. Please refer to the manual of your Wireless Router/Access Point or contact the manufacturer's technical support for more details.

Note If your network is an unsecured network, you will not be prompted to input the Network key. It will connect to your network automatically.





You have now successfully connected to your wireless network.





Technical Support

- For more troubleshooting help, go to:
www.tp-link.com/support/faq.asp
- To download the latest Firmware, Driver, Utility and User Guide, go to:
www.tp-link.com/support/download.asp
- For all other technical support, please contact us by using the following details:

Global

Tel: +86 755 26504400

E-mail: support@tp-link.com

Service time: 24hrs, 7 days a week

Singapore

Tel: +65 62840493

E-mail: support.sg@tp-link.com

Service time: 24hrs, 7 days a week

UK

Tel: +44 (0) 845 147 0017

E-mail: support.uk@tp-link.com

Service time: 24hrs, 7 days a week

USA/Canada

Toll Free: +1 866 225 8139

E-mail: support.usa@tp-link.com

Service time: 24hrs, 7 days a week

Germany / Austria

Tel: +49 1805 875465 (German Service) / +49 1805 TPLINK

E-mail: support.de@tp-link.com

Fee: 0.14 EUR/min from the German fixed phone network and up to 0.42 EUR/min from mobile phone

Service time: Monday to Friday 9:00 AM to 6:00 PM.GMT+ 1 or GMT+ 2 (Daylight Saving Time in Germany)

*Except bank holidays in Hesse

Australia & New Zealand

Tel: AU 1300 87 5465

NZ 0800 87 5465

E-mail: support@tp-link.com.au

Service time: 24hrs, 7 days a week

Malaysia

Tel: 1300 88 875465 (1300 88TPLINK)

Email: support.my@tp-link.com

Service time: 24hrs, 7 days a week

Turkey

Tel: 444 19 25 (Turkish Service)

E-mail: support.tr@tp-link.com

Service time: 9:00 AM to 6:00 PM

7 days a week

Italy

Tel: +39 02 66987799

E-mail: support.it@tp-link.com

Service time: 9:00 AM to 6:00 PM

Monday to Friday

Switzerland

Tel: +41 (0)848 800998 (German Service)

E-mail: support.ch@tp-link.com

Fee: 4-8 Rp/min, depending on rate of different time

Service Time: Monday to Friday 9:00

AM to 6:00 PM. GMT+1 or GMT+2

(Daylight Saving Time)

