




Installation Guide For Linux Driver



TP-LINK Statement for Linux driver

TP-LINK has released Linux driver for some TP-LINK USB wireless adapters to support Linux system. The driver file has included an installation guide about how to install and use the adapter on Linux OS.

The driver is recommended to be installed on Linux OS which applies the kernel version that we have listed on TP-LINK official website.

Archer_T2U_V1_150901 	Published Date	01/09/15	Language	English	File Size	6.29 MB
	Operating System	Linux (Kernel version 2.6~3.16)				
	Notes	For Archer T2U V1				

Since Linux is developed at an open system with various branches, we cannot guarantee that our driver could work on your Linux system.

Given the specificity of the Linux system, we are very sorry that we cannot provide more guidance on the installation, except the existing one, so we sincerely recommend you to seek instruction on the related forums.

We have updated some FAQs about installing driver, please click this link:

<http://www.tp-link.com/en/faq-1076.html>

Contents

1.	Development Environment.....	1
2.	Compile the Driver	1
3.	Load the Driver.....	2
4.	Join the Wireless Network	3
4.1.1.	Identify the device.....	3
4.1.2.	Create the interface	3
4.1.3.	Change the interface status to up.....	4
4.1.4.	Scan AP and see results.....	4
4.1.5.	AP Connect to the AP	4
4.1.6.	Enable DHCP client	6

1. Development Environment

System version: Ubuntu 14.04.1

Kernel version: 3.16.0-30-generic

Gcc version: 4.8.2

2. Compile the Driver

Before you compile the driver, please make sure you have the correct compile tool and kernel sources.

We can install compile tool gcc by command “**apt-get install gcc**”

Note : We recommend you use a suitable compile tool to compile our driver.

For example:

```
tplinku@tplinku-Vostro-3900:~$ cat /proc/version
Linux version 3.13.0-35-generic (buildd@roseapple) (gcc version 4.8.2 (Ubuntu 4.8.2-19ubuntu1) ) #62-Ubuntu SMP Fri Aug 15 01:58:01 UTC 2014
tplinku@tplinku-Vostro-3900:~$
```

According to the command “**cat /proc/version**”, we could see your linux system is compiled by gcc4.8.2. So we recommend you use gcc4.8.2 to compile our driver if possible.

To compile the driver:


1. Access the directory of driver.
2. Before compile, make sure the the path in makefile.c is suitable for your compile environment of your Linux system.

```
ifeq ($(WIFI_MODE),)
RT28xx_MODE = STA
else
RT28xx_MODE = $(WIFI_MODE)
endif
ifeq ($(TARGET),)
TARGET = LINUX
endif
```

```
#PLATFORM: Target platform
PLATFORM = PC
```


```
ifeq ($(PLATFORM),PC)
# Linux 2.6
LINUX_SRC = /lib/modules/$(shell uname -r)/build
# Linux 2.4 Change to your local setting
#LINUX_SRC = /usr/src/linux-2.4
LINUX_SRC_MODULE = /lib/modules/$(shell uname -r)/kernel/drivers/net/wireless/
CROSS_COMPILE =
endif
```

3. Type "`sudo make`" to compile the driver file.

A terminal window with a dark background and light text. The window title is "root@tplinku: /home/tplink/Downloads/t2u". The prompt "root@tplinku: /home/tplink/Downloads/t2u#" is repeated 20 times, followed by "sudo make" and a cursor at the end of the line.

3. Load the Driver

- 1) Go to the directory of the original driver file to run the command "`sudo bash load.sh`"

A terminal window with a dark background and light text. The window title is "root@tplinku: /home/tplink/Downloads/t2u". The prompt "root@tplinku: /home/tplink/Downloads/t2u#" is repeated 18 times, followed by "sudo bash load.sh". The output of the command is shown as a table with columns of driver information. The prompt "root@tplinku: /home/tplink/Downloads/t2u#" is shown at the end of the output.

If it's fail to run the `load.sh`, please type:

```
"rm -rf /etc/Wireless/RT2870STA"
```

```

“mkdir /etc/Wireless/RT2870STA”
“cp ./MODULE/conf/RT2870STA.dat /etc/Wireless/RT2870STA/RT2870STA.dat”
“chmod 777 -R /etc/Wireless/RT2870STA”
“insmod ./UTIL/os/linux/mt7650u_sta_util.ko”
“insmod ./MODULE/os/linux/mt7650u_sta.ko”
“insmod ./NETIF/os/linux/mt7650u_sta_net.ko”
“lsmod | grep "mt7650"”
“ifconfig ra0 up”

```

2) Type “lsmod” to check if the driver is successfully loaded.

```

root@tplinku: /home/tplink/Downloads/t2u
mt7650u_sta          905216  1 mt7650u_sta_net
mt7650u_sta_util    81920   2 mt7650u_sta_net,mt7650u_sta
root@tplinku: /home/tplink/Downloads/t2u#
root@tplinku: /home/tplink/Downloads/t2u#
root@tplinku: /home/tplink/Downloads/t2u#
root@tplinku: /home/tplink/Downloads/t2u#
root@tplinku: /home/tplink/Downloads/t2u#
root@tplinku: /home/tplink/Downloads/t2u# lsmod
Module                Size  Used by
mt7650u_sta_net      40960  1
mt7650u_sta          905216  1 mt7650u_sta_net
mt7650u_sta_util    81920   2 mt7650u_sta_net,mt7650u_sta
ctg80211             524288  0
rfcomm               69632   0
bnep                 20480   2
bluetooth           491520  10 bnep,rfcomm
intel_rapl           20480   0
iosf_mbi             16384   1 intel_rapl
x86_pkg_temp_thermal 16384   0
intel_powerclamp    20480   0
coretemp             16384   0
kvm                  479232  0
snd_hda_codec_realtek 81920   1
snd_hda_codec_generic 69632   1 snd_hda_codec_realtek

```

If you want to unload the driver, run the following command in the same directory.

```

sudo bash unload.sh

```

4. Join the Wireless Network

4.1.1. Identify the device

After the driver is successfully loaded, insert the USB adapter and type “lsusb” to check if the adapter is identified.

```

root@tplinku: /home/tplink/Downloads/t2u# lsusb
Bus 002 Device 007: ID 148f:761a Ralink Technology, Corp.
Bus 002 Device 003: ID 093a:2510 Pixart Imaging, Inc. Optical Mouse
Bus 002 Device 002: ID 8087:0024 Intel Corp. Integrated Rate Matching Hub
Bus 002 Device 001: ID 1d6b:0002 Linux Foundation 2.0 root hub
Bus 001 Device 002: ID 8087:0024 Intel Corp. Integrated Rate Matching Hub
Bus 001 Device 001: ID 1d6b:0002 Linux Foundation 2.0 root hub

```

4.1.2. Create the interface

Type “ifconfig -a” to check if the wireless network interface is created.

4.1.3. Change the interface status to up

Check if the WLAN interface is up. If not, type “`ifconfig ra0 up`”.

4.1.4. Scan AP and see results

Run the following command to scan the signals.

```
sudo iwpriv ra0 set SiteSurvey=1
sudo iwpriv ra0 get_site_survey
```

Ch	SSID	BSSID	Security	Signal(%)	W-Mode	ExtCH	NT
1	WWW	64:66:b3:93:b4:87	WPA2PSK/AES	100	11b/g/n	ABOVE	In
1	hello	10:fe:ed:e9:71:76	WPA1PSKWPA2PSK/TKIPAES	100	11b/g/n	ABOVE	In
11	TP-LINK_41B1	e8:de:27:d3:41:b1	WPA2PSK/AES	100	11b/g/n	NONE	In
1	TP-LINK_wpa281	f8:d1:11:a5:2e:a2	WPA1PSKWPA2PSK/TKIPAES	78	11b/g/n	ABOVE	In
3	ssid1	c4:e9:84:59:4b:59	WPA1PSKWPA2PSK/TKIPAES	100	11b/g/n	NONE	In
3	ssid2	06:e9:84:59:4b:59	WPA1PSKWPA2PSK/TKIPAES	100	11b/g/n	NONE	In
3	ssid3	16:e9:84:59:4b:59	WPA1PSKWPA2PSK/TKIPAES	44	11b/g/n	NONE	In
4	TP-LINK_C2_2_4G	c4:6e:1f:73:19:04	WPA2PSK/AES	94	11b/g/n	ABOVE	In
5	TP-LINK_AP_1234	f4:f2:6d:8c:8a:76	NONE	100	11b/g/n	BELOW	In
5	TP-LINK_93C170	64:66:b3:93:c1:70	WPA1PSKWPA2PSK/TKIPAES	100	11b/g/n	BELOW	In
5	TP-LINK_EDD15E	64:70:02:ed:d1:5e	WPA1PSKWPA2PSK/TKIPAES	89	11b/g/n	BELOW	In
5	TP-LINK_2.4GHz_A2EB4B	f8:1a:67:a2:eb:4b	WPA1PSKWPA2PSK/AES	100	11b/g/n	NONE	In
5	TP-LINK_130969	00:0a:eb:13:09:69	NONE	100	11b/g/n	ABOVE	In
5	123	c4:e9:84:77:cf:56	WPA2PSK/AES	100	11b/g/n	BELOW	In
5	Cathy	60:e3:27:29:d9:0e	WPA2PSK/AES	89	11b/g/n	NONE	In
5		e8:94:f6:79:b1:e0	WPA1PSKWPA2PSK/AES	100	11b/g/n	ABOVE	In
7	AP_vlan1	6e:66:b3:64:20:e6	NONE	100	11b/g/n	BELOW	In
7	AP_vlan2	64:66:b3:64:20:e6	NONE	100	11b/g/n	BELOW	In
7	AP_vlan3	62:66:b3:64:20:e6	NONE	100	11b/g/n	BELOW	In
9	TP-LINK_2408	60:e3:27:58:24:08	WPA2PSK/AES	86	11b/g/n	BELOW	In
10	TP-LINK_3592	c4:e9:84:9b:35:92	WPA2PSK/AES	89	11b/g/n	BELOW	In
11	666	60:e3:27:f1:7a:c5	WPA2PSK/AES	99	11b/g/n	NONE	In
11	xiaozhu	60:e3:27:3b:f5:ad	WPA2PSK/AES	100	11b/g/n	NONE	In
11	AP500	f4:f2:6d:6a:b2:4d	WPA2PSK/AES	100	11b/g/n	BELOW	In
11	TP-LINK_AAF8	c0:4a:00:0a:aa:f8	WPA1PSKWPA2PSK/AES	96	11b/g/n	NONE	In
11	IPcameraTest2.4	e8:de:27:70:15:55	WPA1PSKWPA2PSK/TKIPAES	100	11b/g/n	NONE	In

4.1.5. AP Connect to the AP

- 1) Config STA to link with AP which is WPA2PSK/AES(Authentication/Encryption)

```
iwpriv ra0 set NetworkType=Infra
iwpriv ra0 set AuthMode=WPA2PSK
iwpriv ra0 set EncrypType=AES
iwpriv ra0 set SSID="AP's SSID"
iwpriv ra0 set WPAPSK="AP's wpa-presared key"
iwpriv ra0 set SSID="AP's SSID"
```

Take SSID “IpcameraTest2.4” as an example:

```
tplinku@tplinku-Vostro-3900:~/Downloads/t2u$ sudo iwpriv ra0 set NetworkType=Infra
tplinku@tplinku-Vostro-3900:~/Downloads/t2u$ sudo iwpriv ra0 set AuthMode=WPA2PSK
tplinku@tplinku-Vostro-3900:~/Downloads/t2u$ sudo iwpriv ra0 set EncrypType=AES
tplinku@tplinku-Vostro-3900:~/Downloads/t2u$ sudo iwpriv ra0 set SSID="IPcameraTest2.4"
tplinku@tplinku-Vostro-3900:~/Downloads/t2u$ sudo iwpriv ra0 set WPAPSK="12345678"
tplinku@tplinku-Vostro-3900:~/Downloads/t2u$ sudo iwpriv ra0 set SSID="IPcameraTest2.4"
tplinku@tplinku-Vostro-3900:~/Downloads/t2u$
```

- 2) Config STA to link with AP which is OPEN/NONE(Authentication/Encryption)

```
iwpriv ra0 set NetworkType=Infra
iwpriv ra0 set AuthMode=OPEN
iwpriv ra0 set EncrypType=NONE
iwpriv ra0 set SSID="AP's SSID"
```

- 3) Config STA to link with AP which is SHARED/WEP(Authentication/Encryption)

```
iwpriv ra0 set NetworkType=Infra
iwpriv ra0 set AuthMode=SHARED
iwpriv ra0 set EncrypType=WEP
iwpriv ra0 set DefaultKeyID=1
iwpriv ra0 set Key1="AP's wep key"
iwpriv ra0 set SSID="AP's SSID"
```

- 4) Config STA to link with AP which is WPAPSK/TKIP(Authentication/Encryption)

```
iwpriv ra0 set NetworkType=Infra
iwpriv ra0 set AuthMode=WPAPSK
iwpriv ra0 set EncrypType=TKIP
iwpriv ra0 set SSID="AP's SSID"
iwpriv ra0 set WPAPSK="AP's wpa-preshared key"
iwpriv ra0 set SSID="AP's SSID"
```

- 5) Config STA to link with AP which is WPAPSK/AES(Authentication/Encryption)

```
iwpriv ra0 set NetworkType=Infra
iwpriv ra0 set AuthMode=WPAPSK
iwpriv ra0 set EncrypType=AES
iwpriv ra0 set SSID="AP's SSID"
iwpriv ra0 set WPAPSK="AP's wpa-preshared key"
iwpriv ra0 set SSID="AP's SSID"
```

- 6) Config STA to link with AP which is WPA2PSK/TKIP(Authentication/Encryption)

```
iwpriv ra0 set NetworkType=Infra
iwpriv ra0 set AuthMode=WPA2PSK
iwpriv ra0 set EncrypType=TKIP
iwpriv ra0 set SSID="AP's SSID"
iwpriv ra0 set WPAPSK=12345678
iwpriv ra0 set SSID="AP's SSID"
```


Note: if you want to establish a 11AC connection, type “iwpriv ra0 set WirelessMode=14” or “iwpriv ra0 set WirelessMode=15” before type “iwpriv ra0 set SSID="AP's SSID"”.

4.1.6. Enable DHCP client

- 1) Type “iwconfig ra0” to check if your AP is connected successfully.

```
root@tplinku:/home/tplink/Downloads/t2u# iwconfig ra0
ra0    RateLink STA   ESSID: IPCameraTest5   Nickname: M170100_STA
Mode:Managed   Frequency=5.765 GHz   Access Point: E8:DE:27:70:15:54
Bit Rate=135 Mb/s
RTS thr:off    Fragment thr:off
Encryption key:0AFF-9D56-5FFF-46EE-DBF4-8DA0-D55F-ED36   Security mode
:open
Link Quality=96/100   Signal level:-48 dBm   Noise level:-59 dBm
Rx invalid nwid:0   Rx invalid crypt:0   Rx invalid frag:0
Tx excessive retries:0   Invalid misc:0   Missed beacon:0
```

- 2) Type “dhclient ra0” to get an IP address.

After running the command, the adapter will get an IP assigned by the AP. Then you can run the ping command to check if the wireless connection is successful.

```
tplink@tplink-Inspiron-N4010:~/driver$ ifconfig
lo        Link encap:Local Loopback
          inet addr:127.0.0.1  Mask:255.0.0.0
          inet6 addr: ::1/128 Scope:Host
          UP LOOPBACK RUNNING  MTU:65536  Metric:1
          RX packets:295 errors:0 dropped:0 overruns:0 frame:0
          TX packets:295 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:0
          RX bytes:22543 (22.5 KB)  TX bytes:22543 (22.5 KB)

wlan1     Link encap:Ethernet  HWaddr c4:e9:84:1f:df:3c
          inet addr:192.168.1.102  Bcast:192.168.1.255  Mask:255.255.255.0
          inet6 addr: fe80::c6e9:84ff:fe1f:df3c/64 Scope:Link
          UP BROADCAST RUNNING MULTICAST  MTU:1500  Metric:1
          RX packets:16 errors:0 dropped:699 overruns:0 frame:0
          TX packets:66 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:1000
          RX bytes:2068 (2.0 KB)  TX bytes:11368 (11.3 KB)

tplink@tplink-Inspiron-N4010:~/driver$ ping 192.168.1.1
PING 192.168.1.1 (192.168.1.1) 56(84) bytes of data:
64 bytes from 192.168.1.1: icmp_seq=1 ttl=254 time=11.8 ms
64 bytes from 192.168.1.1: icmp_seq=2 ttl=254 time=7.05 ms
64 bytes from 192.168.1.1: icmp_seq=3 ttl=254 time=1.97 ms
^C
--- 192.168.1.1 ping statistics ---
3 packets transmitted, 3 received, 0% packet loss, time 2003ms
rtt min/avg/max/mdev = 1.971/6.968/11.882/4.046 ms
tplink@tplink-Inspiron-N4010:~/driver$ route
Kernel IP routing table
Destination     Gateway         Genmask         Flags Metric Ref    Use Iface
default         192.168.1.1    0.0.0.0         UG    0     0      0 wlan1
192.168.1.0     *              255.255.255.0   U     0     0      0 wlan1
```

Note: Run the commands under the root account.