


Quick Installation Guide

150Mbps Wireless Range Extender

MODEL NO. TL-WA730RE

Package Contents




System Requirement

· Windows 7 · Windows Vista · Windows XP · Windows 2000

Method One »»»» Setup by Button

If you want to connect to a secured network, while your Wireless Router doesn't have the **QSS/WPS** button, please refer to **Method two**.

1 Hardware Connection




Step 1: Please place your Range Extender **next to** your Wireless Router or Access Point. Here, we take Wireless Router for example.

Step 2: Plug the Power adapter into the power jack of the Range Extender, and the other end to a standard electrical wall socket.


2 Connect to Wireless Network

Connect to the Secured Network


- 1 Push the **QSS/WPS** button on the Wireless Router.



- 2 Press and hold the **RANGE EXTENDER** button on the front panel of TL-WA730RE for about 5 seconds until **RANGE EXTENDER** LED flashes. When the LED becomes solid light, TL-WA730RE has successfully connected to the desired Router.




- 3 After successful connection, TL-WA730RE can be placed between the wireless router and wireless client to boost the signal, but not beyond the coverage of the wireless router.




Connect to the Unsecured Network

- 1 Press and hold the **RANGE EXTENDER** button on the front panel of TL-WA730RE for about 5 seconds until **RANGE EXTENDER** LED flashes.




- 2 When **RANGE EXTENDER** LED becomes solid light, TL-WA730RE has successfully connected to the desired Router.

- 3 After successful connection, TL-WA730RE can be placed between the wireless router and wireless client to boost the signal, but not beyond the coverage of the wireless router.



Method Two »»»» Setup by Utility

1 Hardware Connection




Step 1: Please place your Range Extender **next to** your Wireless Router or Access Point. Here, we take Wireless Router for example.

Step 2: Plug the Power adapter into the power jack of the Range Extender, and the other end to a standard electrical wall socket.

Step 3: Connect the Range Extender to the PC with the Ethernet Cable.

2 Connect to Wireless Network

1 Insert the provided Resource CD into your CD-ROM drive.




2 Please choose 'Easy Setup Assistant'.



3 After confirming the hardware connection and the status of LEDs, click 'NEXT' to continue.





4 Input the IP Address of the Range Extender (the default one is 192.168.1.254). Click 'NEXT' to continue.




5 When the connectivity is checked successfully, please click 'NEXT'.




6 The Range Extender can find the Wireless Router automatically. If it is your desired router, please click 'NEXT'. If not, please click 'SCAN' and select your target router in the list, then click 'NEXT'.




7 Select the security type and enter the network key of the router, then click 'NEXT' to continue.



8 After confirming the configurations, click 'NEXT' to continue. If there is any wrong information, please go 'BACK' to reset.




9 When the configuration is completed successfully, please click 'NEXT'.



Note During this process, you might see some warnings like "A network cable is unplugged". Please ignore them.

10 Please click 'FINISH' to close this wizard.



Note For more advanced settings, please refer to the User Guide on the Resource CD.

Technical Support

- For more troubleshooting help, go to www.tp-link.com/support/faq.asp
- To download the latest Firmware, Driver, Utility and User Guide, go to www.tp-link.com/support/download.asp
- For all other technical support, please contact us by using the following details:

Global

Service Language: English
Tel: +86 755 26504400
E-mail: support@tp-link.com
Service time: 24hrs, 7 days a week

Singapore

Tel: +65 62840493
E-mail: support.sg@tp-link.com
Service time: 24hrs, 7 days a week

Malaysia

Tel: 1300 88 875465 (1300 88TPLINK)
E-mail: support.my@tp-link.com
Service time: 24 hours a day, 7 days a week

Switzerland

Tel: +41 (0)848 800998
E-mail: support.ch@tp-link.com
Fee: 4-8 Rp/min, depending on rate of different time
Service Time: Monday to Friday 9:00 AM to 6:00 PM. GMT+1 or GMT+2 (Daylight Saving Time)

Australia & New Zealand

Tel: AU 1300 87 5465
NZ 0800 87 5465
E-mail: support@tp-link.com.au
Service time: 24hrs, 7 days a week

USA/Canada

Toll Free: +1 866 225 8139
E-mail: support.usa@tp-link.com
Service time: 24hrs, 7 days a week

UK

Tel: +44 (0) 845 147 0017
E-mail: support.uk@tp-link.com
Service time: 24hrs, 7 days a week

Germany / Austria

Tel: +49 1805 875465 (German Service) / +49 1805 TPLINK
E-mail: support.de@tp-link.com
Fee: 0.14 EUR/min from the German fixed phone network and up to 0.42 EUR/min from mobile phone.
Service Time: Monday to Friday 9:00 AM to 6:00 PM. GMT+1 or GMT+2 (Daylight Saving Time in Germany)
* Except bank holidays in Hesse