



4 Wireless Network Connection

Here we take **Windows XP** as example.


- 1 Go to **Start** → **Control Panel** → **Network Connections**. Right click **Wireless Network Connection**, and select **View Available Wireless Networks**.
- 2 Click **Refresh network list**, and then select the SSID (network name) of TL-ER604W. Click **Connect**. The default SSID is TP-LINK_XXXXXX, XXXXXX is the last six characters of the router's MAC address.



- 3 Enter the **Network key** in the pop-up screen. The default wireless password, the same as the PIN code, is printed on the bottom label of the router.



- 4 You've successfully connected to the wireless network.





5 Router Configuration


- 1 Open web browser and type in <http://192.168.0.1>. Press **Enter** button and then enter the User Name and Password (Factory Default: **admin/admin**), and click **Login**.
- 3 Choose menu **Network** → **WAN** → **WAN1**, and then select one connection type from the drop-down list. Here take PPPoE connection as the example. Enter the **Account Name** and **Password** provided by your ISP, and then click the **Connect** button and **Save** button.



- 2 After a successful login, choose menu **Network** → **WAN** → **WAN Mode**, and then select the total number of WAN ports you prefer to use.



- 4 Choose menu **Wireless** → **Wireless Setting** → **Wireless Setting**, then set your wireless parameters. First click **Enable** to turn on the Wireless and select the **Region** from the drop-down list. It's recommended that you edit the following two items, and then click **Save**.
 - 1) Create a unique and easy-to-remember **SSID** (Wireless Network Name).
 - 2) Select **WPA-PSK/WPA2-PSK** under **Security** and enter a **password** in the field. The default wireless password, the same as the PIN code, is printed on the bottom label.




Note: The modification of the Wireless Setting will take effect only after the router is rebooted.

Appendix: Troubleshooting

How do I restore my Router's configuration to its factory default settings?

With the Router powered on, use a pin to press and hold the **Reset** button (about 5 seconds) until the SYS LED lights up and flashes quickly. And then release the button and wait for the Router rebooting to its factory default settings.



What could I do if I forget the user name and password of the Router?

you can restore the Router to factory defaults. The default management address of the Router is <http://192.168.0.1>, default username and password are both admin. All your current settings will be cleared after the Router is restored. If you have backup configuration, please import it now.

Why does the PWR LED work abnormally?

The PWR LED should be lit up when the power system works normally. If the PWR LED worked abnormally, please check as follows:

- 1) Make sure that the power cable is connected properly, and the power contact is normal.
- 2) Make sure the voltage of the power supply meets the requirement of the input voltage of the Router.

What should I do if I could not access the web-based configuration page?

You are recommended to check the following items:

- 1) If you access the configuration page by wireless connection, please make sure your PC connects to the router by wireless.
- 2) If you access the configuration page by wired connection, Check every port LED on the Router and make sure the cable is installed properly. Then try another port on the Router and make sure the cable meets the requirement and works normally.

- 3) Turn off the power. After a while, turn on the power again.

- 4) Make sure the IP address of your PC is set within the subnet of the Router.

- 5) If you still cannot access the configuration page, please restore the Router to its factory defaults. Then the IP address of the computer should be set as 192.168.0.x ("x" is any number from 2 to 254) and Subnet Mask as 255.255.255.0).

Why does the page display abnormally?

Please check as follows:

- 1) Update your browser or replace it with another browser, and try again.
- 2) If the pop-up is blocked, please lower the security level of the browser.

Technical Support

- For more troubleshooting help, go to: <http://www.tp-link.com/en/support/faq>
- To download the latest Firmware, Driver, Utility and User Guide, go to: <http://www.tp-link.com/en/support/download>
- For all other technical support, please contact us by using the following details:

Global
Tel: +86 755 2650 4400
E-mail: support@tp-link.com
Service time: 24hrs, 7 days a week

Singapore
Tel: +65 6284 0493
E-mail: support.sg@tp-link.com
Service time: 24hrs, 7 days a week

UK
Tel: +44 (0) 845 147 0017
E-mail: support.uk@tp-link.com
Service time: 24hrs, 7 days a week

USA/Canada
Toll Free: +1 866 225 8139
E-mail: support.usa@tp-link.com
Service time: 24hrs, 7 days a week

Malaysia
Tel: 1300 88 875 465
Email: support.my@tp-link.com
Service time: 24hrs, 7 days a week

Switzerland
Tel: +41 (0) 848 800 998
(German Service)
E-mail: support.ch@tp-link.com
Fee: 4-8 Rp/min, depending on rate of different time

Service time: Monday to Friday 09:00 to 12:30 and 13:30 to 17:30. GMT+1 or GMT+2 (Daylight Saving Time in Germany)

*Except bank holidays in Hesse
Brazil
Toll Free: 0800 608 9799
(Portuguese Service)
E-mail: support.br@tp-link.com
Service time: Monday to Friday, 09:00 to 20:00; Saturday, 09:00 to 15:00

Ukraine
Tel: 0800 505 508
E-mail: support.ua@tp-link.com
Service time: Monday to Friday 10:00 to 22:00

Russian Federation
Tel: 8 (499) 754 5560/8 (800) 250 5560
(toll-free call from any RF region)
E-mail: support.ru@tp-link.com
Service time: From 10:00 to 18:00 (Moscow time)

*Except weekends and holidays in Russian Federation
Turkey
Tel: 0850 7244 488 (Turkish Service)
E-mail: support.tr@tp-link.com
Service time: 09:00 to 21:00 7 days a week

Australia & New Zealand
Tel: AU 1300 87 5465
NZ 0800 87 5465
E-mail: support.au@tp-link.com (Australia)
support.nz@tp-link.com (New Zealand)
Service time: 24hrs, 7 days a week

Italy
Tel: +39 023 051 9020
E-mail: support.it@tp-link.com
Service time: Monday to Friday 09:00 to 13:00; 14:00 to 18:00

Indonesia
Tel: (+62) 021 6386 1936
E-mail: support.id@tp-link.com
Service time: Monday to Friday, 09:00 to 18:00
*Except public holidays

Germany/Austria
Tel: +49 1805 875 465 (German Service)
+49 1805 TPLINK
+43 820 820 360
E-mail: support.de@tp-link.com
Fee: 0.14 EUR/min from the German fixed phone network and up to 0.42 EUR/min from mobile phone

Service time: Monday to Friday 09:00 to 12:30 and 13:30 to 17:30. GMT+1 or GMT+2 (Daylight Saving Time in Germany)

*Except bank holidays in Hesse
France
Tel: +33 (0) 820 800 860 (French service)
Email: support.fr@tp-link.com
Fee: 0.118 EUR/min from France
Service time: Monday to Friday, 09:00 to 18:00 (Except French Bank holidays)