



Hardware Installation

Before you start, you should prepare the following items


- Windows XP/Vista/7/8 computer with print server setup CD
- One USB device with USB port

Hardware Installation

1. Turn off the USB device's power.
2. Connect your USB device to the TL-PS310U.



3. Connect the TL-PS310U to the router or switch/HUB with the Ethernet cable.



4. Connect the power adapter to the TL-PS310U. When the Link LED lights up, the TL-PS310U is correctly connected to the network.

Factory Default Settings

- IP address: 192.168.0.10/255.255.255.0
- Password: The TL-PS310U does not come with a default password.


Software Installation

1

Install the MFP and Storage Software

- 1 Insert the setup CD into your CD-drive. The auto-run program will be started.

Select **TL-PS310U**




- 2 Choose your operating system to install all software programs.



- 3 When the installation completed, please DO restart your computer.

Restart your computer



2

Configuring the Print Server

- 1 On your desktop you will see a **new icon**, double-click the icon and it will bring up the MFP and Storage Server setup utility.




- 2 In this screen, you will see the product listed as **TL-PS310U XXXXXX (192.168.0.10)**. If your computer is not in the 192.168.0.x network segment, it'll tell you that the TL-PS310U is in different network segment. In this situation, you need to change the IP of the TL-PS310U.



3

Select the print server, right-click on it and select **Server Configurations**



4

Configure the IP address of the print server according to your network, and then click **Set**

Server Configurations

Network Setting :

Server Name : TL-PS310U C7641B

Use DHCP

IP Address : 192 . 168 . 1 . 93

Subnet : 255 . 255 . 255 . 0

Set Cancel

Export configuration to CFG.bin...

Import configuration from CFG.bin...

Backup Firmware

Update Firmware

Change Password

Restart Server

5 Open the above **Server Configurations** screen again and click **Restart Server**, so that you can apply the IP configuration.

The IP address has been changed

Device Status

192.168.1.93

3


Install the USB Device

The MFP and Storage Server will auto-detect the USB device connecting to the USB port of the TL-PS310U.

Connecting to a USB Printer


1

Select the USB printer you want to connect and click **Connect Device**



2


Because the "Disconnect Printer when Idle" option is enabled by default, the server will tell you this. Just click **OK**



You can disable the "Disconnect Printer when Idle" in the **Options** menu.



3

The windows will detect the printer and install its driver automatically



4

After the driver is installed, the printer will be in your system



5

After finish installing the printer driver, please disconnect the printer manually. And then right-click the printer icon, you can use the **“Connect Automatically for Printing”** function. You're highly recommended to use this function for printing.


Enable the **“Connect Automatically for Printing”** function



Connecting to a USB Drive

- 1 It's the same as you connect the printer on the MFP and Storage Server.

Select the USB drive you want to connect and click **Connect Device**



2

After the driver is installed, the Removable Disk will be in your system




4

Disconnect the USB Devices

If you connect the USB devices all the time, other users can't connect and use them. A recommended habit is disconnecting the USB devices when you don't use them.


Disconnect manually

Select the USB device and click **Disconnect Device**



Disconnect when Idle

On the top menu, click **Options**, the "**Disconnect Storage Device When Idle**" and "**Disconnect Printer When Idle**" are on the list



Technical Support

- For more troubleshooting help, go to:
<http://www.tp-link.com/en/support/faq>
- To download the latest Firmware, Driver, Utility and User Guide, go to:
<http://www.tp-link.com/en/support/download>
- For all other technical support, please contact us by using the following details:

Global

Tel: +86 755 2650 4400

Fee: Depending on rate of different carriers, IDD.

E-mail: support@tp-link.com

Service time: 24hrs, 7 days a week

USA/Canada

Toll Free: +1 866 225 8139

E-mail: support.usa@tp-link.com(USA)

support.ca@tp-link.com(Canada)

Service time: 24hrs, 7 days a week

Turkey

Tel: 0850 7244 488 (Turkish Service)

Fee: Depending on rate of different carriers.

E-mail: support.tr@tp-link.com

Service time: 09:00 to 21:00, 7 days a week

Ukraine

Tel: 0800 505 508

Fee: Free for Landline; Mobile: Depending on

rate of different carriers

E-mail: support.ua@tp-link.com

Service time: Monday to Friday, 10:00 to 22:00

Brazil

Toll Free: 0800 608 9799 (Portuguese Service)

E-mail: supporte.br@tp-link.com

Service time: Monday to Friday, 09:00 to 20:00;

Saturday, 09:00 to 15:00

Indonesia

Tel: (+62) 021 6386 1936

Fee: Depending on rate of different carriers.

E-mail: support.id@tp-link.com

Service time: Sunday to Friday, 09:00 to 12:00,

13:00 to 18:00 *Except public holidays

Australia/New Zealand

Tel: NZ 0800 87 5465 (Toll Free)

AU 1300 87 5465 (Depending on 1300 policy.)

E-mail: support.au@tp-link.com (Australia)

support.nz@tp-link.com (New Zealand)

Service time: 24hrs, 7 days a week

Germany/Austria

Tel: +49 1805 875 465 (German Service)

+49 1805 TPLINK

+43 820 820 360

Fee: Landline from Germany: 0.14EUR/min.

Landline from Austria: 0.20EUR/min.

E-mail: support.de@tp-link.com

Service time: Monday to Friday, 09:00 to 12:30

and 13:30 to 18:00. GMT+1 or GMT+2 (DST in

Germany) *Except bank holidays in Hesse

Singapore

Tel: +65 6284 0493

Fee: Depending on rate of different carriers.

E-mail: support.sg@tp-link.com

Service time: 24hrs, 7 days a week

UK

Tel: +44 (0) 845 147 0017

Fee: Landline: 1p-10.5p/min, depending on the

time of day. Mobile: 15p-40p/min, depending

on your mobile network.

E-mail: support.uk@tp-link.com

Service time: 24hrs, 7 days a week

Italy

Tel: +39 023 051 9020

Fee: Depending on rate of different carriers.

E-mail: support.it@tp-link.com

Service time: Monday to Friday, 09:00 to

13:00; 14:00 to 18:00

Malaysia

Toll Free: 1300 88 875 465

Email: support.my@tp-link.com

Service time: 24hrs, 7 days a week

Poland

Tel: +48 (0) 801 080 618

+48 223 606 363 (if calls from mobile phone)

Fee: Depending on rate of different carriers.

E-mail: support.pl@tp-link.com

Service time: Monday to Friday, 09:00 to

17:00. GMT+1 or GMT+2 (DST)

France

Tel: 0820 800 860 (French service)

Fee: 0.118 EUR/min from France

Email: support.fr@tp-link.com

Service time: Monday to Friday, 09:00 to

18:00 *Except French Bank holidays

Switzerland

Tel: +41 (0) 848 800 998 (German Service)

Fee: 4-8 Rp/min, depending on rate of different

time.

E-mail: support.ch@tp-link.com

Service time: Monday to Friday, 09:00 to 12:30

and 13:30 to 18:00. GMT+1 or GMT+2 (DST)

Russian Federation

Tel: 8 (499) 754 5560 (Moscow NO.)

8 (800) 250 5560 (Toll-free within RF)

E-mail: support.ru@tp-link.com

Service time: From 09:00 to 21:00 (Moscow

time) *Except weekends and holidays in RF