

Quick Installation Guide


Indoor/Outdoor Access Point




Scan for EAP Start Guide


 $\mbox{\bf Note}{:}\,\mbox{EAP603-Outdoor}$ is used as an example throughout the guide. Images may differ from your actual product.

©2025 TP-Link 7106500052 REV1.0.0



Installation






Option 1: Via Passive PoE Adapter Option 2: Via PoE Switch Coptional) Mount the PoE Adapter Option 2: Via PoE Switch Option 2: Via PoE Switch

Configuration

Option 1: Standalone Mode


Configure and manage each EAP on its standalone page.



Φ 7.6 mm (19/64 in)

Option 2: Controller Mode

Configure and manage EAPs (and other Omada devices) centrally on an Omada Controller.



Omada App

With the TP-Link Omada app, you can access and manage your Omada devices at a local site or remotely with a tap of your phone.



Scan for Omada App

More Configurations

For more configurations, refer to the User Guides of the Omada Controller and Omada Access Points at: https://support.omadanetworks.com/document/

FHI 🚱

Safety Information

- Keep the device away from fire or hot environments. DO NOT immerse in water or any other liquid.
- Do not attempt to disassemble, repair, or modify the device. If you need service, please contact
- Do not use the device where wireless devices are not allowed.
- Do not use any other chargers than those recommended.
- Do not use a damaged charger or USB cable to charge the device.
- The adapter shall be installed near the equipment and shall be easily accessible.
- The adapter should be used indoors where the ambient temperature is lower than or equal to 40 °C.
- Plug the adapter into a wall outlet with an earthing connection through the power supply cord.
- The socket-outlet shall be installed near the equipment and shall be easily accessible.
 Plug the product into the wall outlets with earthing connection through the power supply cord
- Use only power supplies which are provided by manufacturer and in the original packing of this product. If you have any questions, please don't hesitate to contact us.
- This EAP can be powered only by the passive PoE adapter or equipment that complies with Power Source Class 2 (PS2) or Limited Power Source (LPS) defined in the standard of IEC 62368-1.

TP-Link hereby declares that the device is in compliance with the essential requirements and other relevant provisions of directives 2014/53/EU, 2009/125/EC, 2011/65/EU, and (EU)2015/863. The original EU Declaration of Conformity may be found at https://www.tp-link.com/en/support/ce/.


TP-Link hereby declares that the device is in compliance with the essential requirements and other relevant provisions of the Radio Equipment Regulations 2017. The original UK Declaration of Conformity may be found at https://www.tp-link.com/support/ukca/

 ${\bf Attention:} \ In EU \ member \ states, EFTA \ countries \ and \ Northern \ Ireland, \ the \ operation \ in \ the \ frequency \ range \ 5150 MHz-5350 MHz \ is \ only \ permitted \ indoors.$

Attention: In Great Britain, the operation in the frequency range 5150MHz - 5350MHz is only permitted indoors.

permitted indoors.

For the EAP Controller, go to the **Devices** page and select the desired EAP to specify the channel. For the web browser, go to **Wireless > Wireless Settings** to specify the channel.





More Resources

Main Site	https://www.omadanetworks.com
Video Center	https://support.omadanetworks.com/video
Documents	https://support.omadanetworks.com/document
Product Support	https://support.omadanetworks.com/product
Technical Support	https://support.omadanetworks.com/contact-support

Warranty

For details on the warranty period, policy, and procedures, visit https://support.omadanetworks.com/warranty-services.

Support

For technical support, user guides, and other information, please visit https://support.omadanetworks.com, or simply scan the QR code.

