



Quick Installation Guide

150Mbps Wireless N Router



MODEL NO. TL-WR720N

1 Hardware Connection



- 1 Power off your modem.
- 2 Connect the **WAN** port on your Router to the modem's **LAN** port with an Ethernet cable.
- **⑤** Connect your computer to one of the LAN ports labeled 1~2 on the Router with an Ethernet cable.
- Power on the modem and wait for one minute .
- **9** Plug the provided Power Adapter into the **POWER** jack on the back of the Router and the other end to a standard electrical wall socket.

2 Configuring the Router via Web Management Page

Open your browser and type http://tplinkwifi.net in the address field, then use admin for both user name and password to log in.




Click **Quick Setup** in the main menu and click **Next**.



Select the WAN connection type provided by your ISP.
Or you can select **Auto-Detect** and click **Next** to continue.



The **Dynamic IP** is the suitable connection type for most cases. Here we take it as an example. On the next page, you can rename your wireless network and create your own password. The default wireless name is TP-LINK_XXXX, and the default wireless password, the same as the PIN code, is printed on the bottom label. Click **Next** to continue.



Click **Reboot** or **Finish** to make your settings take effect.

	ations! The Router is now connecting you to the Internet. For detail settings
olease cli	ck other menus if necessary.
The chang	ge of wireless config will not take effect until the Router reboot.

Appendix: Troubleshooting

1. What can I do if I cannot access the Internet?

- 1) Check to verify all connections are connected properly. Try with different Ethernet cables to ensure they are working properly.
- 2) Check to see if you are able to access the Router's web management page. If not, please refer to "What can I do if I cannot open the web management window?".
- 3) Log in the web management page http://tplinkwifi.net, click "Network > WAN", and ensure that the WAN Connection Type is Dynamic IP; this is the suitable connection type for most DSL/Cable modems and other networks.
- 4) For cable modem users, please click "Network > MAC Clone". Click Clone MAC Address button and then click **Save**. Reboot the modem first and then the Router, try to access the Internet from your computer. If the problem persists, please go to the next step.



5) Connect your computer directly to your modem and attempt to access the Internet. If you are still unable to access the Internet, please contact your internet provider for further assistance.

2. What can I do if I cannot open the web management window?

1) For Windows 7/Vista

Go to "Start > Settings > Control Panel". Click "View network status and tasks > View status > Properties" and double-click "Internet Protocol Version 4 (TCP/IPv4)". Select "Obtain an IP address automatically", choose "Obtain DNS server address automatically" and click "OK".

2) For Windows XP/2000


Go to "Start > Control Panel". Click "Network and Internet Connections > Network Connections". Right-click "Local Area Connection", select "Properties" and then double-click "Internet Protocol (TCP/IP)". Select "Obtain an IP address automatically", choose "Obtain DNS server address automatically" and click

3. What can I do if I forget my password?

- 1) For default wireless password: Please refer to the "Wireless Password/PIN" labeled on the bottom of the Router.
- 2) For the web management page password: Reset the Router first and then use admin for both user name and password.

4. How do I restore my Router's configuration to its factory default settings?

If your router does not work properly, you can reset it and then configure it again. With the Router powered on, press and hold the WPS/RESET button on the rear panel for approximately 8 seconds before releasing it.



Technical Support

- For more troubleshooting help, go to www.tp-link.com/support/faq.asp
- To download the latest Firmware, Driver, Utility and User Guide, go to www.tp-link.com/support/download.asp
- For all other technical support, please contact us by using the following details:

Global Tel: +86 755 26504400 E-mail: support@tp-link.com Service time: 24hrs, 7days a week

Singapore Tel: +65 62840493

E-mail: support.sg@tp-link.com Service time: 24hrs, 7days a week

Tel: +44 (0) 845 147 0017 E-mail: support.uk@tp-link.com Service time: 24hrs, 7days a week

USA/Canada

Toll Free: +1 866 225 8139 E-mail: support.usa@tp-link.com Service time: 24hrs,7days a week

Tel: 1300 88 875465 (1300 88TPLINK) E-mail: support.my@tp-link.com Service time: 24 hrs a day,

7days a week Turkey
Tel: 444 19 25 (Turkish Service) E-mail: support.tr@tp-link.com Service time: 9:00 AM to 6:00 PM, 7days a week

Tel: +48 (0) 801 080 618 / +48 22 7217563 (if calls from mobile phone) E-mail: support.pl@tp-link.com Service time: Monday to Friday 9:00 AM to 5:00 PM. GMT+1 or GMT+2 (Daylight Saving Time)

(Daylight Saving Time)

Germany / Austria

Tel:+49 1805 875465 (German Service)
+49 1805 TPLINK
E-mail: Support.de@tp-link.com
Fee: 0.14 EUR/min from the German
fixed phone network and up to 0.42
EUR/min from mobile phone
Service Time: Monday to Friday 9:00 AM to 6:00 PM_GMT+1 or GMT+2 (Daylight Saving Time in Germany)

* Except bank holidays in Hesse

Australia & New Zealand

Tel: AU 1300 87 5465 NZ 0800 87 5465

E-mail: support@tp-link.com.au Service time: 24hrs, 7 days a week

Tel: +39 02 66987799 E-mail: support it ch Femail: support.it@tp-link.com Service time: 9:00 AM to 6:00 PM, from Monday to Friday

<u>Ukrainian</u> Tel: +380 (44) 590-51-14 E-mail: support.ua@tp-link.com Service time: Monday to Friday 14:00 PM to 22:00 PM

Brazilian Toll Free: 0800-770-4337 (Portuguese Service)
E-mail: suporte.br@tp-link.com
Service time: Monday to Saturday
08:00 AM to 08:00 PM

Indonesia

Tel: (+62) 021 6259 135 E-mail: support.id@tp-link.com Service time: Monday to Friday 9:00 -12:00; 13:00 -18:00 *Except public holidays

Switzerland

Tel: +41 (0) 848 800998 (German Service) Femail: support.ch@tp-link.com
Fee: 4-8 Rp/min, depending on rate of
different time
Service time: Monday to Friday 9:00 AM to
6:00 PM. GMT+ 1 or GMT+ 2
(Daylight Saving Time)

Russian Federation Tel: 8 (499) 754-55-60 8 (800) 250-55-60 (toll-free call from any RF region) E-mail: support.ru@tp-link.com Service time: from 10:00 to 18:00 (Moscow time)
*Except weekends and holidays in
Russian Federation

TP-LINK TECHNOLOGIES CO., LTD. www.tp-link.com