



## Smart Wi-Fi Plug Mini Installation

- 1 Download **TP-Link Kasa** from the App Store or Google Play.


OR scan  
QR code

- 2 Connect your mobile device to a **2.4GHz Wi-Fi** network.

*Note: The Smart Plug Mini only supports 2.4GHz networks.*



- 3 Launch **Kasa** and follow the in-app instructions to connect the Smart Plug Mini to your network.



*Note: The U.S. plug version is used throughout the Kasa app.*

## Support

If you encounter any issues during installation or configuration, please visit [www.tp-link.com/support](http://www.tp-link.com/support) for web support and troubleshooting information.

## Smart Wi-Fi Plug Mini



 Press to turn the socket ON or OFF.

Press and hold for 5 seconds or until the LED flashes amber and blue alternately to initiate the app onboarding process (SoftAP).

Press and hold for 10 seconds or until the LED flashes amber rapidly to factory reset the Smart Plug Mini.

### Supported Load Types:

Coffee Maker: 800 W  
Desk Lamp: 235.2 W  
LCD: 270 W  
Heater: 1500 W  
Humidifier: 260 W  
Iron: 1500 W  
Toaster: 850 W  
Tower Fan: 50 W

**LED Flashing amber and blue:** App onboarding process (SoftAP) initiated.

**Flashing blue rapidly:** Connecting to the network.

**Solid blue:** Connected to the network.

**Flashing amber rapidly:** Factory reset.

**Solid amber:** Initializing, rebooting, or no network connection.

**Off:** The Smart Plug Mini is switched OFF.

## Troubleshooting

### 1. What devices can I control with the Smart Plug Mini?

You can control lights, fans, humidifiers, portable heaters, and any small appliances in accordance with the Smart Plug Mini's specifications.

### 2. What should I do when I can't turn devices on or off using Kasa?

- Make sure the devices connected to the Smart Plug Mini are switched to ON.
- Make sure the *Remote Control* feature in the app is enabled to control your devices from outside of your home.

### 3. What should I do when the LED is lit a solid amber?

A solid amber light indicates no network connection. You can troubleshoot the following:

- Check your network connectivity.
- Avoid placing the Smart Plug Mini near potential sources of radio signal interference such as microwave ovens, cordless phones, baby monitors, and motor-driven appliances.
- Repeat the app onboarding process.
- Factory reset the Smart Plug Mini and try to add it again.

### 4. How do I pair the Smart Plug Mini with Amazon Echo?

Visit [www.tp-link.com/en/faq-944.html](http://www.tp-link.com/en/faq-944.html) or within the Kasa Help section for pairing instructions.