



## **Quick Installation Guide**

AV500 3-port Mini Powerline Adapter



MODEL NO. TL-PA4030


# **1** LED and Button Descriptions



|    | ltem          | Status   | Description  |
|----|---------------|----------|--|
| மு | Power LED     | Solid    | The adapter is on.   |
|    |               | Blinking | The adapter is in pairing procedure.   |
|    |               | Off      | The adapter is off.  |
| €} | Powerline LED | Solid    | The adapter is connected to a powerline network.                                 |
|    |               | Blinking | The adapter is transferring data.  |
|    |               | Off      | The adapter isn't connected to any powerline network.                            |
| ß  | Ethernet LED  | Solid    | At least one Ethernet port is connected, but there is no data being transferred. |
|    |               | Blinking | At least one Ethernet port is transferring data.                                 |
|    |               | Off      | No Ethernet port is connected.   |

| Item        | Description   |
|-------------|---|
| Pair Button | Pair button is used to secure a powerline network. To secure your network, please refer to <b>Appendix: Using the Pair Button</b> . |

# **2** Network Installation



TP-LINK powerline adapters are Plug and Play. After taking the steps above, you can surf the Internet.

## To add another adapter

Plug an additional adapter into the wall socket, and the connection will be established automatically within 60 seconds.

## NOTE:

- 1. To surf the Internet, please make sure that your network is properly connected to the Internet.
- 2. If the adapters fail to automatically link to each other, you can establish a private network by using the pair button. To set up a private network, please go to **Appendix: Using the Pair Button** for detailed instructions.

## Appendix: Using the Pair Button (Setting up a private network)

## To set up a private network :

- 1. Press the pair button on adapter A for 1 second and the Power LED will begin flashing. If pressed till all the LEDs turn off (about 10 seconds), the adapter will leave the network.
- 2. Within 2 minutes, press the pair button on adapter B for 1 second and the Power LED will begin flashing as well.
- 3. In about 60 seconds you'll see the Powerline LEDs on both adapters light up, indicating the two adapters have intercommunicated with each other successfully.


\* It is highly recommended to first set up the two adapters in the same room or on the same power strip and then place them in a suitable location

### To join an existing private network:

If you want to add adapter C to the existing private network, please follow the steps.

- 1. Press the pair button on the adapter A or B for 1 second (do not press both), and the Power LED will begin flashing.
- 2. Within 2 minutes press the pair button on adapter C for 1 second, the Powerline LED on the adapter C will light up in about 60 seconds.

\* You can follow the steps above to add more adapters to the private network one by one.



## NOTE:

More advanced configuration, such as reset, firmware upgrade and QoS configuration can be accessed through the utility, so install the Powerline Utility if necessary. (Only for Windows).

For detailed instructions, please refer to the User Guide on the Resource CD.

## Troubleshooting

## Q1. I have followed the above instructions, but my adapters are still not working. What can I do?

- 1. Make sure all the adapters are under the same electric meter.
- 2. If the Power LED does not light up at all, there may be a hardware problem.
- 3. The PLC devices might not communicate with each other if they are in different phrases of a four-wire three-phase circuit.
- 4. As some power strips have surge protector, please make sure the adapters are not separated by the power strips.

## Q2. The adapters were working fine but no longer work now that they've been moved. How do I make them work again?

Plug the adapters into the same power strip and follow Appendix: Using the Pair Button to pair them. If they still don't work, please check for possible interference causes:

- 1. Air-conditioners, washing machines, and other similar household appliances are working too close to the adapters.
- 2. Air switch may lead to failed communication among PLC devices; check whether there are air switches hindering communication

## **Technical Support**

or more troubleshooting help, go to: http://www.tp-link.com/en/support/faq To download the latest Firmware, Driver, Utility and User Guide, go to:

http://www.tp-link.com/en/support/download
For all other technical support, please contact us by using the following details:

Global Tel: +86 755 2650 4400 Fee: Depending on rate of different carriers, IDD. E-mail: support@tp-link.com Service time: 24hrs, 7 days a week

Tel: +44 (0) 845 147 0017 Fee: Landline: 1p-10.5p/min, depending on the time of day. Mobile: 15p-40p/min, depending a-bile network. on your mobile network. E-mail: support.uk@tp-link.com Service time: 24hrs, 7 days a week

- Turkey Tel: 0850 7244 488 (Turkish Service) Fee: Depending on rate of different carriers.
- E-mail: support.tr@tp-link.com Service time: 09:00 to 21:00 7 days a week

Ukraine Tel: 0800 505 508 Fee: Free for Landline; Mobile: Depending on rate of different carriers E-mail: support.ua@tp-link.com Service time: Monday to Friday 10:00 to 22:00

Brazil Toll Free: 0800 608 9799 (Portuguese Service) E-mail: suporte.br@tp-link.com Service time: Monday to Friday, 09:00 to 20:00: Saturday, 09:00 to 15:00

France Tel: 0820 800 860 (French service) Fee: 0.118 EUR/min from France Email: support.fr@tp-link.com Service time: Monday to Friday, 09:00 to 18:00 \*Except French Bank holidays Russian Federation Tel: 8 (499) 754 5560 (Moscow NO.) 8 (800) 250 5560 (Toll-free within RF)

# E-mail: support.ru@tp-link.com Service time: From 10:00 to 18:00 (Moscow

time) \*Except weekends and holidays in RF

Switzerland Tel: +41 (0) 848 800 998 (German Service) Fee: 4-8 Rp/min, depending on rate of different

E-mail: support.ch@tp-link.com e: Monday to Friday, 09:00 to 12:30 and 13:30 to 18:00. GMT+1 or GMT+2 (DST)

# Singapore Tel: +65 6284 0493 Fee: Depending on rate of different carriers.

E-mail: support.sg@tp-link.com Service time: 24hrs, 7 days a week USA/Canada Toll Free: +1 866 225 8139

E-mail: support.usa@tp-link.com (USA) support.ca@tp-link.com(Canada) Service time: 24hrs, 7 days a week Australia/New Zealand Tel: NZ 0800 87 5465 (Toll Free)

### AU 1300 87 5465 (Depending on 1300 policy.)

E-mail: support.au@tp-link.com (Australia) support.nz@tp-link.com (New Zealand) Service time: 24hrs, 7 days a week

Italy Tel: +39 023 051 9020 Fee: Depending on rate of different carriers. E-mail: support.it@tp-link.com Service time: Monday to Friday

## 09:00 to 13:00; 14:00 to 18:00 Indonesia Tel: (+62) 021 6386 1936

Fee: Depending on rate of different carriers. Email: support.id@tp-link.com Service time: Sunday to Friday, 09:00 to 12:00, 13:00 to 18:00 \*Except public holidays

Malaysia Toll Free: 1300 88 875 465 Email: support.my@tp-link.com

## Service time: 24hrs, 7 days a week Poland Tel: +48 (0) 801 080 618 / +48 223 606 363 (if

calls from mobile phone)

Fee: Depending on rate of different carriers. E-mail: support.pl@tp-link.com

Service time: Monday to Friday, 09:00 to 17:00. GMT+1 or GMT+2 (DST) Germany/Austria Tel: +49 1805 875 465 (German Service)

+49 1805 TPLINK

+43 820 820 360

Fee: Landline from Germany: 0.14EUR/min. Landline from Austria: 0.20EUR/min. Service time: Monday to Friday, 09:00 to 12:30 and 13:30 to 18:00. GMT+1 or GMT+2 (DST in Germany) \*Except bank holidays in Hesse