


## Quick Installation Guide

150Mbps Wireless N Range Extender

MODEL NO. TL-WA730RE

### Package Contents




### System Requirement

· Windows 7 · Windows Vista · Windows XP · Windows 2000

## Method One »»»» Setup by Button

If you want to connect to a secured network, while your Wireless Router doesn't have the **QSS/WPS** button, please refer to **Method two**.

### 1 Hardware Connection




- Step 1:** Please place your Range Extender **next to** your Wireless Router or Access Point. Here, we take Wireless Router for example.
- Step 2:** Plug the Power adapter into the power jack of the Range Extender, and the other end to a standard electrical wall socket.


## 2 Connect to Wireless Network

### Connect to the Secured Network


- 1** Push the **QSS/WPS** button on the Wireless Router.



- 2** Press and hold the **RANGE EXTENDER** button on the back panel of TL-WA730RE for about 3 seconds until **RANGE EXTENDER** LED (●) flashes. When the LED becomes solid light, TL-WA730RE has successfully connected to the desired Router.




- 3** After successful connection, TL-WA730RE can be placed between the Wireless Router and Wireless Client to boost the signal, but not beyond the coverage of the Wireless Router. **Half-way** between is the ideal location.




### Connect to the Unsecured Network

- 1** Press and hold the **RANGE EXTENDER** button on the back panel of TL-WA730RE for about 3 seconds until **RANGE EXTENDER** LED (●) flashes.




- 2** When **RANGE EXTENDER** LED (●) becomes solid light, TL-WA730RE has successfully connected to the desired Router.

- 3** After successful connection, TL-WA730RE can be placed between the Wireless Router and Wireless Client to boost the signal, but not beyond the coverage of the Wireless Router. **Half-way** between is the ideal location.



## Method Two »»»» Setup by Utility

### 1 Hardware Connection




**Step 1:** Please place your Range Extender **next to** your Wireless Router or Access Point. Here, we take Wireless Router for example.

**Step 2:** Plug the Power adapter into the power jack of the Range Extender, and the other end to a standard electrical wall socket.

**Step 3:** Connect the Range Extender to the PC with the Ethernet Cable.

### 2 Connect to Wireless Network

**1** Insert the provided Resource CD into your CD-ROM drive.




**2** The Setup Wizard will automatically pop up on your computer's screen. Please select your product model and click '**Easy Setup Assitant**'.




**3** After confirming the hardware connection and the status of LEDs, click '**NEXT**' to continue.





**4** Input the IP Address of the Range Extender (the default one is 192.168.0.254). Click '**NEXT**' to continue.




**5** When the connectivity is checked successfully, please click '**NEXT**'.




**6** The Range Extender can find the Wireless Router automatically. If it is your desired router, please click '**NEXT**'. If not, please click '**SCAN**' and select your target Router in the list, then click '**NEXT**'.




**7** Select the same security type and enter the same network key of the Router, then click '**NEXT**' to continue.



**8** After confirming the configurations, click '**NEXT**' to continue. If there is any wrong information, please go '**BACK**' to reset.




**9** When the configuration is completed successfully, please click '**NEXT**'.



**Note** During this process, you might see some warnings like "A network cable is unplugged". Please ignore them.

**10** Please click '**FINISH**' to close this wizard.



**Note** For more advanced settings, please refer to the User Guide on the Resource CD.

## Technical Support

- For more troubleshooting help, go to [www.tp-link.com/en/support/faq](http://www.tp-link.com/en/support/faq)
- To download the latest Firmware, Driver, Utility and User Guide, go to [www.tp-link.com/en/support/download](http://www.tp-link.com/en/support/download)
- For all other technical support, please contact us by using the following details:
  - Global**  
Tel: +86 755 26504400  
E-mail: support@tp-link.com  
Service time: 24hrs, 7 days a week
  - Singapore**  
Tel: +65 62840493  
E-mail: support.sg@tp-link.com  
Service time: 24hrs, 7 days a week
  - USA/Canada**  
Toll Free: +1 866 225 8139  
E-mail: support.usa@tp-link.com  
Service time: 24hrs, 7 days a week
  - Australia / New Zealand**  
Tel: AU 1300 87 5465  
NZ 0800 87 5465  
E-mail: support@tp-link.com.au  
Service time: 24hrs, 7 days a week
  - Italy**  
Tel: +39 0230519020  
E-mail: support.it@tp-link.com  
Service time: Monday to Friday 9:00 AM to 1:00 PM, 2:00PM to 1:00 PM
  - Indonesia**  
Tel: (+62) 021 6259 135  
E-mail: support.id@tp-link.com  
Service time: Monday to Friday 9:00 -12:00; 13:00 -18:00  
\*Except public holidays
  - Malaysia**  
Tel: 1300 88 875465 (1300 88TPLINK)  
Email: support.my@tp-link.com  
Service time: 24hrs, 7 days a week
  - Poland**  
Tel: +48 (0) 801 080 618 / +48 22 7217563  
(if calls from mobile phone)  
E-mail: support.pl@tp-link.com  
Service time: Monday to Friday 9:00 AM to 5:00 PM, GMT+1 or GMT+2 (Daylight Saving Time)
  - Germany / Austria**  
Tel: +49 1805 875465 (German Service)  
+49 1805 TPLINK  
E-mail: support.de@tp-link.com  
Fee: 0.14 EUR/min from the German fixed phone network and up to 0.42 EUR/min from mobile phone  
Service time: Monday to Friday 9:00 AM to 6:00 PM, GMT+ 1 or GMT+ 2 (Daylight Saving Time in Germany)  
\*Except bank holidays in Hesse
  - Switzerland**  
Tel: +41 (0) 848 800998 (German Service)  
E-mail: support.ch@tp-link.com  
Fee: 4-8 Rp/min, depending on rate of different time  
Service time: Monday to Friday 9:00 AM to 6:00 PM, GMT+ 1 or GMT+ 2 (Daylight Saving Time)
  - Russian Federation**  
Tel: 8 (499) 754-55-60  
8 (800) 250-55-60 (toll-free call from any RF region)  
E-mail: support.ru@tp-link.com  
Service time: From 10:00 to 18:00 (Moscow time)  
\*Except weekends and holidays in Russian Federation
  - France**  
Tel: +33 (0) 820 800 860 (French service)  
Email: support.fr@tp-link.com  
Fee: 0.118 EUR/min from France  
Service time: Monday to Friday 9:00 AM to 6:00 PM (Except French Bank holidays)
  - Brazil**  
Toll Free: 0800-770-4337 (Portuguese Service)  
E-mail: suporte.br@tp-link.com  
Service time: Monday to Saturday 08:00 AM to 08:00 PM