


Quick Installation Guide

150Mbps Wireless N Nano USB Adapter

MODEL NO. TL-WN725N


Package Contents



System Requirement

· Windows XP · Windows Vista · Windows 7 · Windows 8

1 Hardware Connection




You may see the **Found New Hardware Wizard** after the adapter has been inserted. Please click **Cancel**.



2 Software Installation

(The installation procedures in Windows XP/ Vista/ 7/ 8 are similar. Here we use the procedures in Windows 7 as an example.)

- 1** Insert the TP-LINK Resource CD into the CD-ROM drive.




- 2** Find the model TL-WN725N, click it, and then select **Install Driver&Utility**.




Note You will be prompted to choose the setup language from a drop-down list of 14 languages; then click **OK** to proceed. As follows we take English setup for example.


- 3** The **InstallShield Wizard** window will appear. Click **Next** to continue.




- 4** Select **Install TP-LINK Wireless Configuration Utility and Driver**, and then click **Next**.




- 5** Click **Change...** to specify the destination location or you can leave it default. Click **Next** to continue.



- 6** Click **Install** to install the driver and utility for your adapter.



- 7** The installation process may take 1~2 minutes.




- 8** The following screen will then appear. Click **Finish** to complete the setup.




3 Connect to Network


(You can skip to **Appendix: Connect to Wireless Router by WPS** to quickly connect to a network if your Router or Access Point features WPS/QSS function.)

1 After installation, the configuration page will pop up on your desktop.




Note The icon  will appear on your desktop. Double-clicking on the icon can start the utility.

2 Click **Network** in the tools section to display a list of available wireless networks. Highlight the target network name (e.g. TP-LINK_Network1) and then click **Connect** to build a connection.



Note Here we only choose a wireless network with the security type of **WPA/WPA2-Personal** as an example to elaborate the following steps.
If you want to know more about the connection to a wireless network with the security type of **WPA/WPA2-Enterprise**, please refer to the User Guide on the resource CD included.


3 If the network is unsecured, you will directly connect to it. If it is secured (with WPA/WPA2-PSK), there are two ways to connect to it.
Method One: Input the wireless password into the **Security Key** field and then click **OK** to continue.




Method Two: Without entering a key, push the WPS/QSS button on your Router as hinted "You can also connect by pushing the button on the router". Then click **OK** to continue.



4 The following screen indicates successful connectivity. Click **Close** to enjoy the Internet.



5 To view more information about the network connected, click **Status** in the tools section.




Appendix: Connect to Wireless Router by WPS


If your wireless Router features the WPS/QSS function, you can also set up a wireless connection in this way.

Note For more configuration methods of WPS, please refer to the User Guide on the Resource CD.


1 Push the **WPS/RESET** button on the Router. (Here we use Router TL-WR841ND as an example.)



2 Launch the configuration utility and click **WPS** in the tools section. Select **Push the button on my access point or wireless router** and then click **Connect**.



3 Wait for the connection process to complete. The following screen indicates successful connectivity. Click **OK** to finish the WPS connection.



Technical Support

- For more troubleshooting help, go to www.tp-link.com/en/support/faq
- To download the latest Firmware, Driver, Utility and User Guide, go to <http://www.tp-link.com/en/support/download/>
- For all other technical support, please contact us by using the following details:

- | | |
|--|---|
| <p>Global
Tel: +86 755 2650 4400
E-mail: support@tp-link.com
Service time: 24hrs, 7 days a week</p> <p>Singapore
Tel: +65 6284 0493
E-mail: support.sg@tp-link.com
Service time: 24hrs, 7 days a week</p> <p>UK
Tel: +44 (0) 845 147 0017
E-mail: support.uk@tp-link.com
Service time: 24hrs, 7 days a week</p> <p>Ukraine
Tel: 0800 505 508
E-mail: support.ua@tp-link.com
Service time: Monday to Friday 10:00 to 22:00</p> <p>Brazil
Toll Free: 0800 608 9799
(Portuguese Service)
E-mail: suporte.br@tp-link.com
Service time: Monday to Friday, 09:00 to 20:00; Saturday, 09:00 to 15:00</p> <p>Italy
Tel: +39 023 051 9020
E-mail: support.it@tp-link.com
Service time: Monday to Friday, 09:00 to 13:00; 14:00 to 18:00</p> <p>Indonesia
Tel: (+62) 021 6386 1936
E-mail: support.id@tp-link.com
Service time: Monday to Friday, 09:00 to 12:00; Saturday, 09:00 to 15:00
* Except public holidays</p> <p>Germany / Austria
Tel: +49 1805 875 465 (German Service)
+49 1805 TPLINK +43 820 820 360
E-mail: support.de@tp-link.com
Fee: 0.14 EUR/min from the German fixed phone network and up to 0.42 EUR/min from mobile phone.
Service Time: Monday to Friday, 09:00 to 12:30 and 13:30 to 17:30, GMT+1 or GMT+2 (Daylight Saving Time in Germany)
* Except bank holidays in Hesse</p> | <p>Australia / New Zealand
Tel: AU 1300 87 5465
NZ 0800 87 5465
E-mail: support.au@tp-link.com (AU)
support.nz@tp-link.com (NZ)
Service time: 24hrs, 7 days a week</p> <p>Turkey
Tel: 0850 7244 488 (Turkish Service)
NZ 0800 87 5465
E-mail: support.tr@tp-link.com
Service time: 09:00 to 21:00, 7 days a week</p> <p>USA / Canada
Toll Free: +1 866 225 8139
E-mail: support.usa@tp-link.com
Service time: 24hrs, 7 days a week</p> <p>Malaysia
Tel: 1300 88 875 465
E-mail: support.my@tp-link.com
Service time: 24hrs, 7 days a week</p> <p>Poland
Tel: +48 (0) 801 080 618 / +48 22 360 63 63 (if calls from mobile phone)
E-mail: support.pl@tp-link.com
Service time: Monday to Friday 09:00 to 17:00 PM, GMT+1 or GMT+2 (Daylight Saving Time)</p> <p>Switzerland
Tel: +41 (0) 848 800 998 (German Service)
E-mail: support.ch@tp-link.com
Fee: 4-8 Rp/min, depending on rate of different time
Service time: Monday to Friday, 09:00 to 12:30 and 13:30 to 17:30, GMT+1 or GMT+2 (Daylight Saving Time)</p> <p>France
Tel: +33 (0) 820 800 860 (French service)
Email: support.fr@tp-link.com
Fee: 0.118 EUR/min from France
Service time: Monday to Friday 09:00 to 18:00 (Except French Bank holidays)</p> <p>Russian Federation
Tel: 8 (499) 754 5560 / 8 (800) 250 5560 (toll-free call from any RF region)
E-mail: support.ru@tp-link.com
Service time: From 10:00 to 18:00 (Moscow time)
* Except weekends and holidays in Russian Federation</p> |
|--|---|