Ptp-link | Wi-Fi 7

Quick Installation Guide

Wi-Fi 7 Wireless USB Adapter


Images are for demonstration only. ©2025 TP-Link 7106512049 REV1.0.0

Before You Start

- Make sure your Router or Access Point supports the Wi-Fi 7 standard.
- It is recommended to use the adapter on Windows 11 (64-bit) or above.

1 Connect to a Computer

Note: It is recommended to connect the adapter to a USB 3.0 (ss.) port.



2 Install Driver

- a. Go to My Computer or This PC.
- b. Double-click the **TP-Link CD Drive**, then run **SetupInstall.exe** to install driver.




Note:

- If you cannot find the setup program, please download the driver at www.tp-link.com/support. You can also check for new releases and download the latest drivers on this website.
- If an unknown publisher message pops up, select Yes to continue.
- If Windows User Account Control requires admin credentials, type user name and password of your Windows administrator account.



Join a Wireless Network

- a. Click the network icon on the taskbar (the icon might look like one of these: 口, 係, 令, or \end{align*}).
- Select your Wi-Fi network, click Connect and enter the password when prompted.



Troubleshooting

If you have problems during the installation, please refer to the following online FAQs.

- T1. Can't find the hardware version of the adapter: https://www.tp-link.com/faq-46.html
- T2. Can't find or connect to the wireless networks: https://www.tp-link.com/faq-2253.html
- T3. Can't install the driver: https://www.tp-link.com/faq-2252.html



Need more help?

visit https://www.tp-link.com/support, for technical support, replacement services, user guides, and other information; or simply scan the QR code.



Safety Information

- Do not attempt to disassemble, repair, or modify the device. If you need service, please contact us.
 Do not use the device where wireless devices are not
- \cdot Do not use the device where wireless devices are not allowed.
- Keep the device away from water, fire, humidity or hot environments.
- This equipment can be powered only by equipments that comply with Power Source Class 2 (PS2) or Limited Power Source (LPS) defined in the standard of IEC 62368-1.

TP-Link hereby declares that the device is in compliance with the essential requirements and other relevant provisions of directives 2014/53/EU, 2011 /65/EU and (EU) 2015/863.

The original EU Declaration of Conformity may be found at https://www.tp-link.com/en/support/ce

TP-Link hereby declares that the device is in compliance with the essential requirements and other relevant provisions of the Radio Equipment Regulations 2017. The original UK Declaration of Conformity may be found at https://www.tp-link.com/support/ukca

