

Quick Start Guide

Solar-Powered Security Camera KIT

*Images may differ from actual products.




Scan QR code or visit https://www.tp-link.com/support/setup-video/#cloud-cameras



7106511843 REV1.0.0 ©2024 TP-Link

1 Charge the Battery

The battery comes partially charged. We recommend that you fully charge the battery before use. This will take about **seven and a half** hours.



Notes:

- 1. Peel off film from the camera before use.
- 2. Charge the battery using the USB cable included in the package. Inappropriate cables may result in slow charging or failure to charge.
- 3. When you plug in the USB charger, the LED should blink amber quickly for 3 seconds. If not, make sure the power is running and check your connection.
- 4. Warning: Do not tear off the silicone part by force as it may affect the waterproof performance.
- 5. The camera may not power up after falling. Plug in the USB charger to power it on again.
- 6. Keep the ports firmly covered when not in use to ensure waterproof performance.
- 7. Check the battery status on the Tapo app after setup.

2 Set Up the Camera

 Get the Tapo app from the App Store or Google Play. Create an account and log in.







2. Press and hold on your camera for about 3 seconds to turn it on. Open the Tapo app, tap the button in the app, and select your model. Then follow the app instructions to set up your camera.






Camera Status LED Indication


Blinking amber quickly for 3 seconds	Plugging in USB charger
Solid red	Starting up
Blinking red and green	Ready for setup
Blinking red slowly	Connecting to Wi-Fi
Solid amber	Connected to Wi-Fi
Solid green	Connected to the cloud
Blinking red quickly	Camera resetting
Blinking green quickly	Camera updating

3 Camera Mounting Tips

- 1. Avoid placing behind glass. Glass will obstruct the motion sensor of your camera.
- 2. Choose a proper location to mount your camera, or it will be triggered too often by false alarms.
- Avoid pointing the camera directly at swaying trees.
- Avoid pointing the camera directly at vehicles and pedestrians on the road.
- Avoid pointing the camera directly at street lamps and sunlight.
- 3. Do not place the camera upside down.
- Keep the motion sensor level for best results.



5. Tilt the camera downwards at an angle of about 20°.



6. Mount your camera to the side so that movement goes across the lens' field of view to better trigger motion detection and Al detection.





*Do not mount facing the direction of movement.


- 7. For optimal detection performance, we recommend mounting the camera 7-10 ft (2-3 m) above the ground.
 - PIR Detection Zone (Default Wake-up Sensitivity*)
 - PIR Detection Zone (Highest Wake-up Sensitivity*)
- Height:
 7-10 ft (2-3 m)

 Camera Field of View

 23 ft /7 m
 (Default Wake-up Sensitivity)

 30 ft / 9 m
 (Highest Wake-up Sensitivity)


Appearance



1 Spotlights

5 Lens

2 Light Sensor6 Status LED




3 Motion Sensor

7 Speaker

Side

4 Microphone



8 Power Button U

Press and hold for about 3 seconds to turn on/off the camera.

9 microSD Card Slot

Open the cover. Insert a microSD card* and initialize it on the Tapo app for local recording.

*microSD card not included.

10 Reset Button

Press and hold for **5s**: Reset Wi-Fi while keep other settings. Press and hold for **10s**: Reset to factory settings.

USB Type-C Charging Port
Open the cover for USB charging.

^{*}You can adjust the sensitivity in Camera Settings > Detection > Wake-up Sensitivity. The FOV and PIR detection zone shown is based on camera mounted at 7.2 ft/2.2 m $\,$

Solar Panel Mounting Tips

The position and tilt angle of the solar panel greatly affect the solar efficiency.

- 1. Choose a location where the solar panel gets the most sunlight throughout the year.
- 2. Position the panel south-facing in the Northern Hemisphere or north-facing in the Southern Hemisphere. The recommended tilt angle between the panel and the horizontal ground is 35° ~ 45°.
- 3. Regularly wipe the panel to remove dust and debris.



Mount Solar Panel & Camera







1. Drill Holes

Stick the mounting template to a solid and level wall surface. Drill three screw holes according to the template.




2. Mount Bracket

Insert three wall anchors into the holes and use the mounting screws to affix the solar panel bracket over the anchors. Then, insert two screw caps into the upper screw holes.

Screw Cap Orientation









3. Install the Solar Panel

Slide the solar panel onto the mounting bracket until it clicks into place.





4. Adjust Solar Panel Angle


Loosen the adjustable screw, tilt the solar panel to adjust the angle, and then tighten the adjustable screw.

The recommended tilt angle between the panel and the horizontal ground is $35^{\circ} \sim 45^{\circ}$.

5. Install Camera & Adjust Angle Install the camera onto the bracket and tilt the camera downwards at an angle of about 20°.



Ensure the camera is securely attached to the camera bracket by tightening the bottom screw.




Connect to the Camera

Use the appropriate waterproof gasket when connecting the solar panel to your camera. The gasket protects your camera from exposed moisture and dust that may damage the camera.


1. Install Waterproof Gasket

Insert the waterproof gasket into the camera's charging port. Ensure that the gasket is tightly sealed.




2. Power On Camera

Connect the solar panel by inserting the connector into the charging port until snug.



If the power cable is too short...

Extend the power cable using the provided extension cable. Insert the connector into the extension until snug and use the appropriate gasket when connecting the solar panel to your camera.



If the power cable is too long...

Use the cable zip tie provided to bundle up the excess cable. Once tightened, the zip tie cannot be easily adjusted. To release the tie, you





For technical support, the user guide, FAQs, warranty and more, please visit https://www.tapo.com/support/



Safety Information

- Keep the device away from fire or hot environments. DO NOT immerse in water or any other liquid
- TP-Link hereby declares that the device is in compliance with the essential requirements and ott 2014/30/EU, 2014/35/EU, 2011/65/EU and (EU)2015/863.

 The original EU declaration of conformity may be found at https://www.tapo.com/en/support/ce/
- TP-Link hereby declares that the device is in compliance with the essential requirements and other relevant provisions of the Electromagnetic Compatibility Regulations 2016 and Electrical Equipment (Safety) Regulations 2016.

- For Camera:

 Do not use damaged charger or USB cable to charge the device.

 Do not use any other chargers than those recommended.

 Do not use the device where wireless devices are not allowed.

 Adapter shall be easily accessible.

 Use only power supplies which are provided by manufacturer and in the original packing of this product. If you have any questions, please don't hesitate to contact us.

 Keep the device away from fire or hot environments. DO NOT immerse in water or any other liquid.

 Do not disassemble, repair or modify the product.

 Do not disassemble, repair or modify the product.

 Do not disen enear automatically controlled devices such as fire alarms. Radio waves emitted from this product may cause such devices to malfunction resulting in an accident.

 Observe restrictions on using wireless products in fuel depots, chemical plants or when blasting operations are in progress.

 Do not use liquid to clean the product. Only use a dry cloth.

 Never put metal objects inside the product. If a metal object enters the product turn off the circuit breaker and contact an authorised electrician.

- This product may interfere with other electronic proc
 Operating Temperature: -20°C ~ 45°C (-4°F ~ 113°F)
- This equipment can be powered only by equipments that comply with Power Source Class 2 (PS2) or Limited Power Source(LPS) defined in the

Avoid replacement of a battery with an incorrect type that can defeat a safeguard.

Avoid disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.

Do not leave a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas; Do not leave a battery subjected to extremely low air pressure that may result in an explosion or the leakage of

- The original EU declaration of conformity may be found at https://www.tapo.com/support/ce
- TP-Link hereby declares that the device is in compliance with the essential requirements and other relevant provisions of the Radio Equipment

