

# Quick Installation Guide


Indoor/Outdoor Access Point




Scan for EAP Start Guide


 $\mbox{\bf Note}{:}\,\mbox{\sf EAP225-Outdoor}$  is used as an example throughout the guide. Images may differ from your actual product.


©2025 TP-Link 7100002436 REV4.0.0




# Installation










# Connection

#### 1. Connecting Cables & Waterproofing




#### 3. Power On


Option 1: Via Passive PoE Adapter



#### 2. Grounding




Option 2: Via PoE Switch



# Configuration

#### Option 1: Standalone Mode

Configure and manage each EAP on its standalone page.






Standalone Start Guide

#### Option 2: Controller Mode

Configure and manage EAPs (and other Omada devices) centrally on an Omada Controller.



### Omada App

With the TP-Link Omada app, you can access and manage your Omada devices at a local site or remotely with a tap of your phone.



# More Configurations

For more configurations, refer to the User Guides of the Omada Controller and Omada Access Points at:

https://support.omadanetworks.com/document/

#### Safety Information

- Keep the device away from fire or hot environments. DO NOT immerse in water or any other liquid.
- Do not attempt to disassemble, repair, or modify the device. If you need service, please contact us.
- Do not use the device where wireless devices are not allowed
- Do not use damaged charger or USB cable to charge the device.
- Do not use any other chargers than those recommended.
- Adapter shall be installed near the equipment and shall be easily accessible
- Use only power supplies which are provided by manufacturer and in the original packing of this product. If you have any questions, please don't hesitate to contact us.
- Adapter should be used indoors where the ambient temperature is lower than or equal to 40°C Outdoor products are powered through the adapter's output line.
- The plug on the power supply cord is used as the disconnect device, the socket-outlet shall be easily
- Plug the adapter into the wall outlets with earthing connection through the power supply cord.
- For applicable power supplies see user instructions. Refer to the User Manual on the product support

TP-Link hereby declares that the access point is in compliance with the essential requirements and other relevant provisions of directives 2014/53/EU, 2009/125/EC, 2011 /65/EU and (EU) 2015/863. The original EU Declaration of Conformity may be found at https://www.tp-link.com/en/support/ce/


TP-Link hereby declares that the access point is in compliance with the essential requirements and other relevant provisions of the Radio Equipment Regulations 2017. The original UK Declaration of Conformity may be found at https://www.tp-link.com/support/ukca/

Attention: In EU member states, EFTA countries and Northern Ireland, the operation in the frequency range 5150MHz-5350MHz is only permitted indoors.

Attention: In Great Britain, the operation in the frequency range 5150MHz - 5350MHz is only permitted

For EAP Controller, go to the Devices page and select the desired EAP to specify the channel

For web browser, go to Wireless > Wireless Settings to specify the channel.





# More Resources

Main Site	https://www.omadanetworks.com/
Video Center	https://support.omadanetworks.com/video/
Documents	https://support.omadanetworks.com/document/
Product Support	https://support.omadanetworks.com/product/
Technical Support	https://support.omadanetworks.com/contact-support/

## Warranty

For details on the warranty period, policy, and procedures, visit https://support.omadanetworks.com/warranty-services/.

#### Support

For technical support, user guides, and other information, please visit https://support.omadanetworks.com/, or simply scan the QR code.

